

Test and Measurement Division

# **Service Manual**

SMY01

9 kHz to 1040 MHz 1062.5502.11

SMY02

9 kHz - 2080 MHz 1062.5502.12

SMY43

9 kHz to 2080 MHz 1062.5502.43

Volume 1 Service manual consists of 2 volumes

Printed in the Federal Republic of Germany

# **Contents**

Vol	lume	1
vu		- 1

# Safety Instructions Supplement

- 6 Repair of Complete Instrument
- 7 Testing and Repair of Modules

N	Module	Tabbed Divider
A2	CPU	1
A1	Display- Keyboard	2
A4	Synthesizer	3
A5	Output Unit 1.04 GHz	

## Volume 2

# **Safety Instructions**

M	Iodule Iodule	Tabbed Divider
A5	Output Unit 2.08 GHz	1
A6	Attenuator 1 GHz	
A6	Attenuator 2 GHz	
Α7	Power Supply	4
<b>A8</b>	Reference Oscillator	
Δ12	Power Module	c

3

# Safety Instructions

This unit has been designed and tested according to the standards outlined overleaf and has left the manufacturer's premises in a state fully complying with the safety standards.

In order to maintain this state and to ensure safe operation, observe the following instructions, symbols and precautions.

- When the unit is to be permanently cabled, first connect protective ground conductor before making any other connections.
- 2) Built-in units should only be operated when properly fitted into the system.
- For permanently cabled units without built-in fuses, automatic switches or similar protective facilities, the AC supply line shall be fitted with fuses rated to the units.
- 4) Before switching on the unit ensure that the operating voltage set at the unit matches the line voltage.
  - If a different operating voltage is to be set, use a fuse with appropriate rating.
- 5) Units of protection class I with disconnectible AC supply cable and plug may only be operated from a power socket with protective ground contact.

  The protective ground connection should not be made ineffective by an extension cable. Any breaking of the protective ground conductor within or outside of the unit or loosening of the protective ground connection may cause the unit to become electrically hazardous. The protective ground conductor shall not be interrupted intentionally.
- 6) Before opening the unit, isolate it from the AC supply. Adjustment and replacement of parts as well as maintenance and repair should be carried out only by specialists approved by R & S. Observe safety regulations and rules for the prevention of accidents. Use only original parts for replacing parts relevant to safety (e.g. power on/off switches, power transformers or fuses).
- 7) Also observe the additional safety instructions specified in this manual.

# **Explanation of Symbols Used**



- Read operating manual, observe the safety symbols used



- Caution, shock hazard



- Protective ground connection



- Unit ground



Equipotential (floating ground)



- Ground

#### Patent Information

This product contains technology licensed by Marconi Instruments LTD. under US patents 4609881 and 4870384 and under corresponding patents in Germany and elsewhere.

# Supplement to Service Manual SIGNAL GENERATOR SMY43 1062.7805.43

## For model SMY43 the following limit values are valid for diagnostic points or module tests:

- 1. 1062.5502 Chapter 6.3.1.2
   Table:
   Diagnostic point 15 (Sp.fct.115): max. .5V, max. 21.5V
- 1062.6409 Chapter 7.4.4
   VCO control voltage continuously rising from about 1V to about 20V in frequency range 780.000 001 to 1040MHz
- 3. 1062.6409 Chapter 7.4.4Table:VCO2 RF900MHz, 780MHz min. 1V, 1040MHz max. 21V
- 4. 1062.6409 Chapter 7.4.5.4 Table: 780MHz 1V to 2V 1040MHz 18.5V to 21V
- 5. 1062.5502 Chapter 7.4.13.1 Diagnostic point 15: min. .5V, max. 21.5V

## Contents

6	Repa	air5
	6.1	List of Modules and Function Description 5
		6.1.1 Synthesis
		6.1.2 Output Unit
		6.1.3 Controller 6
		6.1.4 Keyboard and Display 6
		6.1.5 Attenuator 6
		6.1.6 Reference Oscillator (Option) 6
		6.1.7 Pulsmodulator and High Output Power (Option) 7
	6.2	Test Instruments and Utilities 7
	6.3	Troubleshooting
		6.3.1 Utilities Installed
		6.3.1.2 Diagnosis9
		6.3.1.3 List of Special Functions
		6.3.2 Module Test with Internal Diagnosis
		6.3.3 Troubleshooting Acc. to the Type of Error 14
		6.3.3.1 Frequency Error14
		6.3.3.2 Level Error 14
		6.3.3.3 AM Error 14
		6.3.3.4 FM/\(\phi\)M Error
		6.3.3.5 Level of Harmonics too High
		6.3.3.6 Poor Spectral Purity14
	6.4	Testing and Adjustment
		6.4.1 Calibration Routines
		6.4.1.1 VCO Calibration
		6.4.1.2 FM Calibration
		6.4.1.3 Calibration of FM-DC Center Frequency 16
		6.4.1.4 Level Preset
		6.4.1.5 Output Level Correction
		6.4.2 Adjustment of the Overall Instrument
		6.4.3 Adjustments Following Replacement of Modules 18
+		Disassembly and Assembly
		6.5.1 Removal and Installation of the Panelling 19
		6.5.2 Removal and Installation of the Controller 19
		6.5.3 Removal and Installation of the Output Unit 19
		6.5.4 Removal and Installation of the Synthesis 20
		6.5.5 Removal and Installation of the Keyboard/Display 20
		6.5.6 Removal and Installation of the Power Supply 20
		6.5.7 Removal and Installation of the ROSC Option 21
		6.5.8 Removal and Installation of the Power Module 21

List of mechanical parts
Exploded View
List of keys
List of power cables
Cross-reference list
Parts list
List of coordinates
Circuit diagram
Component layout diagram

6.1 List of Modules and Function Description

	Module German/	English 2	bbreviation	Part No
A1	Tastatur/Anzeige	Keyboard/Display	FRONT	1062.6809
A2	Rechner	Controller	CPU	1062.6309
A4	Synthese	Synthesis	YSYN	1062.6409
A5	Ausgangsteil 1GHz	Output Unit 1GHz	OPUY01	1062.6209
	Ausgangsteil 2GHz	Output Unit 2GHz	OPUY02	1062.7005
A6	Eichleitung	Attenuator 1GHz	ATT01	0826.5065
	Eichleitung	Attenuator 2GHz	ATT02	0801.1108
A7	Netzteil	Power Supply	POW	1062.5690
	Options:			
A8	SMY-B1			
	Referenzoszillator	Reference Oscillator	ROSC	1039.1027
A12	SMY-B40			
	Pulsmodulator und High Output Power	Pulse Modulator and High Output Power	PMOD	1062.9008

The following text refers to the functional circuit diagram 1062.5502.01FS and circuit diagram 1062.5502.01S.

The SMY 01/02 synthesizes the basic octave from 520 to 1040 MHz, which all other frequencies are derived from by division, mixing or by doubling as is the case with SMY02.

A single-loop-synthesizer generates the basic octave without synthesis error using a fractional divider with a resolution of 1 Hz. The frequency extension by division, mixing and doubling is followed by level conditioning and the mechanical attenuator.

## 6.1.1 Synthesis

The output oscillators are synchronized in a PLL to the reference frequency 2 MHz by means of a fractional divider. Two RF dividers with the factors two and four extend the frequency range up to 65 MHz.

The frequency range below 65 MHz is generated by down-conversion using a 640-MHz oscillator.

The circuit contains a 10-MHz TCXO as standard reference. A reference PLL allows for synchronizing to an external reference frequency. The spectral purity close to the carrier can be improved by synchronizing to an optional OCXO.

The frequency modulation for low frequencies is effected via the division factor and thus via the PLL. In the case of high modulation frequencies, the oscillators are directly modulated. A flat frequency response is obtained if the two modulation paths have the same sensitivity and delay.

The phase modulation is obtained by differentiating the modulation signal.

#### 6.1.2 Output Unit

The signal of the synthesis in the frequency range from 65 to 1040 MHz is passed via an amplitude modulator and an amplitude control element to a switchable filter bank. A changeover switch selects either the direct signal path via the output amplifiers to the level detector and to the output socket or a second path, which generates the frequency range from 9 kHz to 65 MHz by down-conversion with the 640-MHz LO signal. For frequencies below 10 MHz, a second RF detector at the RF signal path of the mixer is activated for level control. The SMY02 provides a third path, which generates the output frequency range above 1040 MHz by doubling.

# 6.1.3 Controller

A processor takes control of the overall instrument. The program memory consists of EPROMs and a battery-backed RAM. The diagnostic voltages are measured by an A/D converter which is integrated in the CPU. Series-connected operational amplifiers allow for switching over the amplification between V=1 and V=16. In addition, the controller module accommodates the AF synthesizer 1 - 500 kHz which has been realized as DDS component. The external LOW-HIGH monitoring logic and the channel switchover for the AM are also integrated.

# 6.1.4 Keyboard and Display

This module contains the keyboard and the keyboard matrix. LEDs indicate the input parameter selected and signal the output of error messages. A spinwheel allows for continuous variation of a selected parameter. Two LCD displays are provided for display of frequency, level and the modulation and AF-frequency settings.

## 6.1.5 Attenuator

The mechanical attenuator extends the adjustable level range by 130 dB in the case of SMY01 and 135 dB for SMY02. An overvoltage protection for dc and ac voltages, which protects the output against externally applied voltages, has been integrated. It consists of a detector, a limiter and a mechanical isolating switch, which is directly actuated by the attenuator control. This isolating switch adopts the open position with switching off the instrument.

# 6.1.6 Reference Oscillator (Option)

The optional oven-controlled crystal oscillator may be used as reference to improve the long-term stability and the residual FM close to the carrier. A 12-bit D/A converter on the synthesis allows for adjusting the module to 10 MHz. An identification circuit on the module enables the controller to identify with switch-on, which position the corresponding switches on the synthesis assume and whether the integrated TCXO is used as reference for synchronization.

If an external reference is used for synchronization, the TCXO on the synthesis is operated, such that the residual FM can not be improved by the oven-controlled crystal oscillator.

# 6.1.7 Pulse Modulator and High Output Power (Option)

This option increases the output level of the SMY up to 19 dBm (25dBm overrange). The pulse modulator switches the RF signal faster than 20 ns. It is controlled via an external TTL signal from the rear panel. When fitting or removing this option, the modules output unit, attenuator and motherboard are modified. Fitting or removing the option is only possible at the factory or at authorized service centers.

# 6.2 Test Instruments and Utilities

- 1.Controller acc. to industrial standard PC/XT/AT with IEC-625/IEEE488 interface for remote control and connecting cable for IEC/IEEE bus. Rohde&Schwarz Basic and the corresponding IEC/IEEE-bus drivers must be installed.
- 2. Program floppy disk containing service programm 'SMYSERVI. BAS'.
- 3.RF power meter, 5 kHz to 1.04(2.08) GHz, e.g., R&S NRVS(1020.1809.02) with power sensor NRV-Z51(875.9004.02).

# 6.3 Troubleshooting

# 6.3.1 Utilities Installed

Internal measuring points are provided on the modules YSYN and OPUY01/02 for self-monitoring and service purposes. The most important of them trigger an internal alarm when limits are exceeded, all points can be measured on the controller module via multiplexers and a A/D converter.

The control voltages and output levels are internally measurable on the modules. In addition, test points are provided for adjustment purposes and at locations which are important for the signal flow, where external measurement would be difficult.

#### 6.3.1.1 Self-Monitoring, Error Message

If the control voltage within a control loop exceeds the permissible range, an alarm is triggered on the controller and indicated on the display. It may be due to missing calibrations, maloperation, violation of the specified setting parameters (e.g., level) or internal faults.

Elimination of errors should be carried out according to the below-mentioned order, since the errors could be sequential errors of the upper errors.

If the controller receives an alarm message, the status LED blinks. In case of range violation of the specification (e.g., level 19 dBm or > 19 dBm with option SMY-B40) the LED normally lights up. When the status key is actuated, the error or overrange can be further specified by an error code in the right display.

# Status codes of errors and overrange/underrange settings:

Status code	Meaning
0	no error
	Function errors
1	10-MHz reference loop out of synchronization
2	640 MHz loop out of synchronization
3	Main-oscillator loop out of synchronization
4	Level control does not work
5	External overvoltage at RF output
6	ROM-data error
7	RAM-data error of the stored settings
8	RAM-data error of VCO correction values
9	RAM-data error of FM correction values
10	RAM-data error of LEVEL PRESET correction values
11	EEPROM-data error of RF-level correction values
12	EEPROM data error of REF-OSC correction values
15	Calibration not possible
	Faulty entries
50	Syntax error
51	Entered value out of permissible range
52	Unit not permitted for selected parameter
53	Header not permitted (IEC/IEEE bus)
54	AF synthesizer can not be switched off with internal modulation switched on
55	FM deviation too large for selected RF
56	Variation not enabled, if the corresponding parameter is not switched on (IEC/IEEE-bus)
57	Calibration of FM-DC center frequency only with FM DC
	Overrange/Underrange settings
70	AM not specified with the level set
71	AM not specified for AF > 50 kHz
72	RF < 9 kHz
73	AM EXT signal out of tolerance
74	FM/qM EXT signal out of tolerance
75	φM not specified for AF < 20 Hz or AF > 20 kHz
76	AF > 500 kHz
77	Level > 13 dBm or > 19 dBm with option SMY-B40
78	OVEN COLD

Table about possible error causes for status message:

Type of error

Possible error cause

Error message "Err. 1"

10-MHz reference loop out of synchronization

External reference selected, however, frequency not within pulling range or level too small.

Error message "Err. 2" 640-MHz loop out of synchronization

640-MHz LO does not supply any signal

Error message "Err. 3"
Main-oscillator loop out of synchronization

RF oscillators do not supply any signal Reference signal missing (int. or ext.) Modulation signal with FM ext. >  $1V_{SS}$ 

Error message "Err. 4"
Level control does not work correctly

Level overrange AM overrange Overrange with AM EXT DC 'Level-Preset' calibration faulty

Error message "Err. 5"
External overvoltage at RF output

Applied RF level too high Applied dc voltage too high Open circuit at RF socket with level overrange

#### 6.3.1.2 Diagnosis

Since the voltage range of the multiplexers is limited to ±5 V, voltage dividers are required at many diagnostic points. The controller takes this scaling factor into account such that the correct value prior to the voltage divider is displayed.

The test points mentioned below can be selected in order to further localize a possible error. The indicated voltages are recommended values for a properly-working instrument. They are displayed via special functions and can be read by a controller via the IEC/IEEE bus.

The diagnosis provides an amplification switchover v=16 for exact determination of low voltages. It is controlled by autoranging which switches over at 200 mV and displays the result with three decimals in 'mV'. The resolution of the diagnosis is 10 mV with amplification v=1 and 0.6 mV with amplification v=16.

Diag.	Special	Test point	Description	IR	min	max	Tf
point	function	·		[V]	[V]		
0	101	Diagnd	Ref 10k0hm with SMY01		03	+.03	1
		Udoubler	RF level at doubler with SMY02	+.1	+5.	3	
1	102	Vđet	Detector output FOPU1/2		+.1	+5.	3
2	103	Vdetmix	Detector in the mixer path		+.1	+5.	3
3	104	Vdetfilt	Detector subsequent to filter				
4	105	Urf_soll	Level control voltage		+.2	3.	3
5	106	Uregelverst	Voltage subsequent to control		-		
			amplifier	x	-6.	0.	3
6	107	Umodulator	Control voltage of AM modulator		-15	0.	3
7	108	Ustellglied	Control voltage 'Level-Preset'		-15	٥.	3

Diag. point	Special function	Test point		IR	min [V]	max [V]	Tf
9	109	R146	Reference 10kOhm		05	+.05	1
10	110	10Ref	10-V reference voltage		9.9	10.1	3
11	111	P11-VTCXO	Control voltage of VTCXO reference	x	3.0	4.7	3
12	112	P11-640	Control voltage of 640-MHz LO	x	4.0	17.0	5
13	113	Ref-640	Level 640-MHz VCO on		.1	.6	1
			• off		-	.05	
14	114	FSYN	Output level FSYN	Ì	.60	1.0	1
15	115	Pl1-FSYN	Control voltage VCO's FSYN	x l	1.75	21.5	5
16	116	FM-Cal	Difference deviation detector, 1kHz	1	0.	.05	3

The column 'IR' indicates, whether a diagnostic point may trigger an interrupt (cf. list of status codes 6.3.1.1)

# 6.3.1.3 List of Special Functions

Special functions	Code	Remote control
		command
Non-interrupting level setting		
Normal level setting	1 2	ATTENUATOR: FIXED
Level EMF	2 3	ATTENUATOR: NORMAL
Normal level		LEVEL: EMF
AM dual-tone	4	LEVEL
AM normal	5	AM: DUAL
	6	AM
FM/φMm dual-tone	7	FM:DUAL (e.g.,FM)
FM/qM normal	8	FM (e.g., FM)
BLANK on	9	BLANK: ON
BLANK off	10	BLANK: OFF
BLANK polarity inverted	11	BLANK: INVERTED
BLANK polarity normal	12	BLANK: NORMAL
ALC bandwidth narrow	13	SPECIAL 13
ALC bandwidth automatically adapted	14	SPECIAL 14
ALC bandwidth broad	15	SPECIAL 15
ALC bandwidth automatically adapted	16	SPECIAL 16
Set power-on-clear-flag	17	
Delete power-on-clear-flag	18	
User request	19	
Switch ALC off	21	ALC:FIXED
Switch ALC on	22	ALC:NORMAL
AM invers	23	SPECIAL 23
AM normal	24	SPECIAL 24
RF Output Impedanz "OPEN" bei Level	25	SPECIAL 25
RF Output Impedanz *50 $\Omega$ * bei Level	26	SPECIAL 26
Display firmware version	29	
Display test	31	SPECIAL 31
ROM test	33	SPECIAL 33
RAM test	35	SPECIAL 35
EEPROM test	37	SPECIAL 37
All internal calibrations		
(SPECIAL 41/43/45)		
VCO calibration routine	41	SPECIAL 41
FM calibration routine	43	SPECIAL 43
LEVEL PRESET calibration routine	45	SPECIAL 45
Calibration RF level on	47	SPECIAL 47
Terminate calibration of RF level	48	SPECIAL 48
Level correction off	49	LEVEL: CORRECTION: OFF
Level correction on	50	LEVEL: CORRECTION: ON
Calibration REF-OSC on	51	SPECIAL 51
Terminate calibration REF-OSC	52	SPECIAL 52
Calibration routine FM-DC center frequency	55	SPECIAL 55
Switch off diagnostic test point	100	TEST: OFF
Switch on diagnostic test point	101-116	TEST: POINT 1 (2B. Pun

# 6.3.2 Module Test with Internal Diagnosis

The diagnostic points are selected using the special functions 101 to 116. The spinwheel allows for stepping through the diagnostic points. 'Special 100' switches off the diagnosis.

#### 6.3.2.1 Troubleshooting on Individual Modules

Prior to making the given settings, the instruments should assume a defined state by a 'PRESET'. Diagnostic points which are not mentioned in the following should be within the given tolerances independent of the settings.

# 6.3.2.1.1 Controller, Display and Diagnosis (CPU)

If the instrument does not react upon switching on the power switch, check whether the 5-V supply voltage is within the tolerance range.

If the instrument does not react upon turning the spinwheel or pressing any key, check whether the instrument is set to remote control (IEC bus) or whether any key has got stuck. If this is the case, proceed as described in the service instructions for the keyboard/display module.

To test the diagnosis, the diagnostic points 109 and 110 can be selected, i.e., two voltages which are constant independent of the operating state. Diagnostic point 109 allows for testing the zero point of the diagnosis via a 1-kOhm reference resistance on the synthesis, a 10-V voltage of a regulator on the same module (diagn. pt. 110) allows for determination of the correct scale.

- The tests described above assume that the synthesis is fitted. The latter must provide a correctly-working 10-V reference for the second measurement.

If instrument settings (also stored ones) are not retained upon switching on and off, replace the lithium battery on the controller module.

(cf. operating manual, Section 4.1.3)

#### 6.3.2.1.2 Synthesis (YSYN)

Correct synchronization of the synthesis oscillators in CW mode can be checked via the diagnostic point 15 (special function 115).

- Switch on test point 15 on the SMY. Step through the frequency range from 520 to 780 MHz. The complete tuning range of the first oscillator is thus swept through.
- The VCO control voltage must continuously increase from approx.
  2 V to approx. 19 V.
- Step through the frequency range from 780.000 001 to 1040 MHz with the test point switched on. The complete tuning range of the second oscillator is thus swept through.
- As above, the VCO control voltage must continuously increase from approx. 2 V to approx. 19 V.

#### 6.3.2.1.3 Output Unit (OPUY01/02)

The correct function of the output unit can be checked most easily by checking the modulator voltage.

- Set the SMY01/02 to 10MHz unmodulated, set the level to 13 dBm (19 dBm with option SMY-B40). Select non-interrupting level setting via special function 1 (Spec 1).
- Use special function 49 to switch off the level correction.
- Terminate the RF-output with 50  $\Omega$ .
- The voltages given in the table below must be measured with a tolerance of ±10% of the display ±60 mV depending on the output frequency and level.

This measurement requires a valid table of 'Level Preset' values to be stored in the controller. The rated values of the detectors and of the command value for level control are indicated in the table for further error localization.

If the values given in the table are not obtained, the signal level subsequent to the filter bank can be measured via the diagnostic point 3 (Spec. 104). Set the maximum level. With SMY02, the level prior to the modulator of the doubler path can be tested as well.

Without option SMY-B40, the values listed below apply:

Level	Vmodul Piagn. Spec.	pt.6	Vde Piagn. Spec.	pt.1 ::	Vdetmix Piagn. pt.2 Spec. 103	Vrf_sol1 Piagn. pt.4 Spec. 105
[dBm]	f ≤ 1040 MHz	f > 1040 MHz	f ≥ 10	MHz	f<10 MHz	
			SMY01	SMY02		
13	6.3	7.5	3.3	3.0	9.97	-3.0
7	3.9	5.4	1.65	1.5	4.98	-1.5
0	•	×	.7	.64	2.13	64
-6	às às	*	.35	.32	1.06	32

The detector voltage is a measure for the actual level applied to the output. A correct modulator voltage requires a correct operating point which is determined by the preset level. Faulty calibration thus leads to a modulator voltage which does not correspond to the values given in the table in spite of correct regulation.

With option SMY-B40, the values listed below apply:

Level	Vmodul Diagn. Spac.	pt.6		let . pt.1 . 102	Vdetmix Diagn. pt.2 Spac. 103	Vrf_soll Piagn. pt.4 Spec. 105
[dBm]	f ≤ 1040 MHz	f > 1040 MHz	f ≥ 1	SHM 0	f<10 MHz	
			SMY01	SMY02		
19	6.3	7.5	1.8	1.8	2.2	-3.0
13	3.9	5.4	. 9	.9	1.1	-1.5
6	п	-	.4	.4	.48	64
0	<b></b>		.2	.2	. 24	32

• Use special function 50 to switch on the level correction again.

# 6.3.2.1.4 AF Generator (CPU)

The output level of the AF generator can be tested easily by means of the external High/Low monitoring logic. The AF generator output must only be connected to the FM ext input on the front of the instrument via a short BNC cable.

- Select external FM modulation (FM ext/AC) on the SMY. Set the AF frequency to 1 kHz.
- \_ The external high/low indication in the right display must indicate neither 'High' nor 'Low'.

If the FM-external monitoring logic is assumed to be faulty, the AM-external monitoring logic can be used also. The test procedure must be carried out correspondingly.

# 6.3.3 Troubleshooting Acc. to the Type of Error

In the following, the errors are grouped acc. to the type of error. The order the boards which are assumed to be faulty are listed corresponds to the signal flow.

# 6.3.3.1 Frequency Error

- A8 Reference Oscillator ROSC (Option)
- A4 Synthesis YSYN
- A5 Output Unit OPUY01/02

#### 6.3.3.2 Level Error

- A5 Output Unit OPUY01/02
- A12 Power Module (option SMY-B40) PMOD
- A6 Attenuator ATT01/02

#### 6.3.3.3 AM Error

- A5 Output Unit OPUY01/02
- A12 Power Module (option SMY-B40) PMOD
- A2 AF Generator CPU

# 6.3.3.4 FM/φM Error

- A4 Synthesis YSYN
- A2 AF Generator CPU

# 6.3.3.5 Level of Harmonics too High

- A5 Output Unit OPUY01/02
- A12 Power Module (option SMY-B40) PMOD

## 6.3.3.6 Poor Spectral Purity

- A4 Synthesis YSYN
- A5 Output Unit OPUY01/02
- Al2 Power Module (option SMY-B40) PMOD

#### 6.4.1 Calibration Routines

Valid calibration values for the various functions are required for trouble-free operation of the instrument according to the given specifications.

The calibration data of VCO, FM, and LEVEL-PRESET calibrations are stored in the battery-backed RAM of the controller. The calibration data of level correction and reference oscillator are stored in the EEPROM.

Most of the required calibrations are performed internally and do not require any external utility. They can be called by means of special functions.

#### 6.4.1.1 VCO Calibration

The VCO calibration is called via special function 41 and determines the VCO slope of the RF oscillators on the synthesis module. The PLL gain which varies due to the VCO slope and the different dividing factors in the feedback path is compensated for by means of the calibration values.

- Without valid VCO calibration, it may occur that the transient response with change of frequency and the FM performance are out of the range specified in the data sheet. This routine must be called subsequent to replacement of the modules YSYN or CPU. The instrument should have reached the final operating temperature.
- The VCO calibration is initiated by special function 41 (see operating manual). Subsequent to calibration, the previous instrument setting is restored.

# 6.4.1.2 FM Calibration

With FM calibration, the scales of the two FM-modulation paths (dividing factor via the PLL control and VCO tuning voltage via the control) are mutually adjusted.

- The VCO calibration must have been called successfully prior to FM calibration in order to receive valid calibration data. Large temperature variations during operation may require the calibration to be repeated (cf. data sheet SMY FM-DC).
- \_ The FM calibration is initiated by special function 43 (see operating manual). Subsequent to calibration, the previous instrument setting is restored.

The calibration data are stored in the RAM after successful calibration, which can be repeated any time.

#### 6.4.1.3 Calibration of FM-DC Center Frequency

Normally, it is not absolutely required to call this calibration since the accuracy of the center frequency is very high even without explicitly calling the calibration. However, if the accuracy is to exceed 0.1% of the FM-deviation, this calibration of the FM-DC center frequency can be called via special function. It is automatically performed with first setting of an FM-DC.

The calibration of the FM-DC center frequency is initiated by special function 55 (see operating manual). It takes approx. 4 seconds.

#### 6.4.1.4 Level Preset

The instrument-specific level preset is performed to ensure that level control always works in the optimum operating point.

- The AM characteristics worsen if the calibration table is missing or incorrect. Level control may even oscillate. The calibration should be performed after the instrument has reached its operating temperature.

This calibration is always required after repair or replacement of the controller, synthesis, output unit or option SMY-B40. The synthesis must work correctly for this calibration.

The level-preset calibration is initiated by special function 45 (see operating manual). Subsequent to calibration, the previous instrument setting is restored.

The calibration data are stored in the RAM after successful calibration, which can be repeated any time.

#### 6.4.1.5 Output Level Correction

The accuracy of the output level is obtained by a level correction according to a table stored in the controller. This table is produced by means of a test program and a calibrated power meter and passed into the EEPROM of the controller via the IEC/IEEE bus. The complete calibration procedure can also be performed manually.

Manual calibration only requires the power meter specified under 6.2, item 3.

Automatic calibration requires the utilities listed in 6.2, items 1 to 3.

# 6.4.1.5.1 Manual Calibration of Level Correction

- · Connect calibrated power meter to RF socket.
- Call special function 47

The first calibration frequency is displayed. By pressing the RF-key the calibration frequencies can be varied, by pressing the LEVEL-key the correction value. The entered value is writen into the calibration table by pressing the ENTER-key. The next calibration frequency is displayed automatically. Proceed as above until reaching the last interpolation value. Call special function 48 to store the obtained values in the EEPROM.

• Call special function 48

To quit the actual calibration proceedure without storing the entered table in the EEPROM the OFF-key is to be set. In this case the calibration table is for temporary use only.

# 6.4.1.5.2 Program-controlled Level Calibration

- Connect calibrated power meter to RF socket.
- Connect controller, SMY and power meter to IEC-bus cable.
- Load Rohde & Schwarz-Basic and IEC-bus driver.
- Load and start the service program 'SMYSERVI.BAS'.
- Call the level-correction calibration in the submenu Calibrations'.

\_Calibration runs automatically.

# 6.4.1.6 Calibration of Reference Oscillator

Adjustment is required to ensure the accuracy of the reference frequency with the reference-oscillator option OCXO fitted. A D/A converter on the synthesis generates a tuning voltage which sets the reference oscillator to the correct frequency. The voltages for each individual OCXO have been determined in the factory. The correct tuning voltage is indicated on the label fitted to the cover of the oscillator. This calibration is performed only one time and must only be repeated with replacement of the controller or the reference-oscillator option as well as with ageing of the option.

If the tolerances of the reference-frequency accuracy are violated due to ageing, proceed as described in the service instructions for the reference oscillator.

If the tuning voltage has been re-determined for a special reference oscillator, the D/A converter data stored in the controller does not correspond with the tuning voltage on the reference crystal. In case of replacement of the controller, therefore take the D/A value stored in the previous controller and enter it to the new controller as described below.

· Call special function 51 (Refcal)

The stored value for the D/A converter is displayed in the right display. It may be 0 to 4095 (default 2048). The value for the D/A converter is derived from the tuning voltage as follows:

DA value = 4095 \* (tuning voltage[V] / 10V)

- · Enter the calculated value via the spinwheel or the keypad.
- · Terminate calibration by calling special function 52.

# 6.4.2 Adjustment of the Overall Instrument

If the instrument is set up of modules which have been tested and adjusted according to Section 7, the calibrations described in Section 6.4.1 are required, only.

# 6.4.3 Adjustments Following Replacement of Modules

Replacement of board

Required adjustments

Controller CPU

All adjustments acc. to 6.4.1

Display/Keyboard FRONT

No adjustment required

Synthesis YSYN

VCO calibration acc. to 6.4.1.1

FM calibration acc. to 6.4.1.2

Level-Preset calibration acc. to

6.4.1.4

Output Unit OPUY

Level-Preset calibration acc. to

6.4.1.4

Output-level correction acc. to

6.4.1.5

Attenuator ATT01/02

Output-level correction acc. to

6.4.1.5

With options installed:

SMY-B40

(Pulse modulator and High

Output Power)

Level-Preset calibration acc. to

6.4.1.4

Output-level correction acc. to

6.4.1.5

Reference oscillator ROSC

Calibration of reference frequency

acc. to 6.4.1.6

# 6.5 Disassembly and Assembly

#### WARNING !!!

Prior to disassembly, switch off the instrument and disconnect the power cable

# 6.5.1 Removal and Installation of the Panelling

- Undo the four screws in the rear-panel feet and remove feet.
- Remove the upper panelling to the rear and to the top
- Turn around the instrument. Remove the lower panelling similar to the upper panelling.

Prior to installation of the panelling, check, whether all modules are correctly connected and screwed to their supports.

- Place the instrument on one edge and install the lower panelling first. Make sure that the packing cords are correctly fitted into the grooves.
- Place the instrument into the horizontal position again and install the upper panelling, correspondingly.
- Make sure with both panellings that the guide noses on the rear panel lock into the cut-outs of the panellings.
- Screw on feet again.

### 6.5.2 Removal and Installation of the Controller

- Remove the panelling (6.5.1).
- Place the instrument on the top.
- Undo the two screws which fix the module to the support frame.
- Carefully lift the module and turn until the three ribbon cables can be disconnected from the sockets on top of the module.
- \_ The module can be removed.

Installation is carried out correspondingly in the reverse order.

# 6.5.3 Removal and Installation of the Output Unit

- Remove the panelling (6.4.1).
- Place the instrument on its bottom.
- · Disconnect the three RF cables on the front of the module.
- Undo the two screws which fix the module to the support frame.
- The module can now be removed to the rear and to the top out of the guide cut-out of the support frame.

Installation is carried out correspondingly in the reverse order.

# 6.5.4 Removal and Installation of the Synthesis

- Remove the panelling (6.4.1).
- Place the instrument on its bottom.
- Remove the controller as described in Section 6.4.2.
- · Detach the RF cables on the front of the module.
- Undo the two screws which fix the module to the support frame.
- The module can now be removed to the rear and to the top out of the guide cut-out of the support frame.
- Remove the panelling (6.4.1).
- Place the instrument on its bottom.

  Installation is carried out correspondingly in the reverse order.

# 6.5.5 Removal and Installation of the Keyboard/Display

- Remove the panelling (6.4.1).
- Place the instrument on its top.
- Remove the controller as described in Section 6.5.2
- Undo the four screws on the front of the display.
- Carefully remove the display to the front. Make sure to lead the ribbon cable which connects the module to the controller through the cut-out of the housing frame.

Installation is carried out correspondingly in the reverse order.

#### 6.5.6 Removal and Installation of the Power Supply

- Remove the panelling (6.4.1).
- Place the instrument on its bottom.
- Disconnect the ribbon cable which connects the module to the motherboard.
- If the reference-oscillator option ROSC is fitted, disconnect the connecting cable to the option, too.
- Undo the screws marked on the rear panel of the instrument.
- · Carefully remove the power supply to the rear.

Installation is carried out correspondingly in the reverse order.

# 6.5.7 Removal and Installation of the ROSC Option

- Remove the panelling (6.4.1).
- Place the instrument on its bottom.
- Disconnect the SMB connector, which connects the option to the synthesis, on the reference oscillator option.
- Disconnect the ribbon cable, which connects the option to the power supply, from the power supply.
- Undo the four screws which fix the module to the instrument frame. They are accessible on the outside of the instrument.
- \_ Remove the reference-oscillator option to the top.

# 6.5.8 Removal and Installation of the Power Module

- Remove the panelling (6.4.1).
- Place the instrument on its bottom.
- Disconnect both MMCX-connectors and both SMA-screw connections.
- Disconnect the ribbon cable.
- · Undo the screws which fix the module to the instrument frame.
- Remove the power module to the top.

When installing the power module, the projecting parts on the PCB must be sticked into the corresponding slots of the middle panel of the instrument. Further installation is carried out correspondingly in the reverse order.



Liste mechanischer Teile Bilder und Erklärung zur Liste mechanischer Teile

List of mechanical parts
Figures and explanation pertaining to list of mechanical parts

Liste des pièces mécaniques Figures et définitions pour liste des pièces mécaniques

# Liste mechanischer Teile

List of mechanical parts

Der SMY01 ist in R&S-Kompaktbauweise 90 aufgebaut.

The SMY01 is designed in accordance with the R&S design 90.

Gehäusegröße:

3E, 1/1, T350

Cabinet size:

Accessories:

3E, 1/1, T350

Maße über alles:

 $435 \times 147 \times 350 (B \times H \times T)$ 

Overall dimensions:

 $435 \times 147 \times 350$  (width  $\times$  height  $\times$  depth)

Ergänzungen:

19"-Adapter

ZZA

19\*-Adapter

77A

Tragegriff, Nachrüstsatz

(falls ein zweiter Tragegriff gewünscht

wird)

Carrying handle, retrofit set (if a second carrying handle is desired)

Lfd. Nr.	Kenn- zeichen	Menge	Benennung/Beschreibung	Sachnummer
No	Unit/ Comp.No	Qty	Designation	Stock No.
1		1	Haube, oben 3E, 1/1, T350 Cover, top	1062.6050
2		1	Haube, unten 3E, 1/1, T3S0 Cover, bottom	396.3773
3		1	Führungsschiene, rechts Guide rail, right	396.4757
4		1	Führungsschiene, links Guide rail, left	396.4763
5		1	Bedienhinweiskarte 1 User guide card 1	1062.5590
6			Bedienhinweiskarte 2 User guide card 2	***********
7		***	Bedienhinweiskarte 3 User guide card 3	
8	,	2	Gerätefuß, vorne Instrument foot, front	396.4534
9		2	Aufstellfuß, unten Foot, bottom	396.4540
11		2	Gerätefuß, hinten Instrument foot, rear	396.45B6
12		В	Zapfen Pin	396.4634
15		2	Seitenleiste T350 5ide strip	396.3073

Lfd. Nr.	Kenn- zeichen	Menge	Benennung/8eschreibung	Sachnummer
No	Unit/ Comp.No	Qty	Designation	Stock No.
16		4	M3 × 6 DIN965 A4	081.9378
17		1	Rückwandfuß, links 3E Rear-panel foot, left	396.4334
18		1	Rückwandfuß, rechts 3E Rear-panel foot, right	396.4128
19		4	Ansatzschr. M4 K.D 7985 5crew	396.4492
21		1	Tragegriff T350 Carrying handle	396.3215
22		2	Griffbuchse Washer	396.3367
23		2	M4×10 DIN965 A4	081.9478
24		2	Abdeckung, Griffseite Cover, handle side	396.3350
25		2	Abdeckung, Leerseite Cover, blank side	396.3344
30		1	Frontrahmen 3E 1/1 Front frame	396.2119
31		4	Seitenfuß Side foot	396.4692
32		2	Stapelnutabdeckung Cover for groove	396.4711
33			Frontgriff Frontgrip	
34		4	M4×8 DIN965	396.1087
35		1	Rückrahmen 3E 1/1 Rear frame	396.2254
36		4	Rahmenschiene T350 Frame rail	396.2360
37		16	M3 × 8 DIN965 A4	081.9384
40		1,09 M	HF-Dichtschnur O-Prof. 2,751 RF seal	396.0916
41		3,03 M	WG HF-Dicht. O-Prof. 2,051 RF seal 396.	

# Liste mechanischer Teile

List of mechanical parts

Der SMY02 ist in R&S-Kompaktbauweise 90 aufgebaut.

The 5MY02 is designed in accordance with the R&S design 90.

Gehäusegröße:

3E, 1/1, T460

Cabinet size:

Accessories:

3E, 1/1, T460

Maße über alles:

 $435 \times 147 \times 460 (B \times H \times T)$ 

Overall dimensions:

 $435 \times 147 \times 460$  (width × height × depth)

Ergänzungen:

19"-Adapter

ZZA

19"-Adapter

ZZA

Tragegriff, Nachrüstsatz

(falls ein zweiter Tragegriff gewünscht wird)

Carrying handle, retrofit set (if a second carrying handle is desired)

Lfd. Nr.	Kenn- zeichen	Menge	Benennung/Beschreibung	Sachnummer
No	Unit/ Comp.No	Qty	Designation	Stock No.
1		1	Haube, oben 3E, 1/1, T460 Cover, top	1062.6044
2		1	Haube, unten 3E, 1/1, T460 Cover, bottom	396.3780
3		1	Führungsschiene, rechts Guide rail, right	396.4757
4		1	Führungsschiene, links Guide rail, left	396.4763
5		1	Bedienhinweiskarte 1 User guide card 1	1062.5590
6		alua a	Bedienhinweiskarte 2 User guide card 2	*******
7		•••	Bedienhinweiskarte 3 User guide card 3	B44
8	·	2	Gerätefuß, vorne Instrument foot, front	396.4534
9		2	Aufstellfuß, unten Foot, bottom	396.4540
11		2	Gerätefuß, hinten Instrument foot, rear	396.4586
12		8	Zapfen Pin	396.4634
15		2	Seitenleiste T460 Side strip	396.3073

Lfd. Nr.	Kenn- zeichen	Menge	Benennung/Beschreibung	Sachnummer
No	Unit/ Comp.No	Qty	Designation	Stock No.
16		4	M3×6 DIN965 A4	0B1.937B
17		1	Rückwandfuß, links 3E Rear-panel foot, left	396.4334
1B		1	Rückwandfuß, rechts 3E Rear-panel foot, right	396.412B
19		4	Ansatzschr. M4 K.D 7985 Screw	396.4492
21		1	Tragegriff T460 Carrying handle	396.3221
22		2	Griffbuchse Washer	396.3367
23		2	M4×10 DIN965 A4	0B1.947B
24		2	Abdeckung, Griffseite Cover, handle side	396.3350
2\$		2	Abdeckung, Leerseite Cover, blank side	396.3344
30		1	Frontrahmen 3E 1/1 Front frame	396.2119
31		4	Seitenfuß Side foot	396.4692
32		2	5tapelnutabdeckung Cover for groove	396.4711
33			Frontgriff Front grip	
34		4	M4×B DIN965	396.1087
35		1	Rückrahmen 3E 1/1 Rear frame	396.2254
36		4	Rahmenschiene T460 Frame rail	396.2377
37		16	M3×8 DIN965 A4	081.9384
40		1,09 M	HF-Dichtschnur O-Prof. 2,7 SI RF seal	396.0916
41		3,S1 M	WG HF-Dicht. O-Prof. 2,0 SI RF seal	396.103\$



SMY02 SIGNAL GENERATOR Exploded Mechanical View

# Manufacturers Cross Index

MFR. CODE	MANUFACTURER	ADDRESS	CITY, STATE, ZIP CODE
D0894	ROHDE & SCHWARZ	MUEHLDORFSTRASSE 15	8000 MUENCHEN 80, GERMANY

Figure & Index. No.	Stock No.	дty	Name & Deacription	CAGE Code	Mfr. Part Number
3-1	1062,6044,00	1 ea	COVER, TOP	D0894	1062.6044.00
3-2	0396.4492.00	4 ea	SCREW, MACHINE: M4 X 12, CHEESE HEAD, X10CRNIMOTI 1810 (DIN7985)	D0894	0396.4492.00
3-3	0396,4334.00	1 ea	REAR-PANEL FOOT, LEFT	D0894	0396.4334.00
3-4	0396.4128.00	1 ea	REAR-PANEL FOOT, RIGHT	D0894	0396.4128.00
3-5	1062.6021.00	1 ea	COVER SET, FRONT AND REAR (VAR 12)	D0894	1062.6021.00
3-6	0396.3780.00	1 ea	COVER, BOTTOM	D0894	0396.3780.00
3-7	0396.4586.00	2 ea	INSTRUMENT FOOT, REAR	D0894	0396,4586,00
3-8	0396,4634.00	8 ea	PIN	D0894	0396.4634.00
3-9	0396,4757,00	1 ea	GUIDE RAIL, RIGHT	D0894	0396,4757,00
3-10	0396.4540.00	2 ea	<b>FOOT, ВОТТОМ</b>	D0894	0396,4540.00
3-11	0396,4534.00	2 ea	INSTRUMENT FOOT, FRONT	D0894	0396.4534.00
3-12	*********		USER GUIDE CARD 3	D0894	*************
3-13	***************************************		USER GUIDE CARD 2	D0894	
3-14	1062.5590.00	1 ea	USER GUIDE CARD 1	D0894	1062,5590,00
3-15	0396.4763.00	1 ea	GUIDE RAIL, LEFT	D0894	0396.4763.00




Fig. 6-3 Cabinet and feet

Figure &	Stock No.	9t <del>y</del>	Name & Description	CAGE Code	Mfr. Part Number
Index. No.				1	1
4-1	0396.8030.00	4 ea	SCREW, MACHINE: M3 X 6, FH, SST (DIN965-A4)	D0894	0396.8030.00
4-2	0396.0916.00	1.09 m	SEALING	D0894	0396.0916.00
4-3	0396.3080.00	2 ea	SIDE STRIP T460 VAR 12	D0894	0396.3080.00
4-4	0396.8046.00	16 ea	SCREW, MACHINE: M3 X 8, FH, SST (DIN965-A4)	D0894	0396.8046.00
4-6	0396.2377.00	4 ea	FRAME GUIDE VAR 12	D0894	0396.2377,00
4-6	0396.1064.00	2 ea	NUT: M4 X RD9, STL	D0894	0396,1064.00
4-7	0079.0525.00	2 ea	NUT: M8, NYLON, WHITE	D0894	0079.0525.00
4-8	0396.2254.00	1 ea	REAR FRAME	D0894	0396.2254.00
4-9	0396.1036.00	3.51 m	SEALING VAR 12	D0894	0396.1035.00
4-10	0081.9084.00	11 ea	SCREW, MACHINE: M3 X 10, CHEESE HEAD, SST (DIN7985-A4)	D0894	0081.9084.00
4-11 .	0396.3221.00	1 ea	CARRYING HANDLE	D0894	0396.3221.00
4-12	0396,3350,00	2 ea	COVER, HANDLE SIDE	D0894	0396,3350.00
4-13	0081.9478.00	2 ea	SCREW, MACHINE: M4 X 10, FH, SST (DIN965-A4)	D0894	0081.9478.00
4-14	0396.3367.00	2 ea	WASHER, SHOULDER: 24 OD, 5 THK, FLAT SIDE, X10CRNIS 189 (DIN671)	D0894	0396.3367.00
4-15	0081.9084.00	3 ea	SCREW, MACHINE: M3 X 10, CHEESE HEAD, SST (DIN7985-A4)	D0894	0081.9084.00
4-16	0062.1130.00	3 ea	FEED-THROUGH, RD4 X RD9, 5 X 6, 6	D0894	0062,1130.00
4-17	0082,4686,00	3 ea	WASHER, FLAT: 4.3 ID X 9 OD, 0.8 THK, SST (DIN125-A4)	D0894	0082.4686.00
4-18	0031.2805.00	3 ea	TUBING RIVET: B4 X 6-MS-E1P, RUBBER, BLACK (DIN7340)	D0894	0031.2805.00
4-19	1062.5860.00	1 ea	ATTENUATOR HOLDER	D0894	1062.5860.00
4-20	0396.4692.00	4 ea	SIDE FOOT	D0894	0396,4692.00
4-21	0396.2119.00	1 ea	FRONT FRAME	D0894	0396.2119.00
4-22	0081,9378,00	2 ea	SCREW, MACHINE: M3 X 6, FH, SST (DIN965-A4)	D0894	0081.9378.00
4-23	0032.6237.00	1 ea	SEALING SPRING	D0894	0032.6237.00
4-24	See EPL	1 ea	ATTENUATOR SMG/SMH VAR 12 (A6)	D0894	See EPL
4-25	1062,5990.00	1 ea	LP HOLDER VAR 12	D0894	1062.5990.00
4-26	1062.5983.00	1 ea	LP HOLDER	D0894	1062.5983.00
4-27	0396.4711.00	2 ea	COVER FOR GROOVE	D0894	0396.4711.00
4-28	0396.3344.00	2 ea	COVER, BLANK SIDE	D0894	0396,3344.00




Figure 6-4 Chassis

Figure &	Stock No.	Qty	Name & Description	CAGE Code	Mfr. Part Number
Index. No.					
5-1	1062.5602.00	1 ea	COVER, VARNISH+INSCRIPTION	D0894	1062.5602.00
5-2	1062,5631.00	1 ea	MOUNTING PLATE	D0894	1062.5631.00
5-3	See EPL	1 ea	KEYBOARD/DISPLAY (A1)	D0894	See EPL
5-4	0001.9499.00	0.075 m	PLASTIC CHANNEL	D0894	0001.9499.00
5-5	1062.5648.00	1 ea	SHIELDING	D0894	1062.5648.00
5-6	See EPL	1 ea	MOTHERBOARD (A3)	D0894	See EPL
5-7	0088.3146.00	4 ea	WASHER, FLAT: 2.7 ID X 6.5 OD, 0.5 THK, NYLON	D0894	0088.3146.00
5-8	0071,5705.00	4 ea	SCREW, MACHINE: M2.5 X 8, CHEESE HEAD, SST (DIN7985-A2)	D0894	0071.5705.00
5-9	See EPL	1 ea	CABLE, ASSY: 34, RIBBON, APPROX 10 CM (W3)	D0894	See EPL
5-10	1062.5890.00	1 ea	SWITCH ROD VAR 12	D0894	1062,5890,00
5-11	0099.1410.00	1 ea	GROMMET, BLACK, RUBBER	D0894	0099,1410.00
5-12	0081,9378.00	8 ea	SCREW, MACHINE: M3 X 6, FH, SST (DIN965-A4)	D0894	0081.9378.00
5-13	See EPL	1 ea	CABLE, ASSY: 26, RIBBON, APPROX 47 CM (W21)	D0894	See EPL
5-14	See EPL	1 ea	CABLE, ASSY: 16, RIBBON, APPROX 33 CM (W77)	D0894	See EPL
5-15	See EPL	1 ea	CABLE, ASSY: 10, RIBBON, APPROX 20 CM (W20)	D0894	See EPL
5-16	0099.7825.00	1 ea	FLAT CABLE HOLDER	D0894	0099.7825.00
5-17	0099.9186.00	Зеа	BNC-CONNECTOR UG 625CÍU	D0894	0099,9186,00
5-18	0035.0813.00	3 ea	SOLDERING LUG, 18 x 10	D0894	0035.0813.00
<b>5-1</b> 9	See EPL	1 ea	CABLE, ASSY: SEMIRIGID COAX, APPROX 30 CM (W1)	D0894	See EPL
5-20	0099.4161.00	3 ea	INSULATING RING FOR BNC-S	D0894	0099,4161.00
5-21	0088.0147.00	6 ea	SCREW, MACHINE: M2.5 X 16, FH, SST (DIN965-A4)	D0894	0088.0147.00
5-22	0396,0897.00	1 ea	SPOUT	D0894	0396,0897.00
5-23	0078.3795.00	1 ea	SCREW, MACHINE: M1.5 X 3, FH, SST (DIN955-A4)	D0894	0078.3795.00
5-2 <del>4</del>	0078.1192.00	1 ea	KNOB: W/SET SCREW, 5/64 ALLEN	D0894	0078.1192.00
5-25	1062.5180.00	1 ea	LABEL, PART NUMBER VAR 12	D0894	1062.6180.00
5-26	1062.5948.00	1 ea	LABEL, MODEL VAR 12	D0894	1062.5948.00
5-27	1062.6167.00	1 ea	LABEL, FREQUENCY RANGE VAR 12	D0894	1062.6167.00
5-28	0396.5518.00	4 ea	WASHER, COUNTERSUNK: 7.2 OD X 1.8 THK, RD 7.5 CUZN40PB2	D0894	0396.5518.00
5-29	0081.9384.00	4 ea	SCREW, MACHINE: M3 X 8, FH, SST (DIN965-A4)	D0894	0081.9384.00




Fig. 6-5 Front panel assembly

Figure & Index. No.	Stock No.	gty	Name & Description	CAGE Code	Mfr. Part Number
6-1	0088.7693.00	62 ea	SCREW, MACHINE: M2 X 5, SST (A2)	D0894	0088.7693.00
6-2	1062.7057.00	1 ea	TOP COVER, OUTPUT UNIT MODULE	D0894	1062.7057.00
6-3	0071.6853.00	6 ea	SCREW, MACHINE: M3 X 8, CHEESE HEAD, SST (DIN7895-A2, DIN6902-A2, DIN6904-A2)	D0894	0071.6853.00
6-4	See EPL	1 ea	OUTPUT UNIT 2.08 GHZ (A5)	D0894	See EPL
6-5	1062.7065.00	1 ea	BOTTOM COVER, OUTPUT UNIT MODULE	D0894	1062.7065.00
6-6	See EPL	1 ea	CABLE, ASSY: SEMIRIGID, COAX, APPROX 12 CM (W26)	D0894	See EPL
6-7	1062.6473.00	1 ea	TOP COVER, SYNTHESIZER MODULE	D0894	1062.6473.00
6-8	See EPL	1 ea	SYNTHESIZER (A4)	D0894	See EPL
6-9	1062.6480.00	1 ea	BOTTOM COVER, SYNTHESIZER MODULE	D0894	1062.6480.00
6-10	1062.6373.00	1 ea	TOP COVER, PROCESSOR MODULE	D0894	1062,6373,00
6-11	See EPL	1 ea	PROCESSOR (A2)	D0894	See EPL
6-12	1062.6380.00	1 ea	BOTTOM COVER, PROCESSOR MODULE	D0894	1062.6380.00
6-13	0071.7572.00	8 ea	SCREW, MACHINE: M2.5 X 6, FH, SST	D0894	0071.7572.00
6-14	0071.5757.00	47 ea	SCREW, MACHINE: M2.5 X 10.4, FH, SST	D0894	0071.5757.00
6-15	See EPL	1 ea	CABLE, ASSY: FLEXIBLE, COAX, APPROX 4 CM (W25)	D0894	See EPL
<b>6</b> -16	See EPL	1 ea	CABLE, ASSY: FLEXIBLE, COAX, APPROX 4 CM (W24)	D0894	See EPL




Fig. 6-6 Circuit boards

Figure	Stock No.	Qty	Name & Description	CAGE	Mfr. Part Number
& Index. No.				Code	
7-1	1062.5831.00	1 ea	POWER SUPPLY HOLDER	D0894	1062.5831.00
7-2	0554.6528.00	1 ea	BOLT, HEX HEAD: M6 X 12 (DIN933)	D0894	0554.6528.00
7-3	0031.5210.00	1 ea	WASHER, FLAT: 6.1 ID X 18 OD, 1.6 THK, SST (DIN9021-A4)	D0894	0031.5210.00
7-4	0005.2524.00	1 ea	WASHER, SPRING: 6.1 ID X 11.8 OD, 2.2 THK, SST (DIN128-A2)	D0894	0005.2524.00
7-5	See EPL	1 ea	FAN UNIT (E1)	D0894	See EPL
7-6	1062.5725.00	1 ea	REAR PANEL	D0894	1062.5725.00
7-7	0071.6853.00	2 ea	SCREW, MACHINE: M3 X 8, CHEESE HEAD, SST (DIN7895-A2, DIN6902-A2, DIN6904-A2)	D0894	0071.6853.00
7-8	0006.0296.00	4 ea	WASHER, SPRING: 3.2 1D X 6.0 OD, O.4 THK, SST (DIN137-A2)	D0894	0005.0296.00
7-9	0082.4670.00	4 ea	WASHER, FLAT: 3.2 ID X 7.0 OD, 0.6 THK, SST (DIN125-A4)	D0894	0082.4670.00
<b>7-1</b> 0	0081.9084.00	4 ea	SCREW, MACHINE: M3 X 10, CHEESE HEAD, SST (DIN7985-A4)	D0894	0081.9084.00
7-11	0071.6853.00	4 ea	SCREW, MACHINE: M3 X 8, CHEESE HEAD, SST (DIN7895-A2, DIN6902-A2, DIN6904-A2)	D0894	0071,6853.00
7-12	1062,5954,00	1 ea	SERIAL, NUMBER	D0894	1062.5954.00
7-13	1062.5754.00	1 ea	COOLING PROFILE	D0894	1062.5754.00
7-14	0005.0296.00	6 ea	WASHER, SPRING: 3.2 ID X 6.0 OD, 0.4 THK, SST (DIN7895-A2)	D0894	0005.0296.00
7-15	0082,4670.00	6 ea	WASHER, FLAT: 3.2 ID X 7.0 OD, 0.5 THK, SST (DIN125-A4)	D0894	0082.4670.00
7-16	0081.9084.00	6 ea	SCREW, MACHINE: M3 X 10, CHEESE D0894 HEAD, SST (DIN7985-A4)		0081.9084.00
7-17	0071.6860.00	1 ca	SCREW, MACHINE: M4 X 8, CHEESE HEAD, SST (DIN7895-A2)	D0894	0071.6860.00
7-18	0081.9384.00	2 ea	SCREW, MACHINE: M3 X 8, FH, SST (DIN965-A4)	D0894	0081.9384.00
7-19	See EPL	2 ea	FUSE (F1/F2)	D0894	See EPL
7-20	0006.0919.00	1 ea	FILTER W/VOLTAGE SELECTION, W/2 FUSE CARTRIDE HOLDERS	D0894	0006.0919.00
7-21	0071.6853.00	4 ea	SCREW, MACHINE: M3 X 8, CHEESE HEAD, SST (DIN7895-A2, DIN6902-A2, DIN6904-A2)	D0894	0071.6853.00
7-22	0016.2837.00	1 ea	WASHER, LOCKING: 4.3 ID X 8.0 OD, 1 THK, SST (DIN6797-A2)	D0894	0016.2837.00
7-23	0543.6705.00	1 ea	CONNECTOR	D0894	0543.6705.00
7-24	0085.0330.00	1 ca	NUT, SQUARE: M4 X 9, 2 THK	D0894	0085.0330.00
7-25	1062.5790.00	1 ea	WIRE SET	D0894	1062.5790.00
7-26	See EPL	1 ea	TRANSFORMER (T1)	D0894	See EPL
7-27	0071.6830.00	2 ea	SCREW, MACHINE: M2.5 X 5, CHEESE HEAD, SST (DIN7985-A2)	D0894	0071.6830.00
7-28	0007.7130.00	1 ea	COVER, POWER SWITCH	D0894	0007.7130.00
7-29	0007.5143.00	1 ea	POWER SWITCH	D0894	0007.5143.00
7-30	1062.5848.00	1 ea	BRACKET, L-SHAPED	D0894	1062.5848.00
7-31	0081.9390.00	4 ea	SCREW, MACHINE: M3 X 10, FH, SST (DIN965-A4)	D0894	0081.9390.00
7-32	0396.3167.00	4 ea	NUT FOR REAR FRAME, TAPPED FOR M3 THREAD	D0894	0396.3167.00
7.33	0528.8500.00	3 ea	STOPPER	D0894	0528.8500.00
7-34	See EPL	1 ea	CABLE, IEC/IEEE CONNECTOR, WITH ATTACHING HARDWARE (W2)	D0894	See EPL

Figure & Index. No.	Stock No.	Qty	Name & Description	CAGE Code	Mfr. Part Number
7-35	0043.5827.00	1 ea	SEALING RUBBER	D0894	0043.5827,00
7-36	1062.5819.00	1 ea	ANGLE FOR CONNECTOR	D0894	1062.5819.00
7-37	0099.9186.00	2 ea	BNC-CONNECTOR UG 625CIU	D0894	0099.9186.00
7-38	0035.0813.00	1 ea	SOLDERING LUG, 18 X 10	D0894	0035.0813.00
7-39	See EPL	1 ea	CABLE, ASSY: FLEXIBLE, COAX, APPROX 53 CM (W27)	D0894	See EPL
7-40	See EPL	1 ea	CABLE, ASSY: 10, RIBBON, APPROX 47 CM (W4)	D0894	See EPL
7-41	0099.9186.00	1 ea	BNC-CONNECTOR UG 625CIU	D0894	0099,9186.00
7-42	0099.7825,00	1 ea	FLAT CABLE HOLDER	D0894	0099.7825.00
7-43	0071,6853.00	5 еа	SCREW, MACHINE: M3 X 8, CHEESE HEAD, SST (DIN7895-A2, DIN6902-A2, DIN6904-A2)	D0894	0071.6853.00
7-44	See EPL	1 ea	POWER SUPPLY (A7)	D0894	See EPL
4-45	0088.0060.00	Зеа	SCREW, MACHINE: M2.5 X 12, CHEESE HEAD (DIN7895-A4)	D0894	00,0300,8800
7- <del>4</del> 6	0082.4663.00	3 ea	WASHER, FLAT: 2.7 ID X 6.5 OD, 0.5 THK, SST (DIN125-A4)	D0894	0082.4663.00
7-47	0005,0280,00	3 ea	WASHER, SPRING: 2.8 JD X 5.5 OD, D0894 0		0005,0280,00
7-48	1062.5719.00	1 ea	SHIELDING	D0894	1062,5719,00
7-49	0088.6680.00	4 ea	NUT, M3 X 6, PRESSFIT	D0894	0088.6680.00




Fig. 6-7 Rear panel assembly

Figure & Index. No.	Stock No.	<b>Gty</b>	Name & Description	CAGE Code	Mfr. Part Number	
Standard Accessories						
8-1	0086,4400,00	1 ea	POWER CORD	D0894	0086.4400.00	
8-2	0200.7575.00	2 ea	FUSE: T2,5HIEC127-2/V	D0894	0200.7575.00	
	1062.5583,18		MANUAL, TECH: OPERATING	D0894	1062.5583.18	
			Optional Accessories			
	1062.5583.28		MANUAL, TECH: SERVICE VOLUMES 1 AND 2	D0894	1062.5583.28	
	1062.7805,02		SMY-C2, SERVICE KIT FOR SMY D0894 1062.7805			




Fig. 6-8 Accessories



Schlüsselliste
für Bauteile-Sachnummern
Code list
for component stock Nos.
Liste
des références des composants



# R&S-Schlüsselliste R&S key list Liste des symboles de référence R&S

Die R&S-Schaltteillisten nennen in der Spalte "Benennung/Beschreibung" die technischen Daten der Bauelemente in Kurzform. Die Art des Bauelements (z.B. Schicht-, Drant-Widerstand usw.) beschreiben die 2 Kennbuchstaben vor der "Benennung" (evtl. auch vor der "Sachnummer"), die nachfolgend erklärt werden, the Ersatzteil-Bestellungen an R&S ist stets die Angabe der vollständigen Sachnummer erforderlich. The R&S Parts Lists give the technical data of the components in short form in the column "Benennung/Beschreibung" (designation). The type of component (e.g. depos.-carbon resistor, wire-wound resistor etc.) is indicated by 2 identification letters before the designation, possibly also before the "Sachnummer" (order number), which are explained below. When ordering spare parts from R&S, the complete order number must always be specified.

La colonne «Désignation/description» des listes de pièces de R&S indique les caractéristiques des élèments sous forme abrègée. Le type d'élèment (p. ex. résistance à couche, résistance bobinée etc...) est décrit par les deux lettres précédant la désignation (et éventuellement le numéro de référence), dont voici l'explication. Prière d'indiquer le numéro de référence («Sachnummer») complet dans toute commande de pièces de rechange.

:h.		order number must always be specified.			mande de pièces de rechange.			
Tesle- familie	Art des Bauelementes	Parts family	Type of component	Famil- le	Type d'element			
A	Aktive Bauelemente, Halbleiter	A	Active components, semiconductors	A	Composants actifs, semiconducteurs			
AD	Universaldiode, z.B. Gleichrichter, Sperrdiode	AD	General-purpose diode, e.g. rectifier, high-resistance diode	AD	Diode d'usage général, p.ex. redresser diode à haute résistance			
AE	Spezialdiode, z.B. Tunnel-, Kapazitäts-, Zener-Diode	AE	Diode (special), e.g. tunnet diode, varactor, Zener diode	AE	Diode speciale, p.ex. diode tunnel, varactor, diode Zener			
AF	Fotohalbleiter, z.B. Foto-Diode, -Transistor, -Widerstand, Leucht- diode	AF	Photo-semiconductor, e.g. resistor, diode, transistor, LED	AF	Semiconducteur photoélectrique, p.ex diode, transistor, résistance photoèl., DEL			
AG	Leistungs-Gleichrichter, z.B. Thyristor, Triac, Selengleichrichter	AG	Power rectifier, e.g. thyristor, triac, selenium rectifier	AG	Redresseur de puissance, p.ex. thyristriac, redresseur, au sélénium			
AK	Kleinsignal-Transistor	AK	Smatt-signal transistor	AK	Transistor faible pulssance			
AL	Leistungs-Transistor	AL	High-power transistor	AL	Transistor grande puissance			
AM	Spezial-Transistor, z.B. FET. MDSFET	AM	Transistor (special), e.g. FET, MOS-FET	АМ	Transistor special, p.ex. TEC, MOSTEC			
ĄΡ	Pettier-, Hall-Element	AP	Peltier element, Hall element	AP	Element Peltier, élement Hall			
AR	Röhre für Empfänger, Verstarker, Gleichrichter	AR	Valve for receiver, amplifier, rectifier	AR	Tube pour récepteur, amplificateur, redresseur			
AS	Spezialrohre, z.B. Senderóhre. EW-Widerstand, Stabilisator	AS	Valve (special), e.g. for transmitter, baretter, baltast valve	AS	Tube (spécial), p.ex. pour émetteur, résistance fer-hydrogène, ballast			
ΑT	Katodenstrahlröhre, z.B. Bildröhre, Ziffern-Anzeigeröhre	AT	Cathode ray tube, e.g. picture tube, digital indicator tube	AT	Tube à rayon cathodique, p.ex. tube à image, tube à affichage numérique			
ΔZ	Zubehör für Hatbleiter v. Röhren	ΑŽ	Accessories for semiconductors and valves	AZ	Accessoires pour semiconducteurs et tubes			
В	Bausteine	В	PC boards, chips	B	Cartes imprimées, puces			
3C	Integr. Schaltkreis (Microcomp.)	вс	Integrated circuit (interface, A/D)	вс	Circuit intègré (microprocesseur)			
	R&S-Dünnschicht- und Dickschicht- schaltung	BD	R&S thinfilm or thickfilm circuit	BD	Circuit R&S à couche mince ou épaisse			
3G	R&S-spezifische Gate-Arrays	BG	R&S gate arrays	BG	Circuits intégrés prédiffusés R&S			
	tntegrierter Schaltkreis (Interface, A/D-Wandler)	BJ	Integrated circuit (interface, A/D converter)	ВЈ	Circuit intègré (interface, convertisseu A/N)			
3L	Log. Schaltkreis z.B. DTL, TTL, HTL, ECL, C-MOS	BL	Logic circuit, e.g. DTL, TTL, HTL, ECL, C-MOS	BL	Circuit logique, p.ex. DTL, TTL, HTL, ECL, C-MOS			
ВМ	Hybridbaustein, z.B. Mischer, Tuner, Modulator	вм	Hybrid chip, e.g. mixer, tuner, modulator	вм	Puce hybride, p.ex. mėlangeur, tuner, modulateur			
	Analogschaltkreis, z.B. Operations- verstärker	BD	Analog circuit, e.g. operational amplifier	во	Circuit analogique, p.ex. amplificateur opérationnel			
	Diptoelektronischer Baustein, z.B. Anzeigeeinheit, Koppler	ВР	Optoelectronic component, e.g. display, coupler	ВР	Composant optoelectronique, p.ex. afficheur, coupleur			
	Schalt- und Steuerbaustein. elektronischer Sensor	BS	Switching and control modul, electronic sensor	BS	Modul de commutation et de commande, sonde électronique			
3V	Stromversorgung, ÜberspSchutz	в٧	Power pack, protective circuit	ВV	Alimentation, protection surcharge			
3Z	Zubehör	BZ	Accessories	BZ	Accessoires			

Telle- lamilie	Art des Bauelementes	Parts family	Type of component	Famil- le	Type determent
С	Kondensatoren	С	Capacitors	С	Condensateurs
СВ	Bypass-, DurchfKondensator	СВ	Bypass capacitor, feed-through capacitor		Condensateur bypass, condensateur de traversée
cc	Keramischer Kondensator	cc	Ceramic capacitor	CC	Condensateur céramique
CD	Drehkondensator	CD	Variable capacitor	CD	Condensateur variable
CE	Elektrolytkondensator	CE	Electrolytic capacitor	CE	Condensateur électrolytique
CG	Glimmerkondensator	CG	Mica capacitor	CG	Condensateur au mica
СН	Sperrschichtkondensator	СН	Semiconductor capacitor	СН	Condensateur semiconducteur
СК	Kunstfolienkondensator	СК	Synthetic-foil capacitor	СК	Condensateur à feuille synthétique
CL	Ker. HochspKondensator	CL	HV capacitor (ceramic)	CL	Condensateur HT céramique,
СМ	Metallpapier-Kondensator	СМ	MP capacitor	СМ	Condensateur à papier métallisé
CN	Kondensatornetzwerk	CN	Capacitor network	CN	Réseau capacitif
СР	Papierkondensator	CP	Paper capacitor	СР	Condensateur au papier
CS	Störschutzkondensator	cs	Interference-suppression capacitor	cs	Condensateur anti-parasite
CT	Trimmkondensator	CT	Trimmer capacitor	СТ	Condensateur ajustable
CV	Vakuum-Kondensator	cv	Vacuum capacitor	cv	Condensateur à vide
D	Drähte, Leitungen	D	Wires, lines	ם	Fils, lignes
DD	Schalt- und Wickeldraht	מם	Hook-up or winding wire	OD	Fil de câblage, fil de bobinage
DF	Flachleitung, Litze	DF	Flat multiple line, stranded wire	DF	Ligne plate, ligne torsadée
DG	Abgeschirmte Leitung	DG	Shielded line	DG	Ligne blindé
DH	Koaxialkabel	DH	Coaxial line	DH	Ligne coaxiale
ט	Isollerschläuche, Schrumpf- schläuche, Wellrohre, Schutzschläuche	רם	Insulating sheaths, shrink-on sleeves, corrugated tubes, protective tubes	อง	Gaines isolantes, gaines thermorétrac- tables tubes ondulés, gaines protectrices
DL	HF-Litzen	DL	RF stranded wires	DL	Lignes torsadées RF
DM	Schaltlitzen (mehrdrähtige Leiter)	DM	Multi-conductor wires	DM	Lignes torsadées (multiconducteurs)
DN	Antenne	DN	Antenna	DN	Antenne
DO	Lichtleiter (optisch)	DO	Optical waveguides	DO	Guides d'onde optiques
DΡ	Leiterplatten (unbestückt)	DΡ	Printed circuit boards (bare)	DP	Cartes imprimées (non équipées)
DO	Multilayer (unbestückt)	DO	Multilayer boards (bare)	DO	Cartes multicouche (non équipées)
DS	Anschlußkabel (mehradrig)	DS	Connecting cable, multicore	DS	Càble de connexion (multiconducteur)
DU	Substratplatten für Dickschicht- schaltungen	DU	Substrate boards for thickfilm circuits	טם	Cartes à substrat pour circuits à couche épaisse
DW	Festmantelkabel	DW	Rigid cables	DW	Câbles rigides
Ε	Elektrische Teile	E	Electric parts	E	Organes électriques
EB	Slei-, NC-Akku, Satterie	E8	Lead or alkaline accumulator, battery	EB	Accumulateur Pb/NC, batterie
ED	Gedruckte Schaltung (bestückte Leiterplatte), nicht steckbar	ED	Printed circuits (assembled), non-pluggable	ED	Circuits imprimés (équipés) non enfichables
EE	Gedruckte Schaltung (bestückte Leiterplatte), steckbar	EE	Printed circuits (assembled), pluggable	EE	Circuits imprimės (ėquipės) enfichables
EF	Glühlampe, Leuchte	EF	Incandescent lamp, pilot lamp	EF	Lampe à incandescence, voyant
EG	Glimmlampe, Entladungslampe	EG	Glow lamp, discharge lamp	EG	Lampe à luminescence lampe à décharge
EK	Kontakt-Streifen, -Feder	EK	Contact clip, contact spring	EK	Lampe de contact, ressort de contact
EL	Lautsprecher, Kopfhörer, Mikrofon	EL	Loudspeaker, headphones, microphone	EL	Haut-parleur, casque, microphone
EM	Motor, Hubmagnet, Drehfeldsystem	ĘМ	Motor, lifting magnet, synchro system	ЕМ	Moteur, électro-aimant de levage, système synchro
EQ	Oszillator, z.B. Quarzoszillator	EO	Oscillator, e.g. crystal oscillator	EO	Oscillateur p.ex. oscillateur à quartz
ΕP	Tief-, Band-, Hochpaß, Bandsperre. Diskriminator	EP	Lowpass, bandpass, highpass litter, band-stop filter, discriminator	EΡ	Filtre passe-bas, passe-bande, passe-haut, suppression de bande, discriminateur
EQ	Schwing-, Filter-Quarz	EQ	Oscillator or filter crystal	EQ	Quartz oscillateur, quartz de filtre
ER	Resonator, piezoelektr./magnetostriktiv	ER	Resonator, plezoelectric/ magnetostrictive	ER	Resonateur pièzo-electrique/ magneto-strictif
E5	Passive Srift-Bautsile	28	Passive SHF-compovents	€3	Composant SIV passfi
ET	Thermostat	ΕŤ	Thermostat	ET	Thermostat
EV	Lüfter, Gebläse	ΕV	Ventilator, blower	ΕV	Ventilateur, soufflerie



Tede- familie	Art des Bauelementes	Parts (armity	Type of component	Famil- le	Type d'element
F	Fassungen, Steckverbindungen	F	Sockets, connectors	F	Douilles, connecteurs
FG	Koax-Umrüstsatz	FG	Coaxial screw-in assembly	FG	Ensemble vissable coaxial
FH	Koax-Übergang auf Fremdsystem	FH	Coaxial adapter	FH	Adaptateur coaxial
FJ	BNC-Systemteil	FJ	BNC screw-in assembly	FJ	Ensemble vissable BNC
FK	Koaxial-UHF-Systemteil	FK	Coaxial UHF screw-in assembly	FK	Ensemble vissable coaxial UHF
FM	Mehrfachstecker, Buchsenleiste	FM	Multipoint connector	FM	Connecteur multiple
FN	Netz-Steckverbindung	FN	AC-supply connector	FN	Connecteur secteur
FO	Runde Mehrfach-Steckverbindung	FO	Round multipoint connector	FO	Connecteur multipoles rond
FP	Druckschalt-Steckverbindung	FР	Multipoint connector for PC boards	FP	Connecteur multipoles pour cartes imprimées
FR	Fassung für Lampe, Sicherung, usw.	FR	Socket for famp, fuse, etc.	FR	Douille pour lampe, fusible etc
FT	Schwachstrom-Steckverbindung	FT	LV plug and socket	FT	Connecteur pour faible courant
FU	Hochspannungs-Steckverbindung	FU	HV plug and socket	FU	Connecteur pour haute tension
F۷	Verbinder (z.B. AMP)	F۷	Push-on connector	FV	Connecteur à enfichage
FZ	Zubehör für koax, Bauelemente	FZ	Accessories for coax, components	FZ	Accessoires pour composants coax.
Н	Software	н	Software	н	Logiciel
HP	Software-Komponenten und Software- Module	HP	Rights to software components and software modules	HP	Droits d'utilisation de composants et modules logiciel
HS	Auf Informationsträger geladene Software	HS	Software data media	нѕ	Logiciel sur support d'information
J	Meßinstrumente	J	Indicators	J	Indicateurs
JD .	Drehspul-Anzeigeinstrument	JD	Moving-coil meter	JD	Galvanomètre à cadre mobile
JE	Dreheiser-Anzeigeinstrument	JE	Moving-iron meter	JE	Galvanomètre à fer mobile
JF	Frequenzmesser	JF	Frequency meter	JF	Fréquencemètre
JG	Drehspulinstrument mit Gleichrichter	1G	Moving-coil meter with rectifier	JG	Galvanomètre à cadre mobile avec redresseur
JH	Betriebsstundenzähler	JH	Operating-hours counter	JH	Compteur d'heures de fonctionnemen
JJ	Impulszähler	JJ	Pulse counter	JJ	Compteur d'impulsions
JK	Kleinst-Instrument, z.B. Abstimmanzeiger	JK	Mini-instrument, e.g. tuning indicator	JK	Petit indicateur, p.ex. indicateur d'accord
M	Mechanisches Zählwerk	JM	Mechanical counter	JM	Compteur mécanique
)P	Projektions-Instrument (Leuchtziffer)	JP	Digital display	JP	Afficheur numérique
JQ	Ouotientenmesser (Kreuzspulinstrum.)	10	Ratiometer (cross coul)	JO	Ouotientmêtre (à cadres croisés)
JU	Uhrwerk	JU	Clockwork	JU	Mouvement d'horlogerie
W	Elektrodyn. Anzeigeinstrument	WL	Electrodynamic meter	JW	Instrument électrodynamique
L	Induktivitäten, Magnetik	L	Inductors, magnetic components	L	Composants inductifs et magnétiques
.В	Blech- und Schnittbandkern mit Zubehör	L8	Laminated and C-cores with accessories	LB	Noyaux feuilletès et noyaux de type C avec accessoires
-C	Keramische Spule	LC	Ceramic coil	LC	Bobine céramique
.D	Netz-, HF-Drossel, Df-Filter	ĻD	Choke, lead-through filter	LD	Self de choc, filtre de traversée
.E	Einzelkreis, Bandfilter	LE	Single tuned circuit, bandpass filter	LE	Circuit accordé, filtre passe-bande
.F	Ferrilkern mit Zubehör	LF	Ferrite cores with accessories	LF	Noyaux en ferrite avec accessoires
	Karbonyleisenkern und elektrischer Kupferkern mit Zubehör	LK	fron carbonyl slugs and copper slugs with accessories	LK	Noyaux en fer carbonyle et en cuivre, avec accessoires
.L	Luftspule	LL	Air-core coils	LL	Bobines à air
.M	Magnetband und -platte	LM	Magnetic tapes and disks	LM	Bandes et disques magnétiques
.s	Schirmbecher	LS	Screening cans	LS	Boitiers de blindage
.T	Netztransformator	LT	Power transformer	LT	Transformateur secteur
.U	NF-Übertrager	LU	AF transformer	LU	Transformateur BF
	Variometer	LV	Variometer	LV	Variomètre
w	Wickelkörper, allgemein	LW	Coil formers, general	LW	Carcasses de bobine, en général

Teile- familie	Art des Bauelementes	Parts lamity	Type of component	Familie	Type d'elemeni
R	Widerstände	R	Resistors	R	Résistances
RD	Drahtwiderstand	RD	Wire-wound resistor		Résistance bobinée
RF	Kohleschicht-Widerstand	RF	Carbon-film resistor	RF	Résistance à couche de carbone
RG	Metallglasur-Widerstand	RG	Metal-coated resistor	RG	Résistance à couche métaltique
RJ	Metaltoxyd-Widerstand	RJ	Metal-oxide resistor	RJ	Résistance à oxyde métatlique
RK	Kaltleiter, Heißleiter, Varistor	RK	PTC, NTC resistors, varistors	RK	Resistances CPT, CNT, varistors
RL	Metallfilm-Widerstand	RL	Metal-film resistor	RL	Résistance à film métatlique
RN	Widerstandsnetzwerk	RN	Resistor network	RN	Réseau de résistance
RR	Draht-Potentiometer	RR	Wire-wound potentiometer	RR	Potentiomètre bobiné
RS	Schicht-Potentiometer	RS	Carbon-film potentiometer	RS	Potentiomètre à couche
RT	Dämpfungsglied, Abschlußwiderstand	RT	Attenuator, termination	RT	Atténuateur, charge
RV	Drahtwiderstand mit Abgriff	RV	Wire-wound resistor, tapped	₽V	Résistance bobinée à prise
RW	Wendelpotentiometer	RW	Helicat potentiometer	RW	Potentiomètre hélicoidal
S	Schalter, Relais, Sicherungen	s	Switches, relays, fuses	S	Commutateurs, relais, fusibles
SB	Drucktastenschalter	SB	Pushbutton switch	SB	Commutateur à touche
SD	Drehschalter	SD	Rotary switch	SD	Commutateur rotatif
SF	Kontaktfedersatz	SF	Spring contact assembly	SF	Jeu de ressorts de contact
SH	HF-Koaxialschatter, •Relais, •Teiler	SH	Coaxial RF switch, RF retay, RF attenuator	SH	Commutateur RF coaxial, relais RF, atténuateur RF
SK	Kipp-, Wipp- und Schiebeschalter	SK	Toggle switch, slide switch	SK	Commutateur à bascule, à glissière
SL	Leistungsschalter Netz/HF	SL	AC supply switch, high-power RF switch	SL.	Commutateur secteur, de puissance RF
SM	Mikroschalter	SM	Microswitch	SM	Microrupteur
SN	Elektromagnet, Relais	SN	Etectromagnetic relay	SN	Relais électromagnétique
SP	Leistungsrelais, Luftschütz	SP	Power relay, air-type contactor	SP	Retais de puissance, contacteur à air
SR	Reedrelais	SR	Reed relay	SR	Relais reed
<b>S</b> S	Sicherung, Schutzschalter	SS	Fuse, automatic cut-out	SS	Fusible, coupe-circuit automatique
ST	Thermoschalter	ST	Thermal circuit breaker	ST	Disjoncteur thermique
SU	Überspannungs-Ableiter	SU	Arrester	SU	Eclateur
SW	Wechselrichter, Näherungsschalter	sw	Inverter (DC-AC), proximity switch	sw	Inverseur (DC-AC), commutateur de proximité
SZ	Zeitschatter	SZ	Time switch	SZ	Interrupteur horaire
V	Verbindungselemente	V	Connecting elements	٧	Eléments de raccordement
VK	Klemme, Klemmleiste	VΚ	Clamp, terminal strip	VK	Pince, réglette à bornes
VL	Lötóse. Stützpunkt	٧L	Soldering tug	VL	Cosse à souder
vs	Schraube, Mutter, Scheibe	vs	Screw, nut, washer	٧s	Vis, écrou, disque
Farbco	Farbcode für Widerstände und Kondensatoren Colour code for resistors and capacitors Code couleur pour resistances et condensateurs				

### Anmerkung:

Die Wertangabe der weitgehend miniaturisierten Bau-elemente erfolgt überwiegend durch Farbkennzeich-nungen, deren Bedeutung der nachfolgenden Tabelle entnommen werden kann

Hinweis: Im Zuge des technischen Fortschrittes setzt R&S zunehmend Metallschichtwiderstande mit 1% Toleranz anstelle von Kohleschichtwiderstanden mit 5% Toleranz ein. Metalischichtwiderstande konnen sich dabei an Stellen befinden, an denen gemaß Schaltteilliste Kohleschichtwiderstandevorgesehen sind. Etwaige ge-ringfugige Differenzen der Nennwerte zwischen Strom-laufpfan, Schaltteilliste und Gerat liegen im zulassigen Toleranzbereich.

Note: The electrical values of the largely miniaturized components are mainly identified by a colour code, the meaning of which can be taken from the table below.

N. B2 Following the state of the art R&S makes increasing use of metal-illm resistors (1% tolerance) instead of carbon-film resistors (5% tolerance). Metal-film resistors may have been employed where carbon-film resistors are specified in the parts list. Any slight differences of nominal values between circuit diagram, parts list and equipment are within tolerance.

### Remarque:

Les valeurs electriques des composants fort miniaturises sont indiquées dans la plupart des cas par un code couleur dont voici l'explication.

#### N. B.:

N. B:
Suwant le progres technique R&S utilise de plus en ptus
des résistances a film metaflique (tolerance 1%) au lieu
des resistances a couche de carbone (tolerance 5%). Des
resistances à film metallique peuvent se trouver en des
points où des types à couche de carbone figurent dans la
liste des composants. Les différences minimes des valeurs
nominales existant eventuellement entre le schema de
circuit, la liste des composants et l'appareit sont dans la marge de tolerance.

Farbe*Coloun*Couleur	A B C	Anordnungsbeispiele für O Examples für Exemple po	
Schwarz/Black/Noir Braun, Brown/Marron	- 0	Widerstande (R) Kondensa e 1% Resistors (R) Capaciton	Kennzeichen B. (Bautelende/2 Farbring) • 2 Zahl
Rot:Red Rouge	2 2 00	22% Resistance (R) Condensate	or (C) Kennzeichen O (Prinkt4: Farbring) + 3 Zahl + Zahl der Nullen  (Punkt4: Farbring) + Toleranz des Nennwerts in %
Orange Orange Gelo Yellow, Jaune	3 3 000	1164	(Feniendes Kennzeichen für D bedeutel (20%)  Das Fehlen eines Kennzeichens bedeutet, daß die Farbe des Bauleilkorpers die Wertangabe darstellt.
Grun/Green/Vert Blatt/Blue/Bleu	5 5 00000	20.5%	Marking A (body colour or first coloured ring) = 1st digit  Marking B (body end or second coloured ring) = 2nd digit  Marking C (got or third coloured ring) = number of zeroes
Violett/Violet Grau/Gray/Gris	7 7 -	:0.1%	Marking O [dot or tourth coloured ring] = tolerance on nominal value in % [with no D marking tolerance = 20%)
Weiß/White/Blanc Gold, Dore	9 9 _	.5%	Reperage A (couleur du corps ou 1er anneau) ± 1er chilfre Reperage B (bout du corps ou 2e anneau) ± 2e chilfre
Silber. Silver/Argente		210%	Reperage C (point ou 3e anneau) = nombre de zeros.  (point ou 3e anneau) = toierance en % de la valeur nominale (L'assence du reperage D signifie = 20%)
Ohne Farbe/No colour/ Pas de couleur		± 20%	L'absence de lout reperage signifie que la couleur du corps du composant représente la valeur correspondante
t) Oleranzring, hier nich		ce ring, here not specified de tolerance, ne pas specifie ici	* Siehe auch DIN 41 429 und DIN 40 825



## Zusammenstellung der lieferbaren Netzkabel List of power cables available Liste des câbles d'alimentation disponibles

Sach-Nr. Stock No. Réfèrence	Schutzkontaktstecker nach: Earthed-contact connector: Fiche à contact de protection:	Vorzugsweise verwendet in: Preferably used in: Utilisé de préférence en:		
DS 006.7013	8\$ 1363: 1967' 13A entspr. IEC 83: 1975 Standard 82	Großbritanien		
	8S 1363: 1967' 13A complying with IEC 83: 1975 Standard 82	Great Britain		
	BS 1363: 1967' 13A suivant CEI 83: 1975 norme B2	Grande-8retagne		
DS 006.7020	Typ 12 nach SEV-Vorschrift 1011.1059, Normblatt S 24 507	Schweiz		
	Type 12 complying with SEV regulation 1011.1059, standard sheet S 24 507	Switzerland		
	Type 12 suivant la norme SEV 1011.10S9, feuille 5 24 507	Suisse		
DS 006.7036	Typ 498/13 nach U5A-Vorschrift UL 498, bzw. IEC 83	USA / Kanada		
	Type 498/13 complying with US regulation UL 498 or with IEC 83	U5A / Canada		
	Type 498/13 suivant la norme E.U.A. UL 498 ou la norme CEI 83	E.U.A. / Canada		
DS 006.7107	Typ SAA3 10 A, 2 S0 V, nach AS C112-1964 Ap:	Australien		
	Type SAA3 10 A, 250 V, complying with A5 C112-1964 Ap.	Australia		
	Type 5AA3 10 A, 250 V, suivant AS C112-1964 Ap.	Australie		
D\$ 025.2365	DIN 49 441, 10 A, 250 V	Europa (ohne Schweiz)		
		Europe (Switzerland not included)		
		Europe (Suisse non comprise)		

#### **Cross-Reference List of Class Designation Letters**

IEC Publication 113-2 (1971) Item Designations, Letter Codes ANSI Y32.2-1975 (IEEE Std 315-1975), Section 22, Class Designation Letters

Note: The designation letters used in the R&S Manuals correspond to the letter codes of the IEC Standard identified in the first column!

IEC Publication 113-2 Terminology	Lette: !EC	Code Y32.2	IEC Publication 113-2 Terminology	Lette: IEC	Code Y32.2
Acoustical indicator	н	LS	Magnetictape recorder	D	A
Adjustable resistor	R	R	Maser	A	Α.
Aerial	W	£	Measuring equipment	?	M
Amplifier	-A	AR.	Microphone	8	MK
Amplifier (with tubes)	A	AR	Miscellaneous	<u> </u>	E
Arrester	F	£	Modulator	ū	A
Assemblies	Α	U,A	Monostable element	D	A,U
Auxiliary switch	\$	\$	Motor	M	8
lattery	G	BT	Optical indicator	H	DS
sistable element	D	U,A	Oscillator	G	Y,G
Brake	Y	MP	Overvoitage discharge device	F	F,E
Busbar	W	W	Parabolicaerial	W	E V
Cable	W	W	Photoelectric cell	В	PU
Cable balancing network	Z	2	Pickup	8	P
Capacitor	C	C	Plug	X	
Changer	U	A,B,G,MT	Pneumatic valve	Y	MP
Circuit breaker	Q	C8	Potentiometer	R	R CP s
Clutch	Y	MP	Power switchgear	Q	CB,S
Coder	U	U,A	Protective device	F	F 5
Compander	Z	A	Pushbutton	Ş	-
Connecting stage	\$	\$	Quartz-oscillator	Ğ	Y
Contactors	K	K	Recording device	٩.	A,M
Control switch	\$	\$	Register	D	M,U,A
Converter	U	A,U,MG	Relay	K	K
Core, storage	D	£	Resistor	R	R
Crystal filter	Z	FL	Resolver	В	В
Crystal transducer	8	Y	Rheostat	R	R
Current transformer	Ť	Ť	Rotating frequency generator	G	G.MG
Delay device	D	DL	Rotating generator	Ğ	ē
Delay line	D	DL	Selector	S	S
Demodulator	U	A	Selector switch	S	S
Dial contact	S	\$	Semiconductor	V	D,CR,Q
Diode	V	D	Shunt (resistor)	R	R
Dipoie	W	E	Signal generator	P	A
Disconnecting plug	X	P	Signaling device	H	DS
Disconnecting socket	X	X	Socket	X	X T0
Discriminator	U	A	Soldering terminal strip	X	E,TB
Disk recoroer	D	A	Static frequency changer	Ü	Α
Dynamotor	В	MG	Storage oevice	Þ	A.U
Electrically operated mechanical device .	Y	MT	Subassembly	A	A DE
Electronic tube	V	V	Supply	G	A.PS
Equalizer	Z	EQ	Supply device	G	A.PS
Filter	Z	FL	Synchro	8	В
Frequency changer	U	A,B,G	Telegraph translator	Û	A
Fuse	F	F	Terminal	x	E
Gas discharge tube	V	V	Terminal board	X	TB AT
Generator	G	G_	Termination	z	AT c 1
Heating device	£	HR	Test jack	X P	E.J A
Hybrio	Z	Z	Testing equipment		RT
indicating device	P	DS	Thermistor	R	A.TC
Induction coil	L	L	Thermo cell	B B	A
inductors	L	L	Thermoelectric sensor	V	
integrating measuring device	. Р	M.MT,Z	Thyristor	v	Q
inverter	U	A,U,PS,MG	Transducer (nonelectrical quantity	D.	A DT
Isolator	Q	ΑT	_ to electrical quantity)	В	A.BT T
Jumper wire	W	W	Transformer	T W	w
Laser	A	MT,A	Transmission path		
Lighting device	Ε	DS	Transistor	V	Q V
Limit switch	\$	\$	Tube (electron)	Ť	Ť
Limiter	Ζ.	MT.RE	Voltage transformer (potential)		w
Line trao	L	FL.MP,V	Waveguine	W	DC
Loudspeaker	В	LS	Waveguioe oirectional couoler	4.8	50
Magnetic amplifier	. A	AR			



Schaltteillisten
numerisch geordnet
Part lists
in numerical order
Listes des pièces détachées
par numéros de référence

Für diese Unterlage beheiten wir uns alle Rechte vor.

Kennz. Comp. No.	Benennung Designation	Sachnummer Stock No.	Hersteller Menufacturer	Bezeichnung Designation		haiten in tained in
•	XX VARIANTENERKLAERUNG IDENTIFICATION DF MODELS VAR 11 = SMYO1 1GHZ MOD. MOD 11 = SMYO1 1GHZ MOD.					
	VAR 12 = SMYO2 1GHZ MDD.   MOD 12 = SMYO2 1GHZ MOD					
	VAR 41 = SMY41 1GHZ UK					
	MOD 41 = SMY41 1GHZ UK VAR 43 = SMY43					
	MOD 43 = SMY43 VAR 44 = SMY44 1GHZUPGRAD					
	MDD 44 = SMY44 1GHZUPGRAD VAR 45 = SMY45 2GHZUK					
	MOD 45 = SMY45 2GHZUK XX ZUGEH.STROML.					
	CIRC.DIAGR. 1062.55D2 S					
A1	ED TASTATUR/ANZEIGE	1062.6809.02				
	KEY8DARD/DISPLAY HIERZU STROML. 1062.6809S				-	
A2	SEE CIRC.DIAGD.1062.6809S	1002 0002 00				
AZ	ED PROCESSOR PROCESSOR	1062.6309.02				
	NUR VAR/ONLY MOD: 11 12 43 HIERZU STRDML. 1062.6309S					
A2	SEE CIRC.DIAGR.1062.6309S   ED PROZESSOR	1062.6309.04				
A3	NUR VAR/ONLY MDD: 41 44 45 ED MOTHERBOARD	1062.6009.02	Auch Lar	neuc		
1	MOTHER8OARO HIERZU STROML. 1062.6009S		Gerate	nene neaer AEZ		
A4	SEE CIRC.DIAGR. 1062.6009S EE SYNTHESIZER	1062 6400 00				
^~	SYNTHESIZER	1062.6409.02				
	NUR VAR/ONLY MOD: 11 12 HIERZU STROML. 1062.6409S					
Α4	SEE CIRC. DIAGR. 1062.6409S   EE SYNTHESIZER	1062.6409.04				
	NUR VAR/ONLY MOD: 41 44 45 HIERZU STROML. 1062.6409S					
A4	SEE CIRC.DIAGR. 1062.6409S EE SYNTHESIZER	1062.6409.43				
	SYNTHESIZER NUR VAR/ONLY MOO: 43	.002.0.00				
- [	HIERZU STROML. 1062.6409S				1	
A5	SEE CIRC.DIAGR.1062.6409S EE AUSGANGSTEIL 1.046GHZ	1062.6209.02				
	OUTPUT STAGE 1,0 GHZ NUR VAR/ONLY MOD: 11					
	HIERZU STROML. 1062.6209S SEE CIRC.DIAGR.1062.6209S					
A5	EE AUSGANGSTEIL 1.046GHZ NUR VAR/ONLY MOD: 41	1062.6209.04				
	HIERZU STROML. 1062.6209S SEE CIRC.DIAGR.1062.6209S					
A5	EE AUSGANGSTEIL 2.08GHZ OUTPUT UNIT 2.08GHZ	1062.7005.02				:
	NUR VAR/DNLY MDD: 12 43 HIERZU STROML.1062.7005 S					
, E	SEE CIRC.DIAG.1062.7005 S	1000 7007 00				
A5	NUR VAR/DNLY MOD: 44 45	1062.7005.04				
_	HIERZU STROML. 1062.7005S SEE CIRC.DIAG. 1062.7005S					ı
A6	ZE EICHLEITUNG (SMX) ATTENUATDR (SMX)	0826.5065.02				j
A6	NUR VAR/ONLY MDD: 11 ZE EICHLEITUNG (SMY)	0826.5065.04				
A6	NUR VAR/DNLY MDD: 41 ZE EICHLEITUNG (SMG/SMH)	0801.1108.02				
A6	NUR VAR/DNLY MDD: 12 43 ZE EICHLEITUNG (SMY)	0801.1108.04				
A7	NUR VAR/ONLY MOD: 44 45 ZE NETZTEIL, EINHEIT	1062.5690.02				
	PDWER SUPPLY HIERZU STROML. 1062.569DS	.002.000.02				
MENP5	413 3PUA ĀI Datum	Schalttellils		Sachnummer	<u> </u>	Blatt-Nr.
Δ	D358	Parts list	IOI	Stock No.		Page
<b>₩</b> ROHDE	E&SCHWARZ   11   16.09.97	GG SMY SIGNA	AL GENERAT.	1062.5502.0	1 SA	1+

Ħ	VOF.
bah	-
88	Rechte
BCI	Rec
Len	alle
ā	
diese	uns
ē	Wir
ž	>

	Kennz. Comp. No.	Banann Designa			Sachnummer Stock No.	Hersteller Manufacturer	Bezeichnung Dasignation		raitan in tainad in
	A 13	SEE CIRC.DIAGR ED ALC-BOARD ALC-BOARD	R. 10625690	S	1062.9920.02				
		NUR VAR/ONLY N	10D: 41 44	45					
	W 1	DW KABEL W1 CABLE W1			1062.6538.00	smyon		1062.	6521.00
	W1	DW KABEL W1			1062.6596.00	SMY02		1062.0	65BO.00
ı	W2	DY KABEL W2			1062.6644.00			1062.0	6621.00
	W4	CABLE W2 DY KABEL W4			1062.6650.00			1062.0	6621.00
	W20	CABLE W4 DY KABEL W20			1062.6667.00			1062.6	6621.00
	W24	CABLE W2O DV KABEL CABLE			1062.6544.0D			1062.6	5509.00
	W25	DV KABEL CABLE			1062.6544.00			1062.6	509.00
	W26	DW KABEL W26			1062.6567.00	2401		1062.6	5521.00
	W26	DW KABEL W26 CABLE W26			1062.6609.00	514902		1062.6	5BO.00
	W27	DV KABEL W27 CABLE W27			1062.6573.00			1062.6	509.00
	W131	DV HF-KABEL-W1: NUR VAR/ONLY M		45	1063.0027.00				
ı	W132	DV HF-KABEL NUR VAR/ONLY M		ĺ	1063.0033.00	İ			
	W133	DV HF-KABEL WIS NUR VAR/ONLY MI	33		1D63.0040.00				
	X101	FJ EINBAUBUCHSE BNC-CONNECTOR UNIT VAR/ONLY ME	JG 625CIU		0099.9186.00	ROSENBERGE	51K-503-200-N4		
	X102	FJ EINBAUBUCHSE BNC-CONNECTOR I	E SYST.BNO		0099.9186.00	ROSENBERGE	51K-503-200-N4		
	X103	FJ EINBAUBUCHSE BNC-CONNECTOR L	E SYST.BNO	F.	0099.9186.00	ROSENBERGE	51K-503-200-N4		
	X104	FJ EINBAUBUCHSI BNC-CONNECTOR I NUR VAR/ONLY MO	E SYST.BNO UG 625CIU	11	0099.91B6.00	ROSENBERGE	51K-503-200-N4		
	X105	FJ EINBAUBUCHSE BNC-CONNECTOR (	E SYST.BNO	F	0099.9186.00	ROSENBERGE	51K-503-200-N4		
	X133	FJ EINLOETBUCHS CONNECTOR NUR VAR/ONLY MO	SE MMCX SI	1	1075.4045.00	SUHNER	90MMCX-S50-0-51/1190		
	MENP5	413 3PUA	Äl Datum Date	97	Schalttellli Perts lis GG SMY SIGN	1 for	Sachnummer Stock No. 1062.5502.01	SA	Biatt-Nr. Page 2-

shalton	VOF.
nlage bol	Rechte
<b>Unte</b> ,	alla
dlesa	r uns
à	3

	Kennz. Comp. No.	Banannung Dasignation		Sachnummar Stock No.	Hersteller Menufecturer	Bazaichnung Dasignation	enthelten contained	
	•	XX VARIANTENERKLA IDENTIFICATION OF VARO2=GRUNDAUSFUE MODO2=BASIC_MODEL	MDDEL5 EHRUNG					
	wз	DY KABEL W3		1062.6080.00			1062.6067	.00
	W21	CABLE W3 DY KABEL W21		1062.6096.00		í	1062.6067	.00
	W77	CABLE W21 DY KABEL W77 CABLE W77		1062.6109.00			1062.6067	.00
	X1	FP BUCH5ENLEI5TE CDNNECTOR 32PDL.	32PDL.	FP 000B.5676.00	SIEMENS V4	2254-B2201-B611		
	X2	FP BUCHSENLEISTE CONNECTOR 32POL.	32POL.	FP 0008.5676.00	SIEMENS V4	2254-82201-8611		
	X4	FP STECKERLEISTE	10P.GER	0846.4593.00	SIEMENS V2	3535-A2200-A102		
	X20	FP STECKERLEISTE	10P.GER	0846.4593.00	SIEMENS V2	3535-A2200-A102		
	хзз	FP 5TIFTL.WIN 3P		FP 0009.7195.00				ı
	X125	FJ EINLOETBUCHSE CONNECTOR		1075.4045.00	SUHNER 90	MMCX-S50-0-51/1190		
	X133	FJ EINLOETBUCHSE CDNNECTDR NICHT BESTUECKT/N	OT FITTED	1075.4045.00	5UHNER 90	MMCX-S50-0-51/1190		
	X231	ENTHALTEN IN SMY- 1062.9920.02 FP STECKERLEISTE CONNECTOR NICHT BESTUECKT NOT FITTED		FP 0738.5335.00	51EMEN5 V2	3535-A2210-A102		
ļ	MENP5	413 3PUA äi	Datum Data	Schalttellii Parts lis		Sachnummer Stock No.		t-Nr.
	ROHDI	E&SCHWARZ 01	16.09.97	ED MOTHERBOARD		1062.6009.01		1-

ED MOTHERBOARD
MOTHERBDARD



## XY-Liste

## **XY List**

#### Erklärung der Spaltenbezeichnungen:

Part: Bauelement-Kennzeichen.

Side: ... Leiterplatten-Seite, auf der sich das Bauelement befindet.

XY: Koordinaten (Millimeter) des Bauelementes auf der Leiterplatte

bezogen auf den Nullpunkt.

SQR, PG: Planquadrat und Seite des Schaltbildes für das jeweilige Bauelement.

#### Explanation of column designations:

Part: Identification of instrument part.

Side: Side of the PC board on which instrument part is positioned.

X/Y: Coordinates (millimeter) of the component on the PC board in reference

to zero point.

SQR, PG: Square and page of the diagram for the respective instrument part.


Part	Side	X				Part				_	_	•				_
W3	в	113		4D		X2						X125			90	
W21	В	114	27	7D	1	X4	В	137	13	2A	1	X133	В	44	26	1B
W77	В	17	51	2D	1	X20	В	23	23	1D	1	X231	В	15	13	3D
X1	В	38	41	3C	1	X33	В	41	26	1C	1					


.


ROHDE	ĀI	Datum  Date	XY-Liste für   Sach-Nummer XY-list for   Stock-Nr	++  Blatt   Page
SCHWARZ		02.07.97	ED MOTHERBOARD   1062.6009.01 XY	1-





Stromläufe
Bestückungspläne
Circuit diagrams
Components plans
Schémas de circuit
Plans des composants










































nsert the braided cord (provided only for instruments requiring a nigh degree of shielding) into the respective groove.



side strips,

battám

top

The braided cords in the front of front frame and rear of rear frame must be fixed by glued joints approx. every 80 mm. Make joints (ø approx. 2 mm) on the bottom of the groove and press braided cord firmly on it.

Use a permanently elastic adhesive, such as Si-rubber 3145 RTV (R&S Part No. WV 088.3152).

Instruments with separate rear panels require the individual components to be adjusted to the same level over the complete instrument width.

Top and bottom cover must be fastened by way of the catches on rear frame.

Note that with high rear panel feet (CMS) the catches are concealed, here tighten the rear feet screws only after the top and bottom cover have been securely fitted into the catches.

# Öffnen und Schließen des Gehäuses

Die gute Schirmdämpfung der Kompaktbauweise 90 erfordert häufige Kontaktstellen und hohe Paßgenauigkeit. In Verbindung mit einem leichten Anlagedruck, der mit dem Festziehen der Rückwandfußschrauben erreicht wird, erhält man einen straffen Sitz der Ober- und Unterhaube auf dem Rahmen.

Zum Öffnen muß man die Rückwandfußverschraubung lösen und die Füße nach rückwärts abziehen (Schrauben bleiben im Fuß haften). Je nach Bedarf läßt sich nun Ober- bzw. Unterhaube ebenfalls nach rückwärts abnehmen. Sitzen die Hauben sehr fest, erleichtert man das Abziehen durch abwechselndes Hebeln in Pfeilrichtung mit einem Schraubenzieher an beiden Geräteseiten (siehe Bild).


Zum Schließen des Gehäuses werden erst die Frontkanten der Hauben in die umlaufende Nut des Frontrahmens und der Seitenleisten eingeführt und dann in die Erhöhungen am Rückrahmen bis Anschlag eingerastet. Das Gerät ist wieder geschlossen, wenn die Rückwandfüße eingeschoben und die Schrauben festgezogen sind.

# Opening and closing the cabinet

To obtain the high degree of shielding of design 90, many points of contact and accurate fitting are employed. When exerting a slight pressure by tightening the rear-panel feet, tight fitting of the top and bottom covers is ensured.

To open the cabinet, first undo the rear panel feet screws and withdraw the feet (captive screws). It is now possible to detach top and bottom cover if required. If the fitting of these cover plates is very tight, removal can be facilitated by alternately levering on both sides of the instrument using a screwdriver (see illustration).

To close the cabinet, insert the front edges of the covers into the groove of the front frame and the side strips and lock them into the catches on the rear frame into detent position. The cabinet is closed when the rear-panel feet are inserted and the screws tightened.




# ing


### struction

onstruction consists of a selfrting aluminium-cast frame front, mounting and rear top and bottom covers nelling).

and panelling:



Dichtschnur (nur bei Geräten mit erhöhtem Schirmdampfungsbedarf vorhanden) jeweils in die umlaufende Nut einlegen. Insert the braided cord (provided only for instruments requiring a high degree of shielding) into the respective groove.



Die Dichtschnüre in der Frontrahmen-Frontseite und in der Rückrahmen-Rückseite müssen durch Klebepunkte in Abständen von ca. 80 mm fixiert werden. Dazu Klebepunkte mit ca. ø2 mm im Nutgrund anbringen und Dichtschnur aufdrücken.

Dauerhaft elastischen Kleber wie z.B. Si-Kautschuk 3145 RTV (R&S-Sachnr. WV 088.3152) verwenden.

Bei Geräten mit geteilten Rückplatten müssen beim Zusammenbau die Einzelelemente über die gesamte Gehäusebreite waagerecht zueinander ausgerichtet werden.

Ober- und Unterhaube müssen mit den Erhöhungen am Rückrahmen fixiert sein.

Achtung: bei hohen Rückwandfüßen (CMS) werden die Fixier-Erhöhungen verdeckt, hier Rückwandfüße erst anschrauben, wenn die Ober- u. Unterkante sicher in den Erhöhungen am Rückrahmen fixiert sind. The braided cords in the front of front frame and rear of rear frame must be fixed by glued joints approx. every 80 mm. Make joints (ø approx. 2 mm) on the bottom of the groove and press braided cord firmly on it.

Use a permanently elastic adhesive, such as Si-rubber 3145 RTV (R&S Part No. WV 088.3152).

Instruments with separate rear panels require the individual components to be adjusted to the same level over the complete instrument width.

Top and bottom cover must be fastened by way of the catches on rear frame.

Note that with high rear panel feet (CMS) the catches are concealed; here tighten the rear feet screws only after the top and bottom cover have been securely fitted into the catches.

# Öffnen u des Gehäu

Die gute So Kompaktbauv häufige Kont Paßgenauigke mit einem le der mit dem i wandfußschra erhält man ei Ober- und Un Rahmen.

Zum Öffnen a wandfußversch die Füße nach (Schrauben haften). Je na nun Ober- bzw falls nach rü Sitzen die Ha leichtert man abwechselnde richtung mit zieher an b (siehe Bild).

Zum Schließ werden erst of Hauben in die Frontrahmens leisten eingeführen Anschlag eing wieder gesch Rückwandfüßdie Schrauben

Nut i Groo

Schlitzschraub Kreuzschlitzsc oder 2 in Nut i

Screwdriver size Phillips screwd in groove in to

# Gehäuse

# .

# Aufbau

Der Aufbau besteht aus einer tragenden Aluminium-Druckguß-Rahmenkonstruktion mit gerätespezifischer Front-, Montage- und Rückplatte, die mit einer Oberund Unterhaube (= Beplankung) ummantelt ist.


# Casing

#### Construction


The construction consists of a self-supporting aluminium-cast frame with front, mounting and rear panel, top and bottom covers (=panelling).

Rahmen und 8eplankung:

Frame and panelling:



Dichtschnur (nur bei Geräten mit erhöhtem Schirmdämpfungsbedarf vorhanden) jeweils in die umlaufende Nut einlegen.



Rear of fro frame and side strips,

Die Dichtschnüre in der Frontrahmen-Frontseite und in der Rückrahmen-Rückseite müssen durch Klebepunkte in Abständen von ca. 80 mm fixiert werden. Dazu Klebepunkte mit ca. Ø2 mm im Nutgrund anbringen und Dichtschnur aufdrücken.

Dauerhaft elastischen Kleber wie z.8. Si-Kautschuk 314S RTV (R&S-Sachnr. WV 088.31S2) verwenden.

Bei Geräten mit geteilten Rückplatten müssen beim Zusammenbau die Einzeleiemente über die gesamte Gehäusebreite waagerecht zueinander ausgerichtet werden.

Ober- und Unterhaube müssen mit den Erhöhungen am Rückrahmen fixiert sein.

Achtung: bei hohen Rückwandfüßen (CMS) werden die Fixier-Erhöhungen verdeckt, hier Rückwandfüße erst anschrauben, wenn die Ober- u. Unterkante sicher in den Erhöhungen am Rückrahmen fixiert sind.



SERVICEUNTERLAGEN RECHNER 1062.6309.01

# Inhaltsverzeichnis

7 Prü	ifen und Instandsetzen der Baugruppe !	5
7.1	Funktionsbeschreibung         7.1.2 Prozessorteil       5         7.1.2.1 CPU mit Peripherie       5         7.1.2.2 Tastaturmatrix       5         7.1.2.3 IEC-Interface       5         7.1.3 Analogteil       5         7.1.3.1 NF-Synthesizer       6         7.1.3.2 AM-Modulationszweig       6	5 5 5 6
7.2	Meßgeräte und Hilfsmittel6	5
7.3	Fehlersuche6	5
7.4	Prüfen und Abgleich 7	,
	7.4.1 Prüfen der Stromversorgung	
	7.4.13 Prüfung der Umschaltung des AM-Ausgangs 9 7.4.14 Prüfen des Spannungskomparators für AM-EXT 9	
7.5	Zerlegung und Zusammenbau	
7.6	Externe Schnittstellen 10	

Schaltteilliste Koordinatenliste Stromlauf Bestückungsplan

#### 7.1 Funktionsbeschreibung

Die Schaltung der Baugruppe Rechner gliedert sich in einen Prozessor- und einen Analogteil.

#### 7.1.2 Prozessorteil

#### CPU mit Peripherie

Der Prozessor ist die Steuereinheit für das gesamte Gerät. Der Kernbaustein ist die CPU N80C196 (D10) mit den Programmspeicher EPROM D206, EEPROM D125 und den batteriegepufferten RAM D210. Die beiden je 8-Bit Ports P3 und P4 der CPU stellen den Adress-/Datenbus dar. PAL D110 wird als Ausgabeport für den Strobe verwendet. Analoge Spannungen im Bereich OV...±5V (X3.6) werden dem internen A/D-Wandler der CPU über Port P0.0 zugeführt. Die abgleichbare 5.12V Referenzspannung des D/A-Wandlers wird mit der Spannungsreferenz REF02 (D107) erzeugt.

Am Eingabeport P1 werden die logischen Zustände der Interrupt-Leitungen erkannt. P1.3 dient zum Erkennen der Option Referenzoszillator. Bei Netzspannungseinbrüchen, Netzausfällen sowie bei Einbzw. Ausschalten des Gerätes liefert die Reset-Schaltung D100 ein definiertes Reset-Signal für die CPU. Weitere Adreßsignale für RAM, EPROM, EEPROM und IEC-Bus werden mit PAL D110 dekodiert.

#### Tastaturmatrix

Von der Tastaturmatrix der Anzeige-Tastatur-Baugruppe gelangen 8 Spalten- und 5 Zeilenleitungen (COLO...COL7, ROW1...ROW5) auf die Baugruppe. Ist keine Taste gedrückt, so liegen ROW1...ROW5 uf HIGH-Potential. COLO...COL7 werden durch D303 auf LOW gehalten.

Ein Tastendruck verbindet nun eine Zeilen- mit einer Spaltenleitung, wodurch die Zeilenleitung auf LOW gesetzt wird. Der entsprechende Kondensator wird dabei entladen. Über D302 wird verzögert mit D305 wegen Tastenprellens, ein Interrupt (KEYINT) erzeugt. Beim Auslesen des Tastencodes wird D303 hochohmig, so daß alle Spaltenleitungen, welche nicht über die geschlossene Taste verbunden sind, schnell HIGH-Potential annehmen. Der entladene Kondensator stellt nun sicher, daß die entsprechende Spaltenleitung während der Zugriffszeit auf LOW gehalten wird.

#### 7.1.2.3 IEC-Interface

Das IEC-Bus-Interface, bestehend aus dem integrierten IEC-Bus Baustein D250 und den beiden Bausteinen D260, D255 implementiert die nach IEEE-Standard 488-1978 definierte Schnittstelle. Das Handshake bei einem Datentransfer wickelt der Baustein selbstständig ab. Der bei einer Statusänderung generierte Interrupt gelangt an den HAI 0 Pin der CPU.

#### 7.1.3 Analogteil

Der Analogteil der Baugruppe Rechner stellt die für den AM- und FM-Betrieb benötigten Modulationsignale bereit. Er besteht aus einem NF-Synthesizer und dem AM-Modulationszweig.

#### NF-Synthesizer

Mit direkter digitaler Synthese wird die Ausgangsfrequenz des Modulationsgenerators erzeugt.

Das Kernstück des Synthesizers ist der DDS-Baustein D420 der einen 32-Bit-Addierer, zwei 32-Bit-Inkrementspeicher, Sinus-ROM und eine Schnittstelle für die serielle Datenübertragung enthält. Im Addierer wird ein Inkrement zyklisch mit einer Taktfrequenz von 2.147484 MHz aufaddiert. Der Takt kommt von dem Quarzoszillator B401. Die höhenwertigen 13-Bit der Summe steuern die Adressen des Sinus-ROM. In diesem sind die Amplitudenwerte einer Periode der Sinusschwingung gespeichert.

Die höhenwertigen 12-Bit der Amplitudenwerte einer Sinusschwingung gelangen an einen D/A-Wandler der ein treppenförmiges Signal liefert. Die zwei 6-Bit D-Register (D430 und D440) unterdrücken die verschiedenen Laufzeiten aus dem Sinus-ROM des DDS-Bausteines. Ein Sample & Hold Schalter unterdrückt die Einschwingvorgänge des D/A-Wandlers. Ein nachgeschaltete 600kHz Tiefpaß sorgt für ausreichende Unterdrückung der Taktfrequenz. Die SinX/X Kompensation ist durch R491 und C490 realisiert.

#### AM-Modulationszweig

Mit dem Analogschalter D500, D510 und D550 wird die Auswahl des AM-Signals zwischen intern und extern getroffen. Der dem Eingang parallel geschaltete Fensterdiskriminator (N544) überwacht die Amplitude des externen Modulationssignals und liefert bei Unteroder Überschreitung dem Prozessor D10 das AMKOMLO- oder AMKOMHI-Signal.

#### 7.2 Meßgeräte und Hilfsmittel

- Digitalmultimeter (z.B. R&S UDS5)
- DC-Spannungsquelle (z.B. R&S NGT)
- Audio Analyzer (z.B. R&S UPA)
- Frequenzgenerator (z.B. R&S SPN)
- RMS-Voltmeter (z.B. R&S URE3)
- Spektrum-Analyzer (z.B. R&S FSA)
- Oszilloskop
- Frequenzzähler

#### 7.3 Fehlersuche

Kein Signal an LFOUT (X3.23) Taktgenerator an X401 prüfen

Signal an P405 prüfen

S&H-Schaltung an P409 prüfen

Tiefpaßfilter und Verstärker N520

an P530 prüfen

AM-INT an AMMOD (X3.34) Schalter D510 und D550 sowie

fehlerhaft Verstärker N530 prüfen

AM-EXT an AMMOD (X3.34) Schalter D500 und D550 und

fehlerhaft Verstärker N530 prüfen

#### 7.4 Prüfen und Abgleich

Alle Meßwerte ohne Toleranzangabe sind als Richtwerte zu verstehen. Spannungen ohne weitere Bezeichnungen bedeuten DC-Spannungen.

#### 7.4.1 Prüfen der Stromversorgung

- Ein Amperemeter in die Versorgungsleitungen der einzelnen Versorgungsspannungen einschleifen.
- \_ Die Stromaufnahme der Baugruppe überprüfen. Die Sollwerte zu den jeweiligen Versorgungsspannungen sind unter "Externe Schnittstellen" zu finden.

### 7.4.2 Einstellen der Power Fail Schwelle

- Die Netzspannung so einstellen, daß an X3.13 (U5VC) 7.1v ±0.1v anliegen.
- \_ R139 so einstellen, daß an D100.10 gerade ein Wechsel des Logikpegels (H zu L bzw. L zu H) stattfindet.

# 7.4.3 Einstellen der Referenzspannung

\_ Mit R102 DC-Spannung an Meßpunkt P101 auf +5.12V ±lmV einstellen.

### 7.4.4 Abgleich des AM-EXT Spannungskomparators

\_ Mit dem Pot R550 am Meßpunkt P513 eine Spannung von -1.02V ±lmV einstellen.

#### 7.4.5 Pegel INT1 Abgleich

- · Einstellung: 1kHz
- · Kalibriertes AC-Voltmeter an INT1 (X3.32) anschließen.
- \_ Mit R450 Ausgangsamplitude am AC-Voltmeter auf 0.7071Veff abgleichen.

#### 7.4.6 INT1 DC-Offset 0V-Abgleich

- Einstellung: AF 1kHz
- DC-Voltmeter an INT1 (X3.32) anschließen.
- \_ Mit R520 DC-Offset auf Minimum abgleichen.

#### 7.4.7 Test der Diagnoseeingänge

- An Meßpunkt Pl00 ein DC-Voltmeter anschließen.
- Einstellung: SPEC 109

SPEC 40 (GAIN16 D105.5 LOW).

- \_ Die gemessene Spannung muß +2.56V ±20mV betragen.
- Einstellung: SPEC 39 (GAIN16 D105.5 HIGH).
- \_ Die gemessene Spannung muß +2.56V ±50mV betragen.

• Einstellung: RF 1GHz

SPEC 40 (GAIN16 D105.5 LOW).

**SPEC 115** 

- \_ Die Spannung an X3.6 messen.
- \_ Die Spannung an P100 muß +2.56V minus die halbe Spannung an X3.6 ±20mV betragen.
- Einstellung: SPEC 39 (GAIN16 Dl05.5 HIGH).
- \_ Die Spannung an X3.6 messen.
- \_ Die Spannung an P100 muß +2.56V minus sechzehn mal die halbe Spannung an X3.6 ±100mV betragen.

#### 7.4.8 Prüfen des Tastatur-Interrupt

- Ein Oszilloskop an P305 anschließen. Eine beliebige Taste drücken.
- \_ Am Osziloskop muß ein LOW-Puls mit ca. 2.5ms Pulsdauer meßbar sein.

### 7.4.9 Prüfen der RAM-Pufferspannung

- \_ Batteriespannung direkt an den Batterieanschlüssen messen.
- Versorgungsspannungen abschalten.
- \_ An D210.28 soll die gemessene Batteriespannung (Tol. -10mV) anliegen.

### 7.4.10 Prüfen der Frequenzgenauigkeit

- Einstellung: AF 100kHz
- Kalibrierten Frequenzzähler an AF INT anschließen.
- \_ Frequenz messen. Max. Fehler ±10Hz.

#### 7.4.11 Pegelgenauigkeit prüfen

#### 7.4.11.1 Frequenzgang

- Einstellung: AF zwischen 10Hz...500kHz variieren.
- Kalibriertes AC-Voltmeter an AF INT anschließen.
- Pegel messen und mit der Tabelle vergleichen. Frequenzgang von 10Hz

bis 50kHz <0.2dB bis 100kHz <0.3dB bis 500kHz <0.5dB

#### 7.4.11.2 Einstellfehler

- Einstellung: AF 1kHz
  - AM INT EIN
- Kalibriertes AC-Voltmeter an AF INT, INT1 (X3.32) und AMMOD (X3.34) Ausgänge anschließen.

\_ Ausgangssignale prüfen.

AF INT 0.7071Veff

INT1 0.7071Veff(X3.32)

AMMOD 0.7071Veff(X3.34) Max. Fehler ±1%

#### 7.4.11.3 INT1 DC-Offset

- DC-Voltmeter an INT1 (X3.32) anschließen.
- \_ DC-Spannung muß <±5mV sein.

#### 7.4.12 Prüfen der spektralen Reinheit

#### 7.4.12.1 Klirrfaktor prüfen

- Einstellung: AF zwischen 20 Hz und 100 kHz variieren.
- Klirrfaktormesser an AFOUT anschließen.
- \_ Klirrfaktor bei verschiedenen Frequenzen messen. Klirrfaktor muß <0.1% sein.</p>

#### 7.4.12.2 Harmonische und Nichtharmonische Störsignale prüfen

- Einstellung: AF zwischen 100kHz und 500kHz variieren.
- Spektrum-Analyzer an AFOUT (Ri =  $1M\Omega$ ) anschließen.
- \_ Oberwellen und Nebenwellenabstand muß < -40dBc sein.

#### 7.4.13 Prüfung der Umschaltung des AM-Ausgangs

- Einstellung: AF 10kHz
  AM INT ON
- Oszilloskop an AMMOD (X3.34) anschließen.
- \_ Am Oszilloskop muß ein 10 kHz Sinussignal zu sehe sein.
- Einstellung: AM EXT AC
- Kurzschlußbrücke X501 zwischen X501.1 und X501.2
- NF-Generator an AM EXT anschließen.
- Einstellung NF-Generator: Frequenz 1kHz

Spannung 0.7071Veff

\_ AMMOD (X3.34) Signal prüfen. Es soll 0.7071Veff anstehen.
Max. Fehler ±1%

#### 7.4.14 Prüfen des Spannungskomparators für AM-EXT

- Einstellung: AM EXT DC ON
- NF-Generator an AM EXT anschließen.
- Einstellung NF-Generator: Frequenz 1kHz

Spannung 0.7071Veff

- \_ Die beiden Ausgänge D545.13 und D545.12 müssen LOW sein.
- · Pegel auf 0.735Veff erhöhen.
- \_ Ausgangspegel an D545.13 muß HIGH sein.
- · Pegel auf 0.680Veff einstellen.
- \_ Pegel an D545.12 muß HIGH sein.

#### 7.5

#### Zerlegung und Zusammenbau

Nach Öffnen des Gerätes und Lösen der Schrauben kann die Baugruppe aus ihrem Steckplatz entnommen werden. Nach dem Lösen der Schrauben der Schirmdeckel ist die Baugruppe an beiden Seiten zugänglich.

Der Einbau der Baugruppe und Zusammenbau des Gerätes erfolgt entsprechend in umgekehrter Reihenfolge.

7.6 Externe Schnittstellen

Pin	Name	Ein/Ausgang 🖔	Herkunft/2	iel	Wertebereich	Signalbeschreibung
x1.1	VAS-P	husgang	A1 FRONT	X1.1	+4.9V+5.3V	+5V Versorgungsspannung
					max.340mA	
X1.2	SERCLK	Ausgang	Al FRONT	X1.2	HCHOS-Pegel	Seriell-Clock
X1.3	VA5-P	Ausgang	Al Pront	X1.3	+4.97+5.37	+5V Versorgungsspannung
					max.340mA	
X1.4	SERDATA	Ausgang	Al FRONT	X1.4	HCMOS-Pegel	Seriell-Data
X1.6	DIS1STB#	Ausgang	Al FRONT	X1.6	HCMOS-Pegel	Display Strobe 1
X1.8	DIS2STB#	Ausgang	Al PRONT	X1.8	HCMOS-Pege1	Display Strobe 2
X1,10	LEDSTB	ynsgang	Al FRONT	X1.10	HCMOS-Pegel	LED-Strobe
X1.11	COL7	Eingang	Al FRONT	X1.11	HCMOS-Pegel	Tasten-Code
X1.12	C/D#	Ausgang	Al PRONT	X1.12	HCHOS-Pegel	
X1.13	COLE	Eingang	AL FRONT	X1.13	HCMOS-Pegel	Tasten-Code
X1.14	DISBUSY	Eingang	Al FRONT	X1.14	HCMOS-Pegel	Steuerleitung
X1.15	COLS	Eingang	Al FRONT	X1.15	HCMOS-Pegel	Tasten-Code
X1,16	RES#	Ausgang	Al PRONT	X1.16	HCHOS-Pegel	Reset
X1.17	COL4	Eingang	Al FRONT	X1.17	HCMOS-Pegel	Tasten-Code
X1.18	ROWS	Eingang	Al FRONT	X1.18	HCMOS-Pegel	Tasten-Code
X1.19	COL3	Eingang	Al PRONT	X1.19	HCHOS-Pegel	Tasten-Code
X1.20	ROW4	Eingang	AL FRONT	X1.20	HCMOS-Pegel	Tasten-Code
X1,21	COL2	Eingang	Al FRONT	X1.21	HCMOS-Pegel	Tasten-Code
X1.22	ROW3	Eingang	Al FRONT	X1.22	HCMOS-Pegel	Tasten-Code
X1.23	COL1	Eingang	Al FRONT	X1.23	HCMOS-Pegel	Tasten-Code
X1.24	ROW2	Eingang	Al FRONT	X1.24	HCMOS-Pegel	Tasten-Code
X1.25	COLO	Eingang	Al FRONT	X1.25	HCMOS-Pegel	Tasten-Code
X1.26	ROW1	Eingang	Al FRONT	X1.26	HCMOS-Pegel	Tasten-Code
		ì		ĺ		
X2.6	ATM	Bidir.	IEC-Bus		HCM:OS-Pegel	Steuerleitung
X2.8	SRQ	Bidir.	IEC-Bus		HCMDS-Pegel	Steuerleitung
x2.10	IFC	Bidir.	IEC-Bus		HCHOS-Pege1	Steuerleitung
K2.12	NDAC	Bidir.	IEC-Bus		HCMOS-Pegel	Steuerleitung
K2.14	NFRD	Bidir.	IEC-Bus		MCMOS-Pegel	Steuerleitung
X2.16	DAV	Bidir.	IEC-Bus		HCMOS-Pegel	Steuerleitung
(2.17	REN	Bidir.	IEC-Bus	ļ	HCKOS-Pegel	Steuerleitung
12.18	EQI	Bidir.	IEC-Bus	Ì	HCMOS-Pegel	Steverleitung
(2.19	DIO8	Bidir.	IEC-Bus		HCMOS-Pegel	Data-Bus
(2.20	D104	Bidir.	IEC-Bus		HCMOS-Pegel	Data-Bus
(2.21	D107	Bidir.	IEC-Bus	1	HCMOS-Pegel	Data-Bus
(2.22	DI03	Bidir.	IEC-Bus	ľ	HCMOS-Pegel	Data-Bus
(2.23	D106	Bidir.	IEC-Bus		HCMOS-Pegel	Data-Bus
(2.24	D102	Bidir.	IEC-Bus		HCMOS-Pegel	Data-Bus

Pin	Name	Ein/Ausgang	Herkunft/2i	el (	Werkebereich	Signalbeschreibung
X2.25	DI05	Bidir.	IEC-Bus		HCMOS-Pegel	Data-Bus
X2.26	DIO1	Bidir.	IEC-Bus		HCMOS-Pegel	Data-Bus
X3.2	SERCLK	Ausgang	A3 MERD	X3.2	NCMOS-Pegel	Seriell-Clock
хз. з	SEQ	Eingang	A3 MBRD	жз.3	HCMOS-Pegel	Sequenz
X3.4	SERDATA	Ausgang	A3 MERD	X3.4	HCHOS-Pegel	Seriell-Data
x3.5	frei					
хз.6	DIAG-5V	Eingang	A3 MERD	X3.6	-5V+5V	Diagnose/Kalibrierung
x3.8	VA15-N	Eingang	A3 MERD	X3.8	-15.5V14.4V	-15V Versorgungsspannung
					max.75mA	
x3,9	VA15-P	Eingang	A3 MERD	хз.9	+14.4V+15.6V	+15V Versorgungsspannung
					max.65mA	
хз.10	VA5-P	Eingang	A3 MBRD	X3.10	+4.9V5.3V	+5V Versorgungsspanung
					max.340mA	
X3.12	VAS-P	Eingang	A3 Motherb.	X3,12	+4.9V5.3V	+5V Versorgungsspanung
					max.340mA	
X3.13	บรงด	Eingang	A3 MBRD	¥3.13	+7.2V+7.8V	Überspannung für Reset
X3.14	HF1STB	Ausgang	A3 MBRD	X3.14	HCMOS-Pegel	Strobe 1 Synthesizer
X3.15	HF2STB	Ausgang	A3 MBRD	жз.15	HCMOS-Pegel	Strobe 2 Synthesizer
X3.16	AT1STB	Ausgang	A3 MBRD	X3.16	HCMOS-Pegel	Strobe 1 Ausgangsverstärker
x3.17	AT25TB	Ausgang	A3 MERD	X3.17	HCMOS-Pegel	Strobe 2 Ausgangsverstärker
x3.18	at3STB	Ausgang	A3 MERD	X3.18	HCMOS-Pegel	Strobe 3 Ausgangsverstärker
X3.19	ELSTB	Ausgang	A3 MERD	X3.19	HCMOS-Pegel	Strobe Eichleitung
x3.20	HFXNT	Eingang	A3 MERD	X3.20	HCMOS-Pegel	Interrupt
X3.21	refoff	Ausgang	A3 MBRD	X3.21	HCMOS-Pegel	Option Ein/Aus
X3.22	HFOVERLOAD	Eingang	A3 MBRD	х3.22	KCMOS-Pegel	Overload HF
X3.23	FMKONLO	Eingang	A3 MBRD	жз.23	KCMOS-Pegel	FM EXT zu klein
X3.24	FMKOMMI	Eingang	A3 MBRD	X3.24	KCMOS-Pege1	FM EXT zu groß
x3.25	OPTERKREF	Eingang	A3 MERD	х3,25	HCMOS-Pegel	Optionserkennung Ref. Oszi.
X3.26	OVENÇOLD	Eingang	A3 MBRD	X3.26	HCMOS-Pegel	Thermostat Option
X3.28	LFOUT	Ausgang	A3 MBRD	X3.28	iVs	Modulationsgenerator
x3.30	AMEXT	Eingang	A3 MBRD	х3.30	1Vs	Ext. Eingang AM
X3.32	INTl	Ausgang	A3 MBRD	жз.32	ıVs	Int FM Ausgang
x3.34	DOMMA	Ausgang	A3 MBRD	X3.34	178	AM Mod. Ausgang
	·	-	-			
X1.5/7/9					CMD	
X2.1/2/3/4					CND	
5/7/9/11					GND	
13/15/					GND	
X3.1/7/11					GND	
27/29/31/33					GND	



SERVICE INSTRUCTIONS

Controller

1062.6309.01

#### Contents

7 Testing and Repair of the Module	5
7.1 Function Description	5
7.1.2 Processor Section	5 5 5
7.1.3 Analog Section	6 6
7.2 Test Instruments and Utilities	6
7.3 Troubleshooting	6
7.4 Testing and Adjustment	7
7.4.1 Testing the Power Supply	7
7.4.4 Adjustment of the AM-EXT Voltage Comparator	
7.4.5 Adjusting Level INT1	7
7.4.6 OV-Adjustment of INT1 DC Offset	7
7.4.7 Testing the Diagnosis Inputs	7
7.4.8 Testing the Keyboard Interrupt	3
7.4.9 Testing the RAM Backup Voltage	
7.4.10 Testing the Frequency Accuracy	
7.4.11 Testing Level Accuracy	3
7.4.12 Testing the Spectral Purity	)
7.4.13 Testing the AM Output Switchover	)
7.4.14 Testing the Voltage Comparator for AM-EXT 9	)
7.5 Disassembly and Assembly	)
7.6 External Interfaces 10	)

Parts list List of coordinates Circuit diagram Component layout diagram

### 7.1 Function Description

The circuit of the controller module consists of a processor section and an analog section.

#### 7.1.2 Processor Section

#### 7.1.2.1 CPU with Peripherals

The processor is the control unit for the overall instrument. The CPU N80C196 (D10) in conjunction with the program memories EPROM D206, EEPROM D125 and the battery-backed RAM D210 forms the nucleus.

The two 8-bit ports P3 and P4 of the CPU represent the address/data bus. PAL D110 is used as output port for the strobe. Analog voltages in the range from 0V to ±5V (X3.6) are applied to the internal A/D converter of the CPU via the port P0.0. The adjustable 5.12V reference voltage of the D/A converter is generated by means of the voltage reference REF02 (D107). The logic states of the interrupt lines are identified at the input port P1. P1.3 is used to identify the reference oscillator option. The reset circuit D100 provides a defined reset signal for the CPU in case of dips or failures of the ac supply voltage as well as with instrument switch-on or switch-off. PAL D110 decodes further address signals for RAM, EPROM, EEPROM and IEC/IEEE bus.

#### 7.1.2.2 Keyboard Matrix

8 vertical lines and 5 horizontal lines (COLO...COL7, ROW1...ROW5) are passed from the keyboard matrix to the keyboard-display module. If no key is pressed, ROW1...ROW5 are applied to HIGH potential. COLO...COL7 are kept at LOW potential by D303. As soon as a key is pressed, a horizontal line is connected to a vertical and the horizontal line assumes LOW state. The corresponding capacitor is discharged. D302 causes a delay and D305 causes an interrupt (KEYINT) due to debouncing. Reading the key code, D303 becomes high-impedance, such that all vertical lines which are not connected via the closed key assume HIGH potential. The discharged capacitor ensures that the corresponding vertical line is kept LOW during the access time.

#### 7.1.2.3 IEC/IEEE Interface

The IEC/IEEE-bus interface, which consists of the integrated IEC/IEEE-bus component D250 and the two components D260, D255 implements the interface according to the IEEE standard 488-1978. This component independently handles the handshake with data transfer. The interrupt generated with a change of status is passed to the pin HAI 0 of the CPU.

#### 7.1.3 Analog Section

The analog section of the controller module provides the modulation signals required for AM and FM modes. It consists of an AF synthesizer and the AM modulation path.

#### AF Synthesizer

The output frequency of the modulation generator is generated by means of direct digital synthesis.

The DDS component D420 which contains a 32-bit adder, two 32-bit incremental memories, sine ROM and an interface for serial data transmission represents the nucleus of the synthesizer. The adder periodically increments at a clock frequency of 2.147484 MHz. The clock is provided by the crystal oscillator B401. The addresses of the sine ROM are controlled by the 13 high-order bits of the sum. The sine ROM stores the amplitude values of one sine-wave period. The 12 high-order bits of the amplitude values of one sine-wave are passed to a D/A converter which supplies a staircase signal. The two 6-bit D-registers (D430 und D440) suppress the different propagation delays of the sine ROM contained in the DDS component. A sample-&-hold switch suppresses the settling procedures of the D/A converter. A following 600-kHz lowpass provides for sufficient suppression of the clock frequency. The sinX/X compensation is realized by R491 and C490.

#### 7.1.3.2 AM-Modulation Path

The analog switch D500, D510 and D550 is used to select the internal or external AM signal. The window discriminator (N544) which is connected in parallel to the input monitors the amplitude of the external modulation signal and, in case of undershoots or overshoots, supplies the signals AMKOMLO or AMKOMHI to the processor D10.

### Test Instruments and Utilities

-	Digital multimeter	(e.g.,	R&S	UDS5)
_	DC-voltage source	(e.g.,	R&S	NGT)
-	Audio analyzer	(e.g.,	R&S	UPA)
	Frequency generator	(e.g.,	R&S	SPN)
-	RMS voltmeter	(e.g.,	R&S	URE3)
	Spectrum analyzer	(e.g.,	R&S	FSA)
	Occi 11 occoro			

Oscilloscope

- Frequency counter

#### Troubleshooting

No signal provided at LFOUT (X3.23)

Check clock generator at X401

Check signal at P405

Check S&H circuit at P409

Check lowpassfilter and amplifier

N520 at P530

AM-INT at AMMOD (X3.34) faulty Check switches D510 and D550 and amplifier N530

AM-EXT at AMMOD (X3.34) faulty Check switches D500 and D550 and amplifier N530

### 7.4 Testing and Adjustment

All measured values indicated without tolerances are recommended values. Voltages given without any further detail are dc voltages.

### 7.4.1 Testing the Power Supply

- Connect an ammeter into the supply lines of the individual supply voltages
- Check the power consumption of the module.

  The rated values of individual supply voltages can be looked up under "External Interfaces".

## 7.4.2 Setting the Power-Fail Threshold

- Set the ac supply voltage such that  $7.1 \text{ V} \pm 0.1 \text{ V}$  are applied to X3.13 (U5VC).
- Adjust R139 such that the logic level at D100.10 is just changing (from H to L or L to H).

#### 7.4.3 Setting the Reference Voltage

Set dc voltage at test point P101 to +5.12 V ±1 mV using R102.

## 7.4.4 Adjustment of the AM-EXT Voltage Comparator

• Set the voltage at test point P513 to -1.02V ±1mV using R550.

#### 7.4.5 Adjusting Level INT1

- Setting: 1kHz
- Connect calibrated ac voltmeter to INT1 (X3.32).
- Adjust output amplitude at ac voltmeter to 0.7071Vrms using R450.

#### 7.4.6 OV-Adjustment of INT1 DC Offset

- Setting: AF 1kHz
- Connect dc voltmeter to INT1 (X3.32).
- Adjust dc offset to OV using R520.

#### 7.4.7 Testing the Diagnosis Inputs

- Connect dc voltmeter to test point P100.
- Setting: SPEC 109 SPEC 40 (GAIN16 D105.5 LOW).
- The measured voltage must be +2.56V ±20mV.
- Setting: SPEC 39 (GAIN16 D105.5 HIGH).

The measured voltage must be +2.56V ±50mV.

• Setting:

RF 1GHz

SPEC 40 (GAIN16 D105.5 LOW).

SPEC 115

- Measure the voltage at X3.6. The voltage at P100 must be +2.56 V minus half the voltage at  $X3.6 \pm 20$ mV.
- Setting: SPEC 39 (GAIN16 D105.5 HIGH).
- Measure the voltage at X3.6. The voltage at P100 must be +2.56V minus sixteen times half the voltage at  $X3.6 \pm 100 \text{mV}$ .

#### 7.4.8 Testing the Keyboard Interrupt

• Connect an oscillscope to P305. Press any key.

A LOW pulse with a pulse duration of approx. 2.5 ms must be measurable on the oscilloscope.

#### 7.4.9 Testing the RAM Backup Voltage

- Measure the battery voltage directly at the battery terminals.
- Switch off the supply voltages.
- The measured battery voltage (tol. -10mV) is to be applied to D210.28.

### 7.4.10 Testing the Frequency Accuracy

- Setting: AF 100kHz
- Connect calibrated frequency counter to AF INT.
- Measure frequency. max. error ±10Hz.

#### 7.4.11 Testing Level Accuracy

#### 7.4.11.1 Frequency Response

- Setting: Vary AF between 10Hz and 500kHz.
- Connect calibrated ac voltmeter to AF INT.
- Measure level and compare to the table below.
   Frequency response of 10Hz

up to 50kHz <0.2dB up to 100kHz <0.3dB

up to 500kHz < 0.5dB

#### 7.4.11.1 Setting Errors

• Setting: AF 1kHz AM INT ON

• Connect calibrated ac voltmeter to outputs AF INT, INT1 (X3.32) and AMMOD (X3.34).

\_ Check output signals.

AF INT 0.7071Vrms

INT1 0.7071Vrms (X3.32)

AMMOD 0.7071Vrms(X3.34) max. error  $\pm 1\%$ 

### 7.4.11.3 INT1 DC-Offset

- Connect dc voltmeter to INT1 (X3.32).
- Absolute value of DC voltage must be < 5 mV.

### 7.4.12 Testing the Spectral Purity

### 7.4.12.1 Testing Distortion

Setting:

- Vary AF between 20 Hz and 100 kHz.
- Connect distortion meter to AFOUT.
- Measure distortion with various frequencies.
   Distortion must be <0.1%.</li>

# 7.4.12.2 Testing Harmonic and Nonharmonic Spuriae

Setting:

- Vary AF between 100 kHz and 500 kHz.
- Connect spectrum analyzer to AFOUT (Zin =  $1M\Omega$ ).

Suppression of harmonics and nonharmonics must be < -40 dBc.

## 7.4.13 Testing the AM Output Switchover

Setting:

AF 10kHz

- AM INT ON
- Connect oscilloscope to AMMOD (X3.34).
- A 10-kHz sinewave signal must be visible on the oscilloscope.

Setting: AM EXT AC

- Shorting jumper X501 between X501.1 and X501.2
- Connect AF generator to AM EXT.

AF generator setting:

frequency 1kHz

voltage 0.7071Vrms

 Test AMMOD (X3.34) signal. The voltage applied should be 0.7071Vrms.
 Max. error ±1%

# 7.4.14 Testing the Voltage Comparator for AM-EXT

Setting: AM EXT DC ON

Connect AF generator to AM EXT.

AF-generator setting: frequency 1kHz

voltage 0.7071Vrms

The two outputs D545.13 and D545.12 must be LOW.

• Increase level to 0.735Vrms.

Output level at D545.13 must be HIGH.

• Adjust level to 0.680Vrms.

Level at D545.12 must be HIGH.

Subsequent to opening the instrument and undoing the screws, the module can be removed from the frame. After undoing the screws of the screening covers, the module is accessible from both sides. Installation of the module and reassembly of the instrument are carried out in the reverse order.

7.6 External Interfaces

Pin Salas	Name	Input/Output	Origin/Dest.	Specified range	Signal description
X1.1	VA5-P	Output	A1 FRONT X1.1	+4.9Vto+5.3V	+5V supply voltage
	ļ			max.340mA	
X1.2	SERCLX	Output	A1 FRONT X1.2	HCMOS level	Serial clock
X1.3	VA5-P	Output	A1 FRONT X1.3	+4.9Vto+5.3V	+5V supply voltage
				max.340mA	
X1.4	SERDATA	Output	A1 FRONT X1.4	HCHOS level	Serial data
X1.6	DIS1STB#	Output	A1 FRONT X1.6	HCHOS level	Display strobe 1
X1.8	DIS2STB#	Output	A1 FRONT X1.8	HCMOS level	Display strobe 2
X1.10	LEDSTB	Output	Al FRONT X1.10	HCMOS level	LED strobe
x1.11	COL7	Input	A1 FRONT X1.11	HCMOS level	Xey code
X1.12	C/D#	Output	A1 FRONT X1.12	MCMOS level	
X1.13	COT 6	Input	Al FRONT X1.13	HCMOS level	Key code
X1.14	DISBUSY	Input	A1 FRONT X1.14	HCMOS level	Control line
X1.15	COL5	Input	Al FRONT X1.15	HCMOS level	Key code
X1.16	RES#	Output	Al FRONT X1.16	HCHOS level	Reset
X1.17	COL4	Input	A1 FRONT X1.17	HCHOS level	Xey code
X1.18	ROW5	Input	Al FRONT X1.18	HCMOS level	Key code
X1.19	COT3	Input	A1 FRONT X1.19	HCMOS level	Key code
X1.20	ROW4	Input	A1 FRONT X1.20	HCHOS level	Key code
X1.21	COL2	Input	A1 FRONT X1.21	HCMOS level	Xey code
X1.22	ROW3	Input	A1 FRONT X1.22	HCHOS level	Key code
X1.23	COL1	Input	A1 FRONT X1.23	HCHOS level	Key code
X1.24	ROW2	Input	A1 FRONT X1.24	HCHOS level	Xey code
X1.25	COLO	Input	A1 FRONT X1.25	HCHOS level	Key code
X1.26	ROW1	Input	A1 FRONT X1.26	HCMOS level	Xey code
					_
X2.6	ATN	Bidirect.	IEC/IEEE bus	HCHOS level	Control line
X2.8	SRQ	Bidirect.	IEC/IEEE bus	HCHOS level	Control line
X2.10	IFC	Bidirect.	IEC/IEEE bus	HCHOS level	Control line
X2.12	NDAC	Bidirect.	IEC/IEEE bus	HCHOS level	Control line
X2.14	NFRD	Bidirect.	IEC/IEEE bus	MCMOS level	Control line
X2.16	DAV	Bidirect.	IEC/IEEE bus	MCMOS level	Control line
X2.17	REN	Bidirect.	IEC/IEEE bus	HCHOS level	Control line
X2.18	EOI	Bidirect.	IEC/IEEE bus	MCMOS level	Control line
X2.19	DIO8	Bidirect.	IEC/IEEE bus	MCMOS level	Data bus
X2.20	DIO4	Bidirect.	IEC/IEEE bus	HCHOS level	Data bus
X2.21	DIO7	Bidir.	IEC/IEEE bus	HCMOS level	Data bus
X2.22	DIO3	Bidir.	IEC/IEEE bus	HCHOS level	Data bus
x2.23	DIO6	Bidir.	IEC/IEEE bus	MCMOS level	Data bus
X2.24	D102	Bidir.	IEC/IEEE bus	HCMOS level	Data bus
X2.25	DIOS	Bidir.	IEC/IEEE bus	MCMOS level	Data bus
X2.26	DIO1	Bidir.	IEC/IEEE bus	MCMOS level	Data bus

Pin	Name	Input/Output	Origin/De	est.	Specified range	Signal description
X3.2	SERCLK	Output	A3 MBRD	X3.2	HCMOS level	Serial clock
x3.3	SEQ	Input	A3 MBRD	X3.3	HCMOS level	Sequence
X3.4	SERDATA	Output	A3 MBRD	X3.4	HCMOS level	Serial data
X3.5	frei					
X3.6	DIAG-5V	Input	A3 MBRD	X3.6	-5V to +5V	Diagnosis/Calibration
хз. 8	VA15-N	Input	A3 MBRD	x3.8	-15.5V to -14.4V	-15V Supply voltage
х3.9	VA15-P	Input	A3 MBRD	X3.9	+14.4V to +15.6V	+15V Supply voltage
x3.10	VA5-P	Input	A3 MBRD	X3.10	max.65mA +4.9V to 5.3V max.340mA	+5V supply voltage
x3.12	VAS-P	Input	A3 Mother	ъ. хз.1		+5V supply voltage
X3.13	U5VC	Input	A3 MBRD	ХЗ.13	+7.2V+7.8V	Overvoltage for reset
X3.14	HF1STB	Output	A3 MBRD	X3.14	HCMOS level	Strobe l synthesizer
X3.15	HF2STB	Output	A3 MBRD	X3.15	HCMOS level	Strobe 2 synthesizer
X3.16	AT1STB	Output	A3 MBRD	X3.16	HCMOS level	Strobe 1 Output amplifier
X3.17	AT2STB	Output	A3 MBRD	X3.17	HCMOS level	Strobe 2 Output amplifier
X3.18	AT3STB	Output	A3 MBRD	X3.18	HCMOS level	Strobe 3 Output amplifier
X3.19	ELSTB	Output	A3 MBRD	X3.19	HCMOS level	Strobe attenuator
X3.20	HFINT	Input	A3 MBRD	X3.20	HCMOS level	Interrupt
X3.21	REFOFF	Output	A3 MBRD	X3.21	HCMOS level	Option on/off
X3.22	HFOVERLOAD	Input	A3 MBRD	X3.22	HCMOS level	Overload RF
X3.23	FMKOMLO	Input	A3 MBRD	X3.23	HCMOS level	FM EXT too small
X3.24	FMKOMHI	Input	A3 MBRD	X3.24	HCMOS level	FM EXT too large
X3.25	OPTERKREF	Input	A3 MBRD	X3.25	HCMOS level	Identif. of ref. oscill.
X3.26	OVENCOLD	Input	A3 MBRD	X3.26	HCMOS level	Thermostat option
X3.28	LFOUT	Output	A3 MBRD	X3.28	lVs	Modulation generator
X3.30	AMEXT	Input	A3 MBRD	X3.30	1Vs	Ext. Input AM
X3.32	INT1	Output	A3 MBRD	X3.32	1Vs	Int FM Output
X3.34	AMMOD	Output	A3 MBRD	X3.34	1Vs	AM Mod. Output

## GND

X1.5/7/9

X2.1/2/3/4/5/7/9/11/13/15 X3.1/7/11/27/29/31/33



Schaltteillisten
numerisch geordnet
Part lists
in numerical order
Listes des pièces détachées
par numéros de référence

Kennz. Comp. No.		Benan Dasign				Sachnummar Stock No.	Herstaller Manufacturer	Bazeichnt Designati			altan in alnad in
•	IDENTI VAR 02 MDD 02 VAR 04 MOD 04 XX ZUG CIRC.D	= GRUNI = BASI = SMY 4 = SMY 4 EH.STROI	N DF DAUS C MC 41/4 41/4	MODELS SFUEHRUNG DDEL 14/45							
8100	1062.6		21.00	DE LICADO	50.0	001 0050 00					
8100 8401	QUARTZ	CRYSTAL	_ UN	PF HC43U IIT 10MHZ	1	091.0250.00			SACHNUMMER		
8401	1	OSCILLAT		0.0SZ 5V	"	036.8120.00	TELEQUARZ	MCD 1500	) 8		
C10		UF+-20%1 OLYTIC (			CE O	008.7927.00	PANASONIC	ECA-1AFO	3221I		
C100	CC 1NF	+-1% 50\ RAMIC CA	/ NP	0 1206	cc o	007.7398.00	PHILIPS_CD	2222 863	*8102		
C105	CC 22PI	F+-1%50\ C CHIP (	/ NP	0 1206	CC O	099.8396.00	MURATA	GRM42-60	OG 220F 50PT		
C110	CC 1NF	+-1% 50V RAMIC CA	NP	0 1206	CC O	007.7398.00	PHILIPS_CD	2222 863	*8102		
C111	CC 1NF-	+-1% 50V RAMIC CA	NP	0 1206	cc o	007.7398.00	PHILIPS_CO	2222 863	*8102		
C112	CE 100	UF+~20%2 DLYTIC (	!5V	RD8X9,5	O	803.0580.00	MATSUSHITA	ECE-A1ES	S-101		
C1 13	CE 100	UF+-20%2 OLYTIC C	5V	RD8X9,5	O	803.0580.00	MATSUSHITA	ECE-A1ES	S-101		
C114	CC 2,2	NF+-10%5 C CHIP C	OVX	7R 1206	cc o	099.8444.00	PHILIPS_CO	2222 581	16618		
C115	CC 1001		OV 3	X7R 1206	cc o	007.5237.00	PHILIPS_CD	2238 581	15649		İ
C116	CC 1001		OV 2	X7R 1206	cc o	007.5237.00	PHILIPS_CD	2238 581	15649		
C117	CC 1001		ov :	X7R 1206	cc o	007.5237.00	PHILIPS_CO	2238 581	15649		
C118	CC 1NF+	H-1% 50V RAMIC CA	NP	0 1206	cc o	007.7398.00	PHILIPS_CO	2222 863	*8102		
C1 19	CC 10NF	+-10%50 CHIP C	۷x:	7R 1206	cc o	099.8521.00	MURATA	GRM42-6X	7R103K 50PT		
C120	CC 1NF+	-1% 50V	NP	1206	cc oc	007.7398.00	PHILIPS_CO	2222 863	*8102		
C121	CC 1NF+	-1% 50V	NP	1206	cc oc	007.7398.00	PHILIPS_CO	2222 863	*8102		
C122	CC 1NF+	-1% 50V RAMIC CA	NPO	1206	CC OC	007.7398.00	PHILIPS_CO	2222 863	*8102		
C123	CC 1NF+	-1% 50V	NPO	1206	CC 00	007.7398.00	PHILIPS_CO	2222 863	*8102		
C125	CC 100N		ov 3	(7R 1206	cc oc	007.5237.00	PHILIPS_CO	2238 581	15649		
C139	CC 100N	F+-10%5 CHIP C	( VO	(7R 1206	CC OC	007.5237.00	PHILIPS_CO	2238 581	15649		
C140		+-1%50V CHIP C			cc oc	099.8780.00	MURATA	GRM42-6C	OG 330F 50PT		
C141	CC 33PF	+-1%50V CHIP C	NPE	1206	cc oc	99.8780.00	MURATA	GRM42-6C	OG 330F 50PT		
C143		F+-10%5		(7R 1206	cc oc	007.5237.00	PHILIPS_CO	2238 581	15649		l
C144	CE 220U	F+-20%10 LYTIC C	οV	RM2,5		008.7927.00					
C145	CE 220U ELECTRO	F+-20%10 LYTIC C	OV APAC	RM2,5 CITDR		008.7927.00					
C146		F+-10%50 CHIP C		(7R 1206 CITDR		007.5237.00	•				
C150	CERAMIC	CHIP C	APA(			007.5237.00					l
C170	CERAMIC	F+-1%50 CHIP C	APAC	CITOR					OG 101F 50PT		
C171	CERAMIC	F+-1%50 CHIP C	APAC	ITOR		99.8415.00			OG 101F 50PT		
C173	SMD CER	-1% 50V	PACI	TDR		007.7398.00					
C174	SMD CER	-1% 50V	PACI	TOR		007.7398.00					1
C185 190		F+-10%50 CHIP C			CC OO	007.5237.00	PHILIPS_CD	2238 581	15649		
MENP5	413	ЗРИА	Ãi	Datum Date		Schaltteilli Parts lis			Sachnummer Stock No.		Blatt-Nr. Page
ROHDI	E&SCH\	NARZ	18	16.09.97		PROCESSOR		106	2.6309.01	SA	1+
L	-				PKD	CESSDR	·				

Kennz. Comp. No.	Benenny Designat		Sechnum Stack I		Hersteller Manufacturer	Bezeichnun Designatio		enthelte contein	
C191	CC 100NF+-10%50	<b></b> .	CC 0007.5	237.00	PHILIPS_CO	2238 581	15649		
C200	CERAMIC CHIP CA CC 100NF+-10%50		CC 0007.5	237.00	PHILIPS_CO	2238 581	15649		
C201	CERAMIC CHIP CA	APACITOR							
	CERAMIC CHIP CA	APACITOR			PHILIPS_CO		j		
C203	CC 100NF+-10%50 CERAMIC CHIP CA		CC 0007.5	237.00	PHILIPS_CO	2238 581	15649		
C204	CC 100NF+-10%50	OV X7R 1206	CC 0007.5	237.00	PHILIPS_CO	2238 581	15649		
C205	CC 10PF+-0,25 5	50VNPO 1206	CC 0099.8	480.00	MURATA	GRM42-6C0	G 100 C50PT		
C2 10	CERAMIC CHIP CA CC 100NF+-10%50		CC 0007.5	237.00	PHILIPS_CO	2238 581	15649		
C211	CERAMIC CHIP CA CC 100NF+-10%50		Ì		PHILIPS_CO				
	CERAMIC CHIP CA	APACITOR							
C220	CC 10PF+-0,25 5 CERAMIC CHIP CA		CC 0099.8	480.00	MURATA	GRM42-6CC	G 100 C50PT		
C230 236	CC 100PF+-1%50V CERAMIC CHIP CA		CC 0099.8	415.00	MURATA	GRM42-6C0	G 101F 50PT		
C3O1	CC 1NF+-1% 50V	NPO 1206	CC 0007.7	398.00	PHILIPS_CO	2222 863	*8102		
C302	SMO CERAMIC CAP		CC 0007.73	398.00	PHILIPS_CO	2222 863	*8102		
C3O3	SMD CERAMIC CAP CC 1NF+-1% 50V	ACITOR			PHILIPS_CO				
	SMD CERAMIC CAP	ACITOR		- 1			1		
C304	CC 1NF+-1% 50V SMO CERAMIC CAP	ACITOR		- 1	PHILIPS_CO				
C305	CC 1NF+-1% 50V SMO CERAMIC CAP		CC 0007.73	398.00	PHILIPS_CO	2222 863	*8102		
C306	CC 100PF+-1%50V	NPO 1206	CC 0099.84	415.00	MURATA	GRM42-6C0	G 101F 50PT		
C307	CERAMIC CHIP CA	NPO 1206	CC 0099.84	115.00	MURATA	GRM42-6CC	G 101F 50PT		
C308	CERAMIC CHIP CA CC 100PF+-1%50V		CC 0099.84	115.00	MURATA	GRM42-6CC	G 101F 50PT		
C310	CERAMIC CHIP CA	PACITOR			PHILIPS_CO				
316	CERAMIC CHIP CA	PACITOR		1					
C320 327	CC 390PF+-1%50V CERAMIC CHIP CA		CC 0099.88	380.00	PHILIPS_CO	2238 863	18391		
C330 334	CC 10NF+-10%50V CERAMIC CHIP CA	X7R 1206	CC 0099.85	521.00	MURATA	GRM42-6X7	R103K 50PT		
C340	CC 33NF+-10% 50	V X7R 1206	CC 0007.51	172.00	PHILIPS_CO	2238 581	16634		
C400	CERAMIC CHIP CA CC 100PF+-1%50V	NPO 1206	CC 0099.84	15.00	MURATA	GRM42-6C0	G 101F 50PT		
C402	CERAMIC CHIP CA CE 220UF+-20%10		CE 0008.79	27.00	PANASONIC	ECA-1AFG2	211		
C404	ELECTROLYTIC CA CE 100UF+-20%25	PACITOR			MATSUSHITA				
	ELECTROLYTIC CA	PACITOR							
C406	CE 100UF+-20%25 ELECTROLYTIC CA	PACITOR			MATSUSHITA				
C409	CC 100NF+-10%50 CERAMIC CHIP CA		CC 0007.52	237.00	PHILIPS_CO	2238 581	15649		
C417	CC 100PF+-1%50V	NPO 1206	CC 0099.84	15.00	MURATA	GRM42-6C0	G 101F 50PT		
C418	CERAMIC CHIP CA CC 100PF+-1%50V	NPO 1206	CC 0099.84	15.00	MURATA	GRM42-6C0	G 101F 50PT		
C419	CERAMIC CHIP CA CC 100PF+-1%50V		CC 0099.84	15.00	MURATA	GRM42~6C0	G 101F 50PT		
C420	CERAMIC CHIP CA	PACITOR			PHILIPS_CO				
	CERAMIC CHIP CA	PACITOR							
C421	CC 100PF+-1%50V CERAMIC CHIP CA	PACITOR	CC 0099.84				G 101F 50PT		
C430	CC 100NF+-10%50 CERAMIC CHIP CA		CC 0007.52	237.00	PHILIPS_CO	2238 581	15649		
C440	CC 100NF+~10%50	V X7R 1206	CC 0007.52	237.00	PHILIPS_CO	2238 581	15649		
C449	CERAMIC CHIP CA CC 100NF+-10%50	V X7R 1206	CC 0007.52	237.00	PHILIPS_CO	2238 581	15649		
C450	CERAMIC CHIP CA CC 100NF+~10%50		CC 0007.52	237.00	PHILIPS_CO	2238 581	15649		
C451	CERAMIC CHIP CA CC 100NF+-10%50	PACITOR			PHILIPS_CO				
	CERAMIC CHIP CA	PACITOR		ı	-				
C452	CC 100NF+-10%50 CERAMIC CHIP CA	PACITOR		1	PHILIPS_CO				
C453	CC 100NF+-10%50 CERAMIC CHIP CA		CC 0007.52	237.00	PHILIPS_CO	2238 581	15649		
MENP5	413 3PUA	Äl Datum		Schaltteill		1	Sachnummer		lett-N
	-	Date		Parts list	C 10f	100	Stock No.		Page
<b>Ø</b> ROHDI	E&SCHWARZ	18 16.09.97	ED PROCE	SSOR		100	2.6309.01	SA	2+
			PROCESSO	)R					

	Kennz. Comp. No.		Benen Design					ummar :k No.	Hersteller Manufacturer		eichnung ignation	]		haiten in tained in
	C454	_	F+-0,25 C CHIP		/NPO 1206	CC	0099	.8480.00	MURATA			G 100 C50		
	C460	CC 47P	F+-1%50\ C CHIP (	v cc	G 1206	cc	0099	.8496.00	MURATA	GRM4	2-6CO	G 470F 50F	T	
	C461	CC 47P	F+- 1%50	v cc	G 1206	cc	0099	.8496.00	MURATA	GRM4	2-6CO	G 470F 50F	РΤ	
	C4 <b>7</b> 2	CC 100	_	50V	X7R 1206	СС	0007	.5237.00	PHILIPS_CO	2238	581	15649		
	C473	CC 100		50V	X7R 1206	СС	0007	.5237.00	PHILIPS_CO	223B	581	15649		
	C474		C CHIP ( NF+-10%		CITOR X7R 1206	СС	0007	5237.00	PHILIP5_CO	2238	581	15649		
	C4 <b>7</b> 5		C CHIP ( NF+-10%		CITOR X7R 1206	İ			PHILIPS_CO					
	C480		C CHIP ( PF+-1%63		CITOR 3QUX11KP				SIEMENS		31-A5			
	C481	CAPACI	TOR		NPO 1206	1			MURATA			G 120 F50F	,_	
	C485		C CHIP C		CITOR X7R 1206	1			PHILIPS_CO					
ı	C490		C CHIP C F+-1%50V					B821.00				3 820F 50P	т	
	C492		C CHIP C		CITOR X7R 1206	l			PHILIPS_CO				•	
ı	C493	CERAMI	C CHIP C	CAPA					PHILIPS_CO					
	C500	CERAMIC	C CHIP C	APA		Ì			SIEMENS		301 31 <b>-</b> A51			
١	C501	CAPACI	TOR	-	3X11 KP				SIEMENS					
	C502	PLASTC-	-FOIL CA	PAC					SIEMENS		31-A53 31-A53			
ı	C503	PLASTC-	-FOIL CA	PAC	_				SIEMENS					
	C504	CAPACI	TOR	·	,3X11 KP				SIEMENS		81-A58			
	C505	FOIL (	CAPACITO	IR	X7R 1206				PHILIPS_CO		81-A51			
I	C506	CERAMIC	CHIP C	APA	CITOR								T	
	C510	CERAMIC	CHIP C	APA				8415.00				101F 50P		
	C530	CERAMIC	CHIP C	APA	CITOR			8213.00				4R7C 50P		
	C550	CERAMIC	CHIP C	APA	CITOR	CC	0055.	8415.00	MURAIA	GRM42	-6006	101F 50P	'	
	C530	CC 100F	R/ONLY M PF+-1%50	V N	PO 1206	СС	0099.	8415.00	MURATA	GRM42	-6CO	101F 50P	т	
		NUR VAR	CHIP C	00:										
	C531	CC 100F	F+-1%50 CHIP C	V N	PO 1206	СС	0099.	8415.00	MURATA	GRM42	-6COG	101F 50P	г	
ı	C531	NUR VAF	R/ONLY M	OD:		D.C.	0007	E614 60	DOEDERGTET	500.0				
	C551	RE5ISTO	R CHIP			Ku	0007.	00.41.00	ROEDERSTEI	UC2 2	21UHM	1%18100		
İ	CESS	FUER CS				00	0000	0445 00	151 D 4 T 4	051110			_	
	C532	CERAMIC	PF+-1%50 CHIP C	APA	CITOR			8415.00				101F 50P		
	C533	CERAMIC	F+-1%50 CHIP C	APA(	CITOR			B415.00				101F 50P		
	C538	CERAMIC	+-1%50V CHIP C	APA	CITOR			8396.00				220F 50P		
	C539	CERAMIC	F+-1%50'CHIP C	APA(	CITOR			8415.00				101F 50P		
	C540	CERAMIC	F+-1%50 CHIP C	APA(	CITOR			8415.00				101F 50P1		İ
	C541	CERAMIC	CHIP C	APAC	CITOR	CC	0099.	8750.00	MURATA	GRM42	-6COG	150F 50P1		
	C542	CC 15PF		1 VO	IPO 1206	СС	0099.	8750.00	MURATA	GRM42	-6COG	150F 50P1	г	
		NUR VAR	CHIP C	OD:	04									
	C542	CE 220U	F+-20%10	οv		CE	000В.	7927.00	PANASONIC	ECA-1	AFG22	1 <b>I</b>		
	C543	CE 220U	LYTIC C	ov	RM2,5	CE	000В.	7927.00	PANASONIC	ECA-1	AFG22	11		
		ELECTRO	LYTIC C	APA(	TIOK									
	MENP5	4 13	3PUA	ÄI	Datum Date			Schalltalli Parts lis				Sachnumma Stock No.	7	Blatt-Nr. Page
	<b>♣</b>			10	16 00 07		n pro	CECEOR		-	lue:	2.6309.0	1 64	
		E&SCH\	WARZ	18	16.09.97			CESSOR		ļ	1002	0303.0	1 3A	3+
L					<u> </u>	۲	ROCE5	OUK						

Kennz. Comp. No.	Banennung Designatien	Sachnummer Stock No.	Hersteller Manufacturer	Bazeichnung Designation		ilten in Inad in
C555	CK 1UF+-5%50V7,5X5,5X10,5	CK 0099.299B.00		MKT 1826-510/054-R		
C556	CAPACITOR  CK 1UF+-5%50V7,5X5,5X10,5  CAPACITOR	CK 0099.2998.00	ERO N	MKT 1826-510/054-R		
C567	CC 100PF+-1%50V NPO 1206	CC 0099.8415.00	MURATA G	SRM42-6COG 101F 50PT		
C568	CERAMIC CHIP CAPACITOR CC 100PF+-1%50V NPO 1206	CC 0099.8415.00	MURATA G	RM42-6COG 101F 50PT		
C575	CERAMIC CHIP CAPACITOR CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	PHILIPS_CO 2	238 5B1 15649		
C578	CERAMIC CHIP CAPACITOR CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	PHILIPS_CO 2	238 581 15649		
C579	CERAMIC CHIP CAPACITOR CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	PHILIPS_CO 2	238 581 15649		
С5ВО	CERAMIC CHIP CAPACITOR CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	PHILIPS_CO 2	238 581 15649		
587 C588	CERAMIC CHIP CAPACITOR CE 100UF+-20%25V RD8X9,5	0803.0580.00	MATSUSHITA E	CE-A1ESS-101		
C589	CE 220UF+-20%10V RM2,5	CE 0008.7927.00	PANASONIC E	CA-1AFG221I		
C590	CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	PHILIPS_CO 2	238 581 15649		
C591	CERAMIC CHIP CAPACITOR CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	PHILIPS_CO 2	238 581 15649		
C592	CERAMIC CHIP CAPACITOR CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	PHILIPS_CO 2	238 581 15649		
598 C599	CERAMIC CHIP CAPACITOR CE 100UF+-20%25V RD8X9,5	0803.0580.00	MATSUSHITA E	CE-A1ESS-101		
	ELECTROLYTIC CAPACITOR					
D10	BC N8OC196 16B.MCU+ADC IC MICRDCDNTROLLER	0010.6924.00	INTEL N	80C196KB		
D100	BO MAX691CWE SUPERVISOR IC UP VOLTAGE SUPERVISOR	1006.4162.00	MAXIM M	AX691CWE		
D 105	BS DG419DY 1XUM ANALOGSCH ANALOG SWITCH	0746.0322.00	SILICONIX O	G419DY		
0107	BO REFO2CP 5V 20MA VREF VOLTAGE REFERENCE	BO 0394.8732.00	PMI R	EF-02CP		
0110	HS EPROM 0110 EPROM 0110	1062.6321.00		į		
D12D	BL PC74HCT573T 8XO-FF 3S OCTAL D-TYPE FLIPFLOP	8L 0812.8796.00	PHILIPS_SE (	PC)74HCT573(0/T)		
0125	8C X24C16S14 2KX8 EEPROM SERIAL EEPROM	1028.8190.00	XICOR X	24C16S(14)		
D135	BL PC74HCTO4T 6XINVERT	8L 0007.5372.00	PHILIPS_SE (	PC)74HCTO4(D/T)		
D150	HEXINVERTER  BL PC74HCT574T 8XD-FF 3S  OCTAL O-TYPE FLIPFLOP	8L 0007.6727.00	PHILIPS (F	PC)74HCT574(T)		ļ
D160	BL PC74HCT574T 8XD-FF 3S	8L 0007.6727.00	PHILIPS (F	PC)74HCT574(T)		
0206	OCTAL O-TYPE FLIPFLOP HS EPROM D206 EPROM D206	1062.6338.00				
D210	EPROM D206 8C 84256-12LP 32KX8 SRAM	0007.6985.00	NEC U	P043256BGU-70LL		
D230	RAM BL PC74HCT245T 8XTRANSC	8L 0007.5414.00	PHILIPS_SE (F	PC)74HCT245(D/T)		
025D	BC NAT7210APD GPIB IF CDN	0010.9198.00	NATIONAL/I NA	AT7210APD		
D255		BJ 0345.6517.00	TEXAS SI	N75160BN		
D260	BUS TRANSCEIVER BJ SN75161AN BXBUS TRANSC	BJ 0345.6523.00	TEXAS SI	N75161BN		
D3O1	BUS TRANSCEIVER BL PC74HCT147T 10T04 ENC	BL 0007.6362.00	PHILIPS (F	PC)74HCT147(T)		
D302	PRIORITY ENCODER BL PC74HCT3OT 8IN NAND	BL 0007.6233.00	PHILIPS_SE (F	PC)74HCT30(D/T)		
D3O3	NAND GATE BL PC74HCT244T BXBUFF 3S	BL 0007.6562.00	PHILIPS_SE (F	PC)74HCT244D(T)		
D3O4	OCTAL BUFFER BL PC74HCT74T 2XD-FLIPFL	BL 0007.6262.00	PHILIPS_SE (F	PC)74HCT74D(T)		
D305	DUAL D-TYPE FLIP FLOP BL PC74HCT123T 2XMONOFLOP	BL 0007.6333.00	PHILIPS_SE (F	PC)74HCT123(D/T)		
D311	DUAL MULTIVIBRATDR BL PC74HCT147T 10T04 ENC	BL 0007.6362.00	PHILIPS (F	PC)74HCT147(T)		
D323	PRIORITY ENCODER BL PC74HCT244T BXBUFF 3S	BL 0007.6562.00	PHILIPS_SE (F	PC)74HCT244D(T)		
D4D2	OCTAL BUFFER BL PC74HCTOOT 4X2IN.NAND	BL 0007.6156.00	PHILIPS_SE (F	PC)74HCTOOD(T)		
	NAND GATE			and the second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second s		
Merce	410 ODUA v. Datum	Schalttelili	ste für	Sachnymmar	Ī	Blatt-Nr.
MENP5	413 3PUA ÄI Date	Parts list		Stock No.		Paga
<b>®</b>	1B 16.09.97	ED PROCESSOR		1062.6309.01	SA	4+
KOHD	E&SCHWARZ	DDOCECCDD				

PROCESSOR

Kennz. Comp. No.	Benennung Designation		Τ	Sachnummer Stock No.	Hersteller Manufacturer		zeichnung signation		haitan in tainad in
D403	BL PC74HCT74T 2X	D-FLIPFL	BL	0007.6262.00				con	ramed 10
D420	DUAL D-TYPE FLIP	DDS-OSZ		1036.8143.00			45102SC-33		
D430	IC NUMERIC CONTR	D-FF	BL	0007.6456.00	PHILIPS	(PC)	)74HCT174(T)		
D440	HEX D-TYPE FLIPFLI BL PC74HCT174T 6XI	D-FF	BL	0007.6456.00	PHILIPS	(PC)	)74HCT174(T)		
D450		DP X12B-DAC		0300.6330.00	BURR_BROWN	DAC	BOCBI-I		
DSOO	D/A-CONVERTER BS DG419DY 1XUM AI	NALOGSCH		0746.0322.00	SILICONIX	DG41	19DY .		
D5 10	ANALOG SWITCH BS DG419DY 1XUM AI	NALOGSCH		0746.0322.00	SILICONIX	DG41	I9DY		
D54S	ANALOG SWITCH BL PC74HCT123T 2XF DUAL MULTIVIBRATOF		BL	0007.6333.00	PHILIPS_SE	(PC)	74HCT123(D/T)		
DSSO	BS DG411DY 4X AN			0920.1723.00	SILICONIX	DG41	1DY	} 	
D555	BL PC74HCT4094T 85 SHIFT REGISTER	ST.SHREG	BL	0007.6885.00	PHILIPS	(PC)	74HCT4094(D)		
G100	EB 3,4V LITHIUM-BA	ATTERIE		056S.1687.00	ACCU_SONNE	SL-7	SO/P/009 11107S0		
L10	LD 25UH 3A 0,0460F	łM.	LD	0026.4849.00	SIEMENS	B821	11-B-C24		
L12	LD 10 UH 10% 3R3 1 CHOKE	144 MA	LD	0026.4184.00	DALE	IM2		i	
L13	LD 10 UH 10% 3R3 1 CHOKE	144 MA	LD	0026.4184.00	DALE	IM2			
L140	LD 56,0UH10%5,700H CHOKE	IMO, 100A	LO	0067.3076.00	DALE	IM2			
L401		8A 1210	LD	0007.9255.00	SIEMENS	8824	22-A1103-K100		
L403	1	8A 1210	LD	0007.9288.00	SIEMENS	B824	22-A1103-K100		
L405		8A 1210	LD	0007.9255.00	SIEMENS	8824	22-A1103-K100		
L472		8A 1210	LO	0007.9258.00	SIEMENS	8824	22-A1103-K100		
L4 <b>7</b> 3		8A 1210	LD	0007.9258.00	SIEMENS	8824	22-A 1103-K 100		
LS00	LD 330 UH10%28,00H CHOKE	MO,04SA	LD	0067.3160.00	OALE	IM2			
L501	LD 470 UH10%42,00H CHOKE	MO,036A	LD	0067.3182.00	OALE	IM2			
L502	LD 470 UH10%42,00H CHOKE	MO,036A	LD	0067.3182.00	OALE	IM2			
L503	LD 330 UH10%28,00H CHOKE			0067.3160.00		IM2			
L590	SMD-INDUCTOR			0007.9258.00		B8242	22 <b>-</b> A1103-K100		
LS91	SMD-INDUCTOR			0007.9288.00		B824	22-A1103-K100		
LS92	LD 10UH 10% 0,1 SMD-INDUCTOR	8A 1210	LD	0007.9285.00	SIEMENS	B8242	22-A1103-K100		
N100	IC DUAL OPAMP	T OPAMP		2045.4943.00					
N450		T OPAMP		OB54.1754.00			ľ		
N490	BO CLC430AJE C IC CURRENT FEEDBAC	F OPAMP K OPAMP		2032.2524.00	COMLINEAR	CL(C)	)430AJE		
N510	BO NE5534D OPERATIONAL AMPLIF	OPAMP IER		OB 15 . 7555 . 00	SIGNETICS	NE553	34(D)		
N520		T OPAMP		0854.1754.00	ANALOG_DEV	(AD)7	744KR		
N530		T OPAMP IER		0803.1057.00	TEXAS	TL 07	72 ACDR		
NS40	BO AD744KR FE BIFET OPAMP	T OPAMP		OB54.1754.00	ANALOG_DEV	(AD)7	744KR		
N540	NUR VAR/ONLY MOD: ( BO AD811JR VIDEOCF IC OPAMP NUR VAR/ONLY MOD: (	OPAMP		2025.2997.00	ANALOG_DEV	ADB 1 1	IJR		
N544	BD LM2903D 2XLP	COMPAR		0520.7734.00	SIGNETICS	LM290	D3(D)		
MENP5	413 3PUA ÄI	Datum Date		Schalttaillis Parts list			Sachnummer Stock No.		Blatt-Nr.
ρ.						_			Page
<b>BUTUI</b>	ERSCHWADZ 1B	16.09.97	E	D PROCESSOR			1062.6309.01	SA	5+

PROCESSOR

Kennz. Comp. No.	Benan Dasign				Sachnummar Stock No.	Hersteller Manufecturer	Bazeichnung Dasignation		haiten in tained in
P100	VL EINPRESSST	IFT	L=6,8	VI	0010.7250.00	AMP	1-928776-5		
P101	VL EINPRESSST	IFT	L=6,8	VI	_ 0010.7250.00	AMP	1-928776-5	1	
P305	PIN VL EINPRESSST	IFT	L=6,8	VL	0010.7250.00	AMP	1-928776-5		
P405	PIN VL EINPRESSST	IFT	L=6,8	Vι	0010.7250.00	AMP	1-928776-5	-	
P406	PIN   VL EINPRESSSTI	IFT	L≃6,8	VL	. 0010.7250.00	AMP	1~928776-5		
P409	PIN VL EINPRESSSTI	IFT	L=6.8	  VL	. 0010.7250.00	AMP	1-928776-5		
P510	PIN VL EINPRESSSTI				. 0010.7250.00		1-928776-5		
P513	PIN VL EINPRESSSTI				. 0010.7250.00			ļ	
P530	PIN VL EINPRESSSTI		•				1-928776-5		
1500	PIN	ırı	L-0,6	١٧٢	. 0010.7250.00	AMP	1-928776-5		
R100	RG 22,1 OHM+-1	<b>%</b> T#	(100 1206	RG	0007.5489.00	ROEDERSTEI	DC2 22,10HM 1%TK100	0	
R101	RESISTOR CHIP RG 22,1KOHM+-1	<b>%</b> TK	(100 1206	RG	0007.5872.00	ROEDERSTEI	DC2 22,1KOHM 1%TK10	00	
R102	RESISTOR CHIP RS 0,25W10K0HW	1 +-	-20% SMD		0007.9649.00		3314G-1-103		
R105	POTENTIOMETER RG 20,0K0HM+-1						DC2 20,0K0HM 1%TK10	00	
R106	RESISTOR CHIP RG 1,3 KOHM+-1						OC2 1,3KOHM 1%TK100		
R108	RESISTOR CHIP RG 1,0M0HM+-1%			l	0815.7532.00		CRC 1206		
50	CHIP RESISTOR			٨٥	U0 15.7582.00	UKALUKIC	CKC 1200		
R109	NUR VAR/ONLY M RL 0,35W20,0K0			RL	0084.3641.00	RESISTA	MK2		
R110	RESISTOR RL 0,35W20,0K0	НМ÷	-0,1%T25	RL	0084.3641.00	RESISTA	MK2		
R111	RESISTOR RG 100 OHM+-1%	TK1	00 1206	RG	0006.8884.00	ROEOERSTEI	OC2 1000HM 1%TK100		
R112	CHIP RESISTOR RG 562 OHM+-1%	TK 1	00 1206	1	,		DC2 5620HM 1%TK100		
R113	CHIP RESISTOR RL 0,35W10,0K0				0084.3064.00		SMA0207/10K-8-E		
R114	RESISTOR RL 0,35W10,0K0			1	0084.3064.00		SMA0207/10K-8-E	1	
R115	RESISTOR RG 1,0 KO +-1%						DC2 1, OKOHM 1%TK100		
R120	CHIP RESISTOR RG 10,0K0HM+-1				1			4	
127	RG CHIP RESIST	OR		1	i		DC2 10,0K0HM 1%TK10		
R130 136	RG 10,0KOHM+-19	OR					DC2 10,0K0HM 1%TK10		
R138	RG 13,0KOHM+-19 RESISTOR CHIP						OC2 13,0KOHM 1%TK10	ю	
R139	RS 0,25W500 OH POTENTIOMETER	M+-	20% SMO	-	0007.9603.00		3314G-1-501		
R140	RG 2,74KOHM+-19 RESISTOR CHIP	//TK	100 1206	RG	0007.5766.00	ROEOERSTEI	OC2 2,74KOHM 1%TK10	ю	
R141	RG 1,82KOHM+-19 RESISTOR CHIP	%TK	100 1206	RG	0007.5720.00	ROEOERSTEI	OC2 1,82KOHM 1%TK10	О	
R142	RG 10,OKOHM+-1; RG CHIP RESISTO		100 1206	RG	0007.0793.00	ROEDERSTEI	DC2 10,0K0HM 1%TK10	0	
R143	RG 100 OHM+-1% CHIP RESISTOR		00 1206	RG	0006.8884.00	ROEDERSTEI	DC2 1000HM 1%TK100		
R144	RG O-OHM WIDERS			RG	0007.5108.00	ORALORIC	CR 1206	!	
R145	RESISTOR CHIP ( RG 100 OHM+-1%			RG	0006.8884.00	ROEOERSTEI	DC2 1000HM 1%TK100		
R146	CHIP RESISTOR RG 10,0KOHM+-1		100 1206	RG	0007.0793.00	ROEOERSTEI	OC2 10,0KOHM 1%TK10	o	
R147	RG CHIP RESISTORG 10,0KOHM+~1	<b>∕</b> ∗τκ	100 1206	RG	0007.0793.00	ROEOERSTEI	DC2 10,0KOHM 1%TK10	o	
R148	RG CHIP RESISTOR 1,0 KO +-1%		00 1206				OC2 1, OKOHM 1%TK100		
R149	CHIP RESISTOR RG O-OHM WICERS	STAI	ND-CHIP		0007.5108.00		CR 1206		
R150	RESISTOR CHIP ( RG 10,0K0HM+-1)	o-01	HM				OC2 10,0K0HM 1%TK10	0	
R151	RG CHIP RESISTORG 10,0KOHM+-1	)R			ľ		OC2 10,0KOHM 1%TK10		
-	RG CHIP RESISTO				2007.0700.00		JJE 10, OKOFIRE I / IKIU		
MENP5	413 3PUA	Äì	Datum		Schalttellis		Sachnumme	er .	Blatt-No
	OF OR		Date		Parts list	for	Stock No.		Paga
BUTUE BUTUE	&SCHWARZ	18	16.09.97	E	O PROCESSOR		1062.6309.0	)1 SA	6+
MUTIUE	. GOUNNARZ	ļ		F	ROCESSOR				

Kennz. Comp. No.	Benennur Designatio		Sachnummer Stock No.	Harstellar Manufacturer	Bazeichnung Designation	enthaltan in containad in
R152	RG 10,0KOHM+-1%	TK100 1206			C2 10,0KOHM 1%TK100	
R153	RG CHIP RESISTO RG 10,0KOHM+-1%	TK100 1206			C2 10,0KOHM 1%TK100	
R154	RG CHIP RESISTO RG 4,75KOHM+-1%		RG 0007.5820.00	ROEOERSTEI OO	C2 4,75KOHM 1%TK100	
R156	RESISTOR CHIP RG 4,75KOHM+-1%	TK100 1206	RG 0007.5820.00	ROEDERSTEI OO	C2 4,75KOHM 1%TK100	
R157	RESISTOR CHIP RG 4,75KOHM+-1%	TK100 1206	RG 0007.5820.00	ROEOERSTEI OO	2 4,75KOHM 1%TK100	
R160	RESISTOR CHIP RN 9X 10KOHM+-S		RN 0343.4523.00	BI_TECHNOL L	10 1 S 103 M*	
R161	RESISTOR NETWORK RN 9X 10KOHM+-SI RESISTOR NETWORK	L10 H5	RN 0343.4523.00	BI_TECHNOL L	10 1 S 103 M*	
R163	RN 9X 10KOHM+-SI RESISTOR NETWORK	L10 H5	RN 0343.4523.00	BI_TECHNOL L	10 1 S 103 M*	
R165	RG 4,75KOHM+-1%7		RG 0007.5820.00	ROEDERSTEI OC	2 4,75KOHM 1%TK100	
R166	RG 4,75KOHM+-1%1 RESISTOR CHIP	TK100 1206	RG 0007.5820.00	ROEDERSTEI OC	2 4,75KOHM 1%TK100	
R170	RG 10,0KOHM+-1%1 RG CHIP RESISTOR		RG 0007.0793.00	ROEGERSTEI DO	2 10,0KOHM 1%TK100	
R171	RG 10,0KOHM+-1%1 RG CHIP RESISTOR		RG 0007.0793.00	ROEDERSTEI OC	2 10,0KOHM 1%TK100	
R172	RG 10,0KOHM+-1%1	₹			2 10,0KOHM 1%TK100	
R174 178	RG 10,0KOHM+-1%T	₹	l í		2 10,0KOHM 1%TK100	
R179	RG 1,0 KO +-1%TK		1		2 1,0K0HM 1%TK100	
R180 R200	RG 1,0 KO +-1%TK CHIP RESISTOR RG O-OHM WIDERST		li		2 1,0KOHM 1%TK100	
R204	RESISTOR CHIP O- RG 2,21KOHM+-1%T	OHM	RG 0007.5108.00		2 2 21KOUN 19/TK100	
R205	RESISTOR CHIP RG 10,0K0HM+-1%T				2 2,21KOHM 1%TK100 2 10,0KOHM 1%TK100	
R220	RG CHIP RESISTOR				2 10,0K0HM 1%TK100	
R221	RG CHIP RESISTOR RG 5,62KOHM+-1%T	1			2 5,62KOHM 1%TK100	
R250	CHIP RESISTOR RN 9X 10KOHM+-SI		RN 0343.4523.00			
R251	RESISTOR NETWORK RG 6,81KOHM+-1%T				2 6,81KOHM 1%TK100	
R252	CHIP RESISTOR RG 1,0 KO +-1%TK	100 1206	RG 0006.7271.00	ROEDERSTEI DC	2 1,0K0HM 1%TK100	
R301	CHIP RESISTOR RG 10,0KOHM+-1%T RG CHIP RESISTOR	K100 1206	RG 0007.0793.00	ROEDERSTEI DC	2 10,0KOHM 1%TK100	
R320	RG 4,75KOHM+-1%T RESISTOR CHIP		RG 0007.5820.00	ROEOERSTEI OC	2 4,75KOHM 1%TK100	
R321	RG 182 KOHM+-1%T RESISTOR CHIP	K100 1206	RG 0007.5989.00	ROEGERSTEI DC:	2 182KOHM 1%TK100	
R322	RG 10,0KOHM+~1%T RG CHIP RESISTOR		RG 0007.0793.00	ROEDERSTEI DC	2 10,0K0HM 1%TK100	
R323	RG 10,0KOHM+-1%T RG CHIP RESISTOR	K100 1206			2 10,0KOHM 1%TK100	
R330 338	RG 1,0 KO +-1%TK CHIP RESISTOR	100 1206			2 1,0KOHM 1%TK100	
R340	RG 10,0KOHM+-1%T RG CHIP RESISTOR				2 10,0K0HM 1%TK100	
R400	RG 47,5 OHM+-1%T RESISTOR CHIP				2 47,50HM 1%TK100	
R401	RG 10,0KOHM+-1%T RG CHIP RESISTOR				2 10,0KOHM 1%TK100	
R402	RG 10,0KOHM+-1%T RG CHIP RESISTOR				2 10,0KOHM 1%TK100	
R403	RG 47,5 OHM+-1%T RESISTOR CHIP	-			2 47,50HM 1%TK100	
R404 R405	RG 47,5 OHM+-1%T RESISTOR CHIP RG 10,0KOHM+-1%T				2 47,50HM 1%TK100 2 10,0K0HM 1%TK100	
R410	RG CHIP RESISTOR RG 10,0KOHM+-1%T		! <b>!</b>		2 10,0KUHM 1%TK100 2 10,0KUHM 1%TK100	
R411	RG CHIP RESISTOR RG 10,0KOHM+-1%T RG CHIP RESISTOR	K100 1206			2 10,0KOHM 1%TK100	
MENP5	413 3PUA Ä	Datum	Schaltteillis		Sachnummer	Blatt-Nr.
		Date	Parts list	for	Stock No.	Page
<b>⋘</b> ROHDE	&SCHWARZ	8 16.09.97	ED PROCESSOR		1062.6309.01	<b>SA</b> 7+

PROCESSOR

Kennz. Comp. No.	Benenni Designa	ung	Sachnummer Stock No.	Hersteller Manufacturer	Bezeichnung Dasignation	entheiten in contained in
R412	RG 47,5 OHM+-1	%TK 100 1206	RG 0007.5566.00		2 47,50HM 1%TK100	
R413	RESISTOR CHIP RG 47,5 DHM+-19	%TK100 1206	<b>!</b>	1	22 47,50HM 1%TK100	
R423	RESISTOR CHIP RG 10,OKOHM+-1; RG CHIP RESISTO		RG 0007.0793.00	ROEDERSTEI DO	2 10,0KOHM 1%TK100	
R424	RG 10,0KOHM+-1	%TK 100 1206	RG 0007.0793.00	ROEDERSTEI DO	2 10,0KOHM 1%TK 100	
R427	RG CHIP RESISTOR RG 10,0K0HM+-19	%TK100 1206	RG 0007.0793.00	ROEDERSTEI DO	2 10,0KOHM 1%TK100	
R428	RG 10,0KOHM+-1;	%TK100 1206	RG 0007.0793.00	RDEDERSTEI DO	2 10,0KOHM 1%TK100	
R430	RG 10,0KOHM+-1%	%TK 100 1206	RG 0007.0793.00	RDEDERSTEI DO	2 10,0KOHM 1%TK100	
R450	RS 0,25W200 OHM		RS 0007.9590.00	SIEMENS S4	G-200 OHM	
R451	RG 909 OHM+-1%1 CHIP RESISTOR	TK 100 1206	RG 0006.7265.00	ROEDERSTEI DO	2 9090HM 1%TK 100	
R460	RG 221 OHM+-1%1 RESISTOR CHIP	TK 100 1206	RG 0007.5614.00	ROEDERSTEI DC	2 2210HM 1%TK100	
R461	RG 221 OHM+-1%T	TK 100 1206	RG 0007.5614.00	ROEDERSTEI DC	2 2210HM 1%TK100	
R462	RESISTDR CHIP RG 2,74KOHM+-1%	ATK 100 1206	RG 0007.5766.00	RDEDERSTEI DC	2 2,74KOHM 1%TK100	
R463	RESISTOR CHIP RG 2,74KOHM+-1% RESISTOR CHIP	%TK100 1206	RG 0007.5766.00	RDEDERSTEI DC	2 2,74KDHM 1%TK100	
R469	RG 301 OHM+-1%T	TK 100 1206	RG 0007.5643.00	ROEDERSTEI DC	2 301DHM 1%TK100	
R470	RESISTOR CHIP RG 47,5 OHM+-1%	4TK 100 1206	RG 0007.5566.00	ROEDERSTEI DC	2 47,5DHM 1%TK100	
R471	RESISTDR CHIP RG 47,5 OHM+-1% RESISTOR CHIP	TK 100 1206	RG 0007.5566.00	ROEDERSTEI DC	2 47,50HM 1%TK100	
R472	RG 10,0KOHM+-1%		RG 0007.0793.00	ROEDERSTEI DC	2 10,0KOHM 1%TK100	
R473	RG 10,0KOHM+-1% RG CHIP RESISTO	TK 100 1206	RG 0007.0793.00	ROEDERSTEI OC:	2 10,0KOHM 1%TK100	
R474	RG 100 OHM+-1%T CHIP RESISTOR	· ·	RG 0006.8884.00	ROEDERSTEI DC	2 1000HM 1%TK100	
R475	RG 301 OHM+-1%T RESISTOR CHIP	K 100 1206	RG 0007.5643.00	ROEDERSTEI DC	2 3010HM 1%TK100	
R480	RG 332 OHM+-1%T	K 100 1206	RG 0007.5650.00	ROEDERSTEI DC	2 3320HM 1%TK100	
R481	RG 243 OHM+-1%TH	K 100 1206	RG 0007.5620.00	ROEDERSTEI DC	2 2430HM 1%TK100	
R482	RG 681 OHM+-1%TH	K 100 1206	RG 0006.9080.00	ROEDERSTEI DC2	2 6810HM 1%TK100	
R485	RG 10,0K0HM+-1% RG CHIP RESISTO	TK 100 1206	RG 0007.0793.00	ROEDERSTEI DC2	2 10,0KOHM 1%TK100	
R486	RG 10,0KOHM+-1% RG CHIP RESISTO	TK 100 1206	RG 0007.0793.00	ROEDERSTEI DC2	2 10,0KOHM 1%TK 100	
R490	RG 1,0 KO +-1%TI CHIP RESISTOR		RG 0006.7271.00	RDEDERSTEI DC2	2 1,0KOHM 1%TK100	
R491	RG 1,82KOHM+-1% RESISTOR CHIP	TK 100 1206	RG 0007.5720.00	ROEDERSTEI DC2	2 1,82KOHM 1%TK100	
R500	RL 0,35W1,10KOH	M+~0,1%T25	RL 0083.9223.00	DRALORIC SMA	0207	
R504	RL 0,35W1,10KOH RESISTOR	-,	RL 0083.9223.00		0207	
R505	RG 4,75KOHM+-1% RESISTOR CHIP		RG 0007.5820.00	ROEDERSTEI DC2	4,75KDHM 1%TK100	
R505	NUR VAR/ONLY MDI RG 10,0KOHM+-1% RG CHIP RESISTOR	TK 100 1206 R	RG 0007.0793.00	ROEDERSTEI DC2	10,0K0HM 1%TK100	
R506	NUR VAR/ONLY MDI RG 200 KOHM+-1%1		RG 0007.5995.00	ROEDERSTEI DC2	200KOHM 1%TK 100	
R515	RESISTOR CHIP RG 4,75KOHM+-1%1	TK 100 1206	RG 0007.5820.00	RDEDERSTEI DC2	4,75KOHM 1%TK100	
DE 1E	RESISTOR CHIP NUR VAR/ONLY MOD		DC 0007 F0-5	DDEDERATE: -:-		
R515	RG 18,2KOHM+-1%T RESISTOR CHIP		KG 0007.5850.00	RUEUERSTEI DC2	18,2KOHM 1%TK100	
R520	NUR VAR/ONLY MOD RS 0,25W 2MOHM + PDTENTIOMETER		RS 0007.9710.00	SIEMENS S4G	-2MOHM	
R529	RG 1,0 KO +-1%TK CHIP RESISTOR	1	RG 0006.7271.00	ROEDERSTEI DC2	1,0KOHM 1%TK100	
:	NUR VAR/DNLY MOD	D: U2				
MENP5	413 3PUA	Äl Datum	Schaltteilli Parts Hs		Sachnummer Stock No.	Blatt-Nr.
PR.						Page
ROHDI	E&SCHWARZ	18 16.09.97	ED PROCESSOR		1062.6309.01	SA   8+
L			PRDCESSDR			

	Kennz. Comp. No.		Beneni Design			T	Sechaummer Stock No.	Hersteller Manufacturer		ezelchnung esignation		haiten In Iteined In
	R529		OHM+-15		100 1206	RG				1000HM 1%TK10D	СОЛ	vanias ių
	R530	NUR VA	ESISTOR R/ONLY M 50HM+-1% ESISTOR			RG	0007.8420.00	PHILIPS	RC	02		
	R530	NUR VA	R/ONLY N	RSTA	ND-CHIP	RG	0007.5108.00	DRALORIC	CR	1206		
	R531	RG 4,7	R/ONLY N 50HM+-1% ESISTOR	4TK 1	00 1206	RG	0007.8420.00	PHILIPS	RC	02		
	R531	RG O-O	R/ONLY N HM WIDER OR CHIP	STA O-0	ND-CHIP	RG	0007.5108.0D	DRALORIC	CR	1206	ļ Į	
	R532	RG 4,75	R/ONLY N 50HM+-1% ESISTOR			RG	0007.8420.00	PHILIPS	RC	02		
ı	R533	RG 4,75	50HM+-1% ESISTOR	TK 1	00 1206	RG	0007.8420.00	PHILIPS	RC (	02		
	R534	RG 1,0 CHIP RE	KO +-1% ESISTOR R/ONLY M			RG	0006.7271.00	ROEDERSTEI	DC2	1,0KOHM 1%TK100		
	R534	RG 619 CHIP RE	OHM+-1% ESISTOR R/ONLY M	TK 1	00 1206	RG	0006.9074.00	ROEDERSTEI	DC2	6190HM 1%TK100		
	R538	RG 1,0	KO +-1%			RG	0006.7271.00	ROEDERSTEI	DC2	1,0K0HM 1%TK100	,	
	R54D	RG 110,		%TK	100 1206	RG	0007.1954.00	ROEDERSTEI	DC2	110K0HM 1%TK100	,	
	R541		SISTOR M WIDER	STA	ND-CHIP	[	0007.5108.00			1206		
	R542	RESISTO	OR CHIP	0-0	HM			•		4750HM 1%TK 100		
ı	R543	RESISTO								6190HM 1%TK100		
ı		CHIP RE	SISTOR									
۱	R544	CHIP RE				KG	0815.7532.00	DRALURIC	CRC	1206		
i	R545		R/ONLY M OKOH+-1		02 100 1206	RG	0007.1948.00	ROEDERSTEI	DC2	100K0HM 1%TK100		1
l	R546	CHIP RE RL 0,60 RESISTO	W 10,0	OHM-	+-1%TK50		0082.8852.00		MK2			
	R547	NUR VAR RL 0,35 RESISTO	R/ONLY M SW33,6KO JR	HM+	-0, 1%T25	RL	0084.4077.00	RESISTA	MK2			
İ	R547					RL	0084.4031.00	RESISTA	MK2			
	R548	RL 0,35 RESISTO		M+-(	0,1%TK25	RL	0083.7889.00	RESISTA	MK2			h
	R548	RL 0,35 RESISTO	W158 OHI IR	M+-(	), 1%TK25	RL	0083.7608.00	RESISTA	MK2			
	R549	RL 0,25 RESISTO	IR .	HM+-	-0, 1%T25	RL	0084.2268.00	DRALORIC	SMA/	207/3,83K-8-E		
	R549	RL 0,35 RESISTO		-+MH	D, 1%T25	RL	0084.2551.00	RESISTA	MK2			
	R550	RS 0,25	W 5KOHM			RS	0007.9632.00	SIEMENS	S4G-	-5KOHM		i
	R551		KOHM+-13	%TK 1	100 1206	RG	0007.0735.00	ROEDERSTEI	DC2	5,62KOHM 1%TK10	0	
	R552		KOHM+-1	%TK 1	100 1206	RG	0007.0735.00	ROEDERSTEI	DC2	5,62KOHM 1%TK10	0	
	R553	CHIP RE RG 681	SISTOR OHM+-1%	TK 10						6810HM 1%TK 100		
	R555	CHIP RE RG 2,0		<b>%TK</b> 1						2,0K0HM 1%TK100	•	1
	R556	RESISTO	R CHIP							2,0KOHM 1%TK100		ļ
	R557	RESISTO	R CHIP							10,0KOHM 1%TK10		
	R558	RG CHÍP	RESIST	OR						10,0KOHM 1%TK10		j
			RESIST		.50 1200				J. V. Z.	10,000 IIII I/IIN IO		
L							er er er er er er er er er er er er er e	<u> </u>				
	MENP5	413	3PUA	ÄI	Datum Dete		Scheitteilli Parts lis			Sachnumme Stock No.		Slett-Nr. Page
	�			18	16.09.97	E	D PROCESSOR			1062.6309.0	1 SA	9+
	KOHDE	E&SCHV	MAKZ			P	ROCESSOR					

PROCESSOR

Kennz. Comp. No.	Bener			T	Sachnummer	Hersteller		Bezeichnung		heiten in
R559	RG 274 KOHM+~			RG	Stock No. 0007,4460.00	Manufacturer  ROEOERSTE		Designation 2 274KOHM 1%TK100		teined in
R560	RESISTOR CHIP RG 274 KOHM+-	•		1		1		2 274KOHM 1%TK100		
R561	RESISTOR CHIP RG 4,02KOH+-0	1		I NO		1				
R564	SMD-RESISTOR	EIA	1206		0009.7814.00	1		ļ		
	RG 33,2 OHM+- RESISTOR CHIP	1		IKG				2 33,20HM 1%TK100		
R566	RG 4,02KOH+-0 SMD-RESISTOR	EIA	1206		0009.7B14.00		CM	F 1206		
R567	RG 4,750HM+~1 CHIP-RESISTOR		100 1206	RG	0007.8420.00	PHILIPS	RC	02		
R568	RG 4,750HM+-1 CHIP-RESISTOR		100 1206	RG	0007.8420.00	PHILIPS	RC	02		
R570	RG 10,0KOHM+- RG CHIP RESIS	1%T	K100 1206	RG	0007.0793.00	ROEOERSTEI	DC	2 10,0KOHM 1%TK100		
R571	RG 1,0 KO +-1	%TK	100 1206	RG	0006.7271.00	ROEDERSTEI	DC	2 1,0K0HM 1%TK100		
R572	RG 1,0 KO +-19 CHIP RESISTOR	//TK	100 1206	RG	0006.7271.00	ROEDERSTEI	DC	2 1,0K0HM 1%TK100		
R575	RG 4,02KOH+-0	, 1%			0009.7814.00	MIKRO-TEK-	CM	F 1206		
R576	RG 4,02KOH+-0	, 1%	TK25 1206	į	0009.7814.00	MIKRO-TEK-	CMF	1206		
R577	SMD-RESISTOR ( RG 4,02KOH+-0	, 1%1	TK25 1206		0009.7814.00					
	SMD-RESISTOR	EIA'	1206							
V110	AE BZV55/C5V6 ZENER DIODE	(	).5W ZDI	AE	0006.9845.00	PHILIPS	BZ∖	/55B5V6		
V120	AD BAV99 DIODE	70\	DNO ADI	AD	0911.0092.00	VALVO	BAV	/99		
V205	AD BAS32 DIODE	<b>7</b> 5\	/ UDI	AD	0006.7288.00	PHILIPS	BAS	32 (L)		
V210	AK 8C8508 N	45	V 200MA	AK	0007.7969.00	VALVO	все	150B		
V220	TRANSISTOR AK 8C8508 N	45	V 200MA	AK	0007.7969.00	VALVO	BC8	508		
V462	TRANSISTOR AE 8ZV55/C12	o	,5W ZDI	ΑE	0006.9897.00	PHILIPS_SE	8ZV	755B12		
V463	ZENER OIODE AE 8ZV55/C6V8	O	,5W ZDI		0006.9868.00			55/86V8		
V470	ZENER OIOOE AK 8SR18 P	40	V 200MA		0007.2073.00					
V471	TRANSISTOR AE HSMS2800				0836.8421.00					
V475	OIODE AK 8SR13 N				0007.2209.00			13		
V476	TRANSISTOR AE HSMS2800				0836.8421.00		_			
V4BO	DIOOE		OV MOSE							
V540	MOS-FET				OB44.7637.00			10DE		
	DIODE				0911.0092.00		BAV			
V550	AE BZV55/C5V6 ZENER DIODE		1		0006.9845.00		8ZV	55B5V6		
V551	AE BZV55/C4V7 ZENER OIODE	0	.5W ZDI	AE	0006.9822.00	PHILIPS	BZV:	55B4V7		
X1	FP STECKERLEIS	TE	26P.GER	FP (	0820.8610.00	SIEMENS	V23	535 <b>-</b> A2200-A262		İ
X2	CONNECTOR 26P. FP STECKERLEIS				0820.B610.00			535-A2200-A262		
хз	CONNECTOR 26P. FP STECKERLEIS		_		0351.3474.00			535-A2200-A342		İ
X104	CONNECTOR 34P FP STIFTLEISTE				0242.3600.00					
	PIN CONNECTOR 2-POLIG/2 PINS		,57			DIRDER	142	-11-0179-00-36		
Х10В	VL STECKLOETOE	SE '		VL (	007B.2747.00	-	R&S	-ZCHNG.07B.2747		
X 109	PLUG-IN SOLDER VL STECKLOETOE	SE :	7,5X1,1	VL (	0078.2747.00	-	R&S	-ZCHNG.078.2747		
X225	PLUG-IN SOLDER	36I		FP (	0242.3600.00	BINDER	742	-11-0179-00-36		
V	PIN CONNECTOR 2-POLIG/2 PINS									ŀ
X401	FP STIFTLEISTE PIN CONNECTOR		P.R2,54	FP (	0242.3600.00	BINDER	742-	-11-0179-00-36		
	2-POLIG/2 PINS									
MENP5	413 3PUA	ÄI	Datum		Schalttellii		7	Sachnummer		Blett-Nr.
		<del>                                     </del>	Dete		Perts list	TOP	-	Stock No.		Page
<b>®</b>   <b>®</b>	&SCHWARZ	18	16.09.97	E	PROCESSOR			1062.6309.01	SA	10+
110712	- CONTENTAL			PI	ROCESSOR		-			l

£	
alten	
	VOC
ģ	>
۵	9
8	Rechte
2	8
ferta	Œ
2	0
ŝ	8118
_	
9	Uns
gesog	=
7	W
_	3
ĕ	

Kennz. Comp. No.		Benennung Designation			Sachnummer Stock No.	Hersteller Menufacturer	9ezeichnung Designation	enth	elten in elned in
X501	FP STIFTL ANGLE PIN		. R2,54 OR	FP	0243.3578.00		742-5-11-0187-00-36	5071	M M
MENP5	413 3F		Datum Date 16.09.97	Ei	Schalttellilis Parts list D PROCESSOR	ite für for	Sechnummer Stock No. 1062.6309.01	SA	Slett-Nr Page

PROCESSOR



# XY-Liste

# **XY List**

#### Erklärung der Spaltenbezeichnungen:

Part: Bauelement-Kennzeichen.

Side: Leiterplatten-Seite, auf der sich das Bauelement befindet.

XY: Koordinaten (Millimeter) des Bauelementes auf der Leiterplatte

bezogen auf den Nullpunkt.

SQR, PG: Planquadrat und Seite des Schaltbildes für das jeweilige Bauelement.

#### Explanation of column designations:

Part: Identification of instrument part.

Side: Side of the PC board on which instrument part is positioned.

XY: Coordinates (millimeter) of the component on the PC board in reference

to zero point.

SQR, PG: Square and page of the diagram for the respective instrument part.

		Se	rvic	e-Rei	leva	nte Ba	ıtei	le /	Ser	vice-	-Rel	evant (	Compo	onen	ts		
Part	Side	X	Y	Sqr	Рg	Part	Side	∋ X	Y	Sqr	Pg	Part	Side	× X	Y	Sqr	Pg
P100	В	172	51	4E	2	R102	В	184	60	4E	2	X104	В	158	69	5F	2
P100	В	172	51	3E	1	R102	В	1B4	60	3F	1	X104	В	158	69	5F	1
P101	В	175	34	5F	2	R139	В	90	75	3C	2	X108	В	25	92	3C	2
P101	В	175	34	3F	1	R139	В	90	75	3C	1	X108	В	25	92	3C	1
P305	В	31	46	8E	4	R450	В	272	73	8D	5	X109	В	25	57	3B	2
P405.	В	266	71	8E	5	R520	В	286	41	7E	6	X109	В	25	57	3B	1
P406	В	264	71	8F	5	R550	В	248	23	4B	6	X225	В	44	53	8D	3
P409	В	261	71	11D	5	X1	В	51	8	2E	4	X401	В	199	108	4E	5
P510	В	298	53	6E	6	Х2	В	83	107	11D	3	X501	В	190	10	1D	6
P513	В	246	28	3C	6	х3	В	114	В	11B	2						
P530	В	287	36	8E	6	хз	В	114	8	2A	1						

ROHDE	—I	Datum Date		ste frr st for	Sach-Nummer Stock-Nr	Blatt Page
SCHWARZ		02.11.93	ED RECHNER PROCESSOR		1062.6309.01 XY	1+



Part Side X	N	Nicht-Service-Relevante Bauteile / Non-Servi									 vice	-Relev	ant Comp	onen	ts	
BA010 B 158 67 5F 1 1 0174 B 136 19 11C 1 C330 B 72 20 3C 4 C10 B 97 30 2B 2 C185 A 182 48 6A 2 C331 B 74 20 3C 4 C10 B 97 30 2B 1 C186 A 178 39 6A 1 C332 B 77 20 3C 4 C10 A 116 19 2E 2 C186 A 178 39 6A 1 C334 B B 22 0 3C 4 C10 A 116 19 2E 1 C187 A 106 31 8A 2 C340 B 14 31 7E 4 C110 A 110 19 2D 1 C188 A 184 31 8A 1 C340 B 14 31 7E 4 C110 A 110 19 2D 1 C188 A 183 66 8A 2 C402 B 194 79 2E 5 C111 A 182 40 2E 1 C187 A 106 31 8A 2 C400 B 14 31 7E 4 C111 A 182 40 2E 1 C189 A 154 38 7A 1 C400 B 202 77 2D 5 C111 A 182 40 2E 1 C189 A 154 38 7A 2 C406 B 202 77 2D 5 C112 B 171 27 2B 1 C189 A 154 38 7A 2 C406 B 202 77 2D 5 C113 B 180 27 2A 2 C189 A 154 38 7A 1 C409 A 225 73 4A 5 C113 B 180 27 2A 2 C180 A 114 57 6A 2 C417 B 212 70 3C 5 C113 B 180 27 2A 1 C191 A 114 104 7A 2 C419 B 199 50 38 5 C114 A 114 25 3D 2 C191 A 114 104 7A 2 C419 B 199 50 38 5 C114 A 114 25 3D 1 C200 A 109 78 2A 3 C421 B 201 40 3E 5 C116 A 172 46 5A 2 C201 A 87 78 2A 3 C440 A 229 103 6A 5 C116 A 184 38 2 C400 B 144 31 E 2 C20 A 38 68 6A 3 C440 A 229 103 6A 5 C116 A 184 38 2 C20 A 38 68 6A 3 C440 A 229 103 6A 5 C116 A 184 38 2 C20 A 38 68 6A 3 C440 A 229 103 6A 5 C116 A 184 33 E 2 C200 A 80 77 7A 3 C421 B 201 40 3E 5 C116 A 184 34 3E 2 C200 A 80 77 7A 3 C440 A 229 103 6A 5 C118 A 184 43 3E 2 C200 A 80 77 7A 3 C451 B 288 7E 5 C120 A 140 19 2C 2 C211 A 80 77 7A 3 C451 B 263 76 7D 5 C120 A 140 19 2C 2 C210 A 80 77 7A 3 C451 B 263 76 7D 5 C120 A 140 19 2C 2 C210 A 80 77 7A 3 C451 B 263 76 7D 5 C120 A 140 19 2C 2 C210 A 80 77 7A 3 C451 B 263 76 7D 5 C121 A 153 19 3C 2 C222 A 56 65 7E 3 C460 B 278 98 75 5 C122 A 153 19 3C 2 C223 B 193 36 2E 3 C444 A 200 17 5 C5 C223 B 180 5 74 8 2 C223 B 133 34 2E 3 C444 A 200 17 5 C5 C223 B 139 36 2E 3 C444 A 300 75 9C 5 C122 A 153 19 3C 2 C223 B 133 34 2E 3 C444 A 200 75 9C 5 C122 A 153 19 3C 2 C223 B 140 27 2E 3 C444 A 300 75 9C 5 C122 A 153 19 3C 2 C223 B 130 3 C452 B 276 5D 5 C122 A 153 19 3C 2 C223 B 130 3 C452 B 276 5D 5 C122 A 153 19 3C 2 C223 B 130 3 C452 B 276 5D 3 C466 B 257 79 8E 5 C123 A 153 22 3C 2 C233 B 133 3	Part	Side X	Y	Sqr	Pg	Part	sid	e X	Y	Sqr	Pg	Part	Side X	Y	Sqr	Pg
BA01   B 199   88   85   5   C185   A 182   48   6A   2   C331   B 74   20   3C   4   C100   B 97   30   28   1   C186   A 178   39   6A   2   C332   B 77   20   3C   4   C100   A 116   19   2E   1   C187   A 106   31   8A   2   C333   B 79   20   3C   4   C110   A 110   19   2E   1   C187   A 106   31   8A   1   C400   B 206   70   3D   5   C1110   A 110   19   2D   1   C187   A 106   31   8A   1   C400   B 206   70   3D   5   C1111   A 182   40   2E   2   C188   A 138   66   8A   2   C402   B 194   79   2E   C1111   A 182   40   2E   2   C188   A 138   66   8A   1   C400   B 206   70   3D   5   C1111   A 182   40   2E   1   C187   A 106   31   8A   1   C400   B 206   70   3D   5   C1112   B 171   27   2B   2   C189   A 154   3B   7A   1   C400   B 206   70   3D   5   C112   B 171   27   2B   2   C189   A 154   3B   7A   1   C400   A 122   C7   2D   5   C112   B 171   27   2B   1   C190   A 114   57   6A   2   C406   B 211   76   2D   5   C113   B 180   27   2A   2   C190   A 114   57   6A   2   C417   B 212   70   3C   5   C114   A 114   25   3D   2   C191   A 114   104   7A   2   C419   B 199   50   3B   5   C114   A 114   25   3D   2   C191   A 114   104   7A   2   C419   B 199   50   3B   5   C114   A 114   25   3D   2   C191   A 114   104   7A   2   C419   B 199   50   3B   5   C115   A 172   46   5A   2   C203   A 38   68   6A   3   C420   A 229   103   6A   5   C116   A 163   43   5A   2   C203   A 38   68   6A   3   C420   A 229   103   6A   5   C116   A 163   43   5A   2   C203   A 38   68   6A   3   C440   A 120   91   7A   5   C116   A 164   A 138   A 2   C205   A 93   84   6A   3   C440   A 140   92   C2   C201   A 80   80   80   A 3   C440   A 140   92   C2   C211   A 80   39   84   6A   3   C440   A 140   92   C2   C211   A 80   39   84   6A   3   C440   A 140   92   C2   C211   A 80   39   6A   5   C440   A 220   91   7A   5   C122   A 140   19   2C   2   C210   A 80   A 80   39   84   6A   3   C440   A 140   92   C1   C220   A 140   19   C220   C210   A 80   A 80   A 80   A 80   A 80   A 80	B100	B 15E	3 6	7 5F	2	C174	В	136	19	11C	2	C327	A 86	23	3C	4
C110 B 97 30 2B 1 C185 A 182 4B 6A 1 C332 B 77 20 3C 4 C100 A 116 19 2E 1 C186 A 178 39 6A 1 C334 B 82 20 3C 4 C100 A 116 19 2E 2 C166 A 178 39 6A 1 C334 B 82 20 3C 4 C100 A 116 19 2E 2 C187 A 106 31 8A 1 C334 B 82 20 3C 4 C110 A 110 19 2D 2 C187 A 106 31 8A 1 C334 B 82 20 3C 4 C110 A 110 19 2D 1 C188 A 138 66 8A 2 C340 B 14 31 7E 4 C111 A 182 40 2E 1 C189 A 184 87 A 2 C406 B 202 77 2D 5 C111 A 182 40 2E 1 C189 A 184 87 A 2 C406 B 202 77 2D 5 C111 A 182 40 2E 1 C189 A 184 87 A 2 C406 B 211 76 2D 5 C112 B 171 27 2B 1 C190 A 114 57 6A 2 C417 B 212 70 3C 5 C113 B 180 27 2A 2 C190 A 114 57 6A 1 C418 B 201 46 3C 5 C113 B 180 27 2A 1 C191 A 114 104 7A 2 C419 B 199 50 3B 5 C114 A 114 25 3D 2 C191 A 114 104 7A 1 C420 B 204 95 5A 5 C116 A 163 43 5A 2 C200 A 109 78 2A 3 C421 B 201 40 3B 5 C116 A 163 43 5A 2 C200 A 109 78 2A 3 C440 A 209 17A 5 C116 A 163 43 5A 2 C200 A 38 68 6A 3 C440 A 209 17A 5 C118 B 171 27 2B 1 C204 B 73 84 6A 3 C440 A 209 17A 5 C116 A 163 43 5A 2 C203 A 38 68 6A 3 C440 A 209 17A 5 C116 A 163 43 5A 2 C203 A 38 68 6A 3 C440 A 209 17A 5 C116 A 163 43 5A 2 C203 A 38 68 6A 3 C440 A 209 17A 5 C118 B 184 43 3E 2 C205 A 93 84 6B A 3 C440 A 209 17A 5 C118 B 184 43 3E 2 C205 A 93 84 6B A 3 C440 A 209 17A 5 C118 B 171 69 4E 2 C210 A 80 77 7A 3 C451 B 263 76 7D 5 C120 A 140 19 2C 2 C211 A 80 77 7A 3 C451 B 263 76 7D 5 C120 A 140 19 2C 2 C211 A 88 39 8A 3 C449 A 106 92 3F 5 C121 A 153 19 3C 2 C204 B 73 84 6B 3 3 C449 A 209 17 7A 5 C121 A 140 22 3C 2 C203 B 139 36 2E 3 C454 B 264 79 8E 5 C121 A 153 19 3C 2 C220 A 54 65 7E 3 C452 B 276 B 278 5 C122 A 153 19 3C 2 C203 B 139 36 2E 3 C454 B 264 79 8E 5 C122 A 153 19 3C 2 C203 B 133 36 2E 3 C454 B 264 79 8E 5 C122 A 153 19 3C 2 C203 B 133 36 2E 3 C454 B 263 76 7D 5 C122 A 153 19 3C 2 C203 B 133 36 2E 3 C454 B 264 79 8E 5 C122 A 153 19 3C 2 C203 B 133 36 2E 3 C454 B 264 79 8E 5 C122 A 153 19 3C 2 C203 B 133 36 2E 3 C454 B 264 79 8E 5 C122 A 153 19 3C 2 C204 B 78 6 C7 2 C204 B 78 6 C7 2 C205 B 276 C7 2 C205 B 276 C7 2 C205 B 276 C7 2 C205 B 276 C7 2 C205 B 276 C7 2 C205												E .	B 72	20	3C	4
C110	1					1										-
C100	1															
C1100												1				
C110	ī					1						1				-
C1110 A 110 19 2D 1 C188 A 138 66 8A 2 C402 B 194 79 2E 5 C111 A 182 40 2E 1 C1BP A 13B 66 8A 1 C404 B 202 77 2D 5 C111 A 182 40 2E 1 C189 A 154 38 7A 1 C409 A 225 73 4A 5 C1112 B 171 27 2B 1 C190 A 114 57 6A 1 C404 B 202 77 2D 5 C112 B 171 27 2B 1 C190 A 114 57 6A 1 C409 A 225 73 4A 5 C112 B 171 27 2B 1 C191 A 114 104 7A 1 C409 A 225 73 4A 5 C113 B 180 27 2A 1 C191 A 114 104 7A 2 C417 B 212 70 3C 5 C113 B 180 27 2A 1 C191 A 114 104 7A 1 C420 B 204 99 50 3B 5 C114 A 114 25 3D 2 C191 A 114 104 7A 1 C420 B 204 99 5A 5 C114 A 114 25 3D 1 C200 A 109 78 2A 3 C421 B 201 40 3B 5 C115 A 172 46 5A 2 C201 A 87 8B 4A 3 C430 A 229 103 6A 5 C116 A 163 43 5A 2 C201 A 87 8B 4A 3 C430 A 229 103 6A 5 C116 A 163 43 5A 2 C204 B 73 84 6A 3 C440 A 230 91 7A 5 C118 A 184 43 3E 2 C205 A 93 84 5D 3 C452 B 268 88 7E 5 C120 A 140 19 2C 1 C220 A 80 77 7A 3 C451 B 263 76 7D 5 C120 A 140 19 2C 1 C220 A 80 77 7A 3 C451 B 267 6B 27 A 5 C121 A 140 22 3C 2 C230 B 139 36 2E 3 C452 B 276 B2 7A 5 C121 A 140 22 3C 1 C231 B 139 34 2E 3 C452 B 276 B2 7A 5 C122 A 153 19 3C 2 C232 B 139 36 2E 3 C454 B 264 79 8E 5 C122 A 153 19 3C 2 C232 B 139 36 2E 3 C452 B 276 B2 7A 5 C122 A 153 19 3C 1 C231 B 139 34 2E 3 C452 B 276 B2 7A 5 C122 A 153 19 3C 1 C231 B 139 34 2E 3 C452 B 276 B2 7A 5 C122 A 153 19 3C 1 C231 B 139 34 2E 3 C452 B 276 B2 7A 5 C122 A 153 19 3C 1 C231 B 133 9 34 2E 3 C452 B 276 B2 7A 5 C122 A 153 19 3C 1 C233 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 1 C235 A 105 25 2D 3 C460 B 275 79 8E 5 C123 A 153 22 3C 1 C233 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 1 C235 A 105 25 2D 3 C472 A 293 72 10C 5 C139 A 123 22 2C C 1 C302 B 98 11 3E 4 C481 B 268 80 10 5 5 C139 A 123 22 2C C 1 C302 B 98 11 3E 4 C481 B 268 80 10 5 C144 B 120 32 6F 1 C314 A 95 20 3D 4 C492 B 277 79 0 8A 5 C144 B 120 32 6F 1 C310 A 74 27 1A 4 C500 B 277 79 0 8A 5 C144 B 120 32 6F 1 C310 A 74 27 1A 4 C500 B 277 79 0 8A 5 C144 B 120 32 6F 1 C310 A 74 27 1A 4 C500 B 277 79 0 8A 5 C144 B 120 32 6F 1 C310 A 74 27 1A 4 C500 B 277 79 0 8A 5 C144 B 120 32 6F 1 C310 A 74 2												1				
C111 A 182 40 2E 2 C189 A 134 66 8A 1 C404 B 202 77 2D 5 C112 B 171 27 2B 2 C189 A 154 38 7A 2 C406 B 211 76 2D 5 C112 B 171 27 2B 1 C190 A 114 57 6A 2 C417 B 212 70 3C 5 C113 B 180 27 2A 1 C191 A 114 104 7A 2 C419 B 199 50 3B 5 C114 A 114 25 3D 2 C191 A 114 104 7A 2 C419 B 199 50 3B 5 C114 A 114 25 3D 1 C200 A 109 78 2A 3 C421 B 201 46 3C 5 C114 A 114 25 3D 1 C200 A 109 78 2A 3 C421 B 201 40 3B 5 C115 A 172 46 5A 2 C201 A 87 8B 4A 3 C421 B 201 40 3B 5 C116 A 163 43 5A 2 C203 A 38 68 6A 3 C440 A 230 91 7A 5 C117 A 172 39 5A 2 C204 B 73 84 6A 3 C440 A 230 91 7A 5 C118 A 184 43 3E 2 C205 A 93 84 5D 3 C450 B 258 98 7E 5 C119 B 171 69 4E 2 C210 A 80 77 7A 3 C451 B 263 76 7D 5 C120 A 140 19 2C 2 C211 A 88 39 8A 3 C452 B 276 62 7A 5 C121 A 140 22 3C 2 C231 B 180 37 42 8 3 C454 B 264 79 8E 5 C121 A 140 22 3C 2 C231 B 139 36 2E 3 C454 B 264 79 8E 5 C122 A 153 19 3C 1 C232 B 140 27 2E 3 C461 B 283 76 8D 5 C122 A 153 19 3C 1 C232 B 140 27 2E 3 C461 B 283 76 8D 5 C122 A 153 19 3C 1 C232 B 139 34 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 1 C233 B 139 34 2E 3 C460 B 275 79 8E 5 C123 A 153 22 3C 1 C232 B 140 27 2E 3 C461 B 283 76 8D 5 C123 A 153 22 3C 1 C235 A 105 22 2D 3 C474 A 300 75 9C 5 C123 A 153 22 3C 1 C235 A 105 22 2D 3 C474 A 300 75 9C 5 C123 A 153 22 3C 1 C236 A 105 22 2D 3 C474 A 300 75 9C 5 C123 A 153 22 3C 1 C236 A 105 25 2D 3 C475 B 268 81 10D 5 C124 A 156 79 6E 1 C306 A 95 22 D 4 C490 B 251 101 11E 5 C140 A 159 B2 5E 1 C304 A 95 22 D 4 C490 B 251 101 11E 5 C144 B 120 32 6F 2 C310 A 74 27 1A 4 C500 B 275 79 08 5 C144 B 120 32 6F 2 C310 A 74 27 1A 4 C500 B 245 55 56 6 C145 B 128 32 6F 2 C310 A 74 27 1A 4 C500 B 275 79 08 5 C144 B 120 32 6F 1 C314 A 95 22 D 4 C490 B 251 101 11E 6 C144 B 120 32 6F 1 C316 A 23 37 7A 4 C500 B 229 55 5E 6 C145 B 128 32 6F 2 C316 A 74 27 1A 4 C500 B 229 55 5E 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C500 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C500 B 279 33 8D 6 C147 A 132 104 9E 2 C316 A 23 37 7A 4 C500 B 229 55 5E 6 C145 B 128 32 6F 2 C316 A 23 37 7A 4 C500 B 229 55 5E 6 C1	1					1						ł				
C112 B 171 27 2B 2 C189 A 154 3B 7A 1 C409 A 225 73 4A 5 C112 B 171 27 2B 1 C190 A 114 57 6A 2 C417 B 212 70 3C 5 C113 B 180 27 2A 1 C191 A 114 104 7A 2 C419 B 199 50 3B 5 C114 A 114 25 3D 2 C191 A 114 104 7A 2 C419 B 199 50 3B 5 C114 A 114 25 3D 1 C200 A 109 78 2A 3 C421 B 201 46 3C 5 C114 A 114 25 3D 1 C200 A 109 78 2A 3 C421 B 201 40 3B 5 C115 A 172 46 5A 2 C201 A 87 B8 4A 3 C421 B 201 40 3B 5 C116 A 163 43 5A 2 C203 A 38 68 6A 3 C440 A 230 91 7A 5 C116 A 163 43 5A 2 C203 A 38 68 6A 3 C440 A 230 91 7A 5 C118 A 184 43 3E 2 C205 A 93 84 5D 3 C450 B 258 98 7E 5 C119 B 171 69 4E 2 C210 A 80 77 7A 3 C451 B 263 76 7D 5 C120 A 140 19 2C 2 C211 A 88 39 8A 3 C452 B 276 E2 7A 5 C120 A 140 19 2C 1 C220 A 54 65 7E 3 C453 B 264 85 8A 5 C121 A 140 22 3C 2 C230 B 139 36 2E 3 C454 B 264 79 8E 5 C121 A 140 22 3C 1 C231 B 139 36 2E 3 C450 B 258 98 7E 5 C122 A 153 19 3C 1 C233 B 133 36 2E 3 C450 B 258 77 9 8E 5 C122 A 153 19 3C 1 C233 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 1 C231 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 1 C232 A 153 39 3C 1 C233 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 1 C232 A 153 39 3C 1 C235 A 105 25 2D 3 C474 A 300 75 9C 5 C123 A 153 22 3C 1 C331 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 1 C331 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 1 C334 B 133 34 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 1 C336 A 105 25 2D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C366 A 105 25 2D 3 C474 A 300 75 9C 5 C123 A 153 22 3C 1 C331 B 133 36 2E 3 C472 A 293 72 10C 5 C134 A 153 22 3C 1 C331 B 133 34 2E 3 C472 A 293 72 10C 5 C134 A 154 B 128 2 C473 B 266 B 267 76 10D 5 C134 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1 C304 A 159 B 25 E 1	C111	A 182	4	0 2E	2	C1BB	A	13B	66	8A						
C112 B 171 27 2B 1 C190 A 114 57 6A 2 C417 B 212 70 3C 5 5 C113 B 180 27 2A 2 C190 A 114 57 6A 1 C418 B 201 46 3C 5 5 C114 A 114 25 3D 2 C191 A 114 104 7A 1 C420 B 204 99 5A 5 C114 A 114 125 3D 1 C191 A 114 104 7A 1 C420 B 204 99 5A 5 C114 A 114 125 3D 1 C200 A 109 78 2A 3 C421 B 201 40 3B 5 C115 A 172 46 5A 2 C201 A 87 88 4A 3 C430 A 229 103 6A 5 C116 A 163 43 5A 2 C200 A 187 88 6A 3 C440 A 230 91 7A 5 C117 A 172 39 5A 2 C204 B 73 84 6A 3 C440 A 230 91 7A 5 C118 A 184 43 3E 2 C205 A 93 84 5D 3 C450 B 204 A 196 92 3F 5 C119 B 171 69 4E 2 C210 A 80 77 7A 3 C451 B 263 76 7D 5 C120 A 140 19 2C 2 C211 A 88 39 8A 3 C450 B 258 98 7E 5 C120 A 140 19 2C 2 C211 A 88 39 8A 3 C452 B 276 E2 7A 5 C121 A 140 22 3C 1 C220 B 139 36 2E 3 C454 B 264 85 8A 5 C121 A 140 22 3C 1 C231 B 139 34 2E 3 C454 B 264 85 8A 5 C122 A 153 19 3C 2 C232 B 140 27 22 3 C421 A 140 27 2E 3 C452 B 276 E2 7A 5 C122 A 153 19 3C 2 C232 B 140 27 2E 3 C454 B 264 79 8E 5 C122 A 153 19 3C 2 C232 B 140 27 2E 3 C451 B 283 76 8D 5 C123 A 153 22 3C 2 C234 B 133 34 2E 3 C454 B 284 79 8E 5 C123 A 153 22 3C 1 C231 B 139 34 2E 3 C454 B 284 79 8E 5 C123 A 153 22 3C 1 C233 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 12 3C 1 C233 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 12 3C 1 C235 A 105 22 D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C236 A 105 22 D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C236 A 105 22 D 3 C474 A 300 75 9C 5 C139 A 123 22 2C 1 C300 A 95 22 D 3 C474 A 300 75 9C 5 C139 A 123 22 2C 2 C301 B 100 11 3E 4 C481 B 288 110D 5 C140 A 159 B2 5E 1 C302 B 98 11 3E 4 C481 B 288 110D 5 C140 A 159 B2 5E 1 C302 B 98 11 3E 4 C481 B 288 110D 5 C140 A 159 B2 5E 1 C305 A 95 22 D 3 C474 A 300 75 9C 5 C143 B 93 36 6F 2 C307 B 95 11 3D 4 C500 B 264 55 3E 6 C143 B 93 36 6F 2 C307 B 95 11 3D 4 C500 B 264 55 3E 6 C143 B 93 36 6F 2 C307 B 95 11 3D 4 C500 B 264 55 3E 6 C143 B 93 36 6F 2 C305 A 95 22 D 4 C492 B 277 90 BA 5 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 283 55 5E 6 C143 B 93 36 6F 2 C305 A 95 20 D 4 C492 B 277 90 BA 5 C144 B 120 32 6F 1 C314 A 156 79 6E 2 C305 A 9	1	A 182	4	0 2E		C189	A	154	38	7A	2	C406	В 211	76	2D	
C113 B 180 27 2A 2 C190 A 114 57 6A 1 C418 B 201 46 3C 5 C114 A 114 25 3D 2 C191 A 114 104 7A 1 C420 B 204 99 5A 5 C114 A 114 25 3D 1 C200 A 109 78 2A 3 C421 B 201 40 3B 5 C115 A 172 46 5A 2 C201 A 87 88 4A 3 C430 A 229 103 6A 5 C116 A 163 43 5A 2 C201 A 87 88 4A 3 C430 A 229 103 6A 5 C116 A 163 43 5A 2 C203 A 38 68 6A 3 C440 A 230 91 7A 5 C117 A 172 39 5A 2 C204 B 73 84 6A 3 C440 A 230 91 7A 5 C118 A 184 43 3B 2 C205 A 93 84 5D 3 C450 B 258 98 7E 5 C119 B 171 69 4E 2 C210 A 80 77 7A 3 C451 B 263 76 7D 5 C120 A 140 19 2C 1 C220 A 54 65 7E 3 C452 B 264 85 8A 5 C121 A 140 22 3C 2 C230 B 139 36 2E 3 C452 B 264 85 8A 5 C121 A 140 22 3C 1 C231 B 139 34 2E 3 C450 B 258 98 7E 5 C122 A 153 19 3C 1 C231 B 139 34 2E 3 C450 B 258 60 5 C122 A 153 19 3C 1 C231 B 133 36 2E 3 C454 B 264 79 8E 5 C122 A 153 19 3C 1 C231 B 133 36 2E 3 C452 B 266 B 27 78 8E 5 C123 A 153 22 3C 1 C234 B 133 34 2E 3 C450 B 258 80 10E 5 C123 A 153 22 3C 2 C234 B 133 34 2E 3 C454 B 269 00 10E 5 C125 A 180 57 4F 2 C236 A 105 25 2D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C366 A 105 25 2D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C366 A 105 25 2D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C366 A 105 25 2D 3 C475 B 280 93 9E 5 C140 A 159 B2 5E 1 C304 A 95 20 3D 4 C480 B 258 88 10D 5 C140 A 159 B2 5E 1 C304 A 95 20 3D 4 C480 B 258 88 10D 5 C140 A 159 B2 5E 1 C304 A 95 20 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 2 C305 A 95 25 3D 4 C490 B 261 101 11E 5 C144 B 120 32 6F 1 C314 A 95 20 3D 4 C490 B 261 101 11E 5 C144 B 120 32 6F 1 C314 A 95 20 3D 4 C490 B 261 101 11E 5 C144 B 120 32 6F 1 C315 A 23 47 6A 4 C501 B 277 90 8A 5 C144 B 120 32 6F 1 C315 A 180 57 4F 2 C303 A 101 20 3E 4 C485 B 257 76 10D 5 C144 B 120 32 6F 1 C315 A 180 57 4F 2 C303 A 101 20 3E 4 C485 B 257 76 10D 5 C144 B 120 32 6F 1 C315 A 180 57 4F 2 C303 A 101 20 3E 4 C485 B 257 76 10D 5 C144 B 120 32 6F 2 C303 A 151 4B 44 46 C501 B 287 76 10D 5 C144 B 120 32 6F 2 C303 A 105 22 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 2 C303 A 105 20 3D 4 C500 B 289 55 5E 6 C145 B 128 32 6F 2 C303 A 105 20 3D 4 C50	1					3			_	7A	1	C409	A 225	73	4A	5
C113 B 180 27 2A 1 C191 A 114 104 7A 2 C419 B 199 50 3B 5 C114 A 114 25 3D 2 C191 A 114 104 7A 1 C420 B 204 99 5A 5 C114 A 114 25 3D 1 C200 A 109 78 2A 3 C421 B 201 40 3B 5 C115 A 172 46 5A 2 C201 A 87 8B 4A 3 C420 A 229 103 6A 5 C116 A 163 43 5A 2 C203 A 38 68 6A 3 C440 A 230 91 7A 5 C117 A 172 39 5A 2 C204 B 73 84 6A 3 C440 A 230 91 7A 5 C118 A 184 43 3B 2 C205 A 93 84 5D 3 C450 B 258 98 75 5 C118 A 184 43 3B 2 C200 A 80 77 7A 3 C451 B 261 B 262 7A 5 C119 B 171 69 4E 2 C210 A 80 77 7A 3 C451 B 263 76 7D 5 C120 A 140 19 2C 2 C211 A 88 39 8A 3 C450 B 258 98 75 7D 5 C120 A 140 19 2C 1 C220 A 54 65 7E 3 C453 B 264 85 8A 5 C121 A 140 22 3C 2 C230 B 139 36 2E 3 C454 B 264 79 8E 5 C122 A 153 19 3C 2 C232 B 140 27 2E 3 C461 B 283 76 8D 5 C122 A 153 19 3C 1 C231 B 139 34 2E 3 C460 B 275 79 8E 5 C122 A 153 19 3C 1 C232 B 140 27 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 1 C233 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 1 C235 A 105 22 2D 3 C474 A 300 75 9C 5 C123 A 153 22 3C 1 C235 A 105 22 2D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C236 A 105 25 2D 3 C474 A 300 75 9C 5 C139 A 123 22 2C 2 C301 B 100 11 3E 4 C480 B 258 88 10D 5 C139 A 123 22 2C 1 C302 B 98 11 3 E 4 C481 B 258 81 10D 5 C140 A 159 82 5E 2 C305 A 95 22 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 1 C306 A 95 22 3D 4 C490 B 261 101 11E 5 C144 B 120 32 6F 1 C306 A 95 22 3D 4 C490 B 261 101 11E 5 C144 B 120 32 6F 1 C305 A 95 22 3D 4 C490 B 261 101 11E 5 C144 B 120 32 6F 1 C305 A 95 22 3D 4 C490 B 261 101 11E 5 C144 B 120 32 6F 1 C305 A 95 22 3D 4 C490 B 261 101 11E 5 C144 B 120 32 6F 1 C306 A 95 25 3D 4 C490 B 261 101 11E 5 C144 B 120 32 6F 1 C306 A 95 22 3D 4 C490 B 261 101 11E 5 C144 B 120 32 6F 1 C305 A 95 22 3D 4 C490 B 261 101 11E 5 C144 B 120 32 6F 1 C306 A 95 22 3D 4 C490 B 261 101 11E 5 C144 B 120 32 6F 1 C306 A 95 22 3D 4 C490 B 261 101 11E 5 C144 B 120 32 6F 1 C306 A 95 22 3D 4 C490 B 261 101 11E 5 C144 B 120 32 6F 1 C306 A 95 22 3D 4 C480 B 289 40 7E 6 C144 B 120 32 6F 2 C305 A 95 22 3D 4 C480 B 287 55 5E 6 C145 B 128 32 6F 1 C334 A 82 4 C48 B	1														3C	5
C114						1						j .				
C114 A 114 25 3D 1 C200 A 109 78 2A 3 C421 B 201 40 3B 5 C115 A 172 46 5A 2 C201 A 87 B8 4A 3 C430 A 229 103 6A 5 C116 A 163 43 5A 2 C203 A 38 68 6A 3 C440 A 230 91 7A 5 C117 A 172 39 5A 2 C204 B 73 84 6A 3 C440 A 230 91 7A 5 C118 A 184 43 3E 2 C205 A 93 84 5D 3 C450 B 258 98 7E 5 C119 B 171 69 4E 2 C210 A 80 77 7A 3 C451 B 263 76 7D 5 C120 A 140 19 2C 1 C220 A 54 65 7E 3 C451 B 263 76 7D 5 C120 A 140 19 2C 1 C220 A 54 65 7E 3 C452 B 276 B2 7A 5 C121 A 140 22 3C 2 C230 B 139 36 2E 3 C454 B 264 79 8E 5 C121 A 140 22 3C 2 C230 B 139 36 2E 3 C454 B 264 79 8E 5 C122 A 153 19 3C 1 C231 B 139 34 2E 3 C460 B 275 79 8E 5 C122 A 153 19 3C 1 C231 B 139 34 2E 3 C460 B 275 79 8E 5 C122 A 153 19 3C 1 C233 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 12 3C 1 C233 B 133 34 2E 3 C473 B 286 90 10E 5 C123 A 153 22 3C 1 C234 B 105 22 2D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C236 A 105 25 2D 3 C474 B 280 93 9E 5 C123 A 153 22 3C 1 C235 A 105 22 2D 3 C474 B 280 93 9E 5 C123 A 153 22 3C 1 C235 A 105 22 2D 3 C474 B 280 93 9E 5 C123 A 153 22 3C 1 C345 B 105 22 2D 3 C474 B 288 81 10D 5 C139 A 123 22 2C 1 C301 B 100 11 3E 4 C480 B 258 88 10D 5 C139 A 123 22 2C 1 C302 B 98 11 3E 4 C480 B 258 88 10D 5 C140 A 159 82 5E 2 C305 A 95 22 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C490 B 261 101 11E 5 C144 B 120 32 6F 1 C301 A 74 27 1A 4 C500 B 246 85 8A 5 C144 B 120 32 6F 1 C301 A 74 27 1A 4 C500 B 246 85 8A 5 C144 B 120 32 6F 1 C301 A 74 27 1A 4 C500 B 246 85 8A 5 C144 B 120 32 6F 1 C301 A 74 27 1A 4 C500 B 246 85 8A 5 C144 B 120 32 6F 1 C301 A 74 27 1A 4 C500 B 246 85 8A 5 C144 B 120 32 6F 1 C301 A 74 27 1A 4 C500 B 246 85 8A 5 C144 B 120 32 6F 1 C301 A 74 27 1A 4 C500 B 246 85 8A 5 C144 B 120 32 6F 1 C301 A 74 27 1A 4 C500 B 240 77 6 C10 B 26 C144 B 120 32 6F 1 C301 A 74 27 1A 4 C500 B 240 7	I .					1						1				
C115						1						l .				
C116 A 163 43 5A 2 C203 A 38 68 6A 3 C440 A 230 91 7A 5 C117 A 172 39 5A 2 C204 B 73 84 6A 3 C449 A 196 92 3F 5 C118 A 184 43 3E 2 C205 A 93 84 6A 3 C450 B 258 96 7E 5 C119 B 171 69 4E 2 C210 A 80 77 7A 3 C451 B 263 76 7D 5 C120 A 140 19 2C 1 C211 A 88 39 8A 3 C452 B 276 B2 7A 5 C120 A 140 19 2C 1 C220 A 54 65 7E 3 C452 B 276 B2 7A 5 C120 A 140 19 2C 1 C220 A 54 65 7E 3 C453 B 264 85 8A 5 C121 A 140 22 3C 2 C230 B 139 36 2E 3 C454 B 264 79 8E 5 C121 A 140 22 3C 1 C231 B 139 34 2E 3 C450 B 275 79 8E 5 C122 A 153 19 3C 1 C231 B 140 27 2E 3 C460 B 275 79 8E 5 C122 A 153 19 3C 1 C231 B 140 27 2E 3 C473 B 286 90 10E 5 C123 A 153 22 3C 2 C234 B 133 34 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 1 C234 B 133 34 2E 3 C473 B 286 90 10E 5 C123 A 153 22 3C 1 C235 A 105 22 2D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C236 A 105 25 2D 3 C474 A 300 75 9C 5 C139 A 123 22 2C 1 C301 B 100 11 3E 4 C480 B 258 88 10D 5 C139 A 123 22 2C 1 C302 B 98 11 3E 4 C480 B 258 88 10D 5 C140 A 159 82 5E 2 C303 A 101 20 3E 4 C481 B 258 88 10D 5 C140 A 159 82 5E 2 C305 A 95 22 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 2 C305 A 95 22 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 2 C305 A 95 22 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 2 C305 A 95 22 3D 4 C490 B 261 55 3E 6 C143 B 93 36 6F 1 C308 B 67 23 3D 4 C490 B 261 55 5E 6 C144 B 120 32 6F 2 C310 A 74 27 1A 4 C502 B 277 50 8A 5 C143 B 93 36 6F 1 C308 B 67 23 3D 4 C500 B 246 55 3E 6 C144 B 120 32 6F 2 C310 A 74 27 1A 4 C502 B 277 50 4E 6 C144 B 120 32 6F 2 C310 A 74 27 1A 4 C502 B 277 50 4E 6 C144 B 120 32 6F 2 C310 A 74 27 1A 4 C502 B 277 50 4E 6 C144 B 120 32 6F 2 C310 A 74 27 1A 4 C502 B 277 50 4E 6 C144 B 120 32 6F 2 C310 A 74 27 1A 4 C502 B 277 50 4E 6 C144 B 120 32 6F 2 C312 A 44 26 3A 4 C500 B 289 40 7E 6 C144 B 120 32 6F 2 C312 A 44 26 3A 4 C500 B 289 30 55 5E 6 C145 B 128 32 6F 2 C314 B 82 4 50 4 C533 B 275 5 B 11E 6	1					4		_	-			1				
C117 A 172 39 5A 2 C204 B 73 84 6A 3 C449 A 196 92 3F 5 C118 A 184 43 3E 2 C205 A 93 84 5D 3 C450 B 258 98 7E 5 C119 B 171 69 4E 2 C210 A 80 77 7A 3 C451 B 263 76 7D 5 C120 A 140 19 2C 1 C220 A 54 65 7E 3 C452 B 276 B2 7A 5 C120 A 140 19 2C 1 C220 A 54 65 7E 3 C453 B 264 85 8A 5 C121 A 140 22 3C 2 C230 B 139 36 2E 3 C460 B 275 79 8E 5 C121 A 140 22 3C 1 C231 8 139 34 2E 3 C460 B 275 79 8E 5 C121 A 140 22 3C 1 C232 B 140 27 2E 3 C461 B 283 76 8D 5 C122 A 153 19 3C 1 C231 B 139 34 2E 3 C460 B 275 79 8E 5 C122 A 153 19 3C 1 C233 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 1 C235 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 1 C235 B 105 22 2D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C236 A 105 25 2D 3 C474 A 300 75 9C 5 C139 A 123 22 2C 1 C302 B 98 11 3E 4 C480 B 258 88 10D 5 C139 A 123 22 2C 1 C302 B 98 11 3E 4 C480 B 258 88 10D 5 C140 A 159 82 5E 2 C303 A 101 20 3E 4 C485 8 277 76 10D 5 C141 A 156 79 6E 2 C305 A 95 22 3D 4 C492 B 277 90 8B 5 C141 A 156 79 6E 2 C305 A 95 22 3D 4 C492 B 277 90 8B 5 C143 B 93 36 6F 1 C306 A 95 22 3D 4 C492 B 277 90 8B 5 C143 B 93 36 6F 1 C306 A 95 22 3D 4 C492 B 277 90 8B 5 C143 B 93 36 6F 1 C306 A 95 22 3D 4 C492 B 277 90 8B 5 C144 B 120 32 6F 2 C310 A 74 27 11 4 C500 B 246 55 3E 6 C144 B 120 32 6F 2 C310 A 74 27 11 4 C500 B 246 55 3E 6 C145 B 128 32 6F 2 C310 A 74 27 11 4 C500 B 246 55 3E 6 C145 B 128 32 6F 1 C311 A 57 39 2A 4 C500 B 246 55 3E 6 C145 B 128 32 6F 1 C311 A 57 39 2A 4 C500 B 246 55 3E 6 C145 B 128 32 6F 2 C310 A 74 27 11 4 C500 B 289 40 7E 6 C146 A 161 74 6F 2 C312 A 44 26 3A 4 C500 B 295 55 E 6 C146 A 161 74 6F 2 C312 A 44 26 3A 4 C500 B 295 55 E 6 C146 A 161 74 6F 2 C312 A 44 26 3A 4 C500 B 295 55 E 6 C146 A 161 74 6F 2 C312 A 44 26 3A 4 C500 B 295 55 E 6 C146 A 161 74 6F 2 C312 A 44 26 3A 4 C500 B 295 55 E 6 C146 A 161 74 6F 2 C312 A 44 26 3A 4 C500 B 295 55 E 6 C146 A 161 74 6F 2 C312 A 44 26 3A 4 C500 B 295 55 E 6 C146 A 161 74 6F 2 C312 A 44 26 3A 4 C500 B 295 55 E 6 C146 A 161 74 6F 2 C314 B B 23 3C 4 C533 B 275 33 4D 6 C147 A 120 22 10B 2 C32 B 66	,					1			_		i					1
C118			3			1										
C119	C118	A 184	4.	3 3E	2	1	Α		84					_		
C120 A 140 19 2C 2 C211 A 88 39 8A 3 C452 B 276 B2 77 5 C120 A 140 19 2C 1 C220 A 54 65 7E 3 C453 B 264 85 8A 5 C121 A 140 22 3C 2 C230 B 139 36 2E 3 C454 B 264 79 8E 5 C121 A 140 22 3C 1 C231 8 139 34 2E 3 C460 B 275 79 8E 5 C122 A 153 19 3C 2 C232 B 140 27 2E 3 C461 B 283 76 8D 5 C122 A 153 19 3C 1 C231 8 133 34 2E 3 C474 A 293 72 10C 5 C122 A 153 19 3C 1 C233 B 133 36 2E 3 C474 A 293 72 10C 5 C123 A 153 22 3C 1 C235 A 105 22 2D 3 C474 A 300 75 9C 5 C123 A 153 22 3C 1 C235 A 105 22 2D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C236 A 105 25 2D 3 C474 B 286 90 10E 5 C139 A 123 22 2C 2 C301 8 100 11 3E 4 C480 B 258 88 10D 5 C139 A 123 22 2C 1 C302 B 98 11 3E 4 C481 B 258 81 10D 5 C140 A 159 82 5E 2 C303 A 101 20 3E 4 C485 8 297 76 10D 5 C140 A 159 82 5E 2 C303 A 101 20 3E 4 C485 8 297 76 10D 5 C141 A 156 79 6E 2 C306 A 95 22 3D 4 C492 B 277 90 8A 5 C141 A 156 79 6E 1 C306 A 95 22 3D 4 C492 B 277 90 8A 5 C143 B 93 36 6F 2 C307 B 95 11 3D 4 C500 B 266 88 BA 5 C144 B 120 32 6F 1 C306 A 95 22 3D 4 C493 B 266 88 BA 5 C143 B 93 36 6F 2 C307 B 95 11 3D 4 C500 B 246 55 3E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 286 55 5E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 283 55 5E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 283 55 5E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 283 55 5E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 283 55 5E 6 C145 B 128 32 6F 1 C311 A 57 39 2A 4 C503 B 283 55 5E 6 C145 B 128 32 6F 2 C314 B 82 49 5A 4 C503 B 283 55 5E 6 C146 A 161 74 6F 2 C314 B 82 49 5A 4 C503 B 283 55 5E 6 C145 B 128 32 6F 1 C311 A 57 39 2A 4 C503 B 283 50 7E 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C500 B 289 40 7E 6 C150 A 132 104 9E 2 C316 A 23 37 7A 4 C533 B 275 B 11E 6 C170 A 111 11 10B 1 C322 B 62 23 3D 4 C533 B 275 B 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C321 A 62 20 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C321 A 62 20 3D 4 C533 B 275 B 11E 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C530 B 201 19 2C 6	C119	B 171	6	9 4E	2	C210	Α	80	77	7A	3					
C121 A 140 22 3C 2 C230 B 139 36 2E 3 C454 B 264 79 8E 5 C122 A 153 19 3C 2 C232 B 140 27 2E 3 C460 B 275 79 8E 5 C122 A 153 19 3C 2 C232 B 140 27 2E 3 C461 B 283 76 8D 5 C122 A 153 19 3C 1 C233 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 2 C234 8 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 1 C235 A 105 22 2D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C236 A 105 25 2D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C236 A 105 25 2D 3 C475 B 280 93 9E 5 C139 A 123 22 2C 2 C301 8 100 11 3E 4 C480 B 258 88 10D 5 C139 A 123 22 2C 1 C302 B 98 11 3E 4 C480 B 258 88 10D 5 C140 A 159 82 5E 2 C303 A 101 20 3E 4 C485 B 297 76 10D 5 C140 A 159 82 5E 2 C303 A 101 20 3E 4 C485 B 297 76 10D 5 C141 A 156 79 6E 2 C305 A 95 22 3D 4 C492 B 277 90 8A 5 C141 A 156 79 6E 1 C304 A 95 20 3D 4 C492 B 277 90 8A 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C492 B 277 90 8A 5 C143 B 93 36 6F 2 C307 B 95 11 3D 4 C500 B 246 55 3E 6 C143 B 93 36 6F 1 C308 B 67 23 3D 4 C500 B 246 55 3E 6 C143 B 93 36 6F 1 C308 B 67 23 3D 4 C500 B 246 55 3E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C501 B 258 55 4E 6 C144 B 120 32 6F 1 C313 A 51 4B 4A 4 C502 B 271 55 4E 6 C145 B 128 32 6F 2 C312 A 44 26 3A 4 C500 B 283 55 5E 6 C145 B 128 32 6F 1 C313 A 51 4B 4A 4 C502 B 271 55 4E 6 C146 A 161 74 6F 1 C313 A 51 4B 4A 4 C502 B 271 55 4E 6 C146 A 161 74 6F 1 C313 A 51 4B 4A 4 C505 A 282 36 7E 6 C146 A 161 74 6F 1 C313 A 51 4B 4A 4 C502 B 271 55 4E 6 C146 A 161 74 6F 1 C313 A 51 4B 4A 4 C505 A 282 36 7E 6 C146 A 161 74 6F 1 C313 A 51 4B 4A 4 C505 A 282 36 7E 6 C146 A 161 74 6F 1 C315 A 23 37 7A 4 C500 B 295 55 5E 6 C146 A 161 74 6F 1 C313 A 51 4B 4A 4 C505 A 282 30 7E 6 C146 A 161 74 6F 1 C315 A 23 37 7A 4 C500 B 279 33 8D 6 C140 A 132 104 9E 1 C322 B 64 23 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C323 B 69 23 3C 4 C538 B 225 33 4D 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C539 B 204 25 2C 6 C173 B 136	1		19	9 2C		C211	A	88	39	A8	3	C452	B 276	B2		
C121 A 140 22 3C 1 C231 8 139 34 2E 3 C460 B 275 79 8E 5 C122 A 153 19 3C 2 C232 B 140 27 2E 3 C461 B 283 76 8D 5 C123 A 153 19 3C 1 C233 B 133 36 2E 3 C461 B 283 76 8D 5 C123 A 153 22 3C 2 C234 8 133 34 2E 3 C461 B 283 76 8D 5 C123 A 153 22 3C 1 C235 A 105 2E 3 C473 B 286 90 10E 5 C123 A 153 22 3C 1 C235 A 105 2E 2D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C236 A 105 25 2D 3 C475 B 280 93 9E 5 C139 A 123 22 2C 2 C301 8 100 11 3E 4 C480 B 258 88 10D 5 C139 A 123 22 2C 1 C302 B 98 11 3E 4 C481 B 258 88 10D 5 C140 A 159 82 5E 2 C303 A 101 20 3E 4 C485 8 297 76 10D 5 C140 A 159 B2 5E 1 C304 A 95 20 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 2 C305 A 95 22 3D 4 C492 B 277 90 8A 5 C141 A 156 79 6E 1 C306 A 95 22 3D 4 C492 B 277 90 8A 5 C141 A 156 79 6E 1 C306 A 95 23 3D 4 C492 B 277 90 8A 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C493 B 266 88 BA 5 C143 B 93 36 6F 1 C306 B 67 2 3 3D 4 C500 B 246 55 3E 6 C143 B 93 36 6F 1 C308 B 67 2 3 3D 4 C500 B 246 55 3E 6 C144 B 120 32 6F 2 C310 A 74 27 1A 4 C502 B 271 55 4E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 283 55 5E 6 C145 B 128 32 6F 1 C311 A 57 39 2A 4 C503 B 283 55 5E 6 C145 B 128 32 6F 1 C313 A 51 4B 4A 4 C505 B 271 55 4E 6 C146 A 161 74 6F 2 C312 A 44 26 3A 4 C504 B 295 55 5E 6 C145 B 128 32 6F 1 C313 A 51 4B 4A 4 C505 B 279 33 8D 6 C146 A 161 74 6F 2 C314 B B2 49 5A 4 C500 B 279 33 8D 6 C146 A 161 74 6F 2 C314 B B2 49 5A 4 C500 B 279 33 8D 6 C146 A 161 74 6F 2 C314 B B2 49 5A 4 C500 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C510 B 289 40 7E 6 C150 A 132 104 9E 1 C320 B 62 23 3D 4 C533 B 275 B 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C321 A 62 20 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C321 A 69 20 3C 4 C53B B 225 33 4D 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C530 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C530 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C530 B 201 19 2C 6	1					1	A			7E	3	C453	B 264	85	8A	5
C122 A 153 19 3C 2 C232 B 140 27 2E 3 C461 B 283 76 8D 5 C122 A 153 19 3C 1 C233 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 2 C234 8 133 34 2E 3 C473 B 286 90 10E 5 C123 A 153 22 3C 1 C235 A 105 22 2D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C236 A 105 25 2D 3 C475 B 280 93 9E 5 C139 A 123 22 2C 2 C301 8 100 11 3E 4 C481 B 258 81 10D 5 C139 A 123 22 2C 1 C302 B 98 11 3E 4 C481 B 258 81 10D 5 C140 A 159 82 5E 2 C303 A 101 20 3E 4 C485 B 297 76 10D 5 C140 A 159 82 5E 1 C304 A 95 20 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 2 C305 A 95 22 3D 4 C492 B 277 90 8A 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C493 B 266 88 BA 5 C143 B 93 36 6F 2 C307 B 95 11 3D 4 C500 B 246 55 3E 6 C143 B 93 36 6F 2 C307 B 95 11 3D 4 C500 B 246 55 3E 6 C143 B 93 36 6F 2 C307 B 95 11 3D 4 C500 B 246 55 3E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C501 B 258 55 4E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 283 55 5E 6 C145 B 128 32 6F 2 C310 A 74 27 1A 4 C502 B 271 55 4E 6 C145 B 128 32 6F 2 C312 A 44 26 3A 4 C501 B 258 55 5E 6 C145 B 128 32 6F 1 C311 A 57 39 2A 4 C500 B 248 55 55 6 6 C146 A 161 74 6F 1 C311 A 57 39 2A 4 C500 B 248 95 55 5E 6 C146 A 161 74 6F 1 C315 A 23 37 7A 4 C503 B 289 40 7E 6 C146 A 161 74 6F 1 C315 A 23 37 7A 4 C503 B 289 40 7E 6 C146 A 161 74 6F 1 C315 A 23 37 7A 4 C503 B 289 40 7E 6 C150 A 132 104 9E 1 C320 B 62 23 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C537 B 232 34 4C 6 C171 A 120 22 10B 2 C323 B 69 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 2 C325 A 76 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 2 C325 A 76 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 2 C325 A 76 23 3C 4 C537 B 232 34 4C 6 C171 B 136 24 11C 2 C325 A 76 23 3C 4 C530 B 201 19 2C 6						1							B 264	79	8E	5
C122 A 153 19 3C 1 C233 B 133 36 2E 3 C472 A 293 72 10C 5 C123 A 153 22 3C 2 C234 8 133 34 2E 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C236 A 105 25 2D 3 C474 A 300 75 9C 5 C125 A 180 57 4F 2 C236 A 105 25 2D 3 C475 B 280 93 9E 5 C139 A 123 22 2C 2 C301 8 100 11 3E 4 C480 B 258 88 10D 5 C140 A 159 82 5E 2 C303 A 101 20 3E 4 C485 8 297 76 10D 5 C140 A 159 B2 5E 1 C304 A 95 20 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 2 C305 A 95 22 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C490 B 266 101 11E 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C492 B 277 90 8A 5 C143 B 93 36 6F 1 C306 A 95 25 3D 4 C490 B 266 15 3E 6 C143 B 93 36 6F 1 C308 B 67 23 3D 4 C501 B 258 55 4E 6 C144 B 120 32 6F 1 C31A A 74 27 1A 4 C500 B 246 55 3E 6 C144 B 120 32 6F 1 C31A A 74 27 1A 4 C502 B 271 55 4E 6 C144 B 120 32 6F 1 C31A A 74 27 1A 4 C502 B 271 55 4E 6 C145 B 128 32 6F 2 C310 A 74 27 1A 4 C502 B 271 55 4E 6 C145 B 128 32 6F 1 C311 A 57 39 2A 4 C501 B 258 55 5E 6 C145 B 128 32 6F 1 C313 A 51 4B 4A 4 C505 A 2B2 36 7E 6 C146 A 161 74 6F 2 C314 B B2 49 5A 4 C501 B 258 55 5E 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C500 B 289 40 7E 6 C150 A 132 104 9E 2 C316 A 23 37 7A 4 C530 A 297 20 11E 6 C150 A 132 104 9E 1 C322 B 64 23 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C539 B 225 33 4D 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C531 B 292 8 11E 6 C171 A 120 22 10B 2 C323 B 69 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 2 C323 B 69 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 2 C323 B 69 23 3C 4 C538 B 225 33 4D 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C540 B 201 19 2C 6	I .					1										, ,
C123	1				_	1										
C123																
C125 A 180 57 4F 2 C236 A 105 25 2D 3 C475 B 280 93 9E 5 C139 A 123 22 2C 2 C301 8 100 11 3E 4 C480 B 258 88 10D 5 C139 A 123 22 2C 1 C302 B 98 11 3E 4 C481 B 258 81 10D 5 C140 A 159 82 5E 2 C303 A 101 20 3E 4 C485 8 297 76 10D 5 C140 A 159 B2 5E 1 C304 A 95 20 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 2 C305 A 95 22 3D 4 C492 B 277 90 8A 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C492 B 277 90 8A 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C492 B 277 90 8A 5 C143 B 93 36 6F 2 C307 B 95 11 3D 4 C500 B 246 55 3E 6 C143 B 93 36 6F 1 C308 B 67 23 3D 4 C501 B 258 55 4E 6 C144 B 120 32 6F 2 C310 A 74 27 1A 4 C502 B 271 55 4E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 283 55 5E 6 C145 B 128 32 6F 2 C312 A 44 26 3A 4 C504 B 295 55 5E 6 C145 B 128 32 6F 2 C312 A 44 26 3A 4 C504 B 295 55 5E 6 C146 A 161 74 6F 2 C314 B B2 49 5A 4 C506 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C506 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C506 B 279 33 8D 6 C150 A 132 104 9E 2 C316 A 23 37 7A 4 C530 A 297 20 11E 6 C150 A 132 104 9E 2 C316 A 23 37 7A 4 C530 A 297 20 11E 6 C150 A 132 104 9E 1 C320 B 62 23 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C323 B 69 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 2 C325 A 76 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 2 C325 A 76 23 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C530 B 201 19 2C 6	l .				_	L	_									
C139 A 123 22 2C 2 C301 8 100 11 3E 4 C480 B 258 88 10D 5 C139 A 123 22 2C 1 C302 B 98 11 3E 4 C481 B 258 81 10D 5 C140 A 159 82 5E 2 C303 A 101 20 3E 4 C485 8 297 76 10D 5 C140 A 159 B2 5E 1 C304 A 95 20 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 2 C305 A 95 22 3D 4 C492 B 277 90 8A 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C492 B 277 90 8A 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C493 B 266 88 BA 5 C143 B 93 36 6F 2 C307 B 95 11 3D 4 C500 B 246 55 3E 6 C143 B 93 36 6F 1 C308 B 67 23 3D 4 C501 B 258 55 4E 6 C144 B 120 32 6F 2 C310 A 74 27 1A 4 C502 B 271 55 4E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 2B3 55 5E 6 C145 B 128 32 6F 1 C311 A 57 39 2A 4 C504 B 295 55 5E 6 C145 B 128 32 6F 1 C313 A 51 4B 4A 4 C505 A 2B2 36 7E 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C506 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C506 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C506 B 279 33 8D 6 C150 A 132 104 9E 2 C316 A 23 37 7A 4 C530 A 297 20 11E 6 C150 A 132 104 9E 1 C320 B 62 23 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C321 A 62 20 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C537 B 222 34 4C 6 C173 B 136 24 11C 2 C325 A 76 23 3C 4 C537 B 222 34 4C 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C537 B 222 34 4C 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C537 B 225 33 4D 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6						1					- 1					
C139 A 123 22 2C 1 C302 B 98 11 3E 4 C481 B 258 81 10D 5 C140 A 159 82 5E 2 C303 A 101 20 3E 4 C485 8 297 76 10D 5 C140 A 159 B2 5E 1 C304 A 95 20 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 2 C305 A 95 22 3D 4 C492 B 277 90 8A 5 C141 A 156 79 6E 1 C306 A 95 22 3D 4 C492 B 277 90 8A 5 C141 A 156 79 6E 1 C306 A 95 22 3D 4 C493 B 266 88 BA 5 C143 B 93 36 6F 2 C307 B 95 11 3D 4 C500 B 246 55 3E 6 C143 B 93 36 6F 1 C308 B 67 23 3D 4 C501 B 258 55 4E 6 C144 B 120 32 6F 2 C310 A 74 27 1A 4 C502 B 271 55 4E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 2B3 55 5E 6 C145 B 128 32 6F 1 C311 A 57 39 2A 4 C504 B 295 55 5E 6 C145 B 12B 32 6F 1 C313 A 51 4B 4A 4 C504 B 295 55 5E 6 C146 A 161 74 6F 2 C314 B B2 49 5A 4 C506 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C506 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C506 B 279 33 8D 6 C150 A 132 104 9E 2 C316 A 23 37 7A 4 C530 A 297 20 11E 6 C170 A 111 11 10B 1 C320 B 62 23 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C321 A 62 20 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C537 B 232 34 4C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C539 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C539 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C539 B 201 19 2C 6						1					- 1					F
C140 A 159 82 5E 2 C303 A 101 20 3E 4 C485 8 297 76 10D 5 C140 A 159 B2 5E 1 C304 A 95 20 3D 4 C490 B 261 101 11E 5 C141 A 156 79 6E 2 C305 A 95 22 3D 4 C492 B 277 90 8A 5 C141 A 156 79 6E 1 C306 A 95 25 3D 4 C492 B 277 90 8A 5 C143 B 93 36 6F 2 C307 B 95 11 3D 4 C500 B 246 55 3E 6 C143 B 93 36 6F 1 C308 B 67 23 3D 4 C501 B 258 55 4E 6 C144 B 120 32 6F 2 C310 A 74 27 1A 4 C502 B 271 55 4E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 2B3 55 5E 6 C145 B 128 32 6F 2 C312 A 44 26 3A 4 C504 B 295 55 5E 6 C145 B 12B 32 6F 1 C313 A 51 4B 4A 4 C504 B 295 55 5E 6 C146 A 161 74 6F 2 C314 B B2 49 5A 4 C506 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C510 B 289 40 7E 6 C150 A 132 104 9E 2 C316 A 23 37 7A 4 C530 A 297 20 11E 6 C170 A 111 11 10B 2 C321 A 62 20 3D 4 C531 B 292 8 11E 6 C171 A 120 22 10B 2 C321 A 69 20 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C537 B 232 34 4C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C539 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C539 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6	C139	A 123	22	2 2C	1	C302	В	98	11		4					1
C141	ł				2	C303	A	101	20	3E	4	C485				- 1
C141						1	A	95		3D	4	C490		101	11E	5
C143 B 93 36 6F 2 C307 B 95 11 3D 4 C500 B 246 55 3E 6 C143 B 93 36 6F 1 C30B B 67 23 3D 4 C501 B 258 55 4E 6 C144 B 120 32 6F 2 C310 A 74 27 1A 4 C502 B 271 55 4E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 2B3 55 5E 6 C145 B 128 32 6F 2 C312 A 44 26 3A 4 C504 B 295 55 5E 6 C145 B 12B 32 6F 1 C313 A 51 4B 4A 4 C505 A 2B2 36 7E 6 C146 A 161 74 6F 2 C314 B B2 49 5A 4 C506 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C506 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C506 B 279 33 8D 6 C150 A 132 104 9E 2 C316 A 23 37 7A 4 C530 A 297 20 11E 6 C150 A 132 104 9E 1 C320 B 62 23 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 2 C321 A 62 20 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C323 B 69 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C538 B 225 33 4D 6 C173 B 136 24 11C 2 C325 A 76 23 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 SCHWARZ	l .					1	A				4				8A	5
C143 B 93 36 6F 1 C30B B 67 23 3D 4 C501 B 258 55 4E 6 C144 B 120 32 6F 2 C310 A 74 27 1A 4 C502 B 271 55 4E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 2B3 55 5E 6 C145 B 128 32 6F 2 C312 A 44 26 3A 4 C504 B 295 55 5E 6 C145 B 12B 32 6F 1 C313 A 51 4B 4A 4 C505 A 2B2 36 7E 6 C146 A 161 74 6F 2 C314 B B2 49 5A 4 C506 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C510 B 289 40 7E 6 C150 A 132 104 9E 2 C316 A 23 37 7A 4 C530 A 297 20 11E 6 C150 A 132 104 9E 1 C320 B 62 23 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 2 C321 A 62 20 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C538 B 225 33 4D 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 C						t .					- 1					5
C144 B 120 32 6F 2 C310 A 74 27 1A 4 C502 B 271 55 4E 6 C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 2B3 55 5E 6 C145 B 128 32 6F 2 C312 A 44 26 3A 4 C504 B 295 55 5E 6 C145 B 12B 32 6F 1 C313 A 51 4B 4A 4 C505 A 2B2 36 7E 6 C146 A 161 74 6F 2 C314 B B2 49 5A 4 C506 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C510 B 289 40 7E 6 C150 A 132 104 9E 2 C316 A 23 37 7A 4 C530 A 297 20 11E 6 C150 A 132 104 9E 1 C320 B 62 23 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 2 C321 A 62 20 3D 4 C532 A 2B3 20 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C323 B 69 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C53B B 225 33 4D 6 C173 B 136 24 11C 2 C325 A 76 23 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 SCHWARZ						1										
C144 B 120 32 6F 1 C311 A 57 39 2A 4 C503 B 2B3 55 5E 6 C145 B 128 32 6F 2 C312 A 44 26 3A 4 C504 B 295 55 5E 6 C145 B 12B 32 6F 1 C313 A 51 4B 4A 4 C505 A 2B2 36 7E 6 C146 A 161 74 6F 2 C314 B B2 49 5A 4 C506 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C510 B 289 40 7E 6 C150 A 132 104 9E 2 C316 A 23 37 7A 4 C530 A 297 20 11E 6 C150 A 132 104 9E 1 C320 B 62 23 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 2 C321 A 62 20 3D 4 C532 A 2B3 20 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C323 B 69 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C53B B 225 33 4D 6 C173 B 136 24 11C 2 C325 A 76 23 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6  SCHWARZ   ED RECHNER   ED RECHNER   Blatt Page						4										
C145 B 128 32 6F 2 C312 A 44 26 3A 4 C504 B 295 55 5E 6 C145 B 12B 32 6F 1 C313 A 51 4B 4A 4 C505 A 2B2 36 7E 6 C146 A 161 74 6F 2 C314 B B2 49 5A 4 C506 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C510 B 289 40 7E 6 C150 A 132 104 9E 2 C316 A 23 37 7A 4 C530 A 297 20 11E 6 C150 A 132 104 9E 1 C320 B 62 23 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 2 C321 A 62 20 3D 4 C532 A 2B3 20 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C323 B 69 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C53B B 225 33 4D 6 C173 B 136 24 11C 2 C325 A 76 23 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6   SCHWARZ   ED RECHNER   ED RECHNER						t .										
C145 B 12B 32 6F 1 C313 A 51 4B 4A 4 C505 A 2B2 36 7E 6 C146 A 161 74 6F 2 C314 B B2 49 5A 4 C506 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C510 B 289 40 7E 6 C150 A 132 104 9E 2 C316 A 23 37 7A 4 C530 A 297 20 11E 6 C150 A 132 104 9E 1 C320 B 62 23 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 2 C321 A 62 20 3D 4 C532 A 2B3 20 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C323 B 69 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C53B B 225 33 4D 6 C173 B 136 24 11C 2 C325 A 76 23 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 SCHWARZ						1					- 1					Į.
C146 A 161 74 6F 2 C314 B B2 49 5A 4 C506 B 279 33 8D 6 C146 A 161 74 6F 1 C315 A 23 47 6A 4 C510 B 289 40 7E 6 C150 A 132 104 9E 2 C316 A 23 37 7A 4 C530 A 297 20 11E 6 C150 A 132 104 9E 1 C320 B 62 23 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 2 C321 A 62 20 3D 4 C532 A 2B3 20 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C323 B 69 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C53B B 225 33 4D 6 C173 B 136 24 11C 2 C325 A 76 23 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6 SCHWARZ   ED RECHNER   ED RECHNER   ED RECHNER	l .															
C146											1					
C150 A 132 104 9E 2 C316 A 23 37 7A 4 C530 A 297 20 11E 6 C150 A 132 104 9E 1 C320 B 62 23 3D 4 C531 B 292 8 11E 6 C170 A 111 11 10B 2 C321 A 62 20 3D 4 C532 A 2B3 20 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C323 B 69 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C53B B 225 33 4D 6 C173 B 136 24 11C 2 C325 A 76 23 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6     The matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of the matter of th		A 161			1	I .	A				4					
C170 A 111 11 10B 2 C321 A 62 20 3D 4 C532 A 2B3 20 11E 6 C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C323 B 69 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C53B B 225 33 4D 6 C173 B 136 24 11C 2 C325 A 76 23 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6	i .					1	A				4					ſ
C170 A 111 11 10B 1 C322 B 64 23 3D 4 C533 B 275 B 11E 6 C171 A 120 22 10B 2 C323 B 69 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C53B B 225 33 4D 6 C173 B 136 24 11C 2 C325 A 76 23 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6	ľ					1					1					6
C171 A 120 22 10B 2 C323 B 69 23 3C 4 C537 B 232 34 4C 6 C171 A 120 22 10B 1 C324 A 69 20 3C 4 C53B B 225 33 4D 6 C173 B 136 24 11C 2 C325 A 76 23 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6						t .										
C171 A 120 22 10B 1 C324 A 69 20 3C 4 C53B B 225 33 4D 6 C173 B 136 24 11C 2 C325 A 76 23 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6	1					1					· 1					
C173 B 136 24 11C 2 C325 A 76 23 3C 4 C539 B 204 25 2C 6 C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6						1					- 1					
C173 B 136 24 11C 1 C326 A 76 20 3C 4 C540 B 201 19 2C 6	•				i											
Total   Datum   XY-Liste for   Sach-Nummer   Blatt   ROHDE   Date   XY-list for   Stock-Nr   Page   & SCHWARZ   ED RECHNER	l .															
ROHDE Date XY-list for Stock-Nr Page SCHWARZ ED RECHNER		+	+		- 						+				-+ <b>-</b> -	+
SCHWARZ ED RECHNER		-I	ı												i	i
		 !	+ 			יבייים מקו	יישואו. יישואו				+ I				-+	+ 1
	Symmod		02	02.11	.93							1062.	6309.01	XY		2+

Part S	ide X		 Sqr	 Pg	Part Side X		 Sqr	 Pg	Part Side X Y	 Sqr	Pg
+   C541	в 30	<del>-</del> 0 3	0 9E	6	D135-A B 156	<del>-</del> 37	 8B	 1	D440-A B 224 103	5D	5
C542	B 23	3 2	9 4C	6	D135-B		9B	1	D440-B	6A	5
C543	B 24	1 2	9 4C	6	D135-C		8B	1	D450 B 241 102	7D	5
C555	В 22		6 6C	6	D135-D		9B	1	D500-A B 201 33	3D	6
C556	B 20		6 6B	6	D135-G		7A	1	D500-B	7A	6
C567	A 26		0 11C	6	D150-A B 112	31	10E	2	D510-A B 286 27		6
C568	B 26		1 11C	6	D150-B		A8	2	D510-B	7A	6
C575	A 25		8 3B	6	D150-A B 112	31	10E	1	D545-A B 210 46	_	6
C578	A 26 A 26		4 2A 4 2A		D150-B	67	8A	1	D545-B	6B	6
C580	A 22		4 2A 3 1A		D160-A B 127	0/	10D 8A	2 2	D545-C D550-A B 261 43	4A 7D	6
C581	A 21		3 1A		D160-B B 127	67	10D	1	D550-R B 261 43	8C	6
C582	A 29		0 3A	6	D160-B	0,	BA	1	D550-C	8D	6
C583	A 29		0 3A		D206-A B 110	78	3D	3	D550-D	7C	6
C584	A 29		0 4A	6	D206-B	, 0	2A	3	D550-E	6A	6
C585	A 30		4 4A	6	D210-A B 109	54	5 D	3	D555-A B 243 44		6
C586	A 21		1 4A	6	D210-B		4A	3	D555-B	5A	6
C587	A 24	6 4	1 5A	6	D230-A B 97	39	6D	3	G100 B 25 92		2
C588	B 21	1 5	3 2B	6	D230-B		7A	3	G100 B 25 92		1
C589	B 20	35	3 2B	6	D250-A B 37	56	8D	3	L10 B 89 22	2B	2
C590	A 26	7 4	4 6A	6	D250-B		5A	3	L10 B 89 22	2B	1
C591	A 26		7 6A	6	D255-A B 69	92	10D	3	L12 B 171 18	2B	2
C592	A 26			6	D255-B		6A	3	L12 B 171 18	2B	1
C593	A 20			6	D260-A 8 80	82	10E	3	L13 B 176 21	2A	2
C594	A 20			6	D260-8		7A	3	L13 B 176 21	2A	1
C595	A 20			6	D301-A B 64	39	10C	4	L140 B 130 28	6F	2
C596	A 28			6	D301-B		2A	4	L140 B 130 28	6F	1
C597	A 279			6	D302-A B 49	24	5C	4	L401 8 190 80	2E	5
C598	A 283			6	D302-B		3A	4	L403 B 191 74	2D	5
C599	B 224			6	D303-A B 41	50	8D	4	L405 B 199 70	2D	5
D10A D10A	8 160 B 160			2	D303-8 D303-C		8C	4	L472 8 293 72	9C	5
DIOA DIOA	8 160			1	D303-C D304-A B 20	50	4A 7D	4 4	L473 B 283 93	9E	5
D10A	8 81			2	D304-R B 20	30	7D	4	L500 8 246 52 L501 8 259 52	3E 4E	6
D100	8 8			1	D304-B		6A	4	L501 8 259 52 L502 8 272 52		6
D105-A	-	-		2	D305-A B 20	39		4	L503 B 284 52	5E	6
D105-B		•	5A	2	D305-B	•	7E	4	L590 B 201 60		6
	8 173	3 5		2	D305-C		6A	4	L591 8 211 60		6
D110				2	D311-A B 81	27	5E	4	L592 B 218 60		6
D110				1	D311-B	•	1A	4	N100-A B 178 45		2
D120-A				2	D323-A B 68	50	6E	4	N100-B	3E	2
D120-B			6A	2	D323-B		11C	4	N100-C	6A	2
D120-A	B 124	5.	5 8D	1	D323-C		5A	4	N100-A B 178 45	4E	1
D120-B			6A	1	D402-A B 230	71		5	N100-B	3E	1
D125-B				2	D402-B		3A	5	N100-C	6A	1
D125-A				2	D402-C		3A	5	N450-A B 267 86		5
D125-A	B 110	10.		1	D402-D		3A	5	N450-B	7A	5
D125-B	D 1-1		7A	1	D402-E		4A	5	N490-A B 269 92		5
D135-E	B 156	3		3	D403-A B 217	82	3D	5	N490-B	8A	5
D135-F	D 154		8C	4	D403-B		2A	5	N510-A B 216 33		6
D135-G D135-A				2	D403-C	D o	1A	5	N510-B	1A	6
D135-A D135-B		` ک	9B	2 2	D420-A B 217 D420-B	92	4D 5A	5	N520-A B 298 40		6
D135-B			9B 8B	2	•	Q 1		5 5	N520-B N530-A B 267 24	4A 9C	6
D135-C			9B	2		21	6A		N530-A B 267 24 N530-B	10C	_
			+					+		+	+
	<b>-</b> I		Datum	1	XY-	List	e f	r	Sach-Nummer	Bl	att
ROHDE			Date		•				Stock-Nr	Pa	ge
& +	+		ŧ		+			<del>!</del>			<u>÷</u>
SCHWARZ		~~	00.55		ED RECHNER				1060 6000		
		02	02.11	93	PROCESSOR			E	1062.6309.01 XY	į.	3+
	+		+		<del>+</del>			+		+	+


						Part S	id					•	Part Side X				•
N530-C	:			2A	. 6	R135		180	66				R160-I		9	D 1	Ì
N540-A					6	R135		180		5D	1	ļ	R161-A B 131	50	9	C 2	İ
N540-B						R136		178		5D	2		R161-B			C 2	
N544-A	В	237	3	7 40	6	R136		178		5D	1	ı	R161-C			C 2	
N544-B				4B		R138		126		2C	2	-	R161-D			C 2	1
N544-C						R138	A	126	25	2C	1		R161-E			D 2	
R100		180				R140		91		3C	2		R161-F			D 2	
R100		180				R140		91		3 C	1		R161-G		9:	D 2	
R101		178				R141		97		4C	2		R161-H		9:		
R101		178				R141		97		4C	1		R161-A B 131	50	9	<b>C</b> 1	
R105		175				R142		181		4C	2		R161-B		9		
R105		175				R142		181		4C	1	- 1	R161-C				
R106		169				R143		110		5B	2	- 1	R161-D		9		
R106		169				R143		110		5B	1		R161-E		91		
R108		158				R144		. 117		58	2	- 1	KIGI-F		9,		
R108		158				R144		117		5B	1	- 1	K161-G		91	_	
R109		175				R145		161		6C	2	- 1	R161-H .		91		
R110		185				R145		161		6C	1		R163-A B 131	48			
R110		185				R146		177		7C	2		R163-B R163-C R163-D R163-E R163-F		10		
R111		123				R146		177		7C	1	j	K163-C		101		
R111		123				R147		150		7F	2		K163-D		101		
R112		114				R147		150		7F	1	ı	R163-E		101		
R112 R113		114 175				R148		163		6F	2		R163-F R163-G		101		
R113		175				R148		163		6F	1	- 1	R163-G		101		
R113 R114		185	5:			R149 R149		181 181		6F	2		R163-H	40	101		
R114		185	5.			R150		154		6F 8F	1		R163-A 8 131				
R115		168				R150		154		8F	2 1		R163-8 R163-C		10I 10I		ļ
R115		168				R151		151		8F	2		R163-D		100		
R120		144				R151		151	79	8F	1		R163-E		100		
R120		144	19			R152		138	_	8D	2		R163-F		100		
R121		144	2:			R152		138		8D	1		R163-G		101		
R121		144	2:			R153		125		8F	2	- 1	R163-H		101		
R122		149				R153		125		8F	1	- 1	R165 A 112				
R122				9 4D					77				R165 A 112		101		
R123		149	22			R154		138	77	9E	1	1	R166 A 128	62			
R123		149	2.			R156		138	81	9E	2		R166 A 128		101		
R124	8	164	104	4 4D	2	R156		138		9E	1		R170 B 156 1		50		
R124	В	164	104	4 4D	1	R157		128	56	8D	2		R170 B 156		50		
R125	Α	165	94	4 4D	2	R157	Α	128	56	8D	1	1	R171 A 163	94	50		
R125	Α	165	94	4 4D	1	R160-A	В	125	76	9D	2	ı		94	50		İ
R126	В	166	104	4 4D	2	R160-B				9D	2			94	50		
R126	В	166	104	4 4D	1	R160-C				9D	2			94	50		
R127	A	111	2	5 4D	2	R160-D				9D	2		R174 B 169 1	104	50		
R127		111	25			R160-F				9D	2		R174 B 169 1	104	50	1	
R130		165	82	2 5E	2	R160-G				9D	2		R175 B 177	88	7 E		
R130	A	165	82	2 5E	1	R160-H				9D	2		R175 B 177	88	7E	3 1	
R131		168	82			R160-I				9D	2		R176 B 177	86	7 E	3 2	
R131		168	82			R160-A	В	125	76		1		R176 B 177	86	<b>7</b> E	3 1	
R132		166	66			R160-B				9D	1		R177 B 133		110		
R132		166	66		1	R160-C				9D	1		R177 B 133		110		
R133		181	76			R160-D				9D	1		R178 B 133		110		
R133		181	76		1	R160-F				9D	1		R178 B 133		110		
R134		181	73		2	R160-G					1		R179 B 163	69			
R134	В +	181	73 +	3 5E	1	R160-H				9D	1	-+-	R179 B 163	69	6c +-	1	
	-	-I		Datur								- 1	Sach-Nummer		E	Blatt	
ROHDE				Date				XY-	-list	fo	r		Stock-Nr		F	age	
& -	+ <b>-</b> -		 !	 !		ED RECHI						+-			+-		<del> -</del>  -
CHWARZ						PROCI											


Part S	Sic	le X	 У	Sqr	Pg	Part	Sid	le X	У	 Sqr	Pg	Part	Sic	le X	 У	Sqr	Pg
R180	F	154	79	6C	 2	R404	B	189	45	2B	<b></b> -	+   R543	- <b>-</b>	190	 4	10	 6
R180	P	154	79	6C	1	R405	В	232	В0	2A	5	R544	E		25		6
R200	P	112	85	3C	3	R410	В	205	87	2A	5	R545	E		33		6
R201	P	112	В3	3C	3	R411	В	208	87	2A	5	R546	E	223	22	4C	6
R204	A	ВВ	74	5E	3	R412	В	192	57	2C	5	R547	E		22	4C	6
R205	A	91	84	5E	3	R413	В	1B9	48	2C	5	R54B	E		25	4B	6
R220	A	54	63	70	3	R423	В	220	108	4D	5	R549	E	223	25	4B	6
R221	A	43	63	7E	3	R424	В	204	90	4D	5	R551	A	212	44	5C	6
R250-A	B	62	53	7D	3	R427	В	224	108	4C	5	R552	B	223	39	5B	6
R250-B				70	3	R428	В	204	105	4C	5	R553	В	253	2B	3B	6
R250-C				7D	3	R430	В	227	105	50	5	R555	A	20B	43	5C	6
R250-0				70	3	R451	В		74	80	5	R556	В	223	36	5B	6
R250-E				7D	3	R460	В	275	73	80	5	R557	В	203	44	5C	6
R250-F				7D	3	R461	В		69	8D	5	R558	A	217	40	5B	6
R250-G				70	3	R462	В	_	69	90	5	R559	A	208	40	5B	6
R250-H				70	3	R463	В		73	90	5	R560	A	217	43	5C	6
R251		150	.41	9E	3	R469	В		82	9E	5	R561	В	290	34	BE	6
R252	В		53	8D	3	R470	В		87	90	5	R564	A	271	25	9C	6
R301	A	_	30	4E	4	R471	В		7B	90	5	R566	В	271	20	9C	6
R302	В	36	29	4E	4	R472	В		81	90	5	R567	В	262	20	10C	6
R303	В	36	26	5E	4	R473	В		B7	9 D	5	R56B	В	263	9	11C	6
R304	В	36	31	5E	4	R474	В	_	83	10D	5	R570	A	250	44	7C	6
R305	A	56	29	5E	4	R475	В	285	75	9C	5	R571	В	271	27	9C	6
R306	A	56	27	5E	4	R4B0	В	269	70	10E	5	R572	A	258	24	10C	6
R307	В	36	23	5E	4	R4B1	В	258	75	10E	5	R575	A	265	24	10C	6
R308	В	43	22	5E	4	R482	В	261	81	10D	5	R576	В	258	2B	10C	6
R309	A	56	24	5E	4	R485	В	297	78	100	5	R577	В	270	40	80	6
R320	В	29	37	7E	4	R486	В	300	76	100	5	V110	В	173	69	4E	2
R321	В	17	31	7E	4	R490	8	260	95	11D	5	V110	В	173	69	4E	1
R322 R323	В	29	30	7E	4	R491	В	259	104	11E	5	V120	A	117	28	30	2
R323	B	17 47	42 47	7E	4	R500	В		62	3E	6	V120	A	117	28	30	1
R331	A	47	44	90 90	4 4	R504	В	300	52	6E	6	V205	A	85	74	5E	3
R331	A	47	42	90 9D	4	R505	В	300	38	7E	6	V210	В	86	77	5E	3
R332	В	37	37	9D	4	R506 R515	В	279	36	7E	6	V220	A	48	62	70	3
R334	В	37	39	90 9D	4	R515		298	41	7E	6	V462	В	280	76	90	5
R335	В	37		100	4	R530		295 297	36	9E	6	V463		277	79	9E	5
R336	В	37		100	4	R530		297 295		10E 11E	6	V470	В		84	9E	5
R337	В	37		100 10D	4	R531		295			6	V471		278	87	9D	5
R338	В	37		10D	4	R532		203 279		10E	6	V475		288	70	9C	5
R340	В	17	39	8A	4	R533		295	30	11E	6	V476		288	74	9D	5
R400		1B9	57	2E	5	R534		295	33	9F	6	V480		297		100	5
R401		230	75	3E	5	R540		1B5	4	3D	6	V540		207	25	2D	6
R402		220	79	3E	5	R540		177	11	2C 2D	6	V550		255	24	3C	6
R403		189	51	2B	5	R541		204	19	2D	6	V551	A	250	24	3B	6
					+	11272				2U 	0						


ROHOE	-I	Datum Oate		-Liste -list		Sach-Nummer Stock-Nr	Blatt Page
SCHWARZ		02.11.93	ED RECHNER PROCESSOR		j	1062.6309.01 XY	5-





Stromläufe
Bestückungspläne
Circuit diagrams
Components plans
Schémas de circuit
Plans des composants

























DATA BUS





BINDENDE ANGABEN UEBER VARIANTEN, TRIMMWERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA. FOR BINDING INFORMATION ON MODELS, TRIMMING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST. \* NICHT BESTUECKEN NOT FITTED


Į


03/01		21.02.97	E۱	MENP	186	NAME	BENENNUNG		
				BERRB.		Ei			
				GEPR.		_	RECHNER		
				NORE			PROCESSOR S		
				PLOTT	24.02.97		•	BEATT-	80
				<i>∕</i> €\			ZEICHNNR.	1.13-	- ak
02/04	48169	12.01.95	JN	\$\$			1062.6309.015		
REND.	RENDERUNGS-	DATUR	NAME	ROH	DE&SU	HUARZ		- 502	
IND.	MITTEILUNG	VII LUIS	инис	ZU GERRE	T SMY		REG.I.V. 1062.5502 ERSTE Z. 1062.	4.9	11/10
A CONTRACTOR OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF TH	9				1	0	11 11	14	30











ACHTUNG: EGB! ELEKTROSTATISCH GEFREHRDETE

SERCLK

INTBUS

BINDENDE ANGABEN UEBER VARIANTEN, TRIMMWERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA.

COLO כפרו C012 0013 500.5 500.5 500.5 500.5

R330 R332 R334 1K L 1K L 1K 8

+5V

14

12

7

5

Þ▽

D303-B

74HCT244T-8

D303-A 74HCT244T-B

1 EN

Б

₿

19 EN

13

15

17

12


В


FOR BINDING INFORMATION ON MODELS, TRIBBING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.

D301-R

74HCT147T-8

03/01		21.02.97	ΕI	MENP	186	NAME	BENENNUNG		
				BEARB.		EI			
				GEPR.			REC	HNER	+
				NORM			PROCE	SSOR	
				PLOTT	21.02.97				
				<i>√</i> 0 <i>∕</i> 0 <i>∕</i> 0			ZEICHNNR.		BLATT-NR.
02/04	48169	12.01.95	JN	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\				1062.63	ng nis
AEND.	AENDERUNGS-	DATUM	NAME	ROH	IDE&SC	HUARZ			
IND.	MITTERLUNG	ווטווע	ann.	ZU GERAE	T SMY		REG. 1. V. 1	062.5502	ERSTE Z. = 1062:5502
	9			***************************************	1	0		11	%/ 12








F


D


В





BINDENDE ANGABEN UEBER VARIANTEN, TRIBDUERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA. FOR BINDING INFORMATION ON MODELS, TRIBBING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.


03/01 21.02.97 ET MENP TAG NAME BET	ENENNUNG	1 1			
		1 1			
BEARB. ET					
SEPR.	RECHNER				
HORM	PROCESSOR				
PLOTT 24.02.97					
7E	ZEICHNNR.				
82/04 48169 12.01.95 JN RS	1062.6309.015	5+			
BEND RENDERUNGS- DAYEN NAME ROHDE&SCHUARZ		6 BL.			
	EE. I. V. 1062.5502 ERSYE Z. 1062.5502				
9 1 10	11 12	12			






























1	0			1	n	11				
AENO. IND.	HITTERLENS	VH190	THE .	zer gebendet SMY		REG.1. \$. 3062.5502 ERSIE 7. 1062.5502				
	BENDERBAGS-	BRIUM	BRRE	ROHDE&SCHWARZ			BL.			
/	48169	29.09.93	на	1 37		1062,6309.01 ED 14				
				(8)		ZEICHN, -NR. OLATI				
				PLOTT 21.02.97				М		
				NURR		PROCESSOR	- 1	А		
				SEPR.		RECHNER	ZΙ			
				BEARB.	Εł		_			
03/01		21.02.97	EI :	MENP ING	NAME	BENENMUNG	1			



UNG: EGB!
ATJSCH GEFAERROETE
ME ERFORDERK EINE
DERE HANDHABUIG.
TION ESD!
TIO SENSITIVE DEVICES
A SPECIAL HANDLING

BINDENDE ANGROED DEBER VARIRATEN. TRIMMUERTE, BRUYEILDERTE UND NICHT BESTDECKTE BAUTEILE SIEHE SA

FOR BINDING INFORBATION ON MODELS, TRIDHING AND COMPONENTS VALUES AND NOMFITTED COMPONENTS SEE PARTS LIST.

4


Λ

5


03/01

/ 48169


REND RENDERUNGSIND BITIESTUNG



Λ




NBHE 21.02.97 E I MENP BERRS. ΕI Z RECHNER PROCESSOR GEPR. #02N PLOTI 81811-82. 2+ ROHDE&SCHWARZ 1062.6309.01 48169 29.69.93 RENDERTHES-MITTELLENG datun 9 11 10



MENP BERRS. SEPR. ERTE, BAUTEILBERTE UND NORA BESTUECKTE BAUTEILE SIEHE SA PLOTT 21.02.97 ROHDE&SC 46 AND COMPONENTS VALUES AND 48169 AENDERUNGS-HITTEILUNG 29.09.93 HO DATUM Λ 6 8

9



ITE A



3

TRIANGERTE, BRUTETEBERTE UNO NICHT BESTUECKTE BRUTELLE SIEHE SA

FOR BINDING INFORMATION ON MODELS. TRIMING AND COMPONENTS UNLUES AND

4

1

5

б

DARSTELLUNG SEITE A VIEW ON SIDE A

2

FUESE ZEICKNUNG IST EIN RECHKERRUESBRUCK, RENDERUNGER KÖENNEN AUR DURCH AENDERN DES DATENSATZES ERFOLGEN

A



3

BINDENDE ANGABEN DEBER VARIANTEN. TRIBUUERTE, BAUTEILVERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA.

FOR BINDING INFORMATION ON HODELS, TRINDING AND COMPONENTS VALUES AND MONFITTED COMPONENTS SEE PARTS LIST

Λ

5



SERVICEUNTERLAGEN ANZEIGE-TASTATUR 1062.6809.02

# Inhaltsverzeichnis

7	P	rüfen und Instandsetzen der Baugruppe	5
	7.1	Funktionsbeschreibung	5
		7.1.1 Tastaturmatrix	5
		7.1.2 Drehimpulsgeber	5
		7.1.3 Anzeigen	5
	7.2	Meßgeräte und Hilfsmittel	5
	7.3	Fehlersuche	6
	7.4	Prüfen und Abgleich	6
		7.4.1 Prüfen der Stromversorgung	6
		7.4.2 Prüfen der Tastaturmatrix	6
		7.4.3 Prüfen des Drehimpulsgebers	6
		7.4.4 Abgleich der LCD-Ansteuerung	6
		7.4.5 Prüfung der LCD- und LED-Ansteuerung	7
	7.5	Zerlegung und Zusammenbau	7
	7 6	Fytorne Schnittstollo	_

Schaltteilliste Koordinatenliste Stromlauf Bestückungsplan

## 7.1 Funktionsbeschreibung

Die Baugruppe besteht aus der Tastaturmatrix, Drehimpulsgeber und dem Anzeigeteil.

## 7.1.1 Tastaturmatrix

Die Eingabetasten des Gerätes sind an den Kreuzungspunkten einer Matrix angeordnet, deren Zeilen- und Spaltenleitungen mit einer Auswerteschaltung auf der Rechner-Baugruppe verbunden sind. Beim Betätigen einer Taste wird die Zeile, in der die Taste angeordnet ist, mit der ihr zugeordneten Spalte verbunden, wodurch auf der Rechner-Baugruppe ein Interrupt erzeugt wird, der den Rechner veranlasst, einen für diese Tastenstellung charakteristischen Code über den Datenbus einzulesen.

Den Parametertasten, SPEC- und der STATUS-Tasten sind Leuchtdioden zugeordnet, die zur Vereinfachung der Bedienung die zuletzt betätigte Taste anzeigen. Eine weitere LED dient als REMOTE-Anzeige. Die Ansteuerung der Tastatur-LEDs erfolgt über den Schieberegisterbausteine D3 und D4.

## 7.1.2 Drehimpulsgeber

Mit dem Drehimpulsgeber kann der jeweils aktivierte Parameter kontinuierlich variiert werden.

Der Drehimpulsgeber mit beiden Hallgeneratoren liefert zwei Pulsfolgen die je nach der Drehrichtung eine Phasendifferenz von + oder - 90 Grad haben. Die nachfolgende Schaltung wertet diese Phasendifferenz als Richtungserkennung aus.

Die Impulse steuern einen Schalter der den + oder - Tastendruck simuliert. Die Variationsschrittweite kann für jeden Parameter einzeln eingegeben werden.

### 7.1.3 Anzeigen

Zur Anzeige der aktuellen Geräteeinstellung besitzt das Gerät zwei LCD-Anzeigen, das Frequenz-Display sowie ein kombiniertes Amplituden-/Modulations-Display. Die Ansteuerung der Segmente der beiden Displays (H10, H20) erfolgt im Multiplexverfahren durch je einen Ansteuerbaustein (D1, D2).

Der Datenverkehr zwischen der Baugruppe Rechner und Anzeige/Tastatur erfolgt seriell. Die LCD-Anzeigen sind, um ihre Ablesbarkeit bei dunklen Umgebungsverhältnissen zu gewährleisten, hinterleuchtet. Der Kontrast der Segmente läßt sich mit R15 abgleichen.

## 7.2 Meßgeräte und Hilfsmittel

- Digitalmultimeter (z.B. R&S UDS5)
- Oszilloskop

#### Fehlersuche 7.3

Anzeige bleibt dunkel Betriebsspannungen (siehe Schnitt-

stellen) und Verkabelung überprü-

fen.

Kontrast der Anzeige

mangelhaft

Abgleich nach 7.4.4

Keine Reaktion auf Tastendruck Taste überprüfen. Erfolgt keine

Reaktion beim Betätigen von Tasten, so ist zu überprüfen, ob

eine Taste festsitzt.

Keine Reaktion bei Betätigen

des Drehimpulsgebers

Hallgenerator prüfen. Erfolgt keine Reaktion beim Betätigen so ist zu überprüfen, ob eine Taste

festsitzt.

#### 7.4 Prüfen und Abgleich

Alle Meßwerte ohne Toleranzangaben sind als Richtwerte zu verstehen. Spannungen ohne weitere Bezeichnungen bedeuten DC-Spannungen.

#### 7.4.1 Prüfen der Stromversorgung

- Ein Ampermeter in die Versorgungsleitungen der einzelnen Versorgungsspannungen einschleifen.
- \_ Die Stromaufnahme der Baugruppe überprüfen. Die Sollwerte zu den jeweiligen Versorgungsspannungen sind unter "Externe Schnittstellen" zu finden.

### Prüfen der Tastaturmatrix

\_ Die einzelnen Tasten der Tastenmatrix auf gute Kontaktgabe prüfen. Maximaler Widerstand gemessen an X1: < 2  $\Omega$ . Die Tastaturmatrix ist auf Kurzschluß zu prüfen.

#### Prüfen des Drehimpulsgebers 7.4.3

- An X1.24 und X1.26 Oszilloskop anschließen.
- Drehimpulsgeber in beide Richtungen drehen.
- \_ Am Oszilloskop müssen Impulse zu sehen sein.

#### Abgleich der LCD-Ansteuerung 7.4.4

\_ R15 so einstellen, daß sich aus frontaler Sicht auf das Display ein guter Kontrast ergibt, ohne daß aus einem Winkel von ca. 30 Grad die nicht angesteuerten Segmente sichtbar werden.

# 7.4.5 Prüfung der LCD- und LED-Ansteuerung

- Die Spezialfunktion 31 einschalten.
  - \_ LCD-Segmente und LED auf Funktion überprüfen.

# 7.5 Zerlegung und Zusammenbau

Nach dem Öffnen des Gerätes und dem Lösen der Schrauben auf der Frontplatte kann die Baugruppe aus dem Rahmen herausgenommen werden. Die Verbindung mit dem Gerät ist weiterhin über Flachbandkabel vorhanden, so daß die Baugruppe für Messungen zugänglich ist. Der Einbau der Baugruppe und Zusammenbau des Gerätes erfolgt entsprechend in umgekehrter Reihenfolge.

7.6 Externe Schnittstelle

Pin	Name	Ein/Ausgang	Herkunft	/Ziel	Wertebereich	Signalbeschreibung
x1.1	VA5-P	Eingang	A2 CPU	x1,1	+4.9V5.3V	+5V Versorgungsspannung
					max.0.2A	
X1.2	SERCLK	Eingang	A2 CPU	X1.2	HCHOS-Pege1	Seriell-Clock
X1.3	VA5-P	Eingang	A2 CPU	X1.3	+4.9V5.3V	+5V Versorgungsspannung
					max.0.2A	
X1.4	SERDATA	Eingang	A2 CPU	X1.4	HCMQS-Pegel	Seriell-Daten
X1.6	DIS1STB	Eingang	A2 CPU	X1.6	HCMOS-Pegel	Display Strobe 1
X1.8	DIS2STB	Eingang	A2 CPU	X1.8	HCMOS-Pegel	Display Strobe 2
X1.10	LEDSTB	Eingang	A2 CPU	X1.10	HCMOS-Pegel	LED-Strobe
X1.11	COL7	Ausgang	A2 CPU	x1.11	HCMOS-Pegel	Tasten-Code
X1.12	C/D#	Eingang	A2 CPU	X1.12	HCMOS-Pegel	Steuersignal
X1.13	COL6	Ausgang	A2 CPU	X1.13	HCMOS-Pegel	Tasten-Code
X1.14	DISBUSY#	Ausgang	A2 CPU	X1.14	HCMOS-Pegel	Steuersignal
X1.15	COL5	Ausgang	A2 CPU	X1.15	HCMOS-Pegel	Tasten-Code
X1.16	RES	Eingang	A2 CPU	X1.16	HCMOS-Pegel	Reset
X1.17	COL4	Ausgang	A2 CPU	X1.17	HCMOS-Pegel	Tasten-Code
X1.18	ROW5	Ausgang	A2 CPU	X1.18	HCMOS-Pegel	Tasten-Code
X1.19	COL3	Ausgang	A2 CPU	X1.19	HCMOS-Pege1	Tasten-Code
X1.20	ROW4	Ausgang	A2 CPU	X1.20	HCMOS-Pegel	Tasten-Code
X1.21	COL2	Ausgang	A2 CPU	X1.21	HCMOS-Pegel	Tasten-Code
X1.22	ROW3	Ausgang	A2 CPU	X1.22	HCHOS-Pegel	Tasten-Code
X1.23	COL1	Ausgang	A2 CPU	X1.23	HCMOS-Pegel	Tasten-Code
X1.24	ROW2	Ausgang	A2 CPU	X1.24	HCMOS-Pegel	Tasten-Code
X1.25	COL0	Ausgang	A2 CPU	X1.25	HCMOS-Pege1	Tasten-Code
X1.26	ROW1	Ausgang	A2 CPU	X1.26	HCMOS-Pegel	Tasten-Code

GND X1.5\7\9



SERVICE INSTRUCTIONS
Display-Keyboard
1062.6809.02

# Contents

,	Tes	ting and kepair of the module	=
	7.1	Function Description	5
		7.1.1 Keyboard Matrix	5
		7.1.2 Spinwheel	5
		7.1.3 Displays	5
	7.2	Test Instruments and Utilities	5
	7.3	Troubleshooting	6
	7.4	Testing and Adjustment	6
		7.4.1 Testing the Power Supply	6
		7.4.2 Testing the Keyboard Matrix	6
		7.4.3 Testing the Spinwheel	6
		7.4.4 Adjusting the LCD Control	6
		7.4.5 Testing Control of LCDs and LEDs	7
	7.5	Disassembly and Assembly	7
	7.6	Eyternal Interfaces	7

Parts list List of coordinates Circuit diagram Component layout diagram

#### 7.1 Function Description

The module consists of the keyboard matrix, spinwheel and the display unit.

#### 7.1.1 Keyboard Matrix

The keys of the instrument are assigned to cross-points of a matrix, the vertical and horizontal lines of which are connected to an evaluation logic on the controller board.

When a key is pressed, the vertical line this key is assigned to, is connected to the corresponding vertical line, thus triggering an interrupt on the controller board, which causes the controller to read in the code characteristic for this key arrangement via the data bus.

The parameter keys, SPEC keys and STATUS keys are assigned LEDs which indicate the key which was last pressed thus ensuring high operating ease. Another LED indicates the REMOTE state. The keyboard LEDs are addressed via the shift-register components D3 and D4.

#### 7.1.2 Spinwheel

The spinwheel enables continuous variation of the activated parameter.

In conjuntion with two Hall generators, the spinwheel generates two pulse sequences with a phase difference of +90 or -90 degress. The subsequent circuit determines the direction by evaluating this phase difference.

The pulses control a switch simulating the keystrokes + or -. The variation-step size can be entered individually for each parameter.

#### 7.1.3 Displays

The instrument provides two LCD displays indicating the current instrument setting, the frequency display and an amplitude/modulation display. The segments of the two displays (H10, H20) are addressed by one controller component each (D1, D2) which are multiplexed.

Data are transmitted serially between the controller module and the display/keyboard module. The LCD displays have a bright, illuminated background to ensure easy reading even in dark environments. The contrast of the segments can be adjusted using R15.

#### 7.2 Test Instruments and Utilities

- Digital multimeter (e.g., R&S UDS5)
- Oscilloscope

#### 7.3 Troubleshooting

Display remains dark Check operating voltages (see

interfaces) and cabling.

Poor contrast of display Adjust acc. to 7.4.4

No reaction upon keystroke Check key. If keystrokes do not

cause any reaction, check, whether

any key has got stuck.

No reaction upon actuating the Check Hall generator. If no spinwheel

reaction is caused by actuating

the spinwheel, check, whether any

key has got stuck.

#### 7.4 Testing and Adjustment

All measured values indicated without tolerances are recommended values. Voltages given without any further detail are dc voltages.

## Testing the Power Supply

- · Connect an ammeter into the supply lines of the supply voltages.
- \_ Check the power consumption of the module. The rated values of the individual supply voltages can be looked up under "External Interfaces".

#### 7.4.2 Testing the Keyboard Matrix

- \_ Check the contacting of the individual keys of the keyboard matrix. Maximum resistance measured at X1: < 2  $\Omega$ .
- Check the keyboard matrix with regard to short-circuit.

#### Testing the Spinwheel 7.4.3

- Connect an oscilloscope to X1.24 and X1.26.
- Turn the spinwheel into both directions.
- \_ Pulses must be visible on the oscilloscope.

#### Adjusting the LCD Control 7.4.4

\_ Adjust R15 such that a good contrast is obtained with frontal view on the display without the non-addressed segments becoming visible from an angle of 30 degrees.

# 7.4.5 Testing Control of LCDs and LEDs

- Switch on special function 31.
- \_ Check function of LCD segments and LEDs.

# 7.5 Disassembly and Assembly

Subsequent to opening the instrument and undoing the screws on the front panel, the module can be removed from the frame. The module is still connected to the instrument via ribbon cables, thus being accessible for measurements.

Installation of the module and reassembly of the instrument are carried out in the reverse order.

7.6 External Interfaces

Pin	Name	Input/Output	origin/	Dest-	Specified range	Signal description
x1.1	VA5~P	Input	A2 CPU	X1.1	+4.9.5.3V	+5V supply voltage
					max.0.2A	
X1.2	SERCLK	Input	A2 CPU	X1,2	HCHOS level	Serial clock
X1.3	VA5-P	Input	A2 CPU	X1.3	+4.9.5.3V	+5V supply voltage
					max.0.2A	
X1.4	SERDATA	Input	A2 CPU	X1.4	HCMOS level	Serial data
X1.6	DIS1STB	Input	A2 CPU	X1.6	HCHOS level	Display strobe 1
X1.8	DIS2STB	Input	A2 CPU	X1.8	HCMOS level	Display strobe 2
X1.10	LEDSTB	Input	A2 CPU	X1.10	HCMOS level	LED strobe
X1.11	COL7	Output	A2 CPU	X1.11	HCHOS level	Key code
X1.12	C/D#	Input	A2 CPU	X1.12	HCHOS level	Control signal
X1.13	COL6	Output	A2 CPU	X1.13	HCMOS level	Xey code
X1.14	DISBUSY#	Output	A2 CPU	X1.14	HCMOS level	Control signal
X1.15	COL5	Output	A2 CPU	X1.15	HCMOS level	Key code
X1.16	RES	Input	A2 CPU	X1.16	HCMOS level	Reset
X1.17	COL4	Output	A2 CPU	X1.17	HCMOS level	Key code
X1.18	ROWS	Output	A2 CPU	X1.18	HCHOS level	Key code
X1.19	COL3	Output	A2 CPU	X1.19	HCHOS level	Key code
X1.20	ROW4	Output	A2 CPU	X1.20	HCMOS level	Key code
X1.21	COL2	Output	A2 CPU	X1.21	HCMOS level	Key code
X1.22	ROW3	Output	A2 CPU	X1.22	HCHOS level	Key code
X1.23	COL1	Output	A2 CPU	X1.23	HCMOS level	Key code
X1.24	ROW2	Output	A2 CPU	X1.24	HCMOS level	Xey code
X1.25	COT0	Output	A2 CPU	X1.25	HCMOS level	Xey code
X1.26	ROW1	Output	A2 CPU	X1.26	HCMOS level	Key code

GND X1.5\7\9



Schaltteillisten numerisch geordnet Part lists in numerical order Listes des pièces détachées par numéros de référence



# XY-Liste

# **XY List**

## Erklärung der Spaltenbezeichnungen:

Part: Bauelement-Kennzeichen.

Side: \_\_\_ Leiterplatten-Seite, auf der sich das Bauelement befindet.

XY: Koordinaten (Millimeter) des Bauelementes auf der Leiterplatte

bezogen auf den Nullpunkt.

SQR, PG: Planquadrat und Seite des Schaltbildes für das jeweilige Bauelement.

### Explanation of column designations:

Part: Identification of instrument part.

Side: Side of the PC board on which instrument part is positioned.

XY: Coordinates (millimeter) of the component on the PC board in reference

to zero point.

SQR, PG: Square and page of the diagram for the respective instrument part.

Kennz. Comp. No.		Bene. Desig				Sechnummer Stock No.	Hersteller Manufecturer	Bezeichnung Designation		heiten in Italned in
B1		N312OU EFF.SWIT		L-EFF.SW.	В	J 0336.4750.00		A3144EU		
B2	BS UG		HAL	.L~EFF.SW.	В.	J 0336.47S0.00	ALLEGRO	A3144EU		
C1 4	SMD CE	ERAMIC C	APA		1		1	2222 B63 *8102		
C5 7	CERAMI	IC CHIP	CAP		CC	0007.5237.00	PHILIPS_CO	223B S81 1S649		
C8		2NF+-10% IC CHIP		X7R 1206 ACITOR	cc	0099.8444.00	PHILIPS_CO	2222 SB1 16618		
C9	CE 4,7	7U F+-10 _UM SMD-	% 1	OV 3528	CE	0007.7275.00	SPRAGUE	293D 47S X9 010 B2T		
C11	CC 100	ONF+-10%	SOV	X7R 1206	cc	0007.5237.00	PHILIPS_CO	2238 S81 15649		
C20	CC 100		50V	X7R 1206	cc	0007.5237.00	PHILIPS_CO	223B 581 1S649		
C21	CC 100		50V	X7R 1206	cc	0007.5237.00	PHILIPS_CO	2238 581 15649		
D1		7225G00		CD DRIV	ВЈ	0392.5320.00	NEC	D722SG (JG)		
D2	BJ UPD	722SG00	L	CD DRIV	ВЈ	0392.5320.00	NEC	D722SG (JG)		
D3	BL PC7	4HC4094	T 85	TR/DRIVER ST.BUSREG	BL	0804.0977.00	PHILIPS_SE	(PC)74HC4094(D/T)		
D4	BL PC7		T BS	ST.BUSREG	BL	0804.0977.00	PHILIPS_SE	(PC)74HC4094(D/T)		
D5	BL PC7	GISTER 4HCTB6T	4)	(2IN.EXOR	BL	0007.6291.00	PHILIPS_SE	(PC)74HCT86(D/T)		
D6		4HCT74T		O-FLIPFL	BL	0007.6262.00	PHILIPS_SE	(PC)74HCT74D(T)		
D7	BL PC7	-TYPE FL 4HCTO8T		FLOP (2IN ANDG	BL	0007.6179.00	PHILIPS_SE	(PC)74HCTO8(D/T)		
D8			5T 4	XASWITCH	8L	0007.6862.00	PHILIPS	(PC)74HCT4066(T)		
41		5V 0,06	١٥.	SOCKEL	EF	0234.4375.00	OSHIND	OL-6B3		
4 110	GLOW L.	127				0826.8587.00	VARITRONIX	R&S 0826.8587		
H20	BP AN LCO-MOI	126				0826.8570.00	VARITRONIX	R&S 0826.8570		
JS1	S8 TAS	TENKAPPE	6X	10,5 HGR	SB	0396.0122.00	DEKORSY	R&S.ZCHNG.396.0122		
3 JS4	SB TAS	10,5 HGR TENKAP.6	( 5X 10	,5 BLAU	SB	0396.0174.00	OEKORSY	R&S.ZCHNG.396.0174		
JS5	PUSHBUT	TENKAPPE	6X	10,5 HGR	SB	0396.0122.00	DEKORSY	R&S.ZCHNG.396.0122		
10 JS11	SB KAPI	10,5 HGR PE GR 10		10,5	SB	0396.0048.00	DEKORSY	R&S.ZCHNG.396.004S		
JS 12		PE GR 10	, SX	10,5	SB	0396.0048.00		R&S. ZCHNG. 396.0045		
JS 13		PE GR 10	,5X	10,5	SB	0396.0045.00		R&S.ZCHNG.396.0045		
JS14	PUSHBUT SB TAST	TENKAPPE	6X	10,S HGR		0396.0122.00		R&S. ZCHNG. 396. 0122		
17 IS18	SB KAPP	10,S HGR PE HGR.1	0,5	X10,5″0"		0396.0216.00		R&S.ZCHNG.396.0216		
IS 19	CAP "O' SB KAPE	PE HGR.1	<b>0,</b> s	X10,S"1"	SB	0396.0222.00		R&S.ZCHNG.396.0222		
S20	CAP "1" SB KAPP	" PE HGR.1		X10,S#4#		0396.0251.00		R&S.ZCHNG.396.0251		
IS21	CAP "4" SB KAPP	, PE HGR.1				0396.0280.00		R&S. ZCHNG. 396. 0280		
IS 22	PUSHBUT SB KAPP	TTON PE HGR.1	0,S	X10,S"."		0396.0339.00		R&S. ZCHNG. 396. 0339		
JS23	CAP HGR SB KAPP	R.10,SX1 PE HGR.1	0,5			0396.0239.00		R&S.ZCHNG.396.0239		
JS24		PE HGR. 1	0,S	X10,S"S"		0396.0268.00		R&S.ZCHNG.396.0268		
JS25		E HGR.1	0,5	X10,S"B"	SB	0396.0297.00		R&S.ZCHNG.396.0297		
JS26		E HGR. 1		X10,5"-"	SB	0396.0322.00		R&S. ZCHNG. 396. 0322		
JS27					SB	0396.0245.00		ZEICHNUNG 396.024S		
MENPS	413	3PUA	ÄL	Datum Dete		Scheittellis		Sachnummer		Blatt-N
<u> </u>			06		E	Parts list  D TASTATUR/AN		1062.6809.01	SA	Pege 1+
'OUDE	&SCH\	WAKZ			K	AYBOARD/DISPLA	ΑY			


	Kennz. Comp. No.		gene: Desig	nnung netion				nummer ock No.	Hersteller Manufacturer		Bezeichnung Designetion		heiten in teined in
	JS2B				5X10,5"6"	SB	0396	6.0274.00	DEKORSY		S.ZCHNG.396.0274		
	JS29	SB KAP	JTTON "6 PPE HGR.		5X10,5"9"	SB	0396	6.0300.00	DEKORSY	R&	S.ZCHNG.396.0300		
	JS30		STENKAPP		X10,5 HGR	SB	0396	6.0122.00	DEKORSY	R&	S.ZCHNG.396.0122		
	,33 JS37	SB TAS	(10,5 HG STENKAPP (10,5 HG	E 6	X10,5 HGR	SB	0396	3.0122.00	DEKORSY	R&	S.ZCHNG.396.0122		
	L1	LD 100 CHOKE	OUH 20%	1A (	0,6500HM	LD	0155	5.9446. <b>0</b> 0	SIEMENS	В8:	2111-E-C25		
	N1		240AE 2 OSFET-I		SFETOPAMP COPAMP		0302	.7040.00	RCA	CA	3240AE		
	P1	VL EIN PIN	PRESSST	IFT	L=6,B	VL	00 10	.7250.00	AMP	1-9	928776-5		
ı	R1		KOHM+- OR CHIP	1%TK	100 1206	RG	0007	.5989.00	ROEDERSTEI	DC	2 1B2KOHM 1%TK100		
1	R3	RG 1,0	KO +-1	%TK <sup>-</sup>	100 1206	RG	0006	.7271.00	ROEDERSTEI	DC	2 1,0KOHM 1%TK100		
ĺ	R4	RG 1,0	ESISTOR KO +-19	%TK 1	00 1206	RG	0006	.7271.00	ROEDERSTEI	DC	2 1,0KOHM 1%TK100		1
ı	R5_	RG 100		1 <b>%</b> TK	100 1206	RG	0007	. 1948.00	ROEDERSTEI	DC	2 100KOHM 1%TK100		
	7 R8	RG 182		1%TK	100 1206	RG	0007	.5989.00	ROEDERSTEI	DC2	2 182KOHM 1%TK 100		
	R9	RG 100		1%TK	100 1206	RG	0007	. 1948.00	ROEDERSTEI	DC2	2 100K0HM 1%TK100		İ
	11 R12	RG 6B1		1 <b>%</b> TK	100 1206	RG	0007	.6110.00	ROEDERSTEI	DC2	2 681KOHM 1%TK100		
ı	R13	RG 100		1%TK	100 1206	RG	0007	. 1948.00	ROEDERSTEI	002	2 100K0HM 1%TK100		
	R14	RG 47,5	ESISTOR 5KOHM+-1	I%TK	100 1206	ŀ					2 47,5KOHM 1%TK100		
	R15		WSKOHM+-		10X 10X5				SPECTROL		M TO 10		
	R16	RG 5,62							ļ		5,62KOHM 1%TK100		
ı	R17		ESISTOR 1KOHM+-1	'%TK							22,1KOHM 1%TK100		
	R18	RESISTO	OR CHIP								10,0K0HM 1%TK100		
	R20	RG CHIF	RESIST	OR							1,0K0HM 1%TK100		
	25 R26	CHIP RE	ESISTOR								1,82K0HM 1%TK100		1
	R27	RESISTO		%TK					İ		10,0K0HM 1%TK100		
	29 R30	RG CHIP	RESIST	OR							1,0K0HM 1%TK100		
	39 R40 45	CHIP RE	ESISTOR 2KOHM+-1								56,2KOHM 1%TK100		
	S1		ER 1XA			SB	0238.	3850.00	SIEMENS	V42	263-D32-M2		
	33 \$37	PUSHBUT SB TAST	TON SWI	TCH	E KNOPF				SIEMENS		263-D32-M2		
			TON SWI										
	V1	AK BC85 TRANSIS		45	/ 200MA	AK	0007.	7969.00	VALVO	всв	50B		
	V2 11	AF HLMP LED	1790 L	ED3	GN569N	•	0007.	5250.00	QUALITY	HLM	P-1790.741BD		
	X1 X10	DY KABE FP STIF PIN CON 2-POLIG	TLEISTE INECTOR	361	P.R2,54			6B73.00 3600.00	BINDER	742	-11-0179-00-36		
	100												
T	MENP5	413	3PUA	Äi	Datum Date			Schaltteilli Parts lie			Sachnummer		Blatt-Nr.
	ROHDE			06	16.09.97			Perts lis	ZEIGE		1062.6809.01	SA	Pege 2-
L						K	AYBOA	RD/DISPL	.AY				

					+						+					
Part	Side X	Y 	Sqr	Pg	Part	Sid	le X	Y	Sqr	Pg	Part	Sid	e X	Y	Sqr	Pg
В1	в 290			3	нз	A	169	88	11D	2	R45	A	. 22	48	2C	2
B2	В 284			3	H4	A	294			2	S1	В	19	9	6F	3
C1	A 112	74		2	H10	В				2	S2	В	19	24	6E	3
C2	A 107	78		2	H20	В		81		2	53	В	19	55	6E	3
C3	A 214	76		2	L1	В		48		2	S4	В	50	9	6E	3
C4	A 222	78		2	N1-A	В	150	100		2	S5	В	_			3
C5	A 166	105		2	N1-B				7A	2	S6	В				3
C6	A 161	93		2	N1-C	_			8A	2	S7	В				3
C7	A 299	54		3	P1		155	76		2	S8	В	91			3
C8 C9	A 282	64		3	R1		112	88		2	S9	В	91			3
C11	A 231 A 14	64		3	R3	A		51	2C	2	S10	В	91			3
C12		19		2	R4	A		48		2	S11	В	109	13		3
C12	A 30 A 130	48 36		2	R5		110	74		2	S12	В	109	34		3
C14	A 130	22	2A 3A	3 3	R6 R7		105	78	2A	2	S13	В	109	55	7£	3
C15	A 248	65	4A	3	R8		102 224	74 84	3A	2	S14	В	138	9	7E	3
C16	A 262	68	4A	3	R9		219	74	8F	2	515		138	24	7D	3
C17	A 243	56	5A	3	R10		217	74	4A 4A	2	516		138	39	7F	3
C18	A 237	54	6A	3	R11		214	78	4A 4A	2	S17		138	55	7E	3
C20	A 92	76	1A	2	R12		149		5A	2 2	S18		168	13	7E	3
C21	A 207	74	3A	2	R13		153	98		2	519		168	29	7E	3
D1-A	A 105	82	4F	2	R14		165	98	5A 58	2	S20	В	168	44	7D	3
D1-B	H 105	OZ.	2A	2	R15		157	93			521		168	59	8F	3
D1-C			2A	2	R16		161	90	5B	2	S22		184	13	8E	3
D2-A	A 217	82	7F	2	R17		164		5A		S23	8	184	29	8E	3
D2-8	,	02	3 <b>A</b>	2	R18		158		6A 7A	2	S24 S25	8	184	44	38 30	3
D2-C			4A	2	R20		295	51	20	3	S25 S26	В	184	59	8D	3
03-A	A 121	36	9D	3	R21		276	68	2D	3	S27	B B	199 199	13 29	8F 8E	3 3
D3-8			28	3	R22		294	58	20	3	S28	8	199	44	8E	3
04-A	A 121	23	9C	3	R23		263	59	2C	3	S29	В	199	59	8E	3
04-B			2B	3	R24		246	56	3D	3	S30	В	222	9	80	3
05-A	A 272	68	30	3	R25		260	62	3E	3	S31		222	24	8F	3
D5-B			30	3	R26		231	57	4C	3	S32		222	39	8E	3
05-C			3C	3	R27		243	67	7A	3	S33	8	222	55	8E	3
05-D			7A	3	R28		259	65	7A	3	S37	8	50	55	9E	3
D5-E			3B	3	R29		133	33	9E	3	V1			104	5A	2
D6-A	A 257	63	3D	3	R30	A	18		10E	3	V2	В	15	39	10E	3
D6-B			3C	3	R31	A	49		10E	3	V3	В	45		10E	3
D6-C			4B	3	R32	A	55		10E	3	V4	В	45		10E	3
D7-A	A 234	57	4C	3	R33	A	90		11E	3	V5	В	86		11E	3
D7-B			5C	3	R34	A	97		11E	3	V6	В	86		11E	3
D7-C			7B	3	R35	A	99		11E	3	V7	В	86		11E	3
D7-D			7A	3	R36	A	90		11E	3	V8	В	86		11E	3
D7-E			5B	3	R37		109		11E	3	V9		105		11E	3
A-80	A 233	44	<b>4</b> E	3	R38		109		11E	3	V10		105		11E	3
D8-B			4D	3	R39		109		11E	3	V11		105		11E	3
D8-C			4D	3	R40	A	20	32	2D	2 ·	X1	В	5	15	1F	2
D8-D			4D	3	R41	A	20	35	2D	2	X10		255	52	4E	3
D8-E			6B	3	R42	A	29	21	20	2	X11		252	52	4E	3
H1	A 16	98	10D	2	R43	A	29	23	2D	2		_				
H2	A 146		10D	2	R44	Α	22	52	2C	2						

ROHDE	-I	Datum Date	XY-Liste f <sup>r</sup> r XY-list for	Sach-Nummer Stock-Nr	Blatt Page
SCHWARZ	1	07.07.93	ED ANZEIGE-TASTATUR DISPLAY-KEYBOARD	1062.6809.01 XY	1-



Stromläufe
Bestückungspläne
Circuit diagrams
Components plans
Schémas de circuit
Plans des composants






# STROMLAUF GILT FUER VAR.01/02

CIRCUIT DIAGRAM IS VALID FOR MOD 01/02

H20

LCD10X 7SEGM



TRS BENERNUNG 01/ 1GPK BEARB. SP ANZEIGE-TASTATUR GEPR. NORM DISPLAY-KEYBOARD PLOTT 08.04.94 BLSTT-NR. ZEICHN.-NR. 2+ 1062.6809.015 ROHDE&SCHUARZ RENDERUNGS-DATUM NAME MITTELLUNG 1062,5502 1052.5502


9


10

1

- 12

\$03






END.	RENOERUNGS. Mitteilung	DATUN	NAME	ZU GERAET	
				® ROH	ሰልፎ
				PLOTT	08.
				NORM	
				GEPR.	
				BEARB.	
1/			SP	1GPK	Ţ


6

EGM


+5V

1 28508-L





4



ΙU


# STROMLAUF GILT FUER VAR.02


CIRCUIT DIAGRAM IS VALID FOR MOD.02





ATTENTION ESD!
ELECTROSTATIC SENSITIVE DEVICES
PREQUIRE A SPECIAL HANDLING


01/			SP	1 GPK BEARB. SEPR. NORH PLOTT	78G 28.04.94	KANE SP SP	ŧ	S I <b>ZE I GE - TAS</b> Splay-keyboard	TATUR	
/ AEND.	AENDERUNGS-	DATUM	NAME	ROH		HUARZ	ZEICHN)	1062.68		
IND.	NITTEILUNG			ZU GERAET		n	RES.1.V.	1052.5502 11	ERSTE Z.	1062.5502











				GEPR. HDRN PLOTT	08.04.94	SP		IZEIGE-TA SPLAY-KEYBOAR			Z
/	AT HAT DAILE		-	\$\$\ \$0\	DEASC	HUARZ	ZEICKH		809.01	ED	3LRTT-MR. 1+ v. el.
REND.	RENDERUNGS- Ritteilung	PRTER	HBITE	SQ SERVE		,,,	REG. I. ♥.	1062.5502	ERSTE Z.	1062.550	2
A 1				1		o :		1.0			

1 161 H10 (F) P 1 929 1 \$17<sup>1</sup> \$3 1 \$37 1 \$13 1 S 6 \$10 1 \$20 1 39 \$16 \$12 \$19 \$23 L \$27 1 58 4 \$15 1 32 1 35 318 1 522 526 1 100 | 150 200 1 1 l 1 1 1 1 50

RCHTUNG: EGB!
ELEKTROSTATISCH GEFRENDETE
BRUELERENE BEROOPERE EINE
DESONDERE MINDKROUNG.
ATTENTION ESD!
ELECTROSTATIS ERISITIVE BEVILES
REQUIRE & SPECIAL MANDLING

3


BINDENDE ANGABEN VEBER VARIANTEN, TRINNVERTE, BAVTEILVERTE VND NICHT BESTVECKTE BAUTEILE SIENE SA


FOR BINDING INFORMATION ON MODELS, TRIMMINS AND COMPONENTS VALUES AND NORFITTED COMPONENTS SEE PARTS LIST.


Λ 5

6

8\_\_\_







TRIMMUERTE, BRUTEILUERTE UND RICHT BESTUECKTE BRUTEILE SIERE SA.

FOR BINDING INFORMATION ON MODELS, TRINNING RAP COMPONENTS VALUES AND RORFITTED COMPONENTS SEE PARTS LIST.

4


1

SP 1GP
DCHR
GEFR
NORH
PLOT
RS
RC
ZU GE


DATUM

AENDERUHGS-Mitteilung

9



LUNG SEITE A Side a



BINDENDE ANGRSEN WEBER VARINNTEN, TRINNWERTE, BAUTEILUERTE UND HICHT BESTWECKTE ARUTEILE SIENE SA.

FOR BINDING INFORMATION ON MODELS, TRIMBING AND COMPONENTS VALUES AND MORFITTED COMPONENTS SEE PARTS LIST.

4

T A

**\*** 2 CTS CTS C16 R26 C7 R20 Ē FUER DIESE ZEICHNUNG 157 EIN RECHNERRUSDRUCK, RENDERUNGEN KOENNEN NUR DURCH RENDERM DES DATENBATZES BRFCLASEM D 250 200 С

> DARSTELLUNG SEITE A VIEW ON SIDE A

В

Α



BINDENDE ANGABEN VEBER VARIBATEN, TRIMMWERTE, BAUTEILUERTE UND NICHT BESTBECKTE BRUTEILE SIERE SA.

FOR BINDING INFORMATION ON MODELS, TRIMBING BID COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.

ΤΛ

5

4



SERVICEUNTERLAGEN
Baugruppe Synthesizer
1062.6409.01

# Inhaltsverzeichnis

7 Prü	fen un	d Instandsetzen der Baugruppe 5
7.1	Funkt	ionsbeschreibung5
	7.1.1	Referenzfrequenzen
	7.1.2	Synthesizer 651040 MHz       6         7.1.2.1 Oszillatoren 5201040 MHz       6         7.1.2.2 Ausgangsteiler       6         7.1.2.3 Fractional-N-Teiler und PLL       6
	7.1.3	FM/φM Modulation
	7.1.4	Kalibrierroutinen       8         7.1.4.1 VCO-Kalibrierung       8         7.1.4.2 FM-Kalibrierung       8
7.2	Meßge	räte und Hilfsmittel9
7.3	Fehler	rsuche9
	7.3.1	Synchronisierfehler9
	7.3.2	Fehler bei CW-Betrieb 10
	7.3.3	Fehler bei FM-/φM-Modulation
	7.3.4	Kalibrierungen11
7.4	Prüfer	und Abgleich12
	7.4.1	Datenübertragung und Stromversorgung 12
	7.4.2	Referenzfrequenzerzeugung       12         7.4.2.1 Referenz Intern       12         7.4.2.2 Referenz Extern       13
	7.4.3	640 MHz Referenz       13         7.4.3.1 Oszillator 640 MHz und PLL       13         7.4.3.2 Ausgangsverstärker 640 MHz       14
	7.4.4	Ausgangsoszillatoren
	7.4.5 7.4.6	PLL der Ausgangsoszillatoren
		Prüfen des Hubteilers

7.4.8 EXT-Überwachung	. 19
7.4.9 Sigma-Delta-Wandler mit FM-DC-Regelung	. 19
7.4.10 FM-Hubeinstellung	. 19
7.4.10.1 Überprüfung FM-Diagnosedetektor	
7.4.10.2 Abgleich FM-Hub	. 20
7.4.10.3 Überprüfung der FM-Kalibrierung	. 20
7.4.11 Einschwingverhalten der Synthese	. 20
7.4.12 Endprüfungen Synthese	. 21
7.4.12.1 Störhub Synthesizer	
7.4.12.2 Störhub 640 MHz Oszillator	. 22
7.4.12.3 Nebenwellen Synthesizer	. 22
7.4.12.4 FM-DC Mittenfrequenzkalibrierung	. 22
7.4.13 Tabellen und Schnittstellen	. 22
7.4.13.1 Liste der Diagnosemeßpunkte	. 22
7.4.13.2 Digitale Schnittstelle	. 23
7.4.13.3 Arbeitspunkte und Pegel von HF-Verstärkern	. 25
7.5 Zerlegung und Zusammenbau	. 26
7.6 Externe Schnittstellen	. 26

Schaltteilliste Koordinatenliste Stromlauf Bestückungsplan

# 7.1 Funktionsbeschreibung

Die Baugruppe YSYN enthält einen FM/φM modulierbaren Synthesizer von 65...1040 MHz, den Hubteiler für FM/φM sowie die Referenzfrequenzerzeugung, bestehend aus einem 10 MHz VTCXO sowie einem 640 MHz Oszillator als LO für den Mischerbereich der Ausgangsstufe.

#### 7.1.1 Referenzfrequenzen

#### 7.1.1.1 Referenz Intern 10 MHz

Als Standardreferenz wird ein 10 MHz VTCXO (N200) verwendet. Ein Emitterfolger mit Pegelwandler (V205 und V210) verstärkt das Ausgangssignal auf TTL-Pegel (Meßpunkt P201). Gleichzeitig wird hier das Signal der Optionsreferenz (Eingang X128, OPT10) eingespeist. In dieser Betriebsart wird der Standardoszillator mit dem Schalttransistor V200 ausgeschaltet und der Zweig für die Optionsreferenz über die Diode V235 durchgeschaltet. Die Teilerstufe (D205-A) erzeugt die 2 MHz Referenzfrequenz für die PLL der Ausgangsoszillatoren und den Sigma-Delta-Wandler sowie die 1 MHz Vergleichsfrequenz für den Phasendetektor der Referenz-PLL (Meßpunkt P202). Das über D200 ausgekoppelte 10 MHz Signal dient als Referenzfrequenz für die PLL des 640 MHz Oszillators. In dieser Betriebsart steht entweder die Standardreferenz oder, falls bestückt, die Optionsreferenz am Ausgang X127 (EXTREF) zur Verfügung. Die genaue Frequenzeinstellung geschieht mit einem 12-Bit-D/A-Wandler (D220), dem eine 10 Volt Referenzspannung (+10REF) zur Verfügung steht (Abstimmspannung UINT oder OPTTUNE).

#### 7.1.1.2 Referenz Extern 5 oder 10 MHz

In der Betriebsart Referenz Extern können 5 MHz oder 10 MHz mit einer Toleranz von ± 3 ppm an X127 (EXT REF) eingespeist werden. Eine Diodenschaltung (V220) erzeugt dazu ein Oberwellenspektrum, ein Resonanzverstärker (V215) filtert das 10-MHz-Signal aus und der folgende Pegelwandler (V216) verstärkt es auf TTL-Pegel (Meßpunkt P204). Nach Frequenzteilung durch 10 (D205-B) wird es im Phasendetektor D210 mit der heruntergeteilten Frequenz des TCXO's verglichen. Der Standardreferenzoszillator wird hierbei in einer PLL mit einer Bandbreite von 2 Hz auf die externe Referenz synchronisiert. Die Abstimmspannung der PLL kann an P203 (U-PLL-VTCXO) nachgemessen werden. Ist ein optionaler Referenzoszillator (SM-B1) vorhanden, so ist dessen Pegel in der Betriebsart Ext. Referenz abgeschaltet.

Über einen Spannungsfolger (N220-C) wird die Abstimmspannung des Oszillators in beiden Betriebsarten mit dem Fensterkomperator N100 überwacht.

#### 7.1.1.3 640 MHz Oszillator mit PLL

Der 640 MHz Oszillator ist mit einem keramischen Resonator (X300) aufgebaut, der mit einer Kapazitätsdiode (V300) fein abgestimmt wird. Die Transistorstufe V305 entdämpft mit ihrer negativen Impedanz den Schwingkreis. Über einen Trennverstärker (N300) wird das Oszillatorsignal am Emitter ausgekoppelt.

Über einen ohmschen Leistungsteiler verteilt sich das Signal auf den Ausgangsverstärker (V330) sowie den Frequenzteiler (B360), der das Signal für die PLL auf 10 MHz herunterteilt.

Der Ausgangsverstärker mit einem "Dual Gate MESFET" (V330) verstärkt das Oszillatorsignal auf ca 10 dBm (X125, REF640). Ist der Mischerzweig im Ausgangsteil nicht aktiv, so läßt sich über die Schalttransistoren (V340, V345) der Ausgangspegel über das Gate2 des Ausgangsverstärkers um mehr als 40 dB absenken (Steuersignal S-Ref 640).

Das über den Festteiler durch 64 erzeugte Signal wird mit der Transistorstufe V370 auf TTL-Pegel gewandelt (Meßpunkt P354) und wird am Phasendetektor (D255) mit der 10-MHz-Referenzfrequenz verglichen. Die Ausgangsspannung des PI-Reglers (N250) stimmt den Oszillator ab, die Bandbreite der PLL beträgt ca. 300 Hz. Der Pegel des 640-MHz-Ausgangsverstärkers wird von einem Diagnosegleichrichter (V347) gemessen. Die Regelspannung der PLL wird von einem Fensterkomparator (N105) überwacht.

#### 7.1.2 Synthesizer 65...1040 MHz

#### 7.1.2.1 Oszillatoren 520..1040 MHz

Zwei Oszillatoren mit einem Abstimmbereich von jeweils 260 MHz erzeugen die Frequenz der Grundoktave. Ein Transistor mit einer negativen Impedanz an der Basis (V404 und V434) entdämpft den Serienschwingkreis, der aus einem Porzellankondensator (C402 und C432), einer gedruckten Induktivität und zwei mal zwei parallel geschalteten Kapazitätsdioden (V400-V403 und V430-V433) besteht. Durch die geringen Toleranzen der schwingkreisbestimmenden Elemente ist kein Frequenzabgleich der Oszillatoren notwendig. Eine Stromquelle (V406 und V436), deren Versorgungsspannung über eine Transistorstufe ein-und ausgeschaltet werden kann, stabilisiert den Arbeitspunkt des Oszillators über den Abstimmbereich. Über einen PIN-Schalter (V490 und V492) wird das Ausgangssignal, je nach aktivem Oszillator, zu der Trennstufe N490 geführt. Ein ohmscher Leistungsteiler verzweigt das Oszillatorsignal auf die Ausgangsteiler sowie den Fractional-N-Teiler der PLL.

#### 7.1.2.2 Ausgangsteiler

Die Ausgangsfrequenzen von 65...520 MHz werden durch Frequenzteilung durch zwei, vier und acht realisiert. Es werden ein Teiler durch 2 (D510) und ein Teiler durch 4 (D520) verwendet. Durch Kettenschaltung der beiden Teiler entsteht der Teilerfaktor acht. Die einzelnen Signalpfade werden über PIN-Schalter (S1...S6) geschaltet. Die Teilerbausteine werden über die Versorgungsspannung mit den Transistoren V510 und V520 ein- und ausgeschaltet. Der Ausgangsverstärker N560 erhöht den Pegel auf ca. 8..12 dBm. Dieser Ausgangspegel wird über den Diagnosegleichrichter V555 überwacht.

# 7.1.2.3 Fractional-N-Teiler und PLL

Die Ausgangsoszillatoren werden in einer PLL mit einem Fractional-Divider auf die Referenzfrequenz von 2 MHz geregelt. Dieser Schaltungsteil ist im Gatearray FRACSYN (D65) integriert. Die beiden MMIC-Verstärker N600 und N610 entkoppeln die Teilerschaltung von den Oszillatoren. Die beiden Frequenzteiler (D620 und D630) teilen die Oszillatorfrequenz durch 16 und liefern somit Eingangsfrequenzen von 32.5...65 MHz für den FRACSYN, der die eigentliche Fractional-Teilung durchführt (Meßpunkt P600).

Der Baustein FRACSYN berechnet für jede Referenzperiode, aus dem über eine serielle Schnittstelle programmierten Teilungsfaktor sowie dem eingestellten Hub, den neuen Teilungsfaktor. Dessen Ausgangstakt CKO von 2 MHz wird mit dem Synchronisierflipflop D655 auf den Eingangstakt des FRACSYN synchronisiert. Das synchronisierte 2 MHz Signal gelangt von hier zum Phasendetektor D700. Die aus dem Phasenvergleich mit der 2 MHz Referenzfrequenz (2REF) gewonnenen UP/DOWN-Ausgangsignale des Phasendetektors werden in dem Differenzverstärker N710 addiert (Meßpunkt P700). Die Verstärkung des folgenden PI-Reglers (N720) läßt sich zur Kompensation der Verstärkungsänderungen in der PLL, hervorgerufen durch den unterschiedlichen Teilungsfaktor sowie die unterschiedliche VCO-Steilheit, mit einem Analogmultiplexer (D720) in 8 Stufen einstellen. Eine Transistorendstufe (V750 und V755) mit Diodenumschaltung der PLL-Bandbreite (V765...768) beschleunigt den Einschwingvorgang der Regelschleife bei Frequenzwechsel.

Die Ausgangsspannung des PI-Reglers (A-PI-SYN) wird von einem Fensterkomparator überwacht (N110). Die Abstimmspannung der Oszillatoren kann über eine Diagnosestelle gemessen werden.

## 7.1.3 FM/φM Modulation

### 7.1.3.1 Funktionsprinzip

Durch die Verwendung eines Bruchteilers mit einem digitalen Modulationseingang läßt sich eine relativ einfache und dennoch präzise FM AC/DC und  $\phi$ M-Schaltung realisieren.

Dabei wird die Modulation über zwei Pfade mit unterschiedlichen Frequenzgängen übertragen. In dem ersten Pfad wird bei FM nach A/D-Wandlung mit einem Sigma-Delta-Wandler direkt der Teilungsfaktor und damit die momentane Mittenfrequenz moduliert. Dieser Teil hat die Tiefpaßfunktion für die Nutzübertragung einer PLL, gleichzeitig ist hier die PLL ein Tiefpaß für das Quantisierungsgeräusch des A/D-Wandlers. In dem zweiten Pfad wird direkt der Oszillator moduliert, dieser Teil hat die Hochpaßfunktion für die Störübertragung einer PLL. Bei gleicher Empfindlichkeit und Laufzeit in beiden Zweigen ergibt sich ein ebener Frequenzgang mit konstanter Gruppenlaufzeit.

φM wird durch Differenzieren der Modulationsspannung erzeugt. Die Grenzfrequenz des Differenzierers liegt bei 40 kHz. Eine DC-Modulation ist somit bei φM nicht möglich. Die Übertragungsfunktionen sind die gleichen wie bei FM.

#### 7.1.3.2 FM/\phiM-Hubteiler

Zur Einspeisung der Modulationssignale stehen die zwei Eingänge INT1 und EXT1 zur Verfügung. Der externe Modulationseingang verfügt über einen hochohmigen Eingangsverstärker (N800) mit umschaltbarer AC/DC-Kopplung (D820). Die Eingangsimpedanz kann über die Steckbrücke X80 gewählt werden. Sie beträgt 100 k $\Omega$  oder 600  $\Omega$ . Über den Schalter D800 wird das gewünschte Modulationssignal ausgewählt. Dabei ist eine Einton- (Extern oder Intern) sowie Zweitonmodulation (Extern und Intern) möglich. Die Verstärker N845 und N850 verstärken das Eingangssignal von  $1\rm V_S$  auf  $6\rm V_S$ . Über den Verstärker N850 wird dazwischen das Signal für den Sigma-Delta-Wandler abgezweigt. Der hier fließende Strom ist immer konstant. Im Steuerzweig für die Modulation über die Oszillatoren wird zur Feineinstellung des Hubes ein multiplizierender 12 Bit D/A-Wandler (D840) verwendet. Der folgende Operationsverstärker führt eine Impedanzwandlung durch.

Zur Grobeinstellung des Hubes am Oszillator wird eine Eichleitung in Kettenleiterstruktur mit 12 dB Schritten verwendet (dividiert 1...4096). Die Abgriffe werden von dem Analogmultiplexer D960 geschaltet. Bei ausgeschalteter Modulation wird über einen FET (N960) der Oszillatoreingang auf Masse gelegt um so das Widerstandsrauschen zu minimieren.

Die Hubwertigkeit für die Modulation des Teilungsfaktors über den Sigma-Delta-Wandler wird grob intern im FRACSYN und fein über die ADWE-Eingänge (Schieberegister D660 und D665) mit 16 Bit Auflösung eingestellt.

Für φM wird in den gemeinsamen Zweig eine Differenzierschaltung (Reedrelais K910) eingeschaltet. Die Übertragungswege sind ansonsten identisch zur FM.

Der Pegel am EXT-Eingang wird von der Fensterkomparatorschaltung mit N860 und D870 überwacht. Bei Abweichung vom Sollpegel von 1...3 % wird je nach Richtung, der Interrupt FMKOMPHI (Eingespeiste Spannung zu groß) oder FMKOMPLO (Eingespeiste Spannung zu klein) ausgelöst.

#### 7.1.3.3 Sigma-Delta-Wandler und FM-DC Regelung

Zur Modulation des Teilungsfaktors wird ein Sigma-Delta-Wandler 3.ter Ordnung (N940, N950, N960, D950 und D965) eingesetzt, der das analoge Modulationssignal in ein digitales Signal umwandelt. Der gleitende Mittelwert des 1 Bit Ausgangssignals entspricht dabei der analogen Eingangsgröße. Das dabei entstehende Quantisierungsgeräusch wird durch die Tiefpaßfunktion der PLL gefiltert. Eine Laufzeitentzerrerschaltung am Eingang des Wandlers sorgt für gleiche Gruppenlaufzeit in beiden Modulationswegen. Da alle Offsetspannungen auch bei AC-Betrieb zu einer Verschiebung der Mittenfrequenz führen, werden diese durch eine Mittelwertregelung kompensiert. Bei FM-DC muß die Regelung geklemmt werden, um die DC-Modulationsspannung nicht auszuregeln. Dieser Schaltungsteil befindet sich ebenfalls im Gatearray FRACSYN.

#### 7.1.4 Kalibrierroutinen

#### 7.1.4.1 VCO-Kalibrierung

Es wird im 5 MHz Raster eine Tabelle der jeweiligen Abstimmspannung der Oszillatoren angelegt. Aus diesen, über die Diagnose ermittelten Werten, kann die jeweilige Oszillatorsteilheit ko(f) berechnet werden. Zwischenwerte werden hierbei linear interpoliert. Sie wird benötigt um die notwendige PLL-GAIN zu ermitteln, mit der die Verstärkungsschwankungen in der Regelschleife kompensiert werden. Die ermittelten Steilheitswerte werden ebenfalls als Startwerte zur Berechnung der Hubsteilheit für die FM-Kalibrierung benötigt.

#### 7.1.4.2 FM-Kalibrierung

Für die Kalibriertabelle der Hubsteilheit mißt ein Diagnosedetektor (N780, V781, C782) bei einer Modulationsfrequenz von 1 kHz den Differenzhub in der Regelschleife. In einer Abgleichroutine werden die Stellglieder des FM/PHIM-Hubteilers so lange verändert, bis der gemessene Differenzhub minimal wird. Aus den so ermittelten Einstellwerten wird die Modulationssteilheit des Oszillators bei der jeweiligen Frequenz berechnet. Diese Tabelle wird ebenfalls im 5 MHz Raster aufgenommen.

#### 7.2 Meßgeräte und Hilfsmittel

- HF-Spektrumanalysator (FSA)
- HF-Signalgenerator (SMGU, SME)
   Funktionsgenerator f>=2 MHz, (AFGU, AFS)
- Oszilloskop f>250 MHz
- AC/DC-Voltmeter (URE3)
- Modulationsanalysator mit Klirrfaktormesser (FMA, FMB)

#### Fehlersuche

Zur Fehlerdiagnose eignet sich ebenso das im Servicekit SMY-Z1 enthaltene Prüfprogramm, das umfangreiche Diagnosemöglichkeiten bietet.

#### 7.3.1 Synchronisierfehler

Die Fehlermeldungen Error 1 bis Error 3 sind eine Veroderung der Fehlerüberwachungen der Phasenregelschleifen für den 10 MHz TCXO, den 640 MHz Oszillator sowie der PLL der Ausgangsoszillatoren. Ist ein Fehler an der 10 MHz PLL vorhanden, so kann dies auch zu einem Ausrasten der anderen Regelschleifen führen. Über den entsprechenden Diagnosepunkt kann jeweils nachgeprüft werden, welche der drei Phasenregelschleifen außer Toleranz sind.

Fehlermeldung "Error 1" 10-MHz-Referenzloop außer Synchronisation

Prüfen ob in der Betriebsart ext. Referenz die richtige Frequenz mit ausreichendem Pegel eingespeist wird

Überprüfen der externen Referenz nach 7.4.2.2

Überprüfen des Fensterkomparators N100

Fehlermeldung "Error 2" 640-MHz-Loop außer Synchronisation

Überprüfen ob 10 MHz Referenzfrequenz am Phasendetektor D255.11 anliegt

Überprüfen des 640 MHz Oszillators und der PLL nach 7.4.3.1

Überprüfen des Fensterkomperators N105

Fehlermeldung "Error 3" Hauptoszillator-Loop außer Synchronisation

Ausgangsoszillatoren nach 7.4.4 überprüfen

Nachmessen ob 2 MHz Referenzsignal am Phasendetektor D700.3 anliegt. PLL der Ausgangsoszillatoren nach 7.4.5 überprüfen

Überprüfen des Fensterkomperators N110

9

Kein Ausgangspegel oder Ausgangspegel zu gering an X124

Ausgangsoszillatoren nach 7.4.4 überprüfen

Ausgangsteiler mit Teilern nach 7.4.6 überprüfen

Nachprüfen der Arbeitspunkte bzw. der HF-Pegel der sich im Pfad befindenden Verstärker (Tabelle 7.4.13.3)

Störhub zu groß (keine Nebenwellen) Kalibrierroutine VCO mit SPEC 41 durchführen

Oszillatoren nach 7.4.4
überprüfen, ebenso deren
Arbeitspunkte nach Tabelle
7.4.13.3
Störhub der Oszillatoren messen,
die eingespeiste DC-Spannung muß
ausreichend brumm- und rauschfrei
sein

PLL der Ausgangsoszillatoren nach 7.4.5.1-7.4.5.3 überprüfen, Versorgungsspannungen von FRACSYN und Phasendetektor nachprüfen (7.4.1)

Nebenwellen > -70 dBc für Ablagefrequenzen > 5 kHz zum Träger Kalibrierroutine VCO mit SPEC 41 durchführen

Phasenoffset des Phasendetektors überprüfen, DC-Spannung an C701 sollte 1.65 V betragen

Versorgungsspannung FRACSYN und Phasendetektor überprüfen (7.4.1)

# 7.3.3 Fehler bei FM-/φM-Modulation

Hubfehler bei FM oder  $\phi$ M; Stereoübersprechen außer Toleranz Starke Modulationsverzerrungen bei Maximalhub Kalibrierroutine FM mit SPEC 43 durchführen

Prüfen des Hubteilers nach 7.4.7 Überprüfung der Hubeinstellung nach 7.4.9

FM-Klirrfaktor zu groß

Kalibrierroutine FM mit SPEC 43 durchführen

Prüfen des Hubteilers nach 7.4.7, Klirrfaktor des Modulationssignals an X84 überprüfen

Überprüfen der FM-Kalibration nach 7.4.10.3

Keine oder falsche FM-Modulation bei Modulationsfrequenzen kleiner 1 kHz

Sigma-Delta-Wandler nach 7.4.9 überprüfen

Abgleich FM-Hub nach 7.4.10.2 durchführen

Keine oder falsche FM-Modulation bei Modulationsfrequenzen größer 1 kHz

Kalibrierroutine FM mit SPEC 43 durchführen

Hubteiler nach 7.4.7 überprüfen

FM-Frequenzgang zu groß

Hubteiler nach 7.4.7 überprüfen Frequenzgang auch nach dem Grobteiler an D960.3 nachmessen (eingestellter FM-Hub > 3 MHz, RF

Mittenfrequenzfehler bei FM-DC Sigma-Delta-Wandler und FM-DC Modulation, bzw. FM-DC-Mittenfrequenzkalibrierung (Specialfunktion 55) wird nicht richtig ausgeführt)

Regelung nach 7.4.9 überprüfen

> 520 MHz)

Keine oder falsche OM-Modulation

Überprüfen ob eine äquivalente eingestellte FM-Modulation richtig ist, ansonsten Fehler beim PM-Differenzierer (Hochpass mit C913 und R848, wird überprüft in 7.4.7) (äquivalente FM = eingestellte PM \* eingespeiste NF-Frequenz)

#### 7.3.4 Kalibrierungen

Fehlermeldung "Error 15" Kalibrierung VCO fehlerhaft Ausgangsoszillatoren nach 7.4.4 überprüfen

PLL der Ausgangsoszillatoren nach 7.4.5 überprüfen

Einschwingverhalten der Synthese nach 7.4.11 überprüfen

Fehlermeldung "Error 15" Kalibrierung FM fehlerhaft

Überprüfen des FM-Diagnosedetektors nach 7.4.10.1, der Offset des Diagnosedetektors (Testpunkt 15 über Diagnose messen, keine NF-Frequenz einspeisen) muß kleiner 50 mV sein

Überprüfen des Hubteilers nach 7.4.7

Sigma-Delta-Wandler nach 7.4.9 überprüfen

Laufzeitentzerrung am Eingang Sigma-Delta-Wandler prüfen

## 7.4 Prüfen und Abgleich

Alle Meßwerte ohne Toleranzangaben sind als Richtwerte zu verstehen. Spannungsangaben ohne weitere Bezeichnung bedeuten DC-Spannungen.

Wird die Baugruppe mit geöffnetem Deckel betrieben, so müssen die zwei Oszillatorkammern mit Prüfdeckeln auf der Bauteil- und Lötseite geschlossen werden.

Vor allen Prüfungen ist mit PRESET der SMY in einen definierten Anfangszustand zu bringen.

### 7.4.1 Datenübertragung und Stromversorgung

(Hierzu Stromlaufblatt 9)

Gemäß Gerätestandard wird die Baugruppe über eine serielle Schnittstelle angesteuert. Die Datenübertragung erfolgt hierbei auf zwei verschiedenen Subadressen. Die Datenübernahme erfolgt mit den beiden Baugruppenstrobes HF1STB und HF2STB. Die Einstellungen und die zugehörigen Daten sind im Kapitel 'Digitale Schnittstellen' zu finden.

Die Stromaufnahme kann überprüft werden, indem anstelle der Spulen L1 bis L5 ein Amperemeter eingeschleift wird. Die Sollwerte sind im Kapitel 'Externe Schnittstellen' zu finden.

Die wichtigsten Referenz- bzw. Versorgungsspannungen werden mit dem DC-Voltmeter nachgemessen.

Nespunkt	Art der Spannung	Spannung [V]
P20	10 V Referenz	+9.9+10.1
P21	Versorgungssp. 5 V analog	+5,1 +5,4
D700_14	Versorgungssp. Phasendetektor	4.65.0 V
D65_84	Versorgungssp. FRACSYN	5.15.5 V

#### 7.4.2 Referenzfrequenzerzeugung

#### 7.4.2.1 Referenz Intern

(Hierzu Stromlaufblatt 2)

Für verschiedene D/A-Wandler Werte wird die Abstimmspannung für die interne Referenz über die Diagnose abgelesen (Funktion D/A-Wandler). Auf dem Oszilloskop muß ein 10 MHz HCMOS Signal sichtbar sein (Funktion Pegelwandler). Mit dem Spektrumanalysator kann der Ausgangspegel EXTREF gemessen werden.

- · Oszilloskop mit Tastkopf an P201 anschliessen
- · Spektrumanalysator an EXTREF (Geräterückwand) anschliessen

· Einstellungen: SPEC 111

RF INT/ON

Die D/A-Wandler-Werte über die Specialfunktion 51 nach Tabelle einstellen und die Diagnosespannung überprüfen. Die eingegebenen Kalibrierwerte werden durch das Drücken der ENTER-Taste übernommen.

SPEC 51	Diagnosespannung am Testpunkt 11
0	± 150 mV
4095	4.75.3 V
2048	2.32.7 V

\_ Signal an P201 prüfen: 10 MHz, HCMOS

\_ Ausgangssignal am Spektrumanalysator messen: 10 MHz, 7.5 ± 2 dBm

## 7.4.2.2 Referenz Extern

(Hierzu Stromlaufblatt 2)

Es wird zuerst der Eingang der Externen Referenz mit der Vervielfacherschaltung getestet.

- · Signalgenerator 5 MHz an EXTREF (Geräterückwand) anschließen.
- · Oszilloskop mit Tastkopf an P204 anschließen.
- · Einstellungen: RF EXT AC
- \_ Signal an P204 prüfen: 10 MHz, HCMOS-Pegel für Eingangspegel von -13...13 dBm am Eingang EXTREF.

Nun erfolgt die Prüfung der PLL und des Ziehbereiches des VTCXO's. Hierbei wird die Regelspannung über die Diagnose überprüft.

- · Einstellungen: SPEC 111
- · Frequenz des Signalgenerators nach Tabelle einspeisen, Pegel: 7 dBm.
- \_ Diagnosespannung nach Tabelle prüfen.

Frequenz an EXTREF	Diagnosespannung Testpunkt 11
10 MHz	2.5 ± 0.5 V
9.999970 MHz	> 0.5 V
10.000030 MHz	< 4.5 V

#### 7.4.3 640 MHz Referenz

#### 7.4.3.1 Oszillator 640 MHz und PLL

(Hierzu Stromlaufblatt 2 und 3)

Es wird die Funktion sowie der Abstimmbereich des Oszillators geprüft.

- · Brücke X20 ziehen und Netzgerät (0...20 V) an X20.2 und X20.3 (Masse) anschließen.
- · Spektrumanalysator mit Einstellung CF 640 MHz, SPAN 50 MHz und REF LEVEL 10 dBm an X125 anschließen.
- · Einstellungen: RF 50 MHz
- \_ Abstimmspannung von 0...20 V variieren, der Oszillator muß im gesamten Abstimmbereich bei 640 ± 20 MHz ohne Aussetzer, Nebenlinien oder Rauschüberhöhungen schwingen.
- \_ Abstimmspannung zwischen 2 und 18 V umschalten, die Frequenzänderung des Oszillators muß > 15 MHz und < 25 MHz sein.
- \_ Die Abstimmspannung für 640 MHz muß > 4V und < 16V sein.

· Netzgerät wieder entfernen und Brücke X20 auf 1-2 stecken.

Bei geschlossener PLL wird nun die Abstimmspannung über die Diagnose gemessen.

· Einstellungen: SPEC 112

\_ Diagnosespannung am Testpunkt 12: 10 ± 6 V

# 7.4.3.2 Ausgangsverstärker 640 MHz

(Hierzu Stromlaufblatt 3)

Der Ausgangspegel wird bei ein- und ausgeschaltetem Signal überprüft.

- · Spektrumanalysator mit Einstellung CF 640 MHz, SPAN 50 MHz, REF LEVEL 15 dBm an X125 anschließen.
- · Einstellungen: RF 50 MHz SPEC 113
- \_ Pegel 640 MHz am Spektrumanalysator messen: 10 ± 2 dBm.
- \_ Diagnosespannung am Testpunkt 13: 100...400 mV.

Die Frequenz des SMY wird nun so eingestellt, daß der LO-Verstärker abgeschaltet wird.

- · Einstellungen: RF 100 MHz
- \_ Pegel 640 MHz am Spektrumanalysator messen: < -30 dBm.

## 7.4.4 Ausgangsoszillatoren

(Hierzu Stromlaufblatt 4, 5 und 7)

Es muß unbedingt der bauteilseitige und der lötseitige Trimmdeckel auf den Oszillatorkammern geschraubt sein.

Es wird die Funktion der beiden Ausgangsoszillatoren sowie deren Abstimmbereich überprüft. Die Diagnosespannung für den Ausgangspegel wird ebenfalls überprüft.

- · Spektrumanalysator mit Einstellung CF 780 MHz, SPAN 800 MHz, REF LEVEL 15 dBm an X124 anschließen.
- Brücke X75 entfernen und Netzgerät an X75.2 und X75.3 (Masse) anschließen.
- Die Abstimmspannung wird für beide Oszillatoren von 0...22 V variiert, der Oszillator muß im gesamten Abstimmbereich ohne Aussetzer, Nebenlinien und Rauschüberhöhungen schwingen. Bei der unteren und oberen Frequenzgrenze beider Oszillatoren muß die Abstimmspannung im angegebenen Toleranzfenster (siehe Tabelle) liegen. Der Ausgangspegel an X124 muß zwischen 7 und 14 dBm liegen.

Einstellung	Oszillator	min. Freq.	Abstimmsp.	max. Freq.	Abstimmsp.
RF 600 MHz	:	520 MHz	1.754 V	780 MHz	16.519.5 V
RF 900 MHz	<b>2</b>	780 MHz	1.754 V	1040 MHz	16.519.5 V

Bei einer Ausgangsfrequenz von ca. 1040 MHz wird noch die Diagnose getestet.

Einstellungen: SPEC 114

- \_ Diagnosespannung am Testpunkt 14: 80...400 mV
- · Netzgerät entfernen und Brücke X75 wieder auf 1-2 stecken.

### 7.4.5 PLL der Ausgangsoszillatoren

Um mögliche Fehler in einer Phasenregelschleife zu erkennen ist es sinnvoll diese aufzutrennen und die Fehlersuche an der geöffneten PLL durchzuführen. Hierzu bleibt die Steckbrücke X75 während den Prüfungen 7.4.5.1 - 7.4.5.3 entfernt.

Um besser die eingestellte Ausgangsfrequenz verfolgen zu können, sollte man einen Spektrumsanalysator an X124 anschliessen.

# 7.4.5.1 Überprüfung der Teiler in der PLL

(Hierzu Stromlaufblatt 6)

Es wird zunächst die Teilerkette im Rückwärtszweig der PLL geprüft.

- · Brücke X75 entfernen und Netzgerät an X75.2 und X75.3 (Masse) anschließen.
- Spannung am Netzteil auf ca. 16 V einstellen (Oszillator 2 schwingt auf ca. 1000 MHz)
- · Oszilloskop mit Tastkopf an P600 anschließen.
- · Einstellungen: RF 1000 MHz
- \_ Signal an P600 prüfen: ca. 62.5 MHz, TTL-Pegel
- · Oszilloskop mit Tastkopf an P610 anschließen.
- \_ Signal an P610 prüfen: ca. 2 MHz, HCMOS-Pegel


#### 7.4.5.2 Überprüfung des Phasendetektors

(Hierzu Stromlaufblatt 7)

Bei der Überprüfung des Phasendetektors wird zunächst sichergestellt, daß die Referenzfrequenz (Signal 2REF), auf die synchronisiert wird, richtig anliegt.


- · Einstellungen: RF 1000 MHz
- \_ Signal an D700.3 mit Tastkopf an Oszilloskop überprüfen: 2 MHz, HCMOS-Pegel
- · Oszilloskop mit Tastkopf nun an P700 anschließen.
- · Spannung am Netzteil an X75 etwas reduzieren, sodaß die Ausgangsfrequenz des Oszillator2 kleiner als 1000 MHz ist.
- \_ Abfallende Sägezahnspannung an P700 mit der Differenzfrequenz der beiden Eingangssignale, DC-Spannung an P700 ist negativ (ca. 0.8 V)

# Abbildung 1



- · Spannung am Netzteil an X75 nun langsam erhöhen, sodaß die Ausgangsfrequenz des Oszillator2 größer als 1000 MHz wird. Hierbei wird die Spannung an P700 beobachtet.
- Ansteigende Sägezahnspannung an P700 mit der Differenzfrequenz der beiden Eingangssignale, DC-Spannung an P700 ist positiv (ca. 4 V)

# Abbildung 2



# 7.4.5.3 Überprüfung des Regelfilters

(Hierzu Stromlaufblatt 7)

Eine exakte Überprüfung des integralen Regelverstärkers bei einer geöffneten Regelschleife ist nicht möglich. Es wird daher nur auf grobe Funktionalität überprüft.

- · Oszilloskop mit Tastkopf an P720 anschließen.
- · Einstellungen: RF 1000 MHz

Die Vorgehensweise bei der Funktionalitätsüberprüfung des Regelverstärkers ist identisch zur Überprüfung des Phasendetektors. Hierzu wird die eingespeiste DC-Spannung an X75 zunächst reduziert, sodaß der Oszillator unter 1000 MHz schwingt. In den integralen Regler fließt nun ein negativer Eingangsstrom, der dessen Ausgangsspannung auf ca. 21..24 V an P720 anwachsen läßt. Wird die Spannung an X75 erhöht, sodaß der Oszillator nun über 1000 MHz schwingt fließt in den integralen Regler ein positiver Eingangsstrom, sodaß dessen Ausgangsspannung auf ca. 0 V absinkt. Ist die eingestellte Differenzfrequenz sehr gering, kann der DC-Spannung an P720 noch eine AC-Spannung mit der entsprechenden Differenzfrequenz überlagert sein.

Es empfiehlt sich auch die Spannung nach dem folgenden Tiefpassfilter zu überprüfen (Spannung an X75.1). Sie muß identisch zur Spannung an P720 sein.

· Netzgerät entfernen und Brücke X75 wieder auf 1-2 stecken.

# 7.4.5.4 Überprüfen der geschlossenen PLL

(Hierzu Stromlaufblatt 4,6 und 7) Nach Stecken der Brücke X75 ist die PLL nun geschlossen.

• Einstellungen: RF FREQUENCY (nach Tabelle)
SPEC 115

- · Spektrumanalysator mit Einstellung CF=FREQUENCY, Span 100 kHz, Rev.lev. 15 dBm an X124 anschliessen.
- \_ Das Ausgangssignal wird bei den verschiedenen RF-Einstellungen überprüft. Es dürfen keine Seitenlinien oder Rauschüberhöhungen auf dem Spektrumsanalysator sichtbar sein.

PREQUENCY	Diagnosespannung Testpunkt 15
520 MHz	1.754 V
779.999999 MHz	16.519.5 V
· 780 MHz	1.754 V
1040 MHz	16.519.5 V

# 7.4.6 Ausgangsstufe mit Teilern

(Hierzu Stromlaufblatt 5)

Es werden die Ausgangsteiler durch 2, 4 und 8 überprüft. Die Diagnosespannung und der Ausgangspegel werden ebenfalls gemessen. Für diese Prüfung wird vorausgesetzt, daß die PLL und die Ausgangsoszillatoren einwandfrei arbeiten und sich somit alle Frequenzen der Grundoktave von 520...1040 MHz einstellen lassen.

• Einstellungen: RF FREQUENCY (nach Tabelle) SPEC 114

\_ Überprüfen der eingestellten Frequenz sowie des Ausgangspegels am Spektrumanalysator nach Tabelle.

\_ Spannung am Testpunkt 14 für alle RF-Frequenzen: 80...600 mV

PREQUENCY	Teller	Pegel an X124
1040 MHz	1	714 dBm
780 MHz	1	714 dBm
779 MHz	1	714 dBm
520 MHz	1	714 dBm
500 MHz	2	714 dBm
250 MHz	4	714 dBm
125 MHz	8	714 dBm

# 7.4.7 Prüfen des Hubteilers

(Hierzu Stromlaufblatt 8)

Es werden die Modulationsmatrix für beide Kanäle, die AC/DC-Umschaltung für den externen Eingang, der Differenzierer für PHIM sowie der Feinhubteiler geprüft.

- · Steckbrücke X84 entfernen.
- · Modulationssignal an der Eingangsbuchse EXT an der Fronteinheit nach Tabelle einspeisen, mit AC/DC-Voltmeter an Meßpunkten nach Tabelle die Sollspannungen nachmessen.
- · Einstellungen: RF 1000 MHz

Einstellung	Signal an Ext	Signal an P840	Signal an X84.1
FM EXT DC 10 MHz	1 V	- 3.32 ± 0.1 V	- 6 1.5 V (Referenzwert)
AF 1 kHz,			
FM INT 10 MHz	~	3.32 ± 0.1 Vs	- 6 1.5 Vs
			(=Referenzwert)
			DC < 40 mV
FM EXT AC 10 MHz	2 MHz, 1 Vs	3.32 ± 0.2 Vs	Referenzwert ± 3 dB
			DC < 40 mV
PHIM EXT 175 rad	20 kHz, <b>1</b> Vs	3.32 ± 0.1 Vs	Referenzwert - 10 dB
			( ± 1 dB)

Es erfolgt nun die Überprüfung der Feinhubteiler

· Einstellungen: RF 1000 MHz

AF 1 kHz FM INT 0 Hz FM STEP 100 Hz

\_ Den FM-Hub mit dem Drehknopf am Frontmodul von 0 Hz bis 2.5 kHz in 100 Hz Stufen variieren. Die NF-Spannung an X84.1 muß von 0 V bis ca. 3.2  $\rm V_S$  in gleichen Schritten (ca. 0.13 V) ansteigen.

#### 7.4.8 EXT-Überwachung

(Hierzu Stromlaufblatt 8)

- · NF-Generator, 1 kHz, Pegel nach Tabelle, an EXT anschliessen.
- \_ Die Funktion der Pegelüberwachung nach Tabelle prüfen.
- · Einstellungen: FM EXT AC 100 kHz

Eingangsspannung an EXT	Anzeige
1 ± 0.005 Vs	-
1.03 ± 0.005 Vs	EXT-HIGH
0.97 ± 0.005 Vs	EXT-LOW

#### Sigma-Delta-Wandler mit FM-DC-Regelung 7.4.9

(Hierzu Stromlaufblatt 8)

Es wird die Funktion des Sigma-Delta-Wandlers sowie der FM-DC-Regelung in den Betriebsarten FM-AC und FM-DC geprüft.

- · Einstellungen: RF 1000 MHz
- · DC-Spannungsquelle (0...1V) an den Modulationseingang EXT anschließen.
- Die angegebenen DC-Spannungen mit einem DC-Voltmeter nach Tabelle prüfen.

Einstellung	DC-Spannung an EXT	DC-Spannung an D950.9	DC-Spanning an D65.75
FM EXT AC 10 MHz	0 V	2.6 ± 0.2 V	2.6 ± 0.2 V
FM EXT DC 10 MHz	0 V	2.6 ± 0.25 V	2.6 ± 0.25 V
FM EXT DC 10 MHz	1 V	3.8 ± 0.2 V	2.6 ± 0.25 V

#### 7.4.10 FM-Hubeinstellung

# Überprüfung FM-Diagnosedetektor

(Hierzu Stromlaufblatt 7 und 8)

Bei der Durchführung der FM-Kalibration wird mit einem FM-Diagnosedetektor der Differenzhub in der Regelschleife gemessen. Zur Prüfung des Detektors wird nun ein definierter Frequenzhub eingestellt, und eine Aussteuerungsmessung mit dem Detektor vorgenommen.

· Einstellungen:

RF 1000 MHz

FM EXT AC 50 kHz

**SPEC 116** 

- · NF-Generator, 1 Vs±5 mV, 1 kHz, an den Eingang EXT anschliessen.
- · Steckbrücke X84 entfernen.
- \_ Diagnosespannung an Testpunkt 16: 1.6 ± 0.4 V.
- · Eingespeiste NF-Frequenz auf 500 Hz, danach auf 1.5 kHz einstel-
- \_ Diagnosespannung an Testpunkt 16: < 0.5 V.
- · Steckbrücke X84.1/2 wieder bestücken.

### 7.4.10.2 Abgleich FM-Hub

(Hierzu Stromlaufblatt 8)

Es wird der Maßstab des FM-Hubes über den Regelungszweig (Steuerung des Teilungsverhältnisses am FRACSYN) abgeglichen.

· Einstellungen:

RF 1000 MHz

FM EXT AC 500 kHz

- $\cdot$  NF-Generator, 1  $\rm V_S$   $\pm$  5 mV, 50 Hz, an den Eingang EXT anschliessen.
- Modulationsanalysator mit Einstellung HP 10 Hz, TP 3 kHz, Detektor RMS\*'2, an X124 anschliessen.
- \_ Mit R930 auf 500 ± 1 kHz FM-Hub abgleichen.
- \_ Mit SPEC 43 FM-Kalibration durchführen.

# 7.4.10.3 Überprüfung der FM-Kalibrierung

(Hierzu Stromlaufblatt 7)

Mit dem Diagnosedetektor wird der Differenzhub bei FM-Modulation in der PLL nach erfolgter Kalibrierung durchgeführt (siehe 7.4.10.2). Die Überprüfung erfolgt in der Grundoktave von 520 bis 1040 MHz in 5 MHz Schritten.

· Einstellungen:

RF 520 MHz

FM INT 500 kHz

AF 1 kHz

**SPEC 116** 

RF STEP 5 MHz

\_ Die Frequenz von 520 MHz bis 1040 MHz mit dem Drehknopf erhöhen. Die Diagnosespannung am Testpunkt 16 muß bei jeder Frequenz im Bereich 0 ± 50 mV sein.

# 7.4.11 Einschwingverhalten der Synthese

Es wird das Einschwingverhalten der PI-Reglerspannung bei einem Frequenzsprung zwischen 520 und 1040 MHz gemessen.

· Einstellungen:

RF 520 MHz

FM OFF


RF EXT AC

- · Buchse EXTREF des Spektrumanalysators mit Buchse EXTREF an der Rückwanne des SMY verbinden.
- Tastkopf an Baugruppenstrobe HF2STB an X1A.16 anschliessen und mit dem Eingang EXT SWEEP TRG an der Rückwanne des Spektrumanalysators verbinden.
- Spekrumanalysator mit Einstellung CF 1040 MHz, SPAN 0 Hz, REF LEVEL 10 dBm, LOG RANGE 20 dB, SWEEP 100 ms, RES BW 2.023 kHz, TRIGGER EXTERNAL, SLOPE NEGATIV, TRIGGER LEVEL 238 mV an X124 anschließen.

- · Um das Einschwingverhalten der Synthese richtig zu messen muß eine Flankendemodulation vorgenommen werden.

  Die RF-Frequenz der Synthesebaugruppe wird zur Vorbereitung auf 1040 MHz eingestellt. Dann wird im FREE RUN Betrieb des Analysators die Center-Frequenz des Spektrumanalysators in 100 Hz Schritten von 1040 MHz ausgehend verkleinert, bis der gemessene Wert auf 0 dBm liegt. Nach Umstellen der Synthese auf RF 520 MHz und des Analysators auf Trigger External erfolgt nun der Frequenzsprung auf 1040 MHz. Die Einstellung am Spektrumanalysator entspricht einem Skalierungsfaktor von ca. 120 Hz/dB.
- \_ 50 ms nach erfolgtem Baugruppenstrobe (Triggersignal) darf sich die Spannung nur noch um maximal ± 100 Hz ( ca. 0.85 dB) ändern. Es ergibt sich typisch ein Spannungsverlauf wie in Abbildung 3.

### Abbildung 3



Res. bu. 2.023kHz, Vid. bu. 3kHz, Sweeptime 100ms

# 7.4.12 Endprüfungen Synthese

Das Durchführen der folgenden Endprüfungen sollte erfolgen, wenn zuvor Messungen oder eine Fehlerbehebung an der Baugruppe stattgefunden hat. Es müssen nun der löt- und bauteilseitige Deckel aufgeschraubt sein. Die Baugruppe befindet sich noch auf dem Prüfadapter.

#### 7.4.12.1 Störhub Synthesizer

- Modulationsanalysator an X 124 anschliessen. Störhub mit Bewertungsfilter 20 Hz...23 kHz und CCITT bei folgenden Frequenzen (in MHz) prüfen:
   520, 580, 640, 710, 779, 780, 840, 900, 970, 1040 MHz
- $\_$  Störhub < 16 Hz<sub>rms</sub> (20 Hz...23 kHz) Störhub < 8 Hz<sub>rms</sub> (CCITT)

### 7.4.12.2 Störhub 640 MHz Oszillator

- Modulationsanalysator an X125 anschließen. Störhub mit Bewertungsfilter 20 Hz...23 kHz und CCITT prüfen.
- · Einstellungen: RF 50 MHz FM OFF
- Störhub < 4 Hz<sub>rms</sub> (20 Hz...23 kHz) Störhub < 2 Hz<sub>rms</sub> (CCITT)

### 7.4.12.3 Nebenwellen Synthesizer

- · Spektrumanalysator mit Einstellung CF=FREQUENCY, SPAN 50 kHz, RES BW 300 Hz, VIDEO BW 30 Hz, REF LEVEL 15 dBm an X124 anschließen. Den Nebenwellenabstand bei den folgenden Frequenzen (in MHz) messen:
  - 520.02, 544.02, 544.08, 640.005, 960.026666, 992.02, 1024.08 MHz
- \_ Der Nebenwellenabstand >= 5 kHz neben dem Träger muß >= 70 dBc sein.

# 7.4.12.4 FM-DC Mittenfrequenzkalibrierung

- · Einstellungen: RF 1000 MHz FM EXT DC 10 MHz
- Netzgerät (± 1 V) an Buchse FM/φM EXT anschließen (die eingestellte DC-Spannung muß hinreichend rausch- und brummfrei sein!).
- · Modulationsanalysator mit Frequenzzähler an X124 anschließen.
- \_ Spannung am Netzgerät auf 0 mV oder Eingangsbuchse FM/φM EXT kurzschließen.
- \_ FM-DC Nulling Intern mit SPEC 55 durchführen. Der Frequenzfehler muß < 10 kHz sein. Die Spannung von -1...+l V variieren und dabei den Störhub messen, er muß < l kHz<sub>rms</sub> (Bewertungsbandbreite 300 Hz...23 kHz) sein. Die Ausgangsfrequenz variiert von 990...1010 MHz.

# 7.4.13 Tabellen und Schnittstellen

# 7.4.13.1 Liste der Diagnosemeßpunkte

Zur Überwachung der wichtigen Regelspannungen und Pegel wird ein Diagnosemultiplexer (74HC4051) eingesetzt. Zur Kompensation von Offsetspannungen kann das Potential der Baugruppenmasse gemessen werden (Diagnosepunkt 9).

	Diagnose- punkt	A MeSpunkt	win.	yes <b>HAX.</b> V	Teilungs-
و	R146	Referenz, 10 KΩ	-50 m	50 m	1
10	D-+10REF	10 V, Referenzspannung	9.9	10.1	3
11	D-PLL-VTCXO	Regelspannung VTCXO 10 MHz	0.3	4.7	3
12	D-PLL-640	Regelspannung VCO 640 MHz	4	17	5
13	D-REF640	Ausgangspegel LO, 640 MHz	0.1	0.6	1
		Pegel abgeschaltet	<0.05		
14	D-FSYN	Ausgangspegel FSYN 651040 MHz0.08	0.6	1	
15	D-PLL-FSYN	Regelspannung VCO's FSYN	1.75	21.5	5
6	D-FM-KAL	Aussteuerung am PD, 1 kHz	0	50 m	3

# Digitale Schnittstelle

Gemäß Gerätestandard verfügt die Baugruppe YSYN über eine serielle Schnittstelle. Mit Strobel werden die Daten für die HC4094-Latches bzw. die seriellen D/A - Wandler übernommen. Mit Strobe2 erfolgt die Übernahme der Daten am FRACSYN.

Polarität Clock: aktive Taktflanke L-->H Polarität Strobel: aktive Taktflanke L-->H Polarität Strobe2: aktive Taktflanke H-->L

Datenübertragung mit Strobel (HFlSTB):

Hubeinstellung für FM und PHIM, RF abhängige Hubkorrektur, Wahl

der RF-Ausgangsteiler, Diagnose, Betriebsarten. Die Daten auf Strobel für die seriellen D/A-Wandler sind von aussen nicht zugänglich und werden daher nicht aufgeführt.

Datenübertragung mit Strobe2 (HF2STB):

Frequenzinformation, Informationen für den Wobbelbetrieb und den Offsetaddierer.

Die Daten auf Strobe 2 sind für den Baustein FRACSYN bestimmt. Sie sind von aussen nicht zugänglich und werden daher nicht aufge-

Latch	Pin	Bezeichnung	Funktion		
D585	11	<b>T</b> 2	Ausgangsteiler 4	0=Ein	1=Aus
	12	Tl	Ausgangsteiler 2	0=Ein	1=Aus
	13	S6	Ausgang Teilerpfad 4,8	0=Aus	1=Ein
	14	<b>\$</b> 5	Eingang Teilerpfad 4	0=Aus	1=Ein
	7	\$4	Pfad Kettenschaltung	0=Aus	1=Ein
	6	S3	Ausgang Teilerpfad 2	0=Aus	1=Ein
	5	S2	Eingang Teilerpfad 2,8	0=Aus	1=Ein
	4	S1	keine Teilung	0=Aus	1=Ein
D855	11	OSZ2	Oszillator 7501040 MHz	0=Aus	1=Ein
	12	osz1	Oszillator 520750 MHz	0=Aus	1=Ein
	13	EXTAC/DC	AC-DC-Umschaltung bei FM-EXT	0=FMAC	1=FMDC
	14	FMINT	Modulationsquelle INT	0=Aus	1=Ein
	7	FMEXT	Modulationsquelle EXT	0=Aus	1=Ein
	6	DEVCOARSE2			MSB
	5	DEVCOARSE1	Hubteiler Grob		
	4	DEVCOARSE0	in 12 dB Schritten		LSB
D670	11	PLL-GAIN2	Einstellung (07)		MSB
	12	PLL-GAIN1	Open-Loop-Gain		
	13	PLL-GAIN0	für HF-Regelschleife		LSB
	14	FM/фM	Differenzierer bei PM	0=FM	1=фМ
	7	FMDIAOFF	Abschalten des FM-Detektors	0=Ein	1=Aus
	6	RESET-FRAC	Masterreset FRACSYN		1=aktiv
	5	s_fm_dia	Reset Gleichrichter 1 kHz	0=Messen	1=Entl.
	4	S_DSIG	Sigma-Delta-Wandler	0=Aus	1=Ein

A. Sugar	Latch	Access Pin	Bezeichnung	Funktion	Strate, til, i e
D665	11	AD15			MSB
	12	AD14			
	13	AD13			
	14	AD12		Ì	
	7	AD11			
	6	AD10			
į	5	AD9	Einstellung Hubwertigkeit		
	4	AD8	am A/D-Eingang FRACSYN	ĺ	
D660	11	AD7	Darstellung im Zweier-		
	12	AD6	komplement		
	13	AD5 .			•
	14	AD4			
	7	AD3			
ì	6	AD2			
	5	AD1			
	4	AD0			LSB
D110	11	MODOFF	Modulation Ein/Aus	0=Ein	1=Aus (CW)
	12	S-REF640	640 MHz Ausgangsstufe	0=Aus	1=Ein
	13	OPTREF	Umschaltung Standard/	0=Standard	1=Option
			Options-Referenz		
	14	INT/EXT	Umschaltung Interne/	0=Extern	1=Intern
			Externe Referenz		bzw.Option
	7	DIAGENA	Diagnose Ein/Aus	0=Aus	1=Ein
	6	DMUX2			MSB
ĺ	5	DMUX1	Diagnosemultiplexer 07		
	4	DMUX0		1	LSB

# 7.4.13.3 Arbeitspunkte und Pegel von HF-Verstärkern

Eine qualitative Prüfung der HF-Wege ist nur mit einem HF-Tastkopf am Spektrumanalysator möglich. Dabei muß vor allem auf eine kurze niederohmige Masseverbindung geachtet werden. Der Vorwiderstand des HF-Tastkopfes sollte mindestens 1 k $\Omega$  betragen. Die angegebenen Werte für die DC-Arbeitspunkte sowie für die HF-Pegel sind als typische Werte zu verstehen.

Verstä	rker	Arbeitspunkt	HF-Pegel, Frequenz	Benerkung
V205	Pin2	2.5 V		RF EXT AC
	Pin1	1.8 V	6 dBm, 10 MHz	
V210	Pin2	0.7 V	HCT, 10 MH2	RF EXT AC
	Pin3	2.1 V		
V215	Pin2	0.7 V		RF EXT AC
·	Pin3	2.6 V	12 dBm, 10 MHz	10 MHz. 0 dBm an EXTREF
V216	Pin2			RF EXT AC
	Pin3	3.1 V	HCT, 10 MHz	10 MHz, 0 dBm an EXTREF
V305	Pin3	- 7.3 V		
	Pin2,4	- 7.7 V	8 dBm, 640 MHz	
и300	Pin1		- 3 dBm, 640 MHz	
	Pin3	4.6 V	7 dBm, 640 MHz	
V330	Pin1	2 V		RF 50 MHz
	Pin2	7.1 V	14 dBm, 640 MHz	X125 mit 50 Ω abschliessen
	Pin3	1.75 V		
	Pin4	0.55 V	5.5 dBm, 640 MHz	,
V370	Pin2	0.6 V		
	Pin3	2.2 V	HCT, 10 MHz	
V404	Pin3	-5.8 V		RF 520 MHz
	Pin2,4	-6.1 V	11 dBm, 520 MHz	
V434	Pin3	-5.8 V	7 dBm, 780 MHz	RF 780 MHz
	Pin2,4	-6.1 V	9.5 dBm, 780 MHz	
N490	Pin1		- 5 dBm, 1000 MHz	RF 1000 MHz
	Pin3	4.6 V	3 dBm, 1000 MHz	
N500	Pin1		- 2 dBm, 1000 MHz	RF 1000 MHz
	Pin3	4.7 V	2 dBm, 1000 MHz	
N510	Pin1		- 6 dBm, 500 MHz	RF 500 MHz
	Pin3	4.4 V	2 dBm, 500 MH2	X124 mit 50 Ω abschliessen
N520	Pin1		- 7 dBm, 250 MHz	RF 250 MHz
	Pin3	4.6 V	4 dBm, 250 MHz	X124 mit 50 $\Omega$ abschliessen
พ560	Pin1		2 dBm, 1000 MHz	RF 1000 MHz
	Pin3	4.8 V	9 dBm, 1000 MHz	X124 mít 50 Ω abschliessen
N600	Pinl		- 7 dBm, 1000 MHz	RF 1000 MHz
	Pin3	4.6 V	2 dBm, 1000 MHz	
N610	Pin1		- 7.5 dBm, 1000 MHz	RF 1000 MHz
	Pin3	4.7 V	0 dBm, 1000 MHz	
V600	Pin2	0.75 V		RF 1000 MHz
	Pin3	0.95 V	10 dBm, 62.5 MHz	

Um die Baugruppe YSYN ausbauen zu können, ist nur die Unterseite des Gerätes zu öffnen. Zunächst wird die Rechnerbaugruppe ausgebaut. Dazu werden die beiden seitlichen Schrauben geöffnet und das Kabel für den IEC-Bus, das zur Rückwanne führt, entfernt. Die Rechnerbaugruppe kann nun herausgenommen werden, die Kabel zur Tastatur/Anzeige sowie zum Motherboard bleiben angesteckt. Nach dem Lösen der beiden seitlichen Schrauben der Synthesebaugruppe können die drei, bzw. vier (bei vorhandenem Optionsquarz) HF-Verbindungen an der Baugruppe abgezogen bzw. aufgeschraubt werden. Die Baugruppe YSYN wird nun seitlich nach hinten aus ihrem Steckplatz entnommen.

Über das sich im Servicekit befindende Flachbandkabel kann die Synthesebaugruppe nun wieder mit dem Motherboard verbunden werden. Die Buchsen X127 und X128 werden ebenfalls über die sich im Servicekit befindlichen koaxialen Kabel mit den entsprechenden Anschlüssen EXTREF sowie, falls vorhanden, mit dem Optionsoszillator verbunden.

Die Schirmdeckel sind auf herkömmliche Weise verschraubt. Beim Betrieb mit geöffnetem Schirmdeckel ist darauf zu achten, daß die Resonatorkammern E und F auf beiden Seiten mit geeigneten Prüfdeckeln verschlossen werden.

# 7.6 Externe Schnittstellen

Die Angaben für den Stromverbrauch der jeweiligen Versorgungsspannung bezieht sich auf den Zustand der Baugruppe nach einem PRESET.

Pin	Name	Ein/Ausgang	Herkunft:	/Ziel	Wertebereich	Signalbeschreibung
X1A.4	EXT1	Eingang	Frontein	neit	1V <sub>s</sub>	Modulationsspannung
X1A.6	INT1	Eingang	Rechner	X3.32	1V <sub>s</sub>	Modulationsspannung
X1A.8	FMKOMPLO	Ausgang	Rechner	X3,23	HCMOS-Pegel	Pegelüberwachung EXT
X1A.9	FMKOMPHI	Ausgang	Rechner	X3.24	HCMOS-Pegel	Pegelüberwachung EXT
X1A.10	OPTUNE	Ausgang	Netzteil	X21.24	010V	Abstimmspannung für
						optionale Referenz (SM-B1)
X1A.12	SERCLK	Eingang	Rechner	X3.2	HCMOS-Pegel	Clock für Datenübertragung
X1A.14	SERDAT	Eingang	Rechner	X3.4	HCMOS-Pegel	Serielle Daten
X1A.15	HF1STB	Eingang	Rechner	X3.14	HCMOS-Pege1	Strobe1
XIA.16	HF2STB	Eingang	Rechner	X3.15	HCMOS-Pege1	Strobe2
X1A.17	HFINT	Ausgang	Rechner	X3.20	TTL-Pegel	Interrupt Regelschleifen
X1A.19	DIAG-5V	Ausgang	Rechner	X3.6	05V	Diagnose
X1A.22	VA24-P	Eingang	Netzteil	X21.22	23.025.0 V	Versorgungsspannung analog
					12 ± 5 mA	
X1A.24	VA15-P	Eingang	Netztei1	X21.13	14.415.6 V	Versorgungsspannung analog
					110 ± 25 mA	
X1A.25	VA15-P	Eingang	Netztei1	X21.13	14.415.6 V	Versorgungsspannung analog
		l			110 ± 25 mA	-
X1A.26	VA7.5-P	Eingang	Netzteil	X21.8	7.27.8 V	Versorgungsspannung analog
	ļ				650 ± 100 mA	
X1A.28	VA-5P	Eingang	Netztei1	<b>X21.</b> 5	4.95.3 V	Versorgungsspannung digital
		Ì			35 ± 10 mA	
X1.A30	VA15-N	Eingang	Netzteil	X21.19	-15.614.4 V	Versorgungsspannung analog
					-195 ± 35 mA	
X128	OPT10	Eingang	Referenzosz.		7.5 ± 1.5 dBm	10 MHz ± 5 ppm
X127	EXTREF	bidir.	Rückwand		5/10 MHz ± 3ppm	Eingang Referenz
					-1313 dBm	
					10MHz, 610 dBm	Ausgang Referenz
X124	FSYN	Ausgang	Ausga <b>n</b> gsteil		714 dBm	Synthese Freq 651040 MH2
X125	REF640	Ausgang	Ausgangst	ei1	812 dBm	Referenz 640 MHz



SERVICE INSTRUCTIONS

Synthesizer

1062.6409.01

# Contents

7 Tes	ting a	nd Repair of the Module 5
7.1	Funct	ion Description 5
	7.1.1	Reference Frequencies
	7.1.2	Synthesizer 65 to 1040 MHz       6         7.1.2.1 Oscillators 520 to 1040 MHz       6         7.1.2.2 Output Dividers       6         7.1.2.3 Fractional-N-Divider and PLL       7
		FM/φM Modulation
	7.1.4	Calibration Routines       8         7.1.4.1 VCO Calibration       8         7.1.4.2 FM-Calibration       9
7.2	Test :	Instruments and Utilities 9
7.3	Troub.	leshooting9
	7.3.2 7.3.3	Synchronization Errors9Error with CW-Operation10Error with FM-/φM-Modulation11Calibrations12
7.4	Testin	ng and Adjustment12
	7.4.2	Data Transmission and Power Supply
		640-MHz Reference
	7.4.5	Output Oscillators
		Testing the Deviation Divider

	7.4.8 EXT Monitoring	19
	7.4.9 Sigma-Delta Converter Including FM-DC Control	19
	7.4.10 FM-Deviation Setting	20
	7.4.10.1 Checking the FM-Diagnostic Detector	20
	7.4.10.2 Adjustment of FM-deviation	
	7.4.10.3 Checking FM-Calibration	21
	7.4.11 Transient Response of Synthesis	21
	7.4.12 Final Tests of Synthesis	22
	7.4.12.1 Residual FM of Synthesizer	22
	7.4.12.2 Residual FM 640-MHz Oscillator	22
	7.4.12.3 Spuriae of Synthesizer	23
	7.4.12.4 FM-DC Center Frequency Calibration	23
	7.4.13 Tables and Interfaces	23
	7.4.13.1 List of Diagnostic Test Points	23
	7.4.13.2 Digital Interface	23
	7.4.13.3 Operating Points and Levels of RF Amplifiers	26
7.5	Disassembly and Assembly	27
7 6	Furtownal Tatomingo	^=

Parts list Coordinates list Circuit diagram Component location plan

# Testing and Repair of the Module

In instuments without fitted option SMY-B40, this module has the variant VAR 02.

In instuments with fitted option SMY-B40, this module has the variant VAR 04.

### 7.1 Function Description

Module YSYN contains a synthesizer which can be FM/ $\phi$ M-modulated from 65 to 1040 MHz, the deviation divider for FM/ $\phi$ M as well as the reference frequency generation consisting of a 10 MHz VTCXO as well as a 640 MHz oscillator as LO for the mixer range of the output stage.

#### 7.1.1 Reference Frequencies

#### 7.1.1.1 Internal Reference 10 MHz

A 10-MHz VTCXO (N200) is used as a standard reference. An emitter follower including level converter (V205 and V210) amplifies the output signal to TTL level (test point P201). At the same time, the signal of the option reference is fed here (input X128, OPT10). In this operating mode, the standard oscillator is switched off using switching transistor V200 and the path for the option reference bypassed via diode V235. The divider stage (D205-A) generates the 2-MHz reference frequency for the PLL of the output oscillators and the Sigma-Delta converter as well as the lMHz reference frequency for the phase detector of the reference PLL (test point P202). The 10-MHz signal which has been coupled out via D200 serves as a reference frequency for the PLL of the 640-MHz oscillator.

In this operating mode, either the standard reference or, if fitted, the option reference is applied at output X127 (EXTREF). Exact frequency setting is effected using a 12-Bit D/A-converter (D220) which is provided by a 10-Volt reference voltage (+10REF) (tuning voltage UINT or OPTTUNE).

#### 7.1.1.2 External Reference 5 or 10 MHz

In the External Reference operating mode, 5 or 10 MHz can be fed with a tolerance of ± 3 ppm at X127 (EXT REF). A diode circuit (V220) generates a harmonics spectrum, a resonance amplifier (V215) filters out the 10-MHz signal and the following level converter (V216) amplifies it to TTL level (test point P204). After dividing the frequency by 10 (D205-B), the signal is compared to the down-divided frequency of the TCXO in phase detector D210. The standard reference oscillator is synchronized with the external reference in a PLL with a bandwidth of 2 Hz. The tuning voltage of the PLL can be remeasured at P203 (U-PLL-VTCXO). If there is an optional reference oscillator (SM-Bl), its level is cut off in the External Reference operating mode. The tuning voltage of the oscillator is monitored in both operating modes using the window comparator N100 via a buffer (N220-C).

5

#### 7.1.1.3 640-MHz Oscillator including PLL

The 640-MHz oscillator is designed using a ceramic resonator (X300) which is fine-tuned by means of a tuning diode (V300). Transistor stage V305 uses its negative impedance to amplify the resonant circuit. The oscillator signal is coupled out at the emitter via a buffer amplifier (N300). Via an resistive power divider, the signal is splitted up to the output amplifier (V330) as well as the frequency divider (B360) which divides the signal for the PLL to the 10 MHz-reference frequency. The output amplifier with a "Dual Gate MESFET" (V330) amplifies the oscillator signal to approx. 10 dBm (X125, REF640). If the mixer path in the output section is not active, the output level can be reduced by more than 40 dB via gate2 of the output amplifier by means of the switching transistors (V340, V345) (control signal S-Ref 640). The signal generated via the fixed divider by 64 is converted to TTL level (test point 354) using transistor stage V370 and is compared with the 10-MHz reference frequency at the phase detector (D255). The output voltage of the PI-controller (N250) tunes the oscillator, the bandwidth of the PLL is approx. 300 Hz. The level of the 640-MHz output amplifier is measured by a diagnostic rectifier (V347). The control voltage of the PLL is

# 7.1.2 Synthesizer 65 to 1040 MHz

monitored by a window comparator (N105).

# 7.1.2.1 Oscillators 520 to 1040 MHz

Two oscillators with a tuning range of 260 MHz each generate the frequency of the basic octave. A transistor with a negative impedance at its basis (V404 and V434) amplifies the series resonant circuit consisting of a porcelain capacitor (C402 and C432), a printed inductor and two times two tuning diode connected in parallel (V400-V403 and V430-V433). Due to the small tolerances of the elements determining the resonant circuit, a frequency adjustment of the oscillators is not necessary. A power source (V406 and V436) whose supply voltage can be switched on and off via a transistor stage stabilizes the operating point of the oscillator via the tuning range. Depending on the active oscillator, the output signal is supplied to the buffer stage N490 via a PIN switch (V490 and V492). An resistiv power divider branches the oscillator signal to the output dividers as well as to the fractional-N-divider of the PLL.

## 7.1.2.2 Output Dividers

The output frequencies of 65 to 520 MHz are implemented by means of frequency division by two, four and eight. A divider by 2 (D510) and a divider by 4 (D520) are used. By forming an iterative network of the two dividers, division factor eight is achieved. The individual signal paths are switched via PIN switches (S1 to S6). The divider components are switched on and off via the supply voltage using transistors V510 and V520. Output amplifier N560 increases the level to approx. 8 to 12 dBm. This output level is monitored via the diagnostic rectifier V555.

6

## 7.1.2.3 Fractional-N-Divider and PLL

The output oscillators are locked to a reference frequency of 2 MHz in a PLL with a fractional divider. This component of the circuit is integrated in gate-array FRACSYN (D65). The two MMIC amplifiers N600 and N610 decouple the divider circuit from the oscillators. The two frequency dividers (D620 and D630) divide the oscillator frequency by 16 and thus provide input frequencies of 32.5 to 65 MHz for the FRACSYN executing the actual fractional division (test point P600). Component FRACSYN calculates the new division factor for every reference period from the division factor programmed via a serial interface as well as the deviation set. Its output clock CKO of 2 MHz is synchronized with the input clock of the FRACSYN using synchronization flipflop D655. The synchronized 2-MHz signal is supplied to phase detector D700 from there.

The UP/DOWN output signals of the phase detector obtained from comparing the phase with the 2-MHz reference frequency (2REF) are added in differential amplifier N710 (test point P700). The gain of the following PI-controller (N720) can be set in 8 stages using an analog multiplexer (D720) to compensate for gain variations in the PLL caused by the different division factor as well as the different VCO slope. A transistor output stage (V750 and V755) with diode switchover of the PLL bandwidth (V765 to 768) accelerates the settling process of the PLL in the case of a frequency change.

The output voltage of the PI-controller (A-PI-SYN) is monitored by a window comparator (N110). The tuning voltage of the oscillators can be measured via a diagnostic point.

# 7.1.3 FM/φM Modulation

#### 7.1.3.1 Function Principle

The use of a fractional divider with a digital modulation input permits implementing a relatively simple and yet precise FM AC/DC and  $\phi M$  circuit.

The modulation is transmitted via two paths with different frequency responses. In the first path, the division factor and thus the instantaneous center frequency is directly modulated in the case of FM after the A/D conversion using a Sigma-Delta converter. This part has the lowpass function for the wanted transmission of a PLL, at the same time the PLL is a lowpass filter for the quantization noise of the A/D converter here. In the second path, the oscillator is modulated directly, this part has the highpass function for the unwanted transmission of a PLL. With equal sensitivity and delay in both paths, the frequency response is flat with a constant group delay.

QM is generated by differentiating the modulation voltage. The

 $\phi$ M is generated by differentiating the modulation voltage. The cut-off frequency of the differentiator is approx. 40 kHz. A DC-modulation is thus not possible with  $\phi$ M. The transmission functions are the same as with FM.

#### 7.1.3.2 FM/φM-Deviation Divider

The two inputs INT1 and EXT1 are available for feeding the modulation signals. The external modulation input has a high-impedance input amplifier (N800) with switchable AC/DC coupling (D820). The input impedance can be selected via jumper X80. It is 100  $k\Omega$  or 600  $\Omega$ .

The desired modulation signal is selected via switch D800. A single-tone modulation (external or internal) and two-tone modulation (external and internal) is possible. Amplifiers N845 and N850 amplify the input signal from lVs to 6Vs. The signal for the Sigma-Delta converter is tapped in between via amplifier N850. The current flowing here is always constant. A multiplicating 12-bit D/A converter (D840) is used to fine-adjust the deviation in the control path for the modulation via the oscillators. The following operational amplifier performs an impedance conversion. For the coarse adjustment of the deviation at the oscillator, an attenuator forming an iterative network with steps of 12 dB is used (divides by 1 to 4096). The taps are switched by analog multiplexer D960. With modulation switched off, the oscillator input is connected to ground via a FET (N960) in order to minimize thermal noise.

The deviation values for the modulation of the division factor via the Sigma-Delta converter is coarsely adjusted internally in the FRACSYN and finely adjusted via the ADWE inputs (shift registers D660 and D665) with a resolution of 16 bits.

For  $\phi M$ , a differentiating circuit is inserted into the common branch (reed relay K910). Otherwise, the transmission paths are identical to FM.

The level at the EXT input is monitored by the window comparator circuit using N860 and D870. In the case of a deviation from the rated level of 1 to 3 %, interrupt FMKOMPHI (voltage fed is too high) or FMKOMPLO (voltage fed is too low) is triggered depending on the direction.

# 7.1.3.3 Sigma-Delta Converter and FM-DC Control

A Sigma-Delta converter of 3rd order (N940, N950, N960, D950 and D965) converting the analog modulation signal into a digital signal is used to modulate the division factor. The variable average of the 1-bit output signal corresponds to the analog input quantity. The quantization noise caused is filtered by the lowpass function of the PLL. A delay equalizing circuit at the input of the converter ensures an equal group delay in both modulation paths.

As all offset voltages lead to a shift of the center frequency also with AC operation, they are compensated by an average control. In the case of FM-DC, the control is to be clamped in order not to level out the DC modulation voltage. This component of the circuit is also located in gate array FRACSYN.

## 7.1.4 Calibration Routines

#### 7.1.4.1 VCO Calibration

In steps of 5 MHz, a table of the respective tuning voltages of the oscillators is created. The respective oscillator slope ko(f) can be calculated from these values determined via diagnosis with a linear interpolation of the intermediate values. It is required in order to determine the necessary PLL-GAIN which is used to compensate the gain fluctuations in the closed loop. The slope values determined are also required as starting values to calculate the rate of rise of deviation for FM calibration.

## 7.1.4.2 FM-Calibration

For the calibration table of the rate of rise of deviation, a diagnostic detector (N780, V781, C782) measures the differential deviation in the closed loop at a modulation frequency of 1 kHz. In an adjustment routine, the control elements of the FM/ $\phi$ M deviation divider are varied until the differential deviation measured is minimal. The modulation slope of the oscillator at the respective frequency is calculated from the setting values thus achieved. This table is also created in steps of 5 MHz.

#### 7.2 Test Instruments and Utilities

- RF-spectrum analyzer (FSA)
- RF-signal generator (SMGU, SME)
- Function generator f>=2 MHz, (AFGU, AFS)
- Oscilloscope f>250 MHz
- AC/DC voltmeter (URE3)
- Modulation analyzer with distortion meter (FMA, FMB)

# 7.3 Troubleshooting

For fault diagnosis, the test program included in service kit SMY-Z1, which offers extensive possibilities of diagnosis, is suitable as well.

# 7.3.1 Synchronization Errors

Error messages Error 1 to Error 3 are an OR-operation of the error controls of the phase locked loops for the 10-MHz TCXO, the 640-MHz oscillator as well as the PLL of the output oscillators. If there is an error at the 10-MHz PLL, this can also cause the other closed loops to be locked out. The relevant diagnostic point can be used to check which of the three phase locked loops is out of tolerance.

Error message "Error 1"
10-MHz reference loop out of synchronization

Check whether the correct frequency with a sufficient level is fed in the external reference operating mode.

Check the external reference according to 7.4.2.2

Check window comparator N100

Error message "Error 2" 640-MHz loop out of synchronization

Check whether 10-MHz reference frequency is applied to phase detector D255.11.

Check the 640-MHz oscillator and the PLL according to 7.4.3.1

Check window comparator N105

Error message "Error 3"
Main oscillator loop out of
synchronization

Check output oscillators according to 7.4.4

Measure whether 2-MHz reference signal is applied to phase detector D700.3. Check PLL of the output oscillators according to 7.4.5

Check window comparator N110

# 7.3.2 Error with CW-Operation

No output level or output level too small at X124

Check output oscillators according to 7.4.4

Check output divider using dividers according to 7.4.6

Check the operating points or the RF levels of the amplifiers in the path (table 7.4.13.3)

Residual FM too high (no spuriae)

Execute calibration routine VCO using SPEC 41

Check oscillators according to 7.4.4, also their operating points according to table 7.4.13.3 Measure residual FM of the oscillators, the DC voltage fed must be sufficiently free of hum and noise

Check PLL of the output oscillators according to 7.4.5.1-7.4.5.3, check supply voltages of FRACSYN and phase detector (7.4.1)

Spuriae > -70 dBc for offset Execute calibratequencies > 5 kHz to carrier using SPEC 41

Execute calibration routine VCO using SPEC 41

Check phase offset of the phase detector, DC-voltage at C701 should be 1.65 V

Check supply voltage FRACSYN and phase detector (7.4.1)

large

Deviation error with FM or OM; Stereo crosstalk out of tolerance Substantial modulation distortions with maximal deviation

Execute calibration routine FM using SPEC 43

Check the deviation divider according to 7.4.7

Check deviation setting according to 7.4.9

FM-distortion factor too high

Execute calibration routine FM using SPEC 43

Check deviation divider according to 7.4.7, check distortion factor of the modulation signal at X84

Check FM calibration according to 7.4.10.3

No or false FM-modulation with Check Sigma-Delta converter modulation frequencies of less according to 7.4.9 than 1 kHz

Perform adjustment of FM deviation according to 7.4.10.2

No or false FM-modulation with Execute calibration routine FM modulation frequencies of more using SPEC 43 than 1 kHz

FM-frequency response too

Check deviation divider acc. to 7.4.7

Check deviation divider acc. to 7.4.7

Measure frequency response also after coarse divider at D960.3 (FM deviation set > 3 MHz, RF > 520 MHz)

Center frequency error with FM-DC modulation, or FM-DC center frequency calibration (special function 55 not performed correctly)

Check Sigma-Delta converter and FM-DC control according to 7.4.9

No or false \phi M-modulation

Check whether an FM modulation set equivalently is correct, otherwise error with PM differentiator (highpass filter with C913 and R848, is checked in 7.4.7) (equivalent FM = PM set \* AF frequency fed)

#### 7.3.4 Calibrations

Error message "Error 15" Calibration VCO faulty

Check output oscillators according to 7.4.4

Check PLL of the output oscillators according to 7.4.5

Check transient response of the synthesis according to 7.4.11

Error message "Error 15" Calibration FM faulty

Check the FM diagnostic detector acc. to 7.4.10.1, the offset of the diagnostic detector (measure test point 15 via diagnosis, do not feed an AF frequency) must be less than 50 mV.

Check the deviation divider according to 7.4.7

Check Sigma-Delta converter according to 7.4.9

Check delay equalization at the Sigma-Delta converter input

## 7.4 Testing and Adjustment

All measured values without tolerances stated are to be understood as guide values. Voltage values without further designation are DC voltages.

If the module is operated with the cover opened, the two oscillator chambers must be closed on the component and solder side by means of test covers.

The SMY has to be brought to a defined initial status by means of PRESET prior to all tests.

# 7.4.1 Data Transmission and Power Supply

#### (Cf. circuit diagram sheet 9)

According to the device standard, the module is controlled via a serial interface. Data transmission is effected on two different subaddresses. The data are accepted by the two module strobes HF1STB and HF2STB. The settings and the pertaining data are to be found in Section 'Digital Interfaces'.

Current consumption can be checked by looping in an amperemeter instead of coils L1 to L5. The rated values can be found in Section 'External Interfaces'.

The most important reference or supply voltages are remeasured using the DC voltmeter.

Test point	Type of voltage	Voltage [V]
P20	10-V reference	+9.9 to +10.1
P21	Supply volt. 5 V analog	+5.1 to +5.4
D700_14	Supply volt. phase detector	4.6 to 5.0 V
D65_84	Supply volt. FRACSYN	5.1 to 5.5 V

# 7.4.2.1 Internal Reference

(Cf. circuit diagram sheet 2)

The tuning voltage for the internal reference is read via the diagnosis for different D/A converter values (function D/A converter). A 10-MHz HCMOS signal must be visible on the oscilloscope (function level converter). Output level EXTREF can be measured using the spectrum analyzer.

• Connect oscilloscope with probe to P201

• Connect spectrum analyzer to EXTREF (rear of the instrument)

• Settings: SPEC 111 RF INT/ON

\_ Set the D/A converter values according to the table via special function 51 and check diagnostic voltage. The calibration values entered are accepted on pressing the ENTER key.

SPEC 51	Diagnostic voltaga at test point 11
0	± 150 mV
4095	4.7 to 5.3 V
2048	2.3 to 2.7 V

\_ Check signal at P201: 10 MHz, HCMOS

\_ Measure output signal at spectrum analyzer: 10 MHz,  $7.5 \pm 2$  dBm

# 7.4.2.2 External Reference

(Cf. circuit diagram sheet 2)

First the input of the external reference is tested using the multiplier connection.

- Connect signal generator 5 MHz to EXTREF (rear of the instr.).
- Connect oscilloscope with probe to P204.
- Settings: RF EXT AC
- \_ Check signal at P204: 10 MHz, HCMOS level for input levels from -13 to 13 dBm at input EXTREF.

Now the PLL and the pulling range of the VTCXO are checked. The control voltage is checked via the diagnosis.

• Settings: SPEC 111

- Feed frequency of the signal generator according to the table, level: 7 dBm.
- \_ Check diagnostic voltage according to the table.

Frequency at EXTREF	Diagnostic voltaga tast point 11
10 MHz	2.5 ± 0.5 V
9.999970 MHz	> 0.5 V
10.000030 MHz	< 4.5 V

# 7.4.3 640-MHz Reference

### 7.4.3.1 Oscillator 640 MHz and PLL

(Cf. circuit diagram sheet 2 and 3)
The function and the tuning range of the oscillator are checked.

- Withdraw jumper X20 and connect power supply unit (0 to 20 V) to X20.2 and X20.3 (ground).
- Connect spectrum analyzer to X125 with setting CF 640 MHz, SPAN 50 MHz and REF LEVEL 10 dBm.
- Settings: RF 50 MHz
- \_ Vary tuning voltage from 0 to 20 V, the oscillator must oscillate without failures, secondary lines or high noise in the entire tuning range at 640 ± 20 MHz.
- \_ Switchover tuning voltage between 2 and 18 V, the frequency change of the oscillator must be > 15 MHz and < 25 MHz.</p>
- \_ The tuning voltage for 640 MHz must be > 4V and < 16V.
- Remove power supply unit again and plug jumper X20 onto 1-2.

Tuning voltage is now measured via diagnosis with the PLL closed.

- Settings: SPEC 112
- \_ Diagnostic voltage at test point 12: 10 ± 6 V

# 7.4.3.2 Output Amplifier 640 MHz

(Cf. circuit diagram sheet 3)

The output level is checked with the signal switched on or off.

- Connect spectrum analyzer with setting CF 640 MHz, SPAN 50 MHz, REF LEVEL 15 dBm to X125.
- Settings: RF 50 MHz SPEC 113
- Measure level 640 MHz at spectrum analyzer: 10 ± 2 dBm.
   Diagnostic voltage at test point 13: 100 to 400 mV.

The frequency of the SMY is set such that the LO amplifier is switched off.

- Settings: RF 100 MHz
- Measure level 640 MHz at the spectrum analyzer: < -30 dBm.

# 7.4.4 Output Oscillators

(Cf. circuit diagram sheets 4, 5 and 7)

The trim cover on the component and the solder side must absolutely be screwed onto the oscillator chambers.

The function of the two output oscillators and their tuning range are checked. The diagnostic voltage for the output level is checked as well.

- Connect spectrum analyzer with setting CF 780 MHz, SPAN 800 MHz, REF LEVEL 15 dBm to X124.
- Remove jumper X75 and connect power supply unit to X75.2 and X75.3 (ground).
- The tuning voltage is varied for both oscillators between 0 and 22 V, the oscillator must oscillate in the entire tuning range without failures, secondary lines and high noise. At the lower and upper frequency limits of both oscillators, the tuning voltage must be in the tolerance window stated (cf. table). The output level at X124 must be between 7 and 14 dBm.

Setting	Oscillator	Min. freq.	Tun. volt.	Max. freq.	Tun. volt.
RF 600 MHz	1	520 MHz	1.75 to 4 V	780 MHz	16.5 to 19.5 V
RF 900 MHz	2	780 MHz	1.75 to 4 V	1040 MHz	16.5 to 19.5 V

With an output frequency of approx. 1040 MHz, diagnosis is tested as well.

Settings: SPEC 114

- \_ Diagnostic voltage at test point 14: 80 to 400 mV
- Remove power supply unit and plug jumper X75 on 1-2 again.

#### 7.4.5 PLL of the Output Oscillators

In order to detect possible errors in a phase locked loop, it is useful to open it and to perform troubleshooting at the opened PLL. Jumper X75 remains removed during tests 7.4.5.1 - 7.4.5.3. To facilitate tracking of the output frequency set, a spectrum analyzer should be connected to X124.

# 7.4.5.1 Checking the Dividers in the PLL

(Cf. circuit diagram sheet 6)

The divider chain in the feedback of the PLL is checked first.


- Remove jumper X75 and connect power supply unit to X75.2 and X75.3 (ground).
- Set voltage at the power supply unit to approx. 16 V (oscillator 2 oscillates to approx. 1000 MHz)
- Connect oscilloscope including probe to P600.
- Settings: RF 1000 MHz
- \_ Check signal at P600: approx. 62.5 MHz, TTL level
- Connect oscilloscope including probe to P610.
- \_ Check signal at P610: approx. 2 MHz, HCMOS level

# 7.4.5.2 Checking the Phase Detector


(Cf. circuit diagram sheet 7)
When the phase detector is checked, first make sure that the reference frequency (signal 2REF) which is synchronized to is applied correctly.

- Settings: RF 1000 MHz
- \_ Check signal at D700.3 using probe at oscilloscope: 2 MHz, HCMOS level
- Now connect oscilloscope including probe to P700.
- Slightly reduce voltage at the power supply unit at X75 such that the output frequency of oscillator2 is less than 1000 MHz.
- \_ Falling saw-tooth voltage at P700 with the differential frequency of the two input signals, DC voltage at P700 is negative (approx. - 0.8 V)

Fig. 1



- Now slowly increase the voltage at power supply unit at X75 such that the output frequency of oscillator2 becomes more than 1000 MHz. The voltage at P700 is observed.
- Rising saw-tooth voltage at P700 with the differential frequency of the two input signals, DC voltage at P700 is positive (approx. 4 V)



# 7.4.5.3 Checking the Loop Integrator

(Cf. circuit diagram sheet 7)
An exact test of the integral loop integrator with an opened loop is not possible. Thus only coarse functionality is checked.

- Connect oscilloscope including probe to P720.
- Settings: RF 1000 MHz

The procedure in the functionality test of the loop amplifier is identical to the test of the phase detector. The fed DC voltage at X75 is first reduced such that the oscillator oscillates below 1000 MHz. Now a negative input current flows into the integral controller, which increases its output voltage to approx. 21 to 24 V at P720. If the voltage at X75 is increased such that the oscillator now oscillates above 1000 MHz, a positive input current flows into the integral controller such that its output voltage decreases to approx. 0 V. If the differential frequency set is very low, an AC voltage with the corresponding differential frequency can be superimposed on the DC voltage at P720. It is also recommended to check the voltage after the subsequent lowpass filter (voltage at X75.1). It must be identical to the voltage at P720.

• Remove power supply unit and plug jumper X75 on 1-2 again.

# 7.4.5.4 Checking the Closed PLL

(Cf. circuit diagram sheet 4,6 and 7)
After plugging jumper X75, the PLL is closed.

• Settings: RF FREQUENCY (acc. to table)
SPEC 115

- Connect spectrum analyzer with setting CF=FREQUENCY, Span 100 kHz, Rev.1ev. 15 dBm to X124.
- \_ The output signal is checked with the different RF settings. No secondary lines or high noise must be visible on the spectrum analyzer.

FREQUENCY	Diagnostic voltage test point 15
520 MHz	1.75 to 4 V
779.999999 MHz	16.5 to 19.5 V
780 MHz	1.75 to 4 V
1040 MHz	16.5 to 19.5 V

# 7.4.6 Output Stage with Dividers

(Cf. circuit diagram sheet 5)

Output dividers by 2, 4 and 8 are checked. The diagnostic voltage and the output level are checked as well. For this test it is necessary that the PLL and the output oscillators work perfectly and thus all frequencies of the ground octave from 520 to 1040 MHz can be set.

• Settings: RF FREQUENCY (acc. to table)
SPEC 114

\_ Check the frequency set as well as the output level at the spectrum analyzer according to the table.

\_ Voltage at test point 14 for all RF frequencies: 80 to 600 mV

PREQUENCY	Divider 22	Level at X124
1040 MHz	1	7 to 14 dBm
780 MHz	1	7 to 14 dBm
779 MHz	1	7 to 14 dBm
520 MHz	1	7 to 14 dBm
500 MHz	2	7 to 14 dBm
250 MHz	4	7 to 14 dBm
125 MHz	8	7 to 14 dBm

### 7.4.7 Testing the Deviation Divider

(Cf. circuit diagram sheet 8)

The modulation matrix for both channels, the AC/DC switchover for the external input, the differentiator for  $\phi M$  as well as the fine deviation divider are checked.

- Remove jumper X84.
- Feed modulation signal at input socket EXT at the front unit according to the table, remeasure the rated voltages at test points according to the table using AC/DC voltmeter.

• Settings: RF 1000 MHz

Setting	Signal at EXT	Signal at P840	Signal at X84.1
FM EXT DC 10 MHz	1 V	- 3.32 ± 0.1 V	- 6 to - 1.5 V
			(Reference value)
AF 1 kHz,			
FM INT 10 MHz	-	3.32 ± 0.1 Vs	- 6 to - 1.5 Vs
			(=Reference value)
			DC < 40 mV
FM EXT AC 10 MHz	2 MHz. 1 Vs	3.32 ± 0.2 Vs	Ref. value ± 3 dB
			DC < 40 mV
<b>Φ</b> M EXT 175 rad	20 kHz, 1 Vs	3.32 ± 0.1 Vs	Ref. value - 10 dB
			( ± 1 dB)

Now the fine deviation dividers are checked

• Settings: R

RF 1000 MHz
AF 1 kHz
FM INT 0 Hz
FM STEP 100 Hz

\_ Vary the FM deviation at the front module from 0 Hz to 2.5 kHz in steps of 100 Hz using the rotary knob. The AF voltage at X84.1 must rise from 0 V to approx. 3.2  $V_{\rm S}$  in equal steps (approx. 0.13 V).

### 7.4.8 EXT Monitoring

(Cf. circuit diagram sheet 8)

- Connect AF generator, 1 kHz, level according to the table, to EXT.
- \_ Check the function of level monitoring according to the table.
- Settings: FM EXT AC 100 kHz

Input voltage at EXT	Display 10 10 10 10 10 10 10 10 10 10 10 10 10
1 ± 0.005 Vs	-
1.03 ± 0.005 Vs	EXT-HIGH
0.97 ± 0.005 Vs	EXT-LOW

## 7.4.9 Sigma-Delta Converter Including FM-DC Control

(Cf. circuit diagram sheet 8)

The function of the Sigma-Delta converter as well as the FM-DC control in operating modes FM-AC and FM-DC is checked.

• Settings: RF 1000 MHz

Connect DC voltage source (0 to 1V) to modulation input EXT.

Check the DC voltages stated using a DC voltmeter according to the table.

Setting	DC-volt. at EXT	DC-volt. at D950.9	DC-volt. at D65.75
FM EXT AC 10 MHz	0 V	2.6 ± 0.2 V	2.6 ± 0.2 V
FM EXT DC 10 MHz	V 0	2.6 ± 0.25 V	2.6 ± 0.25 V
FM EXT DC 10 MHz	1 V	3.8 ± 0.2 V	2.6 ± 0.25 V

# 7.4.10 FM-Deviation Setting

## 7.4.10.1 Checking the FM-Diagnostic Detector

(Cf. circuit diagram sheet 7 and 8)

When FM calibration is carried out, the differential deviation in the locked loop is measured using an FM diagnostic detector. To check the detector, a defined frequency deviation is set and the accuracy measured using the detector.

• Settings:

RF 1000 MHz

FM EXT AC 50 kHz

**SPEC 116** 

- Connect AF generator, 1  $V_S$   $\pm$  5 mV, 1 kHz, to input EXT.
- Remove jumper X84.
- \_ Diagnostic voltage at test point 16: 1.6 ± 0.4 V.
- Set AF frequency fed to 500 Hz, then to 1.5 kHz.
- \_ Diagnostic voltage at test point 16: < 0.5 V.
- Fit jumper X84.1/2 again.

#### 7.4.10.2 Adjustment of FM-deviation

(Cf. circuit diagram sheet 8)

The scale of the FM-deviation is adjusted via the control branch (control of the division ratio at FRACSYN).

• Settings:

RF 1000 MHz

FM EXT AC 500 kHz

- $\bullet$  Connect AF generator, 1  $V_S$   $\pm$  5 mV, 50 Hz, to input EXT.
- Connect modulation analyzer with setting HP 10 Hz, TP 3 kHz, detector RMS\*'2, to X124.
- \_ Use R930 to adjust to an FM-deviation of  $500 \pm 1 \text{ kHz}$ .
- \_ Perform FM-calibration using SPEC 43.

### 7.4.10.3 Checking FM-Calibration

(Cf. circuit diagram sheet 7)

After calibration, differential deviation is measured with FM modulation in the PLL using the diagnostic detector (cf. 7.4.10.2). Checking is performed in the ground octave from 520 to 1040 MHz in steps of 5 MHz.

• Settings: RF 520 MHz

FM INT 500 kHz

AF 1 kHz SPEC 116

RF STEP 5 MHz

\_ Increase the frequency from 520 MHz to 1040 MHz using the rotary knob. The diagnostic voltage at test point 16 must be in the range 0 ± 50 mV with every frequency.

### 7.4.11 Transient Response of Synthesis


The transient response of the PI controller voltage with a sudden frequency change between 520 and 1040 MHz is measured.

• Settings: RF 520 MHz

FM OFF RF EXT AC

- Connect socket EXTREF of the spectrum analyzer with socket EXTREF at the rear panel of the SMY.
- Connect probe at module strobe HF2STB to X1A.16 and connect with input EXT SWEEP TRG at the rear panel of the spectrum analyzer.
- Connect spectrum analyzer with setting CF 1040 MHz, SPAN 0 Hz, REF LEVEL 10 dBm, LOG RANGE 20 dB, SWEEP 100 ms, RES BW 2.023 kHz, TRIGGER EXTERNAL, SLOPE NEGATIV, TRIGGER LEVEL 238 mV to X124.
- Edge demodulation is necessary to measure the transient response of the synthesis correctly.

  The RF frequency of the synthesis module is set to 1040 MHz for preparation. Then the center frequency of the spectrum analyzer is reduced in steps of 100 Hz starting from 1040 MHz in the FREE RUN mode of the analyzer until the value measured is 0 dBm. After switching the synthesis to RF 520 MHz and the analyzer to Trigger External, the frequency changes to 1040 MHz. The setting at the spectrum analyzer corresponds to a scale factor of approx. 120 Hz/dB.
- \_ 50 ms after the module strobe has been performed (trigger signal), voltage may only vary by maximally ± 100 Hz (approx. 0.85 dB). A voltage characteristic as shown in Fig. 3 is typically obtained.



Res. bu. 2. 023kHz, Vid. bu. 3kHz, Succeptine 100ms

# 7.4.12 Final Tests of Synthesis

The following final tests should be performed if measurements or a fault recovery have been executed at the module before. The cover on the solder and the component side have to be screwed on now. The module is still located on the test adapter.

#### 7.4.12.1 Residual FM of Synthesizer

- Connect modulation analyzer to X124. Check residual FM using weighting filter 20 Hz to 23 kHz and CCITT at the following frequencies (in MHz): 520, 580, 640, 710, 779, 780, 840, 900, 970, 1040 MHz
- \_ Residual FM < 16  $\rm Hz_{rms}$  (20 Hz to 23 kHz) Residual FM < 8  $\rm Hz_{rms}$  (CCITT)

#### 7.4.12.2 Residual FM 640-MHz Oscillator

- Connect modulation analyzer to X125. Check residual FM using weighting filter 20 Hz to 23 kHz and CCITT.
- Settings: RF 50 MHz FM OFF
- \_ Residual FM < 4 Hz<sub>rms</sub> (20 Hz to 23 kHz) Residual FM < 2 Hz<sub>rms</sub> (CCITT)

### 7.4.12.3 Spuriae of Synthesizer

- Connect spectrum analyzer with setting CF=FREQUENCY, SPAN 50 kHz, RES BW 300 Hz, VIDEO BW 30 Hz, REF LEVEL 15 dBm to X124. Measure suppression of spuriae at the following frequencies (in MHz): 520.02, 544.02, 544.08, 640.005, 960.026666, 992.02, 1024.08 MHz
- \_ Suppression of spuriae >= 5 kHz before or after the carrier must be >= 70 dBc.

### 7.4.12.4 FM-DC Center Frequency Calibration

• Settings: RF 1000 MHz

FM EXT DC 10 MHz

- Connect power supply unit (± 1 V) to socket FM/ $\phi$ M EXT (the DC voltage set must be sufficiently free of noise and hum!).
- Connect modulation analyzer including frequency counter to X124.
- Set voltage at the power supply unit to 0 mV or short-circuit input socket FM/QM EXT.
- Perform FM-DC Nulling Internal using SPEC 55. The frequency
  error must be < 10 kHz. Vary the voltage from -1 to +1 V and
  measure residual FM, it must be < 1 kHz<sub>rms</sub> (weighting bandwidth
  300 Hz to 23 kHz). The output frequency varies from 990 to 1010
  MHz.

### 7.4.13 Tables and Interfaces

# 7.4.13.1 List of Diagnostic Test Points

A diagnostic multiplexer (74HC4051) is used to monitor the important control voltages and levels.

The potential of the module ground can be measured to compensate for offset voltages (diagnostic point 9).

	Diagnostic point	Test point and was .	Min. V	Max.	Division
9	R146	Reference, 10 KW	-50 m	50 m	1
10	D-+10REF	10 V, reference volt.	9.9	10.1	3
11	D-PLL-VTCXO	Control volt. VTCXO 10 MHz	0.3	4.7	3
12	D-PLL-640	Control volt. VCO 640 MHz	4	17	5
13	D-REF640	Output level LO, 640 MHz	0.1	0.6	1
		Level switched off	<0.05		
14	D-FSYN	Output level FSYN 65 to 1040 MHz	0.08	0.6	1
15	D-PLL-FSYN	Control voltage VCO's FSYN	1.75	21.5	5
6	D-FM-KAL	Accuracy at PD, 1 kHz	0	50 m	3

#### 7.4.13.2 Digital Interface

Module YSYN has a serial interface according to instrument standard. The data for the HC4094 latches and/or the serial D/A converter are accepted by means of Strobel. Strobel is used to effect transfer of the data at FRACSYN.

Polarity clock: active clock edge L-->H Polarity strobel: active clock edge L-->H Polarity strobe2: active clock edge H-->L

Data transmission using strobe1 (HF1STB): Deviation setting for FM and  $\phi M,\ RF\text{-}dependent$  deviation correction, selection of the RF output dividers, diagnosis, operating modes.

The data on strobel for the serial D/A converter cannot be accessed from outside and are thus not listed.

Data transmission using strobe2 (HF2STB):

Frequency information, information for wobble operation and the offset adder.

The data on strobe 2 are determined for component FRACSYN. They cannot be accessed from outside and are hence not listed.

Latch	Pin	Designation	Punction		and productive states the
<b>D</b> 585	11	T2	Output divider 4	0=0n	1=Off
	12	T1	Output divider 2	0=On	1=Off
	13	S6	Output division path 4,8	0=Off	1=0n
	14	<b>S</b> 5	Input division path 4	0=Off	1≠0n
	7	S4	Path iterative network	0=Off	1=0n
	6	S3	Output division path 2	0=Off	1=0n
	5	S2	Input division path 2,8	0=Off	1=0n
	4	S1	No division	0=Off	1=0n
D855	11	osz2	Oscillator 750 to 1040 MHz	0=Off	1=0n
	12	OSZ1	Oscillator 520 to 750 MHz	0=Off	1=0n
	13	EXTAC/DC	AC-DC switchover with FM-EXT	0=FMAC	1=FMDC
	14	FMINT	Modulation source INT	0=Off	1=0n
	7	FMEXT	Modulation source EXT	0=Off	1=0n
	6	DEVCOARSE2			MSB
	5	DEVCOARSE1	Deviation divider coarse		
	4	DEVCOARSE0	in steps of 12 dB		LSB
D670	11	PLL-GAIN2	Setting (0 to 7)		MSB
	12	PLL-GAIN1	Open-loop gain	,	
	13	PLL-GAINO	for RF-locked loop		LSB
	14	<b>г</b> м/ <b>Ф</b> м	Differentiator with PM	0=FM	1=Фм
	7	FMDIAOFF	Switching off the FM detector	0=0n	1=Off
	6	RESET-FRAC	Master reset FRACSYN		1=Active
	5	S_FM_DIA	Reset rectifier 1 kHz	0=Measure	1=Disch.
	4	s_DSIG	Sigma-Delta converter	0=Off	1≃0n

	Latch	Pin	Designation	Function	双金属单位:
0665 ,	11	AD15			MSB
	12	AD14			
	13	AD13			
	14	AD12			
	7	AD11		]	
	6	AD10			
	5	AD9	Setting deviation value		
	4	. AD8	at A/D input FRACSYN	ļ	
D660	11	AD7	Display in dual		
	12	AD6	complement		
	13	AD5			
	14	AD4			
	7	AD3			
	6	AD2			
	5	AD1			
	4	AD0			LSB
D110	11	MODOFF	Modulation ON/OFF	0=0n	1=Off(CW)
	12	S-REF640	640-MH2 output stage	0=Off	1=0n
	13	OPTREF	Switchover standard/ option reference	0=Standard	1=Option
	14	INT/EXT	Switchover internal/	0=Ext. 1=Int	
			external reference		or Option
	7	DIAGENA	Diagnosis On/Off	0=Off	1=0n
	6	DMUX2			MSB
	5	DMUX1	Diagnostic multiplexer 0 to 7		
	4	OXUMO			LSB

# 7.4.13.3 Operating Points and Levels of RF Amplifiers

A test of the RF paths with regard to quality is only possible using an RF probe at the spectrum analyzer. A short low-impedance ground connection is especially important. The series resistor of the RF probe should be at least 1  $k\Omega$ .

The values stated for the DC oprating points as well as for the RF level are to be understood as typical values.

Amplif	ier	Operating point	RF level, frequen	Remark
V205	Pin2	2.5 V		RF EXT AC
	Pin1	1.8 V	6 dBm, 10 MHz	
V210	Pin2	0.7 V	HCT, 10 MHz	RF EXT AC
	Pin3	2.1 V		
V215	Pin2	0.7 V		RF EXT AC
	Pin3	2.6 V	12 dBm, 10 MHz	10 MHz, 0 dBm at EXTREF
V216	Pin2			RF EXT AC
	Pin3	3.1 V	HCT, 10 MHz	10 MHz, 0 dBm at EXTREF
V305	Pin3	- 7.3 V		
	Pin2,4	- 7.7 V	8 dBm, 640 MHz	
и300	Pin1		- 3 dBm, 640 MHz	
	Pin3	4.6 V	7 dBm, 640 MHz	
V330	Pin1	2 V		RF 50 MHz
	Pin2	7.1 V	·14 dBm, 640 MHz	Terminate X125 using 50- $\Omega$ resistor
	Pin3	1.75 V		
	Pin4	0.55 V	5.5 dBm, 640 MHz	
V370	Pin2	0.6 V		
	Pin3	2.2 V	нст, 10 мнг	
V404	Pin3	-5.8 V		RF 520 MHz
	Pin2,4	-6.1 V	11 dBm, 520 MHz	
V434	Pin3	-5.8 V	7 dBm, 780 MHz	RF 780 MHz
	Pin2,4	-6.1 V	9.5 dBm, 780 MHz	
N490	Pin1		- 5 dBm, 1000 MHz	RF 1000 MHz
	Pin3	4.6 V	3 dBm, 1000 MHz	
N500	Pin1		- 2 dBm, 1000 MHz	RF 1000 MHz
	Pin3	4.7 V	2 dBm, 1000 MHz	
N510	Pin1		- 6 dBm, 500 MHz	RF 500 MHz
	Pin3	4.4 V	2 dBm, 500 MHz	Terminate X124 using $50-\Omega$ resistor
N520	Pin1		- 7 dBm, 250 MHz	RF 250 MHz
	Pin3	4.6 V	4 dBm, 250 MHz	Terminate X124 using $50-\Omega$ resistor
N560	Pin1		2 dBm, 1000 MHz	RF 1000 MHz
	Pin3	4.8 V	9 dBm, 1000 MHz	Terminate X124 using 50- $\Omega$ resistor
N600	Pin1		- 7 đBm, 1000 MHz	RF 1000 MHz
	Pin3	4.6 V	2 dBm, 1000 MHz	
N610	Pin1		- 7.5 dBm, 1000 M	Ez RF 1000 MHz
	Pin3	4.7 V	0 dBm, 1000 MHz	
<b>V</b> 600	Pin2	0.75 V		RF 1000 MHz
	Pin3	0.95 V	10 dBm, 62.5 MHz	

#### 7.5

# Disassembly and Assembly

In order to be able to remove the YSYN module, only the bottom of the instrument needs to be opened. First the computer module is removed. Open the two lateral screws and withdraw the cable for the IEC-bus leading to the rear panel. The processor can now be withdrawn, the cables for keyboard/display as well as to the motherboard remain plugged in.

After undoing the two lateral screws of the synthesis module, the three or four (if optional quartz existing) RF connections at the module can be withdrawn or unscrewed. The YSYN module is now taken out of its slot sideways to the rear.

The synthesis module can now be connected with the motherboard again via the ribbon cable in the service kit. Sockets X127 and X128 are also connected to the corresponding connections EXTREF and, if existing, with the optional oscillator via the coaxial cables in the service kit.

The screening covers are screwed in the usual manner. In the case of operation with the screening cover opened, please ensure that the resonator chambers E and F are closed using suitable test covers on both sides.

#### 7.6 External Interfaces

The data for the current consumption of the respective supply voltage refers to the state of the module after a PRESET.

Pin	Name	Input/Output	Origin/Dest	Value range	Signal description
X1A.4	EXT1	Input	Front unit	1V <sub>s</sub>	Modulation voltage
X1A.6	INT1	Input	Processor X3.32	1V <sub>s</sub>	Modulation voltage
X1A.8	FMKOMPLO	Output	Processor X3.23	HCMOS level	Level monitoring EXT
X1A.9	FMKOMPHI	Output	Processor X3.24	HCMOS level	Level monitoring EXT
X1A.10	OPTUNE	Output	Power supply unit	X21,24	0 to 10V Tuning voltage for
					optional reference (SM-B1)
X1A.12	SERCLK	Input	Processor X3.2	HCMOS level	Clock for data transmission
X1A.14	SERDAT	Input	Processor X3.4	HCMOS level	Serial data
X1A.15	HF1STB	Input	Processor X3.14	HCMOS level	Strobel
X1A.16	HF2STB	Input	Processor X3.15	HCMOS level	Strobe2
X1A.17	HFINT	Output	Processor X3.20	TTL level	Interrupt PLLs
X1A.19	DIAG-5V	Output	Processor X3.6	0 to 5V	Diagnosis
X1A.22	VA24-P	Input	Power X21.22	23.0 to25.0 V	Supply voltage analog
			supply	12 ± 5 mA	
X1A.24	VA15-P	Input	Power X21.13	14.4 to 15.6 V	Supply voltage analog
			supply	110 ± 25 mA	
X1A.25	VA15~P	Input	Power X21.13	14.4 to 15.6 V	Supply voltage analog
			supply	110 ± 25 mA	
X1A.26	VA7.5-P	Input	Power X21.8	7.2 to 7.8 V	Supply voltage analog
			supply	650 ± 100 mA	
X1A.28	VA-SP	Input	Power X21.5	4.9 to 5,3 V	Supply voltage digital
			supply	35 ± 10 mA	
X1.A30	VA15-N	Input	Power X21.19	-15.6 to 14.4 V	Supply voltage analog
			supply	-195 ± 35 mA	
X128	OPT10	Input	Reference osc.	7.5 ± 1.5 dBm	10 MHz ± 5 ppm
X127	EXTREF	Bíðir.	Rear panel	5/10 MHz ± 3ppm	Input reference
		·		-13 to 13 dBm	
				10MHz, 6 to 10 dBm	Output reference
X124	FSYN	Output	Output section	7 to 14 dBm	Synthesis freq 65 to 1040 MHz
X125	REF640	Output	Output section	8 to 12 dBm	Reference 640 MHz



Schaltteillisten
numerisch geordnet
Part lists
in numerical order
Listes des pièces détachées
par numéros de référence

Kennz. Comp. No.		Benen Design			Ţ	Sachnu Stock		Hersteller Manüfacturer	Beze Desi	ichnung gnation		helten in Itained in
٠	IDENTI VARO2=0 MODO2=1 VAR O4 MOD O4 VAR 43	GRUNDAU BASIC M = SMY4 = SMY4	N OF SFUE ODEL 1/44 1/44 IS-	MODELS HRUNG /45 /45 98 TEST								
B360	8L PM82 IC PRES		129M	AX PRESC		2024.	397.00	SIEMENS	PM823	112T		
C1		JF+-20%			CE	0008.7	927.00	PANASONIC	ECA-1	AFG221I		
C2	CE 47UF	DLYTIC (	ΟV	RM2,5	CE	0008.7	479.00	PANASONIC	ECA-1	HFG470I	,	
сз_	CE 1001	JE+-20%	25V	RM2.5	CE	0008.7	891.00	PANASONIC	ECA-1	EFG101I		
5 C20	CC 100N		50V .	X7R 1206	cc	0007.5	237.00	PHILIPS_CO	2238	581 15649		
C21	CE 1UF	-	25V	EIA3528	CE	0007.7	217.00	SPRAGUE	293D	105 X9 025 82T		
C25	CC 330F	JM SMD-( PF+-1%50	DV N	PO 1206	cc	0099.8	8 <b>73.0</b> 0	PHILIPS_CO	2238	863 18331		
C26	CE 10UF	+-20%35	5V	7343		1078.3	291.00	SIEMENS	84519	7-A6106-M40*		,
C27	CE 10UF	TALUM (	5V	7343		1078.3	291.00	SIEMENS	B4519	7-A6106-M40*		
СЗО	CC 100N		50V X	7R 1206	cc	0007.5	237.00	PHILIPS_CO	2238	581 15649		
36 C100		lF+-10%5	OV >	7R 1206	СС	0007.5	237.00	PHILIPS_CO	2238	581 15649		
C110	CC 100N		( VO	(7R 1206	cc	0007.5	237.00	PHILIPS_CO	2238	581 15649		
C120		F+-10%5	( VO	(7R 1206	cc	0007.5	237.00	PHILIPS_CO	2238 9	581 15649		
C200	CERAMIC CC 100N			TTOR 7R 1206				PHILIPS_CO				
C202	CERAMIC CC 100N			CITOR C7R 1206	CC	0007.5	237.00	PHILIPS_CO	2238	581 15649	1	
C204	CERAMIC CC 10NF									-6X7R103K 50PT	1	
C205	CERAMIC CC 1NF+				СС	0007.7	398.00	PHILIPS_CO				
C206	SMD CER CC 100N			TOR 7R 1206			- 1	PHILIPS_CO				
C208	CERAMIC CC 10NF					0099.8		_		-6X7R103K 50PT		
C210	CERAMIC	CHIP C	APAC					PHILIPS_CO				
C214	CERAMIC CC 56PF	CHIP C	APAC	ITOR	1	0099.8	Ì			-6COG 560F 50PT		
C217	CERAMIC CC 470P	CHIP C	APAC	ITOR				PHILIPS_CO				
	CERAMIC NUR VAR	CHIP C	APAC	ITOR			,,,,,,		2200 0	10471		
C217	CC 470PI CERAMIC	F+-1%50	V NP	0 1206	СС	0099.8	515.00	PHILIPS_CO	2238 8	363 18471		
	NUR VAR	/ONLY M	00:									
C218		F+-1% 5	OV N	PO 1206	СС	0007.73	375.00	PHILIPS_CO	2222 8	863 18681		
C218	NUR VAR,	ONLY M	00:	02 43	CC	0007 73	875 00	PHILIPS_CO	0000 C	)E2 10604		
02.10	CERAMIC NUR VAR	CHIP C	APAC	ITOR		0007.70	,,3.00	FINELES_CO	2222 C	18681		
C219		ESTUECK	T/NO	T FITTED	CC	0000 0	515 00	DUT) TDC CO	0000 0	10471		
0215	CERAMIC NUR VAR	CHIP C	APAC	ITOR		0099.6	15.00	PHILIPS_CO	2238 8	18471		
C219	CC 470PF CERAMIC NUR VAR	F+-1%50 CHIP C	V NP APAC	0 1206 ITOR	СС	0099.85	515.00	PHILIPS_CO	2238 8	863 18471		
C220		ESTUECK'	T/NO	T FITTED	СС	0007.52	37.00	PHILIPS_CO	2238 F	581 15649		
C221	CERAMIC CC 100NF CERAMIC	CHIP C. F+-10%50	APAC	ITOR 7R 1206			ŀ	PHILIPS_CO				
	JEI WILLY	OHE O		- 1 010								
MENP5	413	ЗРИА	Äi	Datum Date			Schaltteilli Parts list			Sachnummer Stock No.		Blatt-Nr. Page
ROHDE	&SCHV	VARZ	31	16.09.97	Ε	E SYNTI	IESIZER		1	062.6409.0	1 SA	1+

Kennz. Comp. No.	Benen Design			T	Sachnummer Stock No.	Hersteller Manufacturer		ezeichnung lesignation		eiten in eined in
C222	CC 100PF+-1%5	ΟV	NPO 1206	cc	0099.8415.00			M42-6COG 101F 50PT		oniou ili
C224	CERAMIC CHIP CC 100NF+-10%	CAP.	ACITOR X7R 1206		0007.5237.00					
C225	CERAMIC CHIP ( CC 220PF+-1%50			cc	0099.8850.00	PHILIPS CO	223	88 863 18221		•
Ċ227	CERAMIC CHIP ( CC 1NF+-1% 50)	CAP	ACITOR	i i	0007.7398.00					
·	SMO CERAMIC CA	APA	CITOR		3007.7086.00	71112173_00	222	2 000 *0102		
C228	CC 100PF+-1%50	OV I		cc	0099.8415.00	MURATA	GRN	142-6COG 101F 50PT		
C230	CERAMIC CHIP ( CC 100PF+-1%50			cc	0099.8415.00	MURATA		142-6COG 101F 50PT		
C232	CERAMIC CHIP C	AP	ACITOR	1						
0202	SMO CERAMIC CA	APA(	CITOR	1	0007.7398.00	TENTETES_CO	222	2 003 *8102		
C232	NUR VAR/ONLY N RG O-OHM WIOER	RST	NO-CHIP	RG	0007.5108.00	DRALORIC	CR	1206		
	RESISTOR CHIP NUR VAR/ONLY N									
C234	CC 330PF+-1%50 CERAMIC CHIP C	V I	NPO 1206	CC	0099.8873.00	PHILIPS_CO	223	8 863 18331		
C235	CC 330PF+-1%50	V N	NPO 1206	cc	0099.8873.00	PHILIPS_CO	223	8 863 18331		
C236	CERAMIC CHIP C	VO	NPO 1206	СС	0099.8750.00	MURATA	GRM	42-6COG 150F 50PT		
C237	CERAMIC CHIP C CC 1,ONF+-10%5			cc	0009.4938.00	MURATA	GRM	39X7R***K50C500PT		
	SMO-CERAMIC-CA									
C240	CC 1NF+-1% 50V SMD CERAMIC CA	NE	0 1206	СС	0007.7398.00	PHILIPS_CO	222	2 863 *8102		
C245	CC 220NF+-10%5	OV	X7R 1210	cc	0520.6850.00	AVX	121	O 5C 224KA 11A		
C250	CERAMIC CAPACI CC 22PF+-1%50V	NF	0 1206	СС	0099.8396.00	MURATA	GRM	42-6COG 22OF 50PT		
C252	CERAMIC CHIP C CC 1,5NF+-1% 5				0007.7417.00					
C254	CERAMIC CHIP C	APA	CITOR	1	0007.7417.00					
C255	CERAMIC CHIP C CC 100NF+-10%5	APA	CITOR	į						
	CERAMIC CHIP C	APA	CITOR		0007.5237.00			1		
C256	CK 470NF+-5% 2 SMO-FILM-CAPAC	ITO	R		0010.6853.00			- 4		
C258	CC 47NF+-10%50 CERAMIC CHIP C	APA	CITOR		0007.5195.00					
C280	CC 100NF+-10%5	OV	X7R 1206	CC	0007.5237.00	PHILIPS_CO	223	8 581 15649		
C261	CE 1UF +-10% 1	OV	1206	CE	0007.7252.00	SPRAGUE	2930	0 105 X9 010 02T		
C286	CC 100PF+-1%50 CERAMIC CHIP C	V N	PO 1206	СС	0099.8415.00	MURATA	GRM	42-6COG 101F 50PT		
C300	CC 100PF+-1%50	V N	PO 1206	СС	0099.8415.00	MURATA	GRM4	12-6COG 101F 50PT		
C302	CERAMIC CHIP C. CC 3,3PF+-0,25	50	VNP01206	СС	0007.8194.00	MURATA	GRM4	12-6COG 3R3 C5OPT		
C304	CERAMIC CHIP C. CC 1,8PF0,25PF			СС	0099.6806.00					
C306	CHIP CAPACITOR CC 6,8PF0,5PF		NPO 0805		0093.2167.00					
C308	CAPACITOR CC 7,8PFO,25PF				0099.8296.00					
C310	CERAMIC CHIP C.	APA	CITOR			_				
	CERAMIC CHIP C	APA	CITOR		0099.8415.00			12-6COG 101F 50PT		
C312	CE 2,2UF +-10% TANTALUM SMD-C	APA	CITOR		0007.7223.00			I C225 K O25 AS		
C314	CC 100NF+-10%50 CERAMIC CHIP CA			CC	0007.5237.00	PHILIPS_CO	2238	3 581 15649		
C316	CC 100PF+-1%50V CERAMIC CHIP CA		1	СС	0099.8415.00	MURATA	GRM4	12-6COG 101F 50PT		
C320	CC 100NF+-10%50 CERAMIC CHIP CA	OV :	X7R 1206	CC	0007.5237.00	PHILIPS_CO	2238	3 581 15649		
C324	CC 100PF+-1%50	V N	PO 1206	СС	0099.8415.00	MURATA	GRM4	12-6COG 101F 50PT		
C331	CC 100PF+-1%50	V N	PO 1206	СС	0099.8415.00	MURATA	GRM4	12-6COG 101F 50PT		
C335	CERAMIC CHIP CA	V N	PO 1206	СС	0099.8415.00	MURATA	GRM4	12-6COG 101F 50PT		
C336	CERAMIC CHIP CA		X7R 0805	СС	0099.8367.00	MURATA	GRM4	10 X7R221K50PT		
	CERAMIC CHIP CA	APA					***			
MENDE	440 0001	I	Datum		Schaltteilli	ista für	- 1	Sachnummar		Blatt-Nr.
MENP5	413 3PUA	Äl	Date		Parts ils			Stock No.		Page
<b>POUNE</b>	&SCHWARZ	31	16.09.97	E	E SYNTHESIZER			1062.6409.01	SA	2+
.vonde	COUNTANA			s	YNTHESIZER					

C338 C342	CC 100PF+-1	/EOV	NIDO 1000						iteinad in
C342	I CEDARATO OUT			Icc	0099	8415.0	OMURATA	GRM42-6COG 101F 50PT	
	CERAMIC CHIL	450V	NPO 1206	cc	0099	.8415.0	DMURATA	GRM42-6C0G 101F 50PT	
C344	CERAMIC CHIR CC 2,2PF+-O			1			OMURATA		
	CERAMIC CHIE	CAP	ACITOR	ļ				GRM42-6CDG 2R2 C5OPT	
C345	CC 100PF+-10 CAPACITOR	0%	NPO 0805	cc	0082	2.2948.0	MURATA	GRM40 COG 101 K50PT	
C346	CC 1NF+-1% 5			cc	0007	7.7398.00	PHILIPS_CO	2222 863 *8102	
C347	SMD CERAMIC CC 1PF+-0,25			cc	0099	.8667.00	PHILIPS CO	2238 863 15108	
C348	CERAMIC CHIF	CAP	ACITOR	1				1	
	SMD CERAMIC	CAPA	CITOR	1				2222 863 *8102	
C349	CC 100PF+-1% CERAMIC CHIP			cc	0099	.8415.00	MURATA	GRM42-6COG 101F 50PT	
C360	CC 1NF+-1% 5	OV N	PO 1206	cc	0007	.7398.00	PHILIPS_CC	2222 863 *8102	
C361	SMO CERAMIC CC 100NF+-10			СС	0007	.5237.00	PHILIPS_CO	2238 581 15649	
C370	CERAMIC CHIP CC 1NF+-1% 5			ł				2222 863 *8102	
Ì	SMD CERAMIC	CAPA	CITOR	Į.			i		
C373	CC 100NF+-10 CERAMIC CHIP			CC	0007	.5237.00	PHILIPS_CO	2238 581 15649	
C400	CC 10PF+-0,2	5 50	VNPO 1206	cc	0099	.8480.00	MURATA	GRM42-6COG 100 C50PT	
C402	CERAMIC CHIP CC 47PF+-5%		OOV PELL	СС	0467	.9761.00	TEKELEC	501 CHB 470 JWL	
C404	CAPACITOR CC 10PF+-0.2	5 50	/NPO 1206	i		.8480.00	1		
	CERAMIC CHIP	CAP	ACITOR	J				GRM42-6COG 100 C50PT	
C406	CC 4,1PFO,25 CAPACITOR		NPO 0805				VITRAMON	VJ0805AFA	
C408	CC 6,8PF0,5P	F	NPO 0805	CC	0093	.2167.00	PHILIPS_CO	2222 861 15688	
C410	CC 6PF+-0,25		NPO 0805	СС	0099	8280.00	MURATA	GRM40 COG 6RO C50PT	
C412	CERAMIC CHIP CC 12PF+-5%10			cc	0022	.3948.00	PHILIPS CO	2222 861 15129	
C414	CERAMIC CAPA	CITOR	}					1	
	CC 100PF+-1%	CAPA	CITOR			8415.00		GRM42+6COG 101F 50PT	
C416	CC 100PF+-1%! CERAMIC CHIP			CC	0099.	.8415.00	MURATA	GRM42-6COG 101F 50PT	
C4 18	CC 10PF+-0, 2	5 50\	/NPO 1206	СС	0099.	8480.00	MURATA	GRM42-6C0G 100 C50PT	
C4 25	CERAMIC CHIP CC 100PF+-1%			СС	0099.	8415.00	MURATA	GRM42-6C0G 101F 50PT	
2430	CERAMIC CHIP CC 10PF+-0.25	CAPA	CITOR			8480.00		4	
	CERAMIC CHIP	CAPA	CITOR					GRM42-6CDG 100 C50PT	
C432	CC 8,2+-0,1PF			CC	o552.	1648.00	TEKELEC	501 CHB 8R2 BW(V)LE	
2432	NUR VAR/ONLY CC 4,7PF+-0,1	MOO:	O2 OV PEU	CC	VEDV	0540 00	ATC	ATO1000 ADD DUTCH	
	CAPACITOR				voov.	9540.00	IAIC	ATC1008 4R7 BW500XR	
2434	NUR VAR/ONLY CC 10PF+-0,25		43 NPO 1206	CC -	0099	8480.00	MURATA	GRM42-6CDG 100 C50PT	
436	CERAMIC CHIP	CAPA	CITOR						
	CC 2,9PFO,25F						terior de	VJ0805AXA	
:438	CC 4,3PFO,25P CAPACITOR	F	NPO 0805	CC (	0093.	5643.00	MURATA	GRM40C0G4R3C50PT	
440	CC 3,3PF0,25P	F	NPO 0805	CC (	0099.	8273.00	PHILIPS_CO	2222 861 12338	
442	CERAMIC CHIP CC 7,8PFO,25P	F	CTTUR NPO 0805					2222 861 14788	
	CERAMIC CHIP CC 100PF+-1%5	CAPA	CITOR			8415.00			
	CERAMIC CHIP	CAPA	CITOR					GRM42-6CDG 101F 50PT	
	CC 100PF+-1%5 CERAMIC CHIP			CC (	0099.	8415.00	MURATA	GRM42-6CDG 101F 50PT	
448	CC 10PF+-0,25 CERAMIC CHIP	50V	NPO 1206	cc (	0099.	8480.00	MURATA	GRM42-6COG 100 C50PT	
455	CC 100PF+-1%5	OV N	PO 1206	cc (	0099.	8415.00	MURATA	GRM42-6COG 101F 50PT	
	CERAMIC CHIP CC 100NF+-10%		CITOR					2238 581 15649	
	CERAMIC CHIP	CAPA	CITOR						
	CE 10UF+-20%3 SMD-TANTALUM	CAPA						B45197-A6106-M40*	
	CC 100PF+-1%5 CERAMIC CHIP		PO 1206 CITOR	CC (	0099.	8415.00	MURATA	GRM42-6COG 101F 50PT	
MENP5	413 3PUA	Aī	Datum Date			Schaltteilli Parts IIs		Sachnummer Stock No.	Blett-N Page

	Kennz. Comp. No.	Banenr Designa				Sachnummer Stock No.	Hersteiler Manufacturer		ezeichnung esignation		elten in alned in
	C493	CC 100PF+-1%50	V N		СС	0099.8415.00			42-6CDG 101F 50PT	33.11	
	C494	CERAMIC CHIP C CC 100NF+-10%5			СС	0007.5237.00	PHILIPS_CO	223	8 581 15649		
	C500	CERAMIC CHIP C CC 22PF+-1%50V				0099.8396.00	_		42-6COG 220F 50PT		
	C501	CERAMIC CHIP C CC 100PF+-1%50	APA	CITOR		0099.8415.00			42-6COG 101F 50PT		
	C502	CERAMIC CHIP C	APA	CITOR	1						
		CC 100NF+-10%5 CERAMIC CHIP C	APA	CITOR	1	0007.5237.00	1 -				
İ	C505 507	CC 1NF+-1% 50V SMD CERAMIC CA			CC	0007.7398.00	PHILIPS_CO	222	2 863 *8102		
	C510	CC 100PF+-1%50 CERAMIC CHIP C			cc	0099.8415.00	MURATA	GRM	42-6C0G 101F 50PT		
	C511	CC 1NF+-1% 50V SMD CERAMIC CA			cc	0007.7398.00	PHILIPS_CO	222	2 863 *8102		
	C515	CC 100NF+-10%5	OV	X7R 1206	СС	0007.5237.00	PHILIPS_CO	223	B 581 15649		
	C516	CERAMIC CHIP C	V N	PO 1206	СС	0099.8415.00	MURATA	GRM	42-6CDG 101F 50PT		
	C517	CERAMIC CHIP C	V N	PO 1206	СС	0099.8415.00	MURATA	GRM	42-6CDG 101F 50PT		
	C520	CERAMIC CHIP C			СС	0099.8415.00	MURATA	GRM	42-6COG 101F 50PT		- 1
ı	C521	CERAMIC CHIP C CC 1NF+-1% 50V	APA	CITOR		0007.7398.00					
	524	SMD CERAMIC CA	PAC	ITOR					0.		
	C525	CC 100NF+-10%5	APA	CITOR		0007.5237.00					
Į	C526	CC 100PF+-1%50			CC	0099.8415.00	MURATA	GRM4	12-6COG 101F 50PT		- I
	C527	CC 100PF+-1%50'CERAMIC CHIP C			CC	0099.8415.00	MURATA	GRM4	12-6COG 101F 50PT		
	C530	CC 1NF+-1% 50V SMD CERAMIC CA	NP	0 1206	СС	0007.7398.00	PHILIPS_CO	2222	2 863 *8102		
	C532	CC 100PF+-1%50	/ N	PO 1206	СС	0099.8415.00	MURATA	GRM4	12-6COG 101F 50PT		
ı	C550	CERAMIC CHIP CA	/ N	PD 1206	СС	0099.8873.00	PHILIPS_CO	2238	8 863 18331		
1	C551	CERAMIC CHIP CA			СС	0099.8873.00	PHILIPS_CO	2238	3 863 18331		
	C552	CERAMIC CHIP CA				0007.5237.00			1)		
١	C553	CERAMIC CHIP CA	\PA(	CITOR		0007.5237.00					
ı	C555	CERAMIC CHIP CA	PAC	CITOR					4.		
		CC 1PF+-D,25 50 CERAMIC CHIP CA	\PA(	CITOR		0099.8667.00	_				
	C558	CC 1NF+~1% 50V SMD CERAMIC CAP	AC:	ITOR		0007.7398.00					
	C557	CC 100PF+~1%50\ CERAMIC CHIP CA	PA	CITOR		0099.8415.00			12-6C0G 101F 50PT		
	C570	CC 1NF+-1% 50V SMD CERAMIC CAR			СС	0007.7398.00	PHILIPS_CO	2222	863 *8102		
	C571	CC 1NF+-1% 50V SMD CERAMIC CAP	NPO	1206	СС	0007.7398.00	PHILIPS_CO	2222	863 *8102		
	C580	CC 100NF+-10%50	( VC	K7R 1206	СС	0007.5237.00	PHILIPS_CO	2238	581 15649		1
	C600	CC 10PF+-0,25 5	OVI	NPO 1206	СС	0099.8480.00	MURATA	GRM4	2-6C0G 100 C50PT		
	C601	CERAMIC CHIP CA	OVI	NPO 1206	СС	0099.8480.00	MURATA	GRM4	2-6COG 100 C5OPT		
	C602	CERAMIC CHIP CA			СС	0007.5237.00	PHILIPS_CO	2238	581 15649		1
	C604	CERAMIC CHIP CA				0007.8213.00	_		2-6COG 4R7C 50PT		
	C605	CERAMIC CHIP CA	PAC	CITOR		0099.8480.00			2-6C0G 100 C50PT		
	C610	CERAMIC CHIP CA	PAC	CITOR		İ					
		CERAMIC CHIP CA	PAC	CITOR		0007.5237.00			•		
	C615	CC 10PF+-0,25 E	PAC	CITOR		0099.8480.00			2-6COG 100 C50PT		
	C616	CC 100PF+-1%50V CERAMIC CHIP CA			CC	0099.8415.00	MURATA	GRM4	2-6C0G 101F 50PT		
	C620	CC 100PF+-1%50V CERAMIC CHIP CA	' NF	O 1206	СС	0099.8415.00	MURATA	GRM4	2-6C0G 101F 50PT		
	C621	CC 100NF+-10%50 CERAMIC CHIP CA	V V	(7R 1206	СС	0007.5237.00	PHILIPS_CO	2238	581 15649		
	C625	CC 100PF+-1%50\	/ NF	0 1206	СС	0099.8415.00	MURATA	GRM4	2-6C0G 101F 50PT		1
		CERAMIC CHIP CA	YA(	ST TOR							
ļ								1			<b>5</b> 1 51 51
-	MENP5	413 3PUA	Äi	Datum Data		Schaltteiilis Parts list			Sachnummer Stock No.		Slatt-Nr. Page
	<b>\$</b>		31	16.09.97	E	E SYNTHESIZER			1062.6409.01	SA	4+
	ROHDE	&SCHWARZ				YNTHESIZER					
1				f	_	- · · <del>-</del>		- 1			

Kennz. Comp. No.		ກກປຸກB ກation		T	Sachaummar Stock No.	Hersteller Manufacturer	Bezeichnung Designation		naiten in tained in
C630	CC 100PF+-1%5	OV 1	NPO 1206	cc	0099.8415.00		GRM42-6COG 101F 50PT	}	control III
C631	CERAMIC CHIP CC 100NF+-107	50V	X7R 1206	СС	0007.5237.00	PHILIPS_CO	2238 581 15649		
C633	CERAMIC CHIP	VO	IPO 1206	СС	0099.8415.00	MURATA	GRM42-6COG 101F 50PT		
C640	CERAMIC CHIP	50V	X7R 1206	СС	0007.5237.00	PHILIPS_CO	2238 581 15649		
C645	CERAMIC CHIP	50V	X7R 1206	СС	0007.5237.00	PHILIPS_CO	2238 581 15649		
C650	CERAMIC CHIP CE 22UF +-10%	10\	7343	CE	0007.7298.00	KEMET	T491 O 226 K O10 AS		
C655	TANTALUM SMO- CC 100NF+-10%	507	X7R 1206	cc	0007.5237.00	PHILIPS_CO	2238 581 15649		
C661	CERAMIC CHIP			1			2238 863 18221		
C662	CERAMIC CHIP				0099.8415.00	1	GRM42~6COG 101F 50PT		
C690	CERAMIC CHIP			СС	0520.6850.00	AVX	1210 5C 224KA 11A		
693 C698	CERAMIC CAPAC			CE	0007.7298.00	KEMET	T491 O 226 K 010 AS		
C701	TANTALUM SMD-			СС	0099.8521.00	MURATA	GRM42-6X7R103K 50PT		
C702	CERAMIC CHIP			1	0099.8521.00		GRM42-6X7R103K 50PT		
C705	CERAMIC CHIP			1			2238 581 15649		:
C710	CERAMIC CHIP CC 22PF+-1%50			i	0099.8396.00		GRM42-6COG 220F 50PT		
C712	CERAMIC CHIP	CAPA	CITOR		0007.7275.00		293D 475 X9 010 82T		
C7 19	TANTALUM SMO-	CAPA	CITOR	1	0007.7217.00		2930 105 X9 025 B2T		
C720	TANTALUM SMO-	CAPA	CITOR				2222 863 *8102		
C721	SMO CERAMIC C CK 470NF+-5%	APAC	ITOR				2222 394 29474		
C722	SMD-FILM-CAPA	CITO	R	CC	0099.8396.00		GRM42-6COG 220F 50PT		
C731	CERAMIC CHIP CK 220NF+-5%	CAPA	CITOR				2222 393 29224		
C750	SMD-FILM-CAPAC CE 47UF+-20%50	CITO			0008.7479.00				
C753	ELECTROLYTIC ( CC 100PF+-1%50	CAPA	CITOR		0099.8415.00				
C760	CERAMIC CHIP ( CC 8,2NF+-10%	CAPA	CITOR				GRM42-6COG 101F 50PT 2238 581 16626		
C764	CERAMIC CHIP I	ONO	ENSATOR		0007.3257.00				
C765	CAPACITOR CK 1.5UF+-5%			l	0008.1141.00		MKT1826-515/054 MKT1826-515/054		
C779	CAPACITOR CK 100NF+-5%		,	O.			2222 393 29104		
C780	SMO-FILM CC 1,8NF+-1% 5			CC					
C781	CERAMIC CHIP C	APA	CITOR		•		2222 863 18182		
C782	CERAMIC CHIP (	APA	CITOR		ì		2222 863 18182		
C782	CE 4,7UF +-107 TANTALUM SMO-0	APA	CITOR		0007.7230.00		293D475X903502T		
C784	CC 100PF+-1%50 CERAMIC CHIP C CC 10NF+-10%50	APAC	CITOR		0099.8415.00		GRM42-6COG 101F 50PT		
C786	CERAMIC CHIP C	APAC	CITOR		0099.8521.00		GRM42-6X7R103K 50PT		
C787	CERAMIC CHIP C	APAC	CITOR		1		2238 581 15649		
1	CC 100NF+-10%5 CERAMIC CHIP C	APA(	CITOR		j		2238 581 15649		
C789 791	CE 47UF +-10% TANTALUM SMD-0	APAC	CITOR		0007.7300.00		2930 X9 010 02T		
C792	CE 10UF+-20%35 SMO-TANTALUM (	APA(			1078.3291.00		845197-A6106-M40*		
C793	CE 10UF+-20%35	APA(			1078.3291.00		845197-A6106-M40*		
C800	CC 5,6PF+-0,25 CERAMIC CHIP (	APAC	CITOR		0007.8220.00		GRM42-6COG 5R6 C5OPT		
C830	CK 33ONF+-5% 2 SMO-FILM-CAPAC				0010.6660.00	PHILIPS_CO	2222 394 29334		
MENP5	413 3PUA	äì	Datum		Schaltte]iii		Sachnummer		Blatt-Nr.
			Date		Parts lis	1 101	Stock No.		Page
ROHD	E&SCHWARZ	31	16.09.97	E	E SYNTHESIZER		1062.6409.01	SA	5+

Kennz. Comp. No.	Bener Design				Sachnummer Stock No.	Hersteller Menufecturer	Bezeichnun: Designetion			alten in ained in
C840	CC 4,7PF+-0,2			CC	0007.8213.00	MURATA		G 4R7C 5OPT		
C841	CERAMIC CHIP CC 100NF+-10% CERAMIC CHIP	50V	X7R 1206	cc	0007.5237.00	PHILIPS_CO	2238 581	15649		
C842	CC 15PF+-1%	50V	NPO 1206	cc	0099.8750.00	MURATA	GRM42-6CC	G 150F 50PT		
C843	CERAMIC CHIP CC 3,3PF+-0,2	5 50	OVNPO1206	cc	0007.8194.00	MURATA	GRM42-6C0	G 3R3 C5OPT		
C844	CERAMIC CHIP CC 3,3PF+-0,2	5 50	OVNP01206	cc	0007.8194.00	MURATA	GRM42-6CC	G 3R3 C5OPT		
C845	CERAMIC CHIP CC 5,6PF+-0,2	5 50	OVNP01206	СС	0007.8220.00	MURATA	GRM42-6C0	G 5R6 C5OPT		
	NICHT BESTUEC		ACITOR							
C846	CC 100PF+-1%50			cc	0099.8415.00	MURATA	GRM42-6C0	G 101F 50PT		
C850	CC 22PF+-1%50 CERAMIC CHIP	V NE	0 1206	cc	0099.8396.00	MURATA	GRM42-6C0	G 220F 50PT		
C860	CE 220UF+-20% ELECTROLYTIC	107	RM2,5	CE	0008.7927.00	PANASONIC	ECA-1AFG2	211		
C861	CE 220UF+-20% ELECTROLYTIC	107	RM2,5	CE	0008.7927.00	PANASONIC	ECA-1AFG2	211		
C862	CC 1,2NF+-1% E	50V	NPO 1206	cc	0007.7400.00	PHILIPS_CO	2222 863	18122		
C865	CE 2,2UF +-107	4 25	V 6032	CE	0007.7223.00	KEMET	T491 C225	K 025 AS		
C866	CE 2,2UF +-107	4 25	V 6032	CE	0007.7223.00	KEMET	T491 C225	K 025 AS		
C870	CC 1UF+-10% 50 CERAMIC CAPACI	ov x	7R 2220	СС	0520.6873.00	AVX	2220 5C 1	05 KATOOF		
C871	CC 1UF+-10% 50 CERAMIC CAPACI	ov x	7R 2220	cc	0520.6873.00	AVX	2220 5C 1	D5 KATOOF		
C884	CE 47UF +-10%	100	7343	CE	0007.7300.00	SPRAGUE	293D X9 O	10 02T		
C885	CE 47UF +-10%	10V	7343	CE	0007.7300.00	SPRAGUE	293D X9 O	10 02T		
C890 893	CE 100UF+-20%2	25V	RM2.5	CE	0008.7891.00	PANASONIC	ECA-1EFG10	011		
C911	CC 150PF+-1%50 CERAMIC CHIP (	N VC	PO 1206	СС	0099.8509.00	PHILIPS_CO	2238 863	18151		
1 4	NICHT BESTUECK		CITOR							
C913	CC 3,9NF+-1% 5				0010.2987.00	MURATA	GRM42-6C00	G392F50PT		
C940	CC 470PF+-1%50 CERAMIC CHIP C	V N	PO 1206 CITOR	cc	0099.8515.00	PHILIPS_CO	2238 863	18471		
C941	NUR VAR/ONLY M CC 820PF+-1% 5	OV	NPO 1206	СС	0007.7381.00	PHILIPS_CO	2222 863	18821		
C942	CERAMIC CHIP C	OV	NPO 1206	СС	0007.7381.00	PHILIPS_CO	2222 863	18821		_
C942	CERAMIC CHIP C	50	VNP01206	СС	0007.8220.00	MURATA	GRM42-6C00	S 5R6 C5OPT		F
C949	CERAMIC CHIP C CC 82PF+-1%50V CERAMIC CHIP C	NP	0 1206	СС	0099.8821.00	MURATA	GRM42-6CD0	820F 50PT		
C950	CC 1,2NF+-1% 5 CERAMIC CHIP C	OV	NPO 1206	СС	0007.7400.00	PHILIPS_CO	2222 863 1	8122		
C951	CC 270PF+-1%50 CERAMIC CHIP C	V N	PO 1206	СС	0099.8867.00	PHILIPS_CO	2222 863 1	8271		
C953	CC 820PF+-1% 5 CERAMIC CHIP C	OV	NPO 1206	СС	0007.7381.00	PHILIPS_CO	2222 863 1	8821		
C954	CE 47UF +-10% TANTALUM SMD-C	107	7343	CE	0007.7300.00	SPRAGUE	293D X9 01	O D2T		
C959	CC 68PF+-1%50V CERAMIC CHIP C	NP	0 1206	СС	0099.8815.00	MURATA	GRM42-6C00	680F 50PT		
C960	CC 8,2PF+-0,25 CERAMIC CHIP C	50	VNP01206	СС	0007.8242.00	MURATA	GRM42-6C00	8R2 C50PT		
	NICHT BESTUECK									
C962	CC 100NF+-10%5 CERAMIC CHIP C			СС	0007.5237.00	PHILIPS_CO	2238 581 1	5649		
C980	CE 47UF +-10% TANTALUM SMD-C	107	7343	CE	0007.7300.00	SPRAGUE	293D X9 01	O D2T		
C989	CC 100NF+-10%5 CERAMIC CHIP C	ov :	X7R 1206	СС	0007.5237.00	PHILIPS_CO	2238 581 1	5649		
C990	CC 100NF+-10%5 CERAMIC CHIP C	ov :	X7R 1206	CC	0007.5237.00	PHILIPS_CO	2238 581 1	5649		
MENP5	413 3PUA	Äl	Datum Date		Schalttelill Parts list			Sachnummer Stock No.		Blatt-Nr. Pega
<b>\$</b>		31	16.09.97	E	E SYNTHESIZER		1062	2.6409.01	SA	6+
ROHDE	E&SCHWARZ		- Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and the Consideration and th	s	YNTHESIZER			-		-
		1.	1							

	Kennz. Comp. No.		Baneni Dasign				Sachnummer Stock No.	Harsteller Manufacturer		Bazeichnung Dasignation		alten in ained in
	C995		UF +-10% UM SMD-0			CE	0007.7223.00	KEMET		91 C225 K O25 AS		
	D20	,	01CS 10\				1002.5129.00	PMI	RF	F01C(S)		
	D65 ·		E REFERE 8611 FRA				1043.9493.00					•
	D110	IC GAT	EARRAY		ST.BUSREG	BL		İ		C)74HC4094(D/T)		
	D115	BUS RE	GISTER		CH.AN.MUX	1				C)74HC4051(D/T)		
	D125				TIPLEXER SCHMITT T	1				C)74HC132(D/T)		
ı	D200	QUAD 2- BL 74A	-INP NAN COOSC		SCHMITT ZIN NAND	1	0820.3477.00			AC00(SC)		
	D205		AND GATT 4HC39OT		(DEC.CNT					C)74HC39O(D/T)		
Ì	D210	BL PC74		2)	(D-FF	1	0007.3505.00					
	D215	BS DG4			LOP NALDGSCH		0746.0322.00					
	D220	BJ DACE			X12B-DAC	İ	1012.9510.00	PMI	DAC	8143FS		
1	D255	BL 74A0	74SC	2XD	NVERTER -FLIPFL	BL	0820.3602.00	NSC	74	(C74(SC)		
ļ	D510	BL UPBS		2:	1 PRESC		0840.6113.00	NEC	(UF	)B581C		
ı	D520	BL, UPBS			ER 1 PRESC		OB20.3390.00	NEC	(UF	)B582C		
	D5B5	3	HC4094T	BS	T.BUSREG	BL	OBO4.0977.00	PHILIPS_SE	(PC	)74HC4094(D/T)		
ı	D620		2093D 2/				1062.6438.00	MOTOROLA	120	93(D)		
ı	D630	BL MC12	R PRESC	4/8	PRESC		1062.6438.00	MOTOROLA	120	93(D)		
ļ	D640	8L 74FC		NN	AND GATE	8L	0007.3628.00	PHILIPS_SE	(N)	74F00(D)		
ł	D655	8L 74AC	NPUT NA T74SC 2 D~FLIP	XRS	FLIPFLOP	BL	0008.0680.00	HARRIS	(CD	74)ACT74(M)		
1	D660		HC4094T		T.8USREG	BL	0804.0977.00	PHILIPS_SE	(PC	)74HC4094(D/T)		
1	D665		HC4094T	88	T.8USREG	8L	0804.0977.00	PHILIPS_SE	(PC	)74HC4094(D/T)		
1	D670		HC4094T	88	T.8USREG	8L	0804.0977.00	PHILIPS_SE	(PC	)74HC4094(D/T)		
ł	D700	8L 74AC			-FLIPFL	8L	0820.3602.00	NSC	74A	C74(SC)		- 1
ı	D7 10		9DY 1XU		NALOGSCH		0746.0322.00	SILICONIX	DG4	19DY		
l	D720				H.AN.MUX TIPLEXER	BL	0007.3592.00	PHILIPS_SE	(PC	)74HC4051(D/T)		
	D800	QUAD AN	ALOG CM	os.:			1004.7058.00	SILICONIX	DG4	13DY		
l	DB20	ANALOG	SWITCH	/I Ai	NALOGSCH		0746.0322.00	SILICONIX	DG4	19DY		
	DB40		IAL D/A-	-CD			1012.9510.00			8143FS		i
	D855	<b>BUS REG</b>	ISTER							)74HC4094(D/T)		
	DB70	DUAL MU	LTIVIBR/	TO				_		)74HCT123(D/T)		
	D950		TYPE FLI	PF	-FLIPFL		0820.3602.00			C74(SC)		
	D960	8CHANNE	L ANAL.N	IUL.	TIPLEXER		}			)74HC4051(D/T)		
	D965	QUAD AN			NALDGSCH H		0351.0000.00	21L1CUNI X	SD5	400CY		ŀ
	K240	SR 5V 5		X 1	SIL		1012.9604.00	HAMLIN	HE3	621A0500		
	K910	SR 5V 5	00 DHM :	X1	SIL		1012.9604.00	HAMLIN	HE3	621A0500		
	L1	LD 10UH SMD-IND		ο,	1BA 1210	LD	0007.9255.00	SIEMENS	B82	422-A1103-K100		
	L2	LD 10UH	10%	ο,	18A 1210	LO	0007.9255.00	SIEMENS	BB2	422-A1103-K100		
H	MENP5	413	3PUA	ÄI	Datum		Schaltteltti			Sachnummer		Biatt-Nr.
-	Δ				Date		Parts lis			Stock No.		Page
	ROHDE	E&SCHV	VARZ	31	16.09.97	E	E SYNTHESIZER			1062.6409.01	SA	7+

Kennz. Comp. No.			ennun ignatio					nummer ck No.	Harsteller Manufacturer		Bezeichnung Designation		halten in Itelned in
L3		JH 8EI	0,8	ΑΟ,	660HM	LE	0026	.4126.00	DALE		6		
L4		JH BEI	0,81	IA O,	660HM	LC	0026	.4126.00	DALE	IN	6		
L5		BUH BEI	1,6	ЗАО,	160HM		0026	.4061.00	DALE	IM	6		
Ĺ6	CHOKE LD 10U SMD-IN	JH 10% IDUCTOR		), 18A	1210	LD	0007	.9255.00	SIEMENS	88	2422-A 1103-K100	,	
L6	LD 1,2 CHOKE	R/ONLY	10, 18	OMMO	,620A	LD	0067	.2870.00	DALE	IM	2		
L8	LD 10U		0		1210	LD	0007	.9255.00	SIEMENS	88	2422-A1103-K100		
L9	LD 100		0	, 18A	1210	LD	0007	.9255.00	SIEMENS	88	2422-A 1103-K 100		
L12	SMD-IN LD 10U	H 10%	0	, 18A	1210	LD	0007	.9255.00	SIEMENS	В8:	2422A 1103-K 100		
15 L18	SMD-IN LD 10U	H 10%	0	, 18A	1210	LD	0007	9255.00	SIEMENS	88:	2422-A 1103-K 100		
L19	SMD-IN LD 10U SMD-IN	H 10%	0	, 18A	1210	LD	0007.	9255.00	SIEMENS	88	2422-A 1103-K100		
L20	LD 10U SMD-IN	H 10%	0	, 18A	1210	LD	0007.	9255.00	SIEMENS	88	2422-A1103-K100		
L22	LD 10U SMD-IN	H 10%	0	, 18A	1210	LD	0007.	9255.00	SIEMENS	882	2422-A1103-K100		
L23	LD 10U	H 10%	0	, 18A	1210	LD	0007.	9255.00	SIEMENS	883	2422-A 1103-K 100		
L28	LD 10U	H 10%	0	, 18A	1210	LD	0007.	9255.00	SIEMENS	B82	2422-A1103-K100		
L29	LO 1UH SMO-IN	10%	0	, 38A	1210	LD	6006.	0130.00	SIEMENS	B82	2422-A 1102-K 100		
L33	LD 1UH SMD-IN	10%	0	,38A	1210	LO	6006.	0130.00	SIEMENS	B82	2422-A 1102-K 100		
L35	LD 10UH SMO-INI	H 10%	0	, 18A	1210	LO	0007.	9255.00	SIEMENS	882	422-A1103-K100		
L200	LO 5601 CHOKE			, 15A	1210		4032.	4388.00	SIEMENS	882	422-A3561-K100		
L202	LO 1UH SMO-INO NUR VAR	DUCTOR			1210 43	LO	6006.	0130.00	SIEMENS	882	422-A1102-K100		
L202	RG O-OH RESISTO NUR VAR	HM WIOS OR CHIE	ERSTA	ANO-C		RG	0007.	5108.00	DRALORIC	CR	1206		
L204	LO 1UH SMO-ING NUR VAR	10% DUCTOR	0,	38A	1210	LO	6006.	0130.00	SIEMENS	882	422-A1102-K100		
L204	RG O-OH RESISTO NUR VAR	HM WIDE OR CHIF	RSTA 0-0	AND-C DHM	HIP	RG	0007.	5108.00	DRALORIC	CR	1206		
L227	LD 1,50 CHOKE						0067.	3247.00	DELEVAN	102	5-24		
L300	LD 220N SMD-COI	NH10%0,	4AOF	₹5	1206		1062.	6515.00	STETTNER	550	3 004 21		
L302	LO 470N SMD-MUL	<b>#10%0F</b>	₹5 0,				0007.	9226.00	токо	MLF	3216 O R47 KL		
L306	LD 220N SMD-IND	H 10%	Ο,	28A	1210	LD	0520.	7911.00	SIEMENS	B82	422-A3221-K100		
L346	LD 32 N SMD-VHF	#H SMD-	A8GL	Q5,	1H5		. 8000	9436.00	COMPONEX	E 5	58 CN-10 0020		
L400	LD 220N SMD-COI	H10%0,		85	1206		1062.	65 15 . 00	STETTNER	550	3 004 21		
L402	LD 220N SMD-COI	H10%0, L 1206	4AOR		1206		1062.0	6515.00	STETTNER	550	3 004 21		
L404	LD 220N SMD-COI	L 1206	;		1206				STETTNER	550	3 004 21		
L406	LD 220N SMD-COI	L 1206	;		1206				STETTNER	550	3 004 21		
L430	LD 220N SMD-COI	L 1206	i		1206				STETTNER		3 004 21		
L432	LD 220N SMD-COI	L 1206	ì		1206			- 1	STETTNER		3 004 21		
L434	LD 220N SMD-COI	L 1206	i		1206				STETTNER		3 004 21		
L436 L492	LD 220N SMD-COI LD 1UH	L 1206 10%	ì		1206 1210				STETTNER SIEMENS		3 004 21 422-A1102-K100		
	SMD-IND	OUCTOR											
MENP5	413	3PUA	ÄI		atum Date			Schaltteith Parts list			Sachnummer Stock No.		Blatt-Nr. Page
<b>(</b>			31	16.	09.97	F	E SYN	THESIZER			1062.6409.01	SA	8+
ROHDE	&SCH\	WARZ	'				YNTHE					<b>-</b>	0,1
				!				~ 4 ~ L1\					

Für diese Unterlage beheiten wir uns alle Rochte vor.

	Kennz. Comp. No.	Benen Design				Sachnummer Stock No.	Hersteller Manufacturer		Bazeichnung Dasignation		natten in teined in	٦
	L494	LD 1UH 10% SMD-INDUCTOR	0	,3BA 1210	L	6006.0130.00			2422-A1102-K100			1
	L500	LD 1UH 10%	0	38A 1210	LC	6006-0130.00	SIEMENS	В8	2422-A1102-K100			
	L502	SMD-INDUCTOR LD 1UH 10%	0,	,38A 1210	LC	6006.0130.00	51EMEN5	В8	2422-A1102-K100			ı
	L505	5MD-INDUCTOR LD 1UH 10%	0,	38A 1210	LD	6006.0130.00	SIEMENS	B8:	2422-A1102-K100			
	L506	SMD-INDUCTOR	٥,	38A 1210	LD	6006.0130.00	SIEMENS	B8:	2422-A1102-K100			
	L507	SMD-INDUCTOR LD 1UH 10%	0,	38A 1210	LD	6006.0130.00	SIEMENS	вв	2422-A 1 102-K 100			
	L515	SMD-INDUCTOR LD 1UH 10%	Ο,	38A 1210	LD	6006.0130.00	SIEMENS	B8:	2422-A 1 102-K 100			I
	L516	5MD-INDUCTOR LD 1UH 10%	0,	38A 1210	LD	6006.0130.00	5IEMENS	B8:	2422-A1102-K100			
	L525	5MD-INDUCTOR LD 1UH 10%	٥,	38A 1210	LD	6006.0130.00	SIEMENS	B82	2422-A1102-K100			
	L530	SMD-INDUCTOR LD 1UH 10%	Ο,	38A 1210	LD	6006.0130.00	SIEMENS	B82	2422-A1102-K100			l
	L550	5MD-INDUCTOR LD 1UH 10%	٥,	38A 1210	LD	6006.0130.00	5IEMENS	B82	2422-A 1 102-K 100			I
	L551	SMD-INDUCTOR LD 1UH 10%	0,	38A 1210	ഥ	6006.0130.00	SIEMEN5	B82	2422-A1102-K100			ı
	L570	SMD-INDUCTOR LD 1UH 10%	٥,	38A 1210	LD	6006.0130.00	SIEMENS	B82	2422-A1102-K100			l
	L5 <b>71</b>	SMD-INDUCTOR LD 1UH 10%	٥,	38A 1210	LD	6006.0130.00	5IEMENS	B82	2422-A1102-K100			l
	L600	SMD-INDUCTOR LD 1UH 10%	Ο,	38A 1210	Lo	6006.0130.00	SIEMEN5	B82	1422-A1102-K100			I
	L610	SMD-INDUCTOR LD 1UH 10%	٥,	38A 1210	LD	6006.0130.00	SIEMENS	B82	422-A1102-K100			l
	L621	5MD-INDUCTOR LD 1UH 10%	Ο,	3BA 1210	LD	6006.0130.00	SIEMEN5	B82	422-A 1 102-K 100			
	L631	SMD-INDUCTOR LD 1UH 10%	٥,	38A 1210	LD	6006.0130.00	SIEMEN5	B82	422-A1102-K100			
	L645	SMO-INDUCTOR LD 10UH 10%	٥,	18A 1210	LD	0007.9255.00	SIEMENS	882	422-A1103-K100			l
Vor.	L655	SMD-INDUCTOR LD 10UH 10%	٥,	18A 1210	LO	0007.9255.00	SIEMENS	882	422-A1103-K100		1	ĺ
uns alle Rechte vor.	L695	SMO-INDUCTOR LD 12NH 10%	٥,	70A 1210		1002.4900.00	SIEMENS	882	422-A3120-K100			
ilo Ri	L800	SMD-INDUCTOR LD 330NH 10%	٥,	20A 1210	LD	0520.7534.00	SIEMENS	882	422-A3331-K100			
	L801	SMD-INDUCTOR LD 330NH 10%	0,	20A 1210	LD	0520.7534.00	SIEMENS	882	422-A3331-K 100			l
ž	N20	SMD-INDUCTOR 80 MC14580		OV ODAND	Ì	2007 2702 00	CT ONET - 00	1104	450(0)			ĺ
	N100	OPERATION AMPL	IFI			0007.3763.00			458(0)			
	N 105	OUAL		COMPAR		0520.7734.00						
	N103	DUAL		COMPAR		0520.7734.00			903(D)			
	N200	DUAL		COMPAR		0520.7734.00			903(D)			
	N200	EO 10.000000MH	ATO	R VTCXO		1036.4331.00	PHILIP5_CO	992	2 515 00037			
	N200	NUR VAR/ONLY ME EO 10MHZ-QU.OS	z.00	CXO 5V		1062.6680.00	MILLIREN	210	-0618			
	N220	CRYSTAL OSZILLA NUR VAR/ONLY MO	DD:	04		0007 7000 00	revan	<b>*</b> . *	741 (22)			İ
		OPERATIONAL AMI				0007.7B23.00			74A(CD)			
	N250 N300	BO NE5534D OPERATIONAL AMI BM M5AO3B6 DC-				08 15 . 7555 . 00			534(D)			
	N490	BRDAD-BAND AMPI	_IF]	ER		084B.4461.00						
	1	BM MSA0386 DC-1 BROAD-BAND AMPI	_IF1	ER		OB4B.4461.00						
	N500 N510	BM MAR6-SM DC~2 MICROWAVE MONDI	LITI	C CIRC	1	6024.3666.00						
	N510 N520	BM MSAO3B6 DC-2 BROAD-BAND AMPE	_IF]	ER	1	0848.4461.00						İ
ı	N560	BM MSA0386 DC-2 BROAD-BAND AMPL	_IF1	ER		OB4B.4461.00 H						l
١	NSOC	BM M5AO4B6 DC-3 BROADBAND AMPL				0846.4293.00	VANTEK	MSA.	-0486			
ŀ	MENP5	413 3PUA	ΪÄ	Datum		Schaltteillis		_	Sachnummer		Blatt-Nr.	
	^	2,0 0,00	<u> </u>	Date		Parts list	for		Stock No.		Page	
-0200	ROHDI	E&SCHWARZ	31	16.09.97	E	E SYNTHESIZER			1062.6409.01	SA	9+	

5YNTHE5IZER

Kennz. Comp. No.		nnung		Sachnummer Stock No.	Hersteller Manufecturer	Bezeichnung Designetion		halten in tained in
N600	8M MSA0386 DO 8ROAD-8AND AF			0848.4461.0	O HEWLETT_PA	HPMA-0386		
N610	8M MSA0386 DO	0-2.	4G MMIC	0848.4461.0	O HEWLETT_PA	HPMA-0386		
N705	80 REFO2CS		VREF	0009.6882.0	O ANALOG_DEV	REF02CS		
N7 10	IC VOLTAGE RE		OPAMP	0815.7555.0	OSIGNETICS	NE5534(D)		
N720	OPERATIONAL A	MPL.	IFIER OPAMP	0815.7555.0	OSIGNETICS	NE5534(D)		
N780	OPERATIONAL A		IFIER FET DPAMP	0803.1057.00	DITEXAS	TL 072 ACDR		
N800	OPERATIONAL A 80 AD744KR		IFIER ET OPAMP		O ANALOG_DEV			
N840	BIFET OPAMP 80 AD843KN		ET OPAMP		- 10			
	IC OPAMP			1	D ANALOG_DEV			
N842	80 AD829JR 1X IC OPAMP			Í	ANALOG_DEV			
N845	80 AD744KR 8IFET OPAMP	F	ET OPAMP	0854.1754.00	ANALOG_DEV	(AD)744KR		
N850	80 NE5534D OPERATIONAL A	MPI 1	OPAMP FIER	0815.7555.00	SIGNETICS	NE5534(D)		
N860	80 LM119J	2X	COMPAR	0007.5337.00	LINEAR_TEC	LM119J (AJ)		
N940	COMPARATOR 80 AD744KR	F	ET OPAMP	0854.1754.00	ANALOG_DEV	(AD)744KR		
N950	81FET OPAMP 80 TLO74ACD		ET OPAMP	0007.7823.00	TEXAS	TLO74A(CD)		
N96D	OPERATIONAL A 80 LM211D	MPLI	FIER COMPAR	0007.7869.00	1	LM211(D)		
	COMPARATOR							
P20	VL EINPRESSST PIN	IFT	L=6,8	VL 0010.7250.00	AMP	1-928776-5		
P21	VL EINPRESSST	IFT	L=6,8	VL 0010.7250.00	AMP	1-928776-5		
P201	PIN VL_EINPRESSST	IFT	L≖6,8	VL 0010.7250.00	AMP	1-928776-5		
204 P354	PIN VL EINPRESSST	IFT	L=6,8	VL 0010.7250.00	AMP	1-928776-5		
P600	PIN VL EINPRESSST			VL 0010.7250.00		1-928776-5		
P610	PIN VL EINPRESSST			VL 0010.7250.00	1			
P700	PIN				1	1-928776-5		
	VL EINPRESSST PIN		Ť	VL 0010.7250.00		1-928776-5		
P720	VL EINPRESSST		•	VL 0010.7250.00		1-928776-5		
P840	VL EINPRESSST	IFT	L≃6,8	VL 0010.7250.00	AMP	1-928776-5		
R5	RD 2.4 W 1,5			RD 0067.9274.00	TEPRO	TS-28		
R20	WIRE WOUND RES			RS 0007.9649.00		33146-1-103		
	POTENTIOMETER NICHT BESTUECH							
R21	NOT FITTED RG 22,1 OHM+-	1%TK	100 1206	RG 0007.5489.00	ROEDERSTEI	DC2 22,1DHM 1%TK100		
R22	RESISTOR CHIP RG 39,2KOHM+-					DC2 39,2KOHM 1%TK100		
	RESISTOR CHIP NICHT BESTUECH NOT FITTED				, ACCOUNTS OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE	502 05,2NOIM 1//1N100		
R23	RG 10,0KDHM+-		100 1206	RG 0007.0793.00	ROEDERSTEI	DC2 10,0KOHM 1%TK100		
R24	RG CHIP RESIST		100 1206	RG 0007.5866.00	ROEDERSTEI	DC2 20,0KOHM 1%TK100		
R25	RESISTOR CHIP RG 10,0KOHM+-	1%TK			ļ.	DC2 10,0KDHM 1%TK100		
R26	RG CHIP RESIST	TOR .		0009.8904.00				
R27	SMD-RESISTDR E	IA1	206	0009.7666.00				
R28	SMD-RESISTOR							
	RG 100 OHM+-17 CHIP RESISTOR					DC2 100DHM 1%TK100		
R29	RG 1,D KD +-17 CHIP RESISTOR					DC2 1,0KDHM 1%TK100		
R30	RG 47,5 OHM+	1%TK	10D 12D6	RG 0007.5566.00	RUEDERSTEI	DC2 47,50HM 1%TK100		
MENP5	413 3PUA	Ät	Datum Dete	Schalttell Parts li		Sechnummar Stock No.		Blatt-N Paga
<b>*</b>		31	16.09.97	EE SYNTHESIZE	R	1062.6409.01	SA	10+
ROHDE	&SCHWARZ							

Kennz. Comp. No.	Benen Design		* ****	Τ	Sachnummer Stock No.	Hersteller Manufecturer	Bezeichnung Designation		thaiten in
R31	RG 10,0 OHM+-		100 1206	RO	0006.8649.00		CR(8) 1206		11011100 111
R100	RG 22,1 OHM+- RESISTOR CHIP	1%TK	100 1206				DC2 22,10HM 1%TK100		
R110	RG 47,5 OHM+-	_	100 1206	RG	0007.5566.00	ROEDERSTEI	DC2 47,50HM 1%TK100		
R111	RESISTOR CHIP RG 100 OHM+-1	%TK 1	00 1206	1			DC2 1000HM 1%TK100		
R112	CHIP RESISTOR RG 47,5 OHM+-		100 1206	RG	0007.5566.00	ROEDERSTEI	DC2 47,50HM 1%TK100		
R113	RESISTOR CHIP RG 100 OHM+-1: CHIP RESISTOR	%TK 1	00 1206	RG	0006.8884.00	ROEDERSTEI	DC2 1000HM 1%TK100		
R114	RG 47,5 OHM+	1%TK	100 1206	RG	0007.5566.00	ROEDERSTEI	DC2 47,50HM 1%TK100		
R115	RG 475 OHM+-19 RESISTOR CHIP	⁄TK 1	00 1206	RG	0007.5695.00	ROEDERSTEI	DC2 4750HM 1%TK 100		
R116	RG 47,5 OHM+-	1%TK	100 1206	RG	0007.5566.00	ROEDERSTEI	DC2 47,50HM 1%TK100		
R117	RG 475 OHM+-1% RESISTOR CHIP	4TK 1	00 1206	RG	0007.5695.00	ROEDERSTEI	DC2 4750HM 1%TK100		
R118	RG 475 OHM+-17 RESISTOR CHIP	∢ΤΚ 1¢	00 1206	RG	0007.5695.00	ROEDERSTEI	DC2 4750HM 1%TK100		
R119	RG 47,5 OHM+-1 RESISTOR CHIP	I%TK	100 1206	1			DC2 47,50HM 1%TK100		
R120	RG 10,0 OHM+-1 CHIP -RESISTOR	₹ .		l	0006.8649.00		CR(8) 1206		
R125	RG 4,75KOHM+-1 RESISTOR CHIP			ı	J		DC2 4,75KOHM 1%TK100		
R142	RG 4,75KOHM+-1		•	1			DC2 4,75KOHM 1%TK100		
R144 R145	RG 15,0KOHM+-1 RESISTOR CHIP RG 4,75KOHM+-1			1			DC2 15,0K0HM 1%TK100		
R146	RESISTOR CHIP RG 10,0KOHM+-1						DC2 4,75KOHM 1%TK100		
R150	RG CHIP RESIST RG 12,1KOHM+-1	OR		l			DC2 10,0K0HM 1%TK100 DC2 12,1K0HM 1%TK100		
R152	CHIP RESISTOR RG 1,5 KOHM+-1				,		DC2 12, 1KOHM 1%TK 100		
R154	RESISTOR CHIP RG O-OHM WIDER				0007.5108.00		CR 1206		
R 156	RESISTOR CHIP RG 11, OKOHM+-1	0-01	łM				DC2 11,0K0HM 1%TK100		
R158	CHIP RESISTOR RG 3,57KOHM+-1	%TK1	00 1206		1		DC2 3,57KOHM 1%TK100		
R160	RESISTOR CHIP RG 392 DHM+-1%	TK10	0 1206		4		DC2 3920HM 1%TK100		
R162	RESISTOR CHIP RG 100,0KOH+-1: CHIP RESISTOR	%TK 1	00 1206	RG	0007.1948.00	ROEDERSTEI D	0C2 100K0HM 1%TK100		
R164	RG 10,0KOHM+-1; RG CHIP RESIST		00 1206	RG	0007.0793.00	ROEDERSTEI C	OC2 10,0KOHM 1%TK100		
R166	RG 27,4KOHM+-1		00 1206	RG	0007.5895.00	ROEOERSTEI D	0C2 27,4KOHM 1%TK100		
R167	RG 681 OHM+-1% CHIP RESISTOR	TK 1C	0 1206	RG	0006.9080.00	ROEDERSTEI D	C2 6810HM 1%TK100		
R170	RG 4,75KOHM+-1% RESISTOR CHIP				i		0C2 4,75K0HM 1%TK100		
R172	RG 4,75KOHM+-19 RESISTOR CHIP		- 1				0C2 4,75KOHM 1%TK100		1
R174	RG 4,75KOHM+-19 RESISTOR CHIP						C2 4,75KOHM 1%TK100		
R178	RG 47,5KOHM+-1% RESISTOR CHIP		- 1				C2 47,5KOHM 1%TK100		
R180	RG 47,5 OHM+-19 RESISTOR CHIP						0C2 47,50HM 1%TK100		
R181 R201	RG 475 OHM+-1%1 RESISTOR CHIP RG 10,0 OHM+-1%				į		C2 4750HM 1%TK100		
R201	CHIP -RESISTOR RG 100 DHM+-1%1				0006.8884.00		R(8) 1206 C2 1000HM 1%TK100		
R204	CHIP RESISTOR RG 4.75KOHM+-17	_	Į.				C2 4,75KOHM 1%TK100		
	RESISTOR CHIP NUR VAR/ONLY MO	DD:	02 43						
R204	RG 332 DHM+-1%1 RESISTOR CHIP NUR VAR/ONLY MO			KG (	0007.5650.00	KUEDERSTEI D	C2 3320HM 1%TK100		
	•								
MENP5	413 3PUA	Äi	Datum Date		Schaltteillis Parts list		Sachnummer		Blatt-Nr.
és.					ra()\$ 11\$1		Stock No.		Page
POUDE & SCHWARZ		31	16.09.97	E	E SYNTHESIZER		1062.6409.01	SA	11+

Kennz, Comp. No.		Benan Design				Sachnummer Stock No.	Harstallar Manufacturer		lazaichnung Jasignation		altan in Jainad in
R206				100 1206	RG	0007.5808.00			2 3,92KOHM 1%TK100		
R207	RG 4,7		1%TK 1	100 1206	RG	0007.5820.00	ROEDERSTEI		2 4,75KOHM 1%TK100		
R208	RG 10,		1%TK 1	100 1206	RG	0006.8649.00	DRALORIC	CR	(8) 1206		
R209	RG 10,		1%TK 1	100 1206	RG	0006.8649.00	DRALORIC	CR	(8) 1206		
R210	RG 221	RESISTOR OHM+-17		00 1206	RG	0007.5614.00	ROEDERSTEI	DC2	2 2210HM 1%TK 100		
R212	RG 475	OR CHIP OHM+-1;	%TK 10	0 1206	RG	0007.5695.00	ROEDERSTEI	DC2	2 4750HM 1%TK100		
R213	RG 10,	OR CHIP OKOHM+-		00 1206	RG	0007.0793.00	  ROEDERSTEI	DC2	2 10,0KOHM 1%TK100		
R214		P RESIST 0HM+-1%		0 1206	1		1		2740HM 1%TK100		
R215	L	OR CHIP OHM+-1%	4TK 10	0 1206					2 2210HM 1%TK100		
R216		OR CHIP 5KOHM+-1	1%TK 1	00 1206			1		4,75KOHM 1%TK100		
R218		OR CHIP 1KOHM+-1	1%TK 1	00 1206					2,21KOHM 1%TK100		
R219		OR CHIP OHM+-1%	TK 10	0 1206			1		4750HM 1%TK100		
R220	RESIST	OR CHIP OHM+-1%							1000HM 1%TK 100		
R221	CHIP RE	ESISTOR SKOHM+-1							4,75KOHM 1%TK100		
R222	RESISTO	OR CHIP OKOHM+-1							10,0KOHM 1%TK 100		
R223	RG CHIF	RESIST	OR				1		2740HM 1%TK100		
R224	RESISTO	OR CHIP 1 OHM+-1							68,10HM 1%TK100		
R225	CHIP RE	SISTOR OHM+-1%			1				2740HM 1%TK100		
	RESISTO				```	2001.0007.00		502	27-TOTIM 1/#1/(100		
R225		OHM+-1%			RG	0007.5637.00	ROEDERSTEI	0C2	2740HM 1%TK100		
	NUR VAF	R/ONLY M		04 T FITTED							
R228		OHM+-1%			RG	0007.5637.00	ROEOERSTEI	0C2	2740HM 1%TK100		
R227		OHM+-1%	TK 10	0 1206	RG	0006.8884.00	ROEOERSTEI	DC2	1000HM 1%TK100		
R228		OHM+-1%	TK 10	0 1206	RG	0007.5614.00	ROEOERSTEI	0C2	2210HM 1%TK 100		
R229		KOHM+-1	%TK 10	00 1206	RG	0007.5850.00	ROEDERSTEI	DC2	18,2KOHM 1%TK100		
R230		KOHM+-1'	%TK 10	00 1206	RG	0007.5866.00	ROEDERSTEI	DC2	20,0K0HM 1%TK100		
R232	RG 10,0	KOHM+-1	%TK 10	00 1206	RG	0007.0793.00	ROEDERSTEI	DC2	10,0K0HM 1%TK100		
R234		KOHM+-1		00 1206	RG	0007.5743.00	ROEDER5TEI	DC2	2,21KOHM 1%TK100		
R236		OHM+-1%	TK 100	1206	RG	0007.5589.00	ROEDERSTEI	DC2	1500HM 1%TK100		
R236	NUR VAR	R/ONLY MI R +-1% TI	OD: (	0603		0000 6047 00	POEDEDSTET	D11	0603		
1,7250	5MD-RES	SISTOR E	IA060	03		0009.6947.00	WOEDEKS   E1	ווח	0603OH		
R238		KOHM+-1			RG	0007.5872.00	ROEDERSTEI	DC2	22,1KOHM 1%TK100		
R239	RG 10,0	OHM+-1: RESISTOR		00 1206	RG	0006.8649.00	DRALORIC	CR(	3) 1206		1
R240		OHM+-1%		1206	RG	0007.5637.00	ROEDERSTEI	DC2	2740HM 1%TK100		
R241		KOHM+-1	%TK 10	00 1206	RG	0007.5820.00	ROEDER5TEI	DC2	4,75KOHM 1%TK100		
R242		KOHM+-19	%TK 10	00 1206	RG	0007.5820.00	ROEDER5TEI	DC2	4,75KOHM 1%TK100		
R243 245		KOHM+-15	%TK 10	00 1206	RG	0007.6033.00	ROEDERSTEI	DC2	332KOHM 1%TK100		
R246		IOHM+-5%	TK200	1206		0008.0645.00	ROEDERSTEI				
R247		OHM+-1%	TK 100	1206	RG	0007.5614.00	ROEDERSTEI	DC2	2210HM 1%TK100		
MENP5	413	3PUA	ÄI	Datum . Date		Schalttalli Parts its			Sachnummar Stock No.		Biatt-Nr. Paga
<b>\$</b>			31 1	16.09.97	E	E 5YNTHE5IZE	₹		1062.6409.01	SA	12+
ROHDE	E&SCH\	WARZ				SYNTHESIZER					
31MILSIZEK									l .		

Kennz. Comp. No.	Banannung Dasignation			Sachnummer Stock No.	Hersteller Manufacturer	Bezeichnung Designation	anthalten in contained in
R248	RG 332 KDHM+-1%TK 100	1206	RG			DC2 332KDHM 1%TK100	CONTOURS IN
R251	RESISTOR CHIP RG 4,75K0HM+-1%TK100		ĺ			DC2 4,75KOHM 1%TK100	
R253	RESISTOR CHIP RG 4,75KOHM+-1%TK100	1206	RG	0007.5820.00	ROEOERSTEI	DC2 4,75KOHM 1%TK 100	
R255	RESISTOR CHIP RG 4,75KOHM+-1%TK100	1206				DC2 4,75KOHM 1%TK100	
R258	RESISTOR CHIP RG 6,80KOH+-0,1%TK25	1206		0009.8891.00	MIKRO-TEK-	CMF 1206	
R260	SMD-RESISTOR EIA1206 RG 3,32KOHM+-1%TK100	1206	RG	0007.5789.00	ROEDERSTEI (	DC2 3,32KOHM 1%TK100	
R264	RESISTOR CHIP RG 6,80KOH+-0,1%TK25	1206		0009.8891.00	MIKRO-TEK- (	CMF 1206	
R266	1 _	1206	RG	0006.7271.00	ROEOERSTEI 1	DC2 1,0KDHM 1%TK100	
R267	• · · · · · · · · · · · · · · · · ·	1206	RG	0006.7271.00	ROEOERSTEI D	DC2 1,0KOHM 1%TK100	
R269	CHIP RESISTDR RG 1,0 KO +-1%TK100 CHIP RESISTOR	1206	RG	0006.7271.00	ROEDERSTEI D	DC2 1,0KOHM 1%TK100	
R270	l	1206	RG	0006.7271.00	ROEDERSTEI D	DC2 1,0KDHM 1%TK100	
R276	RG 4,75KOHM+-1%TK100 RESISTOR CHIP	1206	RG	0007.5820.00	ROEDERSTEI D	0C2 4,75KDHM 1%TK10D	
R277	RG 4,75KOHM+-1%TK100 RESISTOR CHIP	1206	RG	0007.5820.00	ROEDERSTEI D	0C2 4,75K0HM 1%TK100	
R278	RG 221 OHM+-1%TK100 RESISTOR CHIP	1206	RG	0007.5614.00	ROEOERSTEI D	0C2 221DHM 1%TK100	
R280	RG 6,81KOHM+-1%TK100 CHIP RESISTOR	1206	RG	0007.0758.00	ROEDERSTEI D	0C2 6,81K0HM 1%TK100	
R281	RG 8,25KOHM+-1%TK100 CHIP RESISTOR	1206	RG	0007.0770.00	ROEOERSTEI D	0C2 8,25KOHM 1%TK100	
R282	RG 6,81KOHM+-1%TK100 CHIP RESISTOR	1206	RG	0007.0758.00	RDEOERSTEI D	0C2 6,81KOHM 1%TK100	
R283	RG 8,25KOHM+-1%TK100 : CHIP RESISTOR	1206	RG	0007.0770.00	ROEOERSTEI D	C2 8,25KOHM 1%TK100	
R284		1206	RG	0006.7271.00	ROEOERSTEI D	C2 1,0K0HM 1%TK100	
R285	RG 1,0 KO +-1%TK100 : CHIP RESISTOR	1206 F	RG	0006.7271.00	ROEOERSTEI D	C2 1,0K0HM 1%TK100	11 Y
R286	RG 7,5KOHM+-1%TK100 1 RG CHIP RESISTOR	1206	RG	0007.0764.00	ROEDERSTEI D	C2 7,50KOHM 1%TK100	
R287	RG 30,1KOHM+-1%TK100 1 RESISTOR CHIP	1206	RG	0007.5908.00	ROEOERSTEI D	C2 30,1KDHM 1%TK100	
R288	RG 100,0K0H+-1%TK100 1 CHIP RESISTOR					C2 100K0HM 1%TK100	
R289	CHIP RESISTOR					C2 1,0K0HM 1%TK100	
R290	RG 10,0 OHM+-1%TK100 1 CHIP -RESISTOR			0006.8649.00		R(B) 1206	
R291	RG 22,1 OHM+-1%TK100 1 RESISTOR CHIP					C2 22,10HM 1%TK100	
R302	RESISTDR	- 1		ŀ		R O8 M 56R 1% O8D5	
R304	RG 1,82KDHM+-1%TK100 1 RESISTOR CHIP	- 1				C2 1,82KOHM 1%TK100	
R306	RG 1,82KOHM+-1%TK100 1 RESISTOR CHIP					C2 1,82KOHM 1%TK100	
R308 R310	RG 1,82KDHM+-1%TK100 1 RESISTOR CHIP					C2 1,82KOHM 1%TK100	
R310	RESISTOR CHIP			i		C2 2000HM 1%TK100	
R314	RG 4,75KDHM+-1%TK100 1 RESISTOR CHIP RG 221 OHM+-1%TK100 1					C2 4,75KOHM 1%TK100	
R314	RESISTOR CHIP RG 68,1 OHM+-1%TK100 1	-				C2 2210HM 1%TK100 C2 68,10HM 1%TK100	
R324	CHIP RESISTOR	ĺ				C2 182DHM 1%TK100	
R326	RESISTDR CHIP RG 24,3 OHM+-1%TK100 1			1		C2 24,3DHM 1%TK100	
R328	RESISTOR CHIP RG 150 OHM+-1%TK100 1					C2 1500HM 1%TK100	
	RESISTOR CHIP NICHT BESTUECKT		\			02 1300imi 1/01K100	
R330	NDT FITTED RG O-OHM WIDERSTAND-CH	IIP R	eg (	0007.5108.00	DRALÓRIC C	R 1206	
	RESISTOR CHIP O-DHM	"	`		UI		
	,						
MENP5	413 3PUA Āt Dat	tum ete		Schalttelills Perts list		Sachnummer Stock No.	Blatt-Nr. Pege

Kannz. Comp. No.		Beneni Design		****		Sachaummer Stock No.	Hersteller Manufecturer	Bezeichnung Designation		alten in ained in
R331		OHM+-17	4TK 10	0 1206	RG	0006.8884.00	ROEDERSTEI	DC2 100DHM 1%TK100		
R332	RG 47,	ESISTOR 5 OHM+-	1%TK 1	00 1206	RG	0007.5566.00	ROEDERSTEI	DC2 47,50HM 1%TK100		
R335	RG 68,	OR CHIP	1%TK 1	00 1206	RG	0006.8849.00	ROEDERSTEI	DC2 68,10HM 1%TK100		
R336	RG 182	ESISTOR OHM+-17	6TK10	0 1206	RG	0007.5595.00	ROEDERSTEI	DC2 1820HM 1%TK100		
R337	RG 2,2	OR CHIP !1KOHM+-1	1%TK 1	00 1206	RG	0007.5743.00	ROEDERSTEI	DC2 2,21KOHM 1%TK100		
R338	RG 1,0	OR CHIP KO +-1%	(TK 10	0 1206	RG	0006.7271.00	ROEDERSTEI	DC2 1,0KOHM 1%TK100		
R339	RG 12,	ESISTOR 1KOHM+-1	1%TK 1	00 1206	RG	0007.0841.00	ROEDERSTEI	DC2 12,1KOHM 1%TK100		
R340	RG 100	ESISTOR ,OKOH+-1	1 <b>%</b> TK1	00 1206	RG	0007.1948.00	ROEDERSTEI	DC2 100K0HM 1%TK100		
R341	RG 10,	ESISTOR OKOHM+-1		00 1206	RG	0007.0793.00	ROEDERSTEI	DC2 10,0K0HM 1%TK100		
R342	RG 47,	P RESIST 5KOHM+-1		00 1206	RG	0007.5950.00	ROEDERSTEI	DC2 47,5KOHM 1%TK100		
R343	RG 3,0	OR CHIP 1KOHM+-1	<b>%</b> TK1	00 1206	RG	0007.5772.00	ROEDERSTEI	DC2 3,01KDHM 1%TK100		
R344		OR CHIP 2KOHM+-1	%TK 1	00 1206	RG	0007.5808.00	RESISTA	DC2 3,92KOHM 1%TK100		
R345	RG 12,	OR CHIP 1KOHM+-1	%TK1	00 1206	RG	0007.0841.00	ROEDERSTEI	DC2 12, 1KOHM 1%TK100		
R346	RG 10,6	ESISTOR O OHM+-1		00 1206		0006.8649.00		CR(8) 1206		
R347	RG 100	RESISTOR ,OKOH+-1		00 1206	RG	0007.1948.00	ROEDERSTEI	DC2 100K0HM 1%TK100		
R348	RG 10,0	ESISTOR OKOHM+-1		00 1206	RG	0007.0793.00	ROEDERSTEI	DC2 10,0K0HM 1%TK100		
R361		P RESIST 1_OHM+-1		00 1206	RG	0007.5489.00	ROEDERSTEI	DC2 22,10HM 1%TK100		
R370		OHM+-1%	TK 10	0 1206	RG	0006.8884.00	ROEDERSTEI	DC2 1000HM 1%TK100		
R371	RG 4,75	ESISTOR 5KOHM+-1	%TK 1	00 1206	!			DC2 4,75KOHM 1%TK100		
R372		OHM+-1%	TK 10	1206	l			DC2 2210HM 1%TK100		
R373		OHM+-1		00 1206	RG	0006.8649.00	DRALORIC	CR(8) 1206		
R375	RG 2,0	RESISTOR KOHM+-1		00 1206	RG	0007.5737.00	ROEDERSTEI	DC2 2,0K0HM 1%TK100		
R400		20HM+-1%	TK 100	1206		0007.8388.00		RC 02		
R402		20HM+-1%	TK 100	1206	RG	0007.8388.00	PHILIPS	RC 02		1111
R404		20HM+-1%	TK 100	1206	RG	0007.8388.00	PHILIPS	RC 02		
R406		20HM+-1%	TK 100	1206	RG	0007.8388.00	PHILIPS	RC 02		
R408		20HM+-1%	TK 100	1206	RG	0007.8388.00	PHILIPS	RC 02		
R410		W 22R +	- 1%	0805	RG	0007.8920.00	HONEST JAP	MR 08 M 22R 1% 0805		
R412		KOHM+-1	%TK 10	00 1206	RG	0007.5720.00	ROEDERSTEI	DC2 1,82KOHM 1%TK100		
R414		KO +-1%	TK 100	1206	RG	0006.7271.00	ROEDERSTEI	DC2 1,0KDHM 1%TK100		
R416		KOHM+=1	%TK 10	00 1206	RG	0006.9968.00	ROEDERSTEI	DC2 1,21KOHM 1%TK100		
R418		KO +-1%	TK 100	1206	RG	0006.7271.00	ROEDERSTEI	DC2 1,0K0HM 1%TK100		
R420		5 OHM+-19	%TK10	00 1206	RG	0006.8861.00	ROEDERSTEI	DC2 82,50HM 1%TK100		
R422		OHM+-1%	TK 100	1206	RG	0007.5643.00	ROEDERSTEI	DC2 3010HM 1%TK100		
R424		KOHM+-1	%TK10	00 1206	RG	0006.9968.00	ROEDERSTEI	DC2 1,21KOHM 1%TK100		
R425		KOHM+-1	%TK 10	00 1206	RG	0007.5714.00	ROEDERSTEI	DC2 1,5KOHM 1%TK100		
R426		KOHM+-19	%TK10	00 1206	RG	0007.5820.00	ROEDERSTEI	DC2 4,75KOHM 1%TK100		
R427	RESISTO	KOHM+-1	%TK 10	00 1206	RG	0007.0793.00	ROEDERSTEI	DC2 10,0KOHM 1%TK100		
R430		P RESISTO 20HM+-1% SISTOR		1206	RG	0007.8388.00	PHILIPS	RC 02		
MENP5	419	3PUA	ÄL	Datum		Schaliteliii		Sachnummer		Blatt-Nr.
				Date		Parts lis	i for	Stock No.		Paga
ROHDE	:&SCH\	WARZ	31	6.09.97	E	E SYNTHESIZER	ł	1062.6409.01	SA	14+
SYNTHESIZER										

Kennz. Comp. No.	Benannung Dasignation	Sachnummer Harsteller Stock No. Manufactu	Bezeichnung rer Designation	enthalten in contained in
R431	RG 10R +-1% TK200 060 SMD-RESISTOR EIA0603			Contained in
R432	NUR VAR/ONLY MOD: 02 RG 3,320HM+-1%TK100 120	6 RG 0007.8388.00 PHILIPS	RC O2	
R434	CHIP-RESISTOR RG 3,320HM+-1%TK100 120	RG 0007.8388.00 PHILIPS	RC 02	
R436	CHIP-RESISTOR RG 3,320HM+-1%TK100 120	RG 0007.8388.00 PHILIPS	RC 02	
R438	CHIP-RESISTOR RG 3,320HM+-1%TK100 120		RC 02	-
R440	CHIP-RESISTOR RG 0,05W 27R +-1% 080			
R442	RESISTOR RG 1,82KOHM+-1%TK100 120			
R444	RESISTOR CHIP RG 1,0 KO +-1%TK100 120			1
R446	CHIP RESISTOR RG 1,21KOHM+-1%TK100 1200	100011211100 11002521001		
	CHIP RESISTOR			
R448	RG 1,0 KO +-1%TK100 1206 CHIP RESISTOR	The desired field file		
R450	RG 82,5 OHM+-1%TK100 1200 CHIP RESISTOR			
R452	RG 243 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5620.00 ROEDERST	EI DC2 2430HM 1%TK100	
R454	RG 1,21KOHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.9968.00 ROEDERST	EI DC2 1,21KOHM 1%TK100	
R455	RG 1,5 KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5714.00 RDEDERST	EI DC2 1,5KOHM 1%TK100	
R456	RG 4,75KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5820.00 RDEDERST	EI DC2 4,75KOHM 1%TK100	
R457	RG 10,0K0HM+-1%TK100 1206	RG 0007.0793.00 ROEDERST	EI 0C2 10,0K0HM 1%TK100	
R483	RG 100 OHM+-1%TK100 1206	RG 0006.8884.00 ROE0ERST	EI DC2 1000HM 1%TK100	
	CHIP RESISTOR NICHT BESTUECKT			
R490	NOT FITTEO RG 2,21KOHM+-1%TK100 1206	RG 0007.5743.00 ROEDERST	EI DC2 2,21KOHM 1%TK100	
R491	RESISTOR CHIP RG 68,1 OHM+-1%TK100 1206	RG 0006.8849.00 ROEDERST		
R495	CHIP RESISTOR RG 82,5 OHM+-1%TK100 1206	RG 0006.8861.00 ROEDERST		
R496	CHIP RESISTOR RG 121 OHM+-1%TK100 1206	RG 0006.8903.00 ROEDERSTI		
R497	CHIP RESISTOR RG 68,1 OHM+-1%TK100 1206	RG 0006.8849.00 ROEDERST		
R499	CHIP RESISTOR RG 68,1 OHM+-1%TK100 1206			
R500	CHIP RESISTOR RG 150 OHM+-1%TK100 1206	RG 0007.5589.00 ROEDERSTE		
R502	RESISTOR CHIP RG 150 OHM+-1%TK100 1206	RG 0007.5589.00 RDEDERSTE		
R505	RESISTOR CHIP RG 182 OHM+-1%TK100 1206	RG 0007.5595.00 ROEDERSTE		
R506	RESISTOR CHIP RG 392 OHM+-1%TK100 1206			
R507	RESISTOR CHIP RG 392 OHM+-1%TK100 1206	RG 0007.5672.00 ROEDERSTE		
R510	RESISTOR CHIP RG 1,0 KO +-1%TK100 1206	RG 0007.5672.00 ROEDERSTE		
R511	CHIP RESISTOR RG 56,2 OHM+-1%TK100 1206	RG 0006.7271.00 ROEDERSTE		
R515	CHIP RESISTOR	RG 0006.8826.00 ROEDERSTE		
	RG 121 OHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.8903.00 ROEDERSTE		
R520	RG 1,0 KO +-1%TK100 1206 CHIP RESISTOR	RG 0006.7271.00 ROEDERSTE		Ī
R521	RG 56,2 OHM+-1%TK 100 1206 CHIP RESISTOR	RG 0006.8826.00 RDEDERSTE		
R525	RG 332 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5650.00 ROEDERSTE		
R526	RG 15,0 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5450.00 ROEDERSTE		
R527	RG 332 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5650.00 ROEDERSTE		
R528	RG 68,1 DHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.8849.00 ROEDERSTE	I DC2 68,10HM 1%TK100	
MENP5	413 3PUA Äi Datum Date	Schaltteillista für Parts list for	Sachnummer Stock No.	Biatt-Nr. Page
ROHDE	88CHWARZ 31 16.09.97		1062.6409.01	

SYNTHESIZER

Kennz. Comp. No.	Benennung Designation		Sachnummer Stock No.	Hersteller Manufecturer	Bezeichnung Designation	enthelten in contained in				
R530	RG 332 OHM+-1%TK100	1206			C2 3320HM 1%TK100	enviamen in				
R531	RESISTOR CHIP RG 27,4KOHM+-1%TK10	0 1206	1		C2 27,4KOHM 1%TK100					
R550	RESISTOR CHIP RG 150 OHM+-1%TK10D	1206	RG 0007.5589.00	ROEDERSTEI D	C2 1500HM 1%TK100					
Ŕ552	RESISTOR CHIP RG 47,5 OHM+-1%TK 100	1206	i		C2 47,50HM 1%TK100					
R555	RESISTOR CHIP RG 100 OHM+-1%TK100	1206	1	}	C2 1D00HM 1%TK100					
R556	CHIP RESISTOR RG 100,0K0H+-1%TK10	1206	RG 0007.1948.00	ROEDERSTEI D	C2 100KOHM 1%TK100					
R557	CHIP RESISTOR RG 10,0KOHM+-1%TK100	1206	RG 0007.0793.00	ROEDERSTEI DO	C2 10,0KOHM 1%TK100					
R570	RG CHIP RESISTOR RG 392 OHM+-1%TK100	1206	i i		C2 3920HM 1%TK100					
R571	RESISTOR CHIP RG 392 OHM+-1%TK100	1206	RG 0007.5672.00	ROEDERSTEI DO	2 3920HM 1%TK100					
R579	RESISTOR CHIP RG 22,1 OHM+-1%TK100	1206	RG 0007.5489.00	ROEDERSTEI DO	C2 22,10HM 1%TK100					
R581	RESISTOR CHIP RG 4,75KOHM+-1%TK10C	1206	RG 0007.5820.00	ROEDERSTEI DO	2 4,75KOHM 1%TK100					
R600	RESISTOR CHIP RG 10R +-1% TK50	0805	RG 0007.8888.0D	HONEST_JAP R	73 C(E)2XF (1%)					
R603	RESISTOR RG 68,1 OHM+-1%TK100	1206	RG 0006.8849.00	ROEDERSTEI DO	2 68,10HM 1%TK100					
R605	CHIP RESISTOR RG 100 OHM+-1%TK100 CHIP RESISTOR	1206	RG 0006.8884.00	ROEDERSTEI DO	2 1000HM 1%TK100					
R606	RG 100 OHM+-1%TK 100 CHIP RESISTOR	1206	RG 0006.8884.00	ROEDERSTEI DO	2 1000HM 1%TK100					
R607	RG 82,5 OHM+-1%TK100 CHIP RESISTOR	1206	RG 0006.8861.00	ROEDERSTEI DO	2 82,50HM 1%TK100					
R610	RG 68,1 OHM+-1%TK100 CHIP RESISTOR	1206	RG 0006.8849.00	ROEDERSTEI DO	2 68,10HM 1%TK100					
R611 614	RG 4,75KOHM+-1%TK100 RESISTOR CHIP	1206	RG 0007.5820.00	ROEDERSTEI DO	2 4,75KOHM 1%TK100					
R615	RG 82,5 OHM+-1%TK100 CHIP RESISTOR	1206	RG 0006.8861.00	ROEDERSTEI DO	2 82,50HM 1%TK100					
R616	RG 82,5 OHM+-1%TK100 CHIP RESISTOR	1206	RG 0006.8861.00	ROEDERSTEI DC	2 82,50HM 1%TK100					
R817	RG 82,5 OHM+-1%TK100 CHIP RESISTOR	1206			2 82,50HM 1%TK100					
R620	RG 1,0 KO +-1%TK100 CHIP RESISTOR	1206			2 1.0KOHM 1%TK100					
R621	RG 1.0 KO +-1%TK100 CHIP RESISTOR	1206			2 1,0K0HM 1%TK100					
R630	RG 1,0 KO +-1%TK100 CHIP RESISTOR	1206	]		2 1,0KOHM 1%TK100					
R631	RG 1,0 KO +-1%TK100 CHIP RESISTOR	1206			2 1,0K0HM 1%TK100					
R633	RG 100 OHM+-1%TK100 CHIP RESISTOR	1206	RG 0006.8884.00							
R635	RG 33,2 OHM+-1%TK100 RESISTOR CHIP	_			2 33,20HM 1%TK100	1				
R636	RG 221 OHM+-1%TK100 RESISTOR CHIP	1206	RG 0007.5614.00 F							
R637 R638	RG 221 OHM+-1%TK100 RESISTOR CHIP	1206	RG 0007.5614.00 F		•					
R639	RG 4,75KOHM+-1%TK100 RESISTOR CHIP		-		2 4,75KOHM 1%TK100					
R640	RG 4,75KOHM+-1%TK100 RESISTOR CHIP RG 10,0 OHM+-1%TK100				2 4,75KOHM 1%TK100					
R643	CHIP -RESISTOR RG 1,5 KOHM+-1%TK 100		RG 0006.8649.00 E		(B) 12D6 2 1,5KOHM 1%TK100					
R644	RESISTOR CHIP RG 562 OHM+-1%TK100		RG 0006.9068.00 F							
R645	CHIP RESISTOR RG 33,2 OHM+-1%TK100				2 33,20HM 1%TK100					
R647	RESISTOR CHIP RG 4,75KOHM+-1%TK100				2 4,75KOHM 1%TK100					
R650	RESISTOR CHIP RG 4,75KOHM+-1%TK100				2 4,75KOHM 1%TK100					
	RESISTOR CHIP NICHT BESTUECKT	_			,					
R651	NOT FITTED RG 4,75KOHM+-1%TK100	12D6	RG 0007.5820.00 R	ROEDERSTEI DC:	2 4,75KOHM 1%TK100					
	RESISTOR CHIP									
MENP5		)atum	Schaltteills		Sachnummer	Biatt-Nr.				
		Date	Perts list	101	Stock No.	Page				
<b>OHDE</b>	&SCHWARZ 31 16.	09.97	EE SYNTHESIZER		1062.6409.01	SA 16+				
	SYNTHESIZER									

Kennz. Comp. No.	Banannung Designation	Sachnummer Stock No.	Hersteller Bezeichnung Manufacturer Designation	enthaltan in contained in
	NICHT BESTUECKT			
R652	NOT FITTED RG 4,75KOHM+-1%TK100 120 RESISTOR CHIP NICHT BESTUECKT	6 RG 0007.5820.00	ROEDERSTEI DC2 4,75KOHM 1%TK100	
R653	NOT FITTED   RG 4,75KOHM+-1%TK100 120   RESISTOR CHIP   NICHT BESTUECKT   NOT FITTED	6 RG 0007.5820.00	ROEDERSTEI DC2 4,75KOHM 1%TK100	
R654	RG 4,75KOHM+-1%TK100 120	RG 0007.5820.00	ROEDERSTEI DC2 4,75KOHM 1%TK100	
R655	RG 33,2 OHM+-1%TK100 1200 RESISTOR CHIP	RG 0007.5520.00	ROEDERSTEI DC2 33,20HM 1%TK100	
R656	RG 4,75KOHM+-1%TK100 1200 RESISTOR CHIP	1	ROEDERSTEI DC2 4,75KOHM 1%TK100	
R658	RG 221 OHM+-1%TK100 1200 RESISTOR CHIP	1,000	ROEDERSTEI DC2 2210HM 1%TK100	
R659	RG 4,75KOHM+-1%TK100 1200 RESISTOR CHIP		ROEDERSTEI DC2 4,75KOHM 1%TK100	
R660	RG 4,75KOHM+-1%TK100 1200 RESISTOR CHIP	RG 0007.5820.00	ROEDERSTEI OC2 4,75KOHM 1%TK100	
R661	RG 4,75KOHM+-1%TK100 1206 RESISTOR CHIP NICHT BESTUECKT NOT FITTED	RG 0007.5820.00 R	ROEDERSTEI DC2 4,75KOHM 1%TK100	
R662	RG 475 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5695.00 R	DEDERSTEI DC2 4750HM 1%TK100	
R663	RG 4,75KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5820.00 R	OEDERSTEI DC2 4,75KOHM 1%TK100	
R667	RG 4,75KOHM+-1%TK100 1206 RESI5TOR CHIP NICHT BESTUECKT	RG 0007.5B20.00 R	OEDERSTEI DC2 4,75KOHM 1%TK100	
R668	NOT FITTEO RG 4,75K0HM+-1%TK100 1206 RESISTOR CHIP NICHT BESTUECKT	RG 0007.5820.00 R	OEDERSTEI DC2 4,75KOHM 1%TK100	
R669	NOT FITTED RG 4,75KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5820.00 R	OEDERSTEI DC2 4,75KOHM 1%TK100	
R670	NICHT BESTUECKT NOT FITTED RG 4,75KOHM+-1%TK100 1206 RESISTOR CHIP NICHT BESTUECKT	RG 0007.5820.00 R	OEDERSTEI DC2 4,75KOHM 1%TK100	
R671	NOT FITTEO	RG 0007.5820.00 R	DEDERSTEI DC2 4,75KDHM 1%TK100	
R672	NICHT BESTUECKT	RG 0007.5820.00 RG	DEDERSTEI DC2 4,75KOHM 1%TK100	
R673	NOT FITTEO RG 4,75KOHM+-1%TK100 1206 RESI5TOR CHIP NICHT BESTUECKT NOT FITTED	RG 0007.5820.00 RG	DEDERSTEI OC2 4,75KOHM 1%TK100	
R674	RG 4,75K0HM+-1%TK100 1206 RESISTOR CHIP NICHT BESTUECKT NOT FITTED	RG 0007.5B20.00 RG	DEDER5TEI DC2 4,75KOHM 1%TK100	
R675	RG 4,75K0HM+-1%TK100 1206 RESI5TOR CHIP NICHT BESTUECKT NOT FITTED	RG 0007.5820.00 RC	DEDERSTEI DC2 4,75KOHM 1%TK100	
R676	RG 4,75KOHM+-1%TK100 1206 RESISTOR CHIP NICHT BESTUECKT NOT FITTED	RG 0007.5820.00 RC	DEDERSTEI DC2 4,75KOHM 1%TK100	
R677	RG 4,75KOHM+-1%TK100 1206 RESISTOR CHIP NICHT BESTUECKT NOT FITTED	RG 0007.5820.00 RC	DEDERSTEI DC2 4,75KOHM 1%TK100	
R678	RG 4,75KOHM+-1%TK100 1206 RESISTOR CHIP NICHT BESTUECKT	RG 0007.5820.00 RC	DEDERSTEI DC2 4,75KOHM 1%TK100	
MENP5	413 3PUA AJ Datum	Schalttalliiste Parts list fo		Blatt-Nr.
				Page
ROHDE	&SCHWARZ 31 16.09.97	EE SYNTHE51ZER	1062.6409.01	SA   17+

5YNTHE5IZER

Kennz. Comp. No.	genennung Designation		Sachnummer Stock No.	Hersteller Manufacturer	Sezeichnung Designetion		aiten in Iinad in
R679	NOT FITTED RG 4,75KDHM+-1%TH RESISTOR CHIP	(100 1206	RG 0007.5820.00	ROEDERSTEI	DC2 4,75KDHM 1%TK100		
	NICHT BESTUECKT						
R680	NOT FITTED RG 4,75KDHM+-1%TH	(100 1206	RG 0007.5820.00	RDEDERSTEI	DC2 4,75KOHM 1%TK100		
	RESISTOR CHIP NICHT BESTUECKT						
R681	NOT FITTED RG 4,75KOHM+-1%TH	(100 1206	RG 0007.5820.00	ROEDERSTE I	DC2 4,75KOHM 1%TK100		
	RESISTOR CHIP NICHT BESTUECKT						
R686	NOT FITTED	(100 1006	PG 0007 E000 00	DOEDEDOTE T	DC2 / 7EVOLUM 4VTV 4CC		
688	RG 4,75KOHM+-1%TH RESISTOR CHIP	•		ļ	DC2 4,75KOHM 1%TK100		
R690 693	RG 1,0 OHM+-1%TK1 CHIP-RESISTOR		RG 0007.8265.00	_	-		
R695	RG 130 DHM+-1%TK1 RESISTOR CHIP		RG 0007.5572.00		DC2 130DHM 1%TK 100		
R696	RG 10,0 OHM+-1%TK CHIP -RESISTOR	(100 1206	RG 0006.8649.00		CR(8) 1206		
R697	RG O-OHM WIDERSTA		RG 0007.5108.00	DRALORIC	CR 1206		
R698	RG 2,21KOHM+-1%TK RESISTOR CHIP		RG 0007.5743.00	ROEDERSTEI	DC2 2,21KOHM 1%TK100		
R700	RG 4,75KOHM+-1%TK RESISTOR CHIP	100 1206	RG 0007.5820.00	ROEDERSTEI	DC2 4,75KOHM 1%TK100		
R701	RG 4,75KOHM+-1%TK	100 1206	RG 0007.5820.00	ROEDERSTEI	DC2 4,75KOHM 1%TK100		
R702	RESISTOR CHIP RG 221 OHM+-1%TK1	00 1206	RG 0007.5614.00	ROEDERSTEI	DC2 2210HM 1%TK100		11.7
R703	RESISTOR CHIP RG 1,0 KO +-1%TK1	00 1206	RG 0006.7271.00	ROEDERSTEI	DC2 1,0K0HM 1%TK100		
R704	CHIP RESISTOR RG 1,0 KO +-1%TK1	00 1206	RG 0006.7271.00	ROEDERSTEI	DC2 1,0K0HM 1%TK100		
R705	CHIP RESISTOR RG 274 OHM+-1%TK1	00 1206	i		DC2 2740HM 1%TK100		
R706	RESISTOR CHIP RG 2,0 KOHM+-1%TK	ļ			DC2 2,0K0HM 1%TK100		
R707	RESISTOR CHIP RG 1,0 KO +-1%TK1				DC2 1,0K0HM 1%TK100		1
R708	CHIP RESISTOR RG 1,0 KO +-1%TK1	1			DC2 1,0K0HM 1%TK100		
R709	CHIP RESISTOR RG 10,0 0HM+-1%TK		RG 0006.8649.00		CR(8) 1206		
R710	CHIP -RESISTOR RG 2.0 KOHM+-1%TK				DC2 2.0KOHM 1%TK 100		
	RESISTOR CHIP						
R712	RG 10,0K0HM+-1%TK RG CHIP RESISTOR				DC2 10,0K0HM 1%TK100		
R713	CHIP RESISTOR				DC2 8,25KOHM 1%TK100		
R719	RG 47,5 OHM+-1%TK RESISTOR CHIP				DC2 47,5DHM 1%TK100		
R720	RG 4,75KDHM+-1%TK RESISTOR CHIP				DC2 4,75KDHM 1%TK100		
R721	RG 121,0KDH+-1%TK CHIP RESISTOR		RG 0007.1960.00		DC2 121KDHM 1% TK100		
R722	RG 27,4KOHM+-1%TK RESISTOR CHIP				DC2 27,4KOHM 1%TK100		
R723	RG 15,0KOHM+-1%TK RESISTOR CHIP				DC2 15,0KDHM 1%TK100		
R724	RG 9,09KOHM+-1%TK	100 1206	RG 0007.0787.00	RDEDERSTEI	DC2 9,09KDHM 1%TK100		
R725	RG 6,19KOHM+-1%TK	100 1206	RG 0007.0741.00	RDEDERSTEI	DC2 6,19KOHM 1%TK100		
R726	RG 4,75KOHM+-1%TK	100 1206	RG 0007.5820.00	ROEDERSTEI	DC2 4,75KDHM 1%TK100		
R727	RESISTOR CHIP RG 3,57KOHM+-1%TK	100 1206	RG 0007.5795.00	ROEDERSTEI	DC2 3,57KOHM 1%TK100		
R728	RESISTOR CHIP RG 2,74KOHM+-1%TK	100 1206	RG 0007.5766.00	ROEDERSTEI	DC2 2,74KDHM 1%TK100		
R729	RESISTOR CHIP RG 6,81KOHM+-1%TK	100 1206	RG 0007.0758.00	RDEDERSTEI	DC2 6,81KOHM 1%TK100		
R730	CHIP RESISTOR RG 2,74KDHM+-1%TK	.100 1206	RG 0007.5766.00	ROEDERSTEI	DC2 2,74KOHM 1%TK100		
R733	RESISTDR CHIP RG 100,0KDH+-1%TK	100 1206	RG 0007.1948.00	RDEDERSTEI	DC2 100KDHM 1%TK100		1
	CHIP RESISTOR						
MENP5	413 3PUA ÄI	Detum Date	Schaltteilli Parts lis		Sechnummer Stock No.		Blett-Nr. Page
		Dald	1 61(5 (1)			0.5	
ROHDE	E&SCHWARZ 31	16.09.97	EE SYNTHESIZER	<b>t</b>	1062.6409.01	SA	18+
			SYNTHESIZER				

Kennz. Comp. No.	Benennung Designation	Sachnummer Stock No.	Hersteller Bezeichnung Manufacturer Designation	entheiten in contained in
R7S0	RG 33,2 OHM+-1%TK100 1206	RG 0007.5520.00	ROEDERSTEI DC2 33,20HM 1%TK	100
R751	RESISTOR CHIP RG 22,1 OHM+-1%TK100 1206	RG 0007.5489.00	ROEDERSTEI DC2 22,10HM 1%TK	100
R752	RESISTOR CHIP RG 30,1KOHM+-1%TK100 1206	1	ROEDERSTEI DC2 30,1KOHM 1%TH	
R7S3	RESISTOR CHIP RG 7,5KOHM+-1%TK100 1206		ROEDERSTEI DC2 7,50KOHM 1%TH	[
	RG CHIP RESISTOR		·	
R762	RG 5,11KOHM+-1%TK100 1206 CHIP RESISTOR	RG 0007.0729.00	ROEDERSTEI DC2 5,11KOHM 1%TH	(100
R763	RG 4,32KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5814.00	RESISTA DC2 4,32KOHM 1%TK	(100
R764	RG 332 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5650.00	ROEDERSTEI DC2 3320HM 1%TK10	00
R777	RG 15,0 OHM+-1%TK100 1206	RG 0007.5450.00	ROEDERSTEI DC2 15,00HM 1%TK1	100
R780	RESISTOR CHIP RG 1S,OKOHM+-1%TK100 1206	RG 0007.5843.00	ROEDERSTEI DC2 15,0KOHM 1%TK	100
R781	RESISTOR CHIP RG 13,0KOHM+~1%TK100 1206	RG 0007.5837.00	ROEDERSTEI DC2 13,0KOHM 1%TK	100
R782	RESISTOR CHIP RG 1,0M0HM+-1%TK100 1206	RG 081S.7532.00		
	CHIP RESISTOR	l		
R783	RG 20,0K0HM+-1%TK100 1206 RESISTOR CHIP	i i	ROEDERSTEI DC2 20,0KOHM 1%TK	
R784	RG 10,0KOHM+-1%TK100 1206 RG CHIP RESISTOR	RG 0007.0793.00	ROEDERSTEI DC2 10,0KOHM 1%TK	100
R785	RG 221 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5614.00	ROEDERSTEI DC2 2210HM 1%TK10	ю
R786	RG 22,1KOHM+-1%TK100 1206	RG 0007.S872.00	ROEĐERSTEI DC2 22,1KOHM 1%TK	100
R787	RESISTOR CHIP RG 15,0K0HM+-1%TK100 1206	RG 0007.5843.00	ROEDERSTEI DC2 15,0KOHM 1%TK	100
R792	RESISTOR CHIP RG 10,0 OHM+-1%TK100 1206	RG 0006.8649.00	DRALORIC CR(8) 1206	
R793	CHIP -RESISTOR RG 10,0 0HM+-1%TK100 1206	RG 0006.8649.00		
	CHIP -RESISTOR			
R800	RG 100 OHM+-1%TK100 1206 CHIP RESISTOR		ROEDERSTEI OC2 1000HM 1%TK10	0
R802	RG 1,0 KO +-0,1%TK25 1206 SMD-RESISTOR	1	PHILIPS_CO MPC 01	
R803	RG 110,0K0H+-1%TK100 1206 CHIP RESISTOR	RG 0007.1954.00	ROEDERSTEI OC2 110KOHM 1%TK1	00
R804	RG 619 OHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.9074.00	ROEDERSTEI OC2 6190HM 1%TK10	0
R812	RG 988 OHM+-0, 1%TK2S 1206	0010.1981.00	MIKRO-TEK- CMF 1206	
R813		RG 0815.7532.00	DRALORIC CRC 1206	
R820	CHIP RESISTOR RG 1S,0 OHM+-1%TK100 1206	RG 0007.5450.00	ROEDERSTEI DC2 1S,OOHM 1%TK10	00
833 R834	RESISTOR CHIP RG 4,750HM+-1%TK100 1206	RG 0007.8420.00		
837 R840	CHIP-RESISTOR RG 4,75KOHM+-1%TK100 1206	1		100
842	RESISTOR CHIP		ROEOERSTEI DC2 4,75KOHM 1%TK	100
R843	RG 3,32KOH+-O,1%TK2S 1206 SMD-RESISTOR EIA1206	0009.7772.00	WIKRO-TEK+ CMF 1206	
R843	NUR VAR/ONLY MOD: 02 43 RL 0,35W2,34KOHM+~0,1%T25	RL 0083.9852.00	DRALORIC SMAO207/2,34K-8-E	
	RESISTOR NUR VAR/ONLY MOD: 04			
R844	RG 681 OHM+-1%TK100 1206	RG 0006.9080.00	ROEDERSTEI DC2 6810HM 1%TK10	o
R845	CHIP RESISTOR RG 82S OHM+-1%TK100 1206	RG 0006.7259.00	ROEDERSTEI DC2 8250HM 1%TK10	0
R846	CHIP RESISTOR RG 2,21KOHM+-1%TK100 1206	i	ROEDERSTEI DC2 2,21KOHM 1%TK	
R847	RESISTOR CHIP	RG 0006.8649.00		
	CHIP -RESISTOR			
R848	RG 1,0 KO +-0,1%TK25 1206 SMD-RESISTOR	_	PHILIPS_CO MPC 01	
R849	RG 1,82KOH+-O,1%TK25 12O6 SMD~RESISTOR	•	MIKRO-TEK- CMF 1206	
R850		RG 0006.8855.00	ROEDERSTEI DC2 75,00HM	
R851	RG_3,32KOHM+-1%TK100 1206	RG 0007.5789.00	ROEDERSTEI DC2 3,32KOHM 1%TK	100
R853	RESISTOR CHIP RG 27,4KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5895.00	ROEDERSTEI DC2 27,4KOHM 1%TK	100
MENP5	413 3PUA ÄI Detum Date	Schaftlelills Parts list		
�	31 16.09.97	EE SYNTHESIZER	1062.6409	.01 SA 19+

SYNTHESIZER

Kennz, Comp. No.	Benannung Dasignation	Sachnummer Stock No.	Herstellar Manufacturar	Bazeichnung Designation	enthaitan in containad in
R857	RG 4,75KOHM+-1%TK100 1206	RG 0007.5820.00	ROEDERSTEI	DC2 4,75KOHM 1%TK100	
R860	RESISTOR CHIP RG 200 OHM+-1%TK100 1206	RG 0007.5608.00	ROEDERSTEI	DC2 2000HM 1%TK 100	
R861	RESISTOR CHIP RG 29,1KOH+-0,1%TK25 1206	0010.4109.00	MIKRO-TEK-	CMF 1206	
•	RESISTOR NUR VAR/ONLY MOD: 02 43				
R861	RL 0,35W28,0K0HM+-0,1%T25	RL 0084.3929.00	RESISTA	MK2	
0000	RESISTOR NUR VAR/ONLY MOD: 04				
R862	RG 118 OHM+-0,1%TK25 1206 RESISTOR	0010.3977.00	MIKRO-TEK-	CMF 1206	
R862	NUR VAR/ONLY MOD: 02 43 RL 0,35W169 OHM+-0,1%TK25	RL 0083.7666.00	RESISTA	MK2	
	RESISTOR NUR VAR/ONLY MOD: 04			_	
R863	RG 2,94KOH+-0,1%TK25 1206	0010.4038.00	MIKRO-TEK-	CMF 1206	
DOOG	RESISTOR NUR VAR/ONLY MOD: 02 43				
R863	RL 0,35W4,17KOHM+-0,1%T25 RESISTOR	RL 0084.2339.00	RESISTA	MK2	
R864	NUR VAR/ONLY MOD: 04 RG 2,74KOHM+-1%TK100 1206	RG 0007.5766.00	ROEDERSTET	DC2 2,74KOHM 1%TK100	
R865	RESISTOR CHIP RG 10,0 OHM+-1%TK100 1206	RG 0006.8649.00		CR(B) 1206	
R866	CHIP -RESISTOR				
	RG 10,0 0HM+-1%TK100 1206 CHIP -RESISTOR	RG 0006.8649.00		CR(8) 1206	
R870	RG 4,75KOHM+-1%TK100 1206 RESISTOR CHIP	1		DC2 4,75KOHM 1%TK100	
R871	RG 274 KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.4460.00	ROEDERSTEI	DC2 274KOHM 1%TK100	
R872	RG 4,75KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5820.00	ROEDERSTEI	DC2 4,75KOHM 1%TK100	
R873	RG 274 KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.4460.00	ROEOERSTEI	OC2 274KOHM 1%TK100	
R874	RG 475 OHM+-1%TK 100 1206	RG 0007.5695.00	ROEDERSTEI	DC2 4750HM 1%TK 100	
R875	RESISTOR CHIP RG 475 OHM+-1%TK100 1206	RG 0007.5695.00	ROEDERSTEI	OC2 4750HM 1%TK100	
R880	RESISTOR CHIP RG 47,5 OHM+-1%TK100 1206	1		DC2 47,50HM 1%TK100	
R881	RESISTOR CHIP RG 475 OHM+-1%TK100 1206			OC2 4750HM 1%TK100	
R882	RESISTOR CHIP RG 47,5 OHM+-1%TK100 1206			OC2 47,50HM 1%TK100	
R883	RESISTOR CHIP RG 475 OHM+-1%TK100 1206			DC2 47,50HM 1%TK100	
	RESISTOR CHIP				
R884	RG 10,0 0HM+-1%TK100 1206 CHIP -RESISTOR			CR(8) 1206	
R885	RG 47,5 OHM+-1%TK100 1206 RESISTOR CHIP			DC2 47,50HM 1%TK100	
R930	RS 0,25W 1KOHM +-20% SMO RG POTENTIOMETER	RS 0007.9610.00	BOURNS	3314G-1-102	
R931	RG 9,09K0HM+-1%TK100 1206 CHIP RESISTOR	RG 0007.0787.00	ROEOERSTEI	DC2 9,09KOHM 1%TK100	
R932	RG 7,5KOHM+-1%TK100 1206 RG CHIP RESISTOR	RG 0007.0764.00	ROEDERSTEI	DC2 7,50KOHM 1%TK100	
R933	RG 7,5KOHM+-1%TK100 1206	RG 0007.0764.00	ROEDERSTEI	DC2 7,50KOHM 1%TK100	
R938	RG CHIP RESISTOR RG 51, 1KOHM+-1%TK100 1206	RG 0007.1877.00	ROEDERSTEI	DC2 51,1KOHM 1%TK100	
R939	CHIP RESISTOR RK SMD-HEISSL.22K 1206	0008.9220.00	SIEMENS	857621-C223-J	
R940	SMD-NTC-RESISTOR RG 1,21KOHM+-1%TK100 1206	i		DC2 1,21KOHM 1%TK100	
R943	CHIP RESISTOR RG 1,0 KO +-1%TK100 1206	1		DC2 1, OKOHM 1%TK100	
R949	CHIP RESISTOR RG 4,75KOHM+-1%TK100 1206			DC2 4,75KOHM 1%TK100	
R950	RESISTOR CHIP RG 2,74K0HM+-1%TK100 1206	1			
	RESISTOR CHIP	-		DC2 2,74K0HM 1%TK100	
R951	RG 1,21KOHM+-1%TK100 1206 CHIP RESISTOR			DC2 1,21KOHM 1%TK100	
R952	RG 5,11KOHM+-1%TK100 1206 CHIP RESISTOR	ļ		DC2 5,11KOHM 1%TK100	
R953	RG 5,62KOHM+-1%TK100 1206 CHIP RESISTOR	RG 0007.0735.00	ROEDERSTEI	DC2 5,62KOHM 1%TK100	
MENP5	413 3PUA Äi Detum	Schaltteilli Parts list		Sachnummer Stock No.	Siett-N Page
<b>®</b> <b>POH</b> DI	31 16.09.97			1062.6409.01	
ועמטט	- QJUNYARZ	SYNTHESIZER			

Kennz. Comp. No.	Benennung Dasignation			Sachnummer Stock No.	Harsteller Manufacturer	Bezeichnung Dasignation		haltan in Italned in
R954	RG 9,09K0HM+-1%T	K100 1206	RG		<del></del>	DC2 9,09KDHM 1%TK100	1	
R955	CHIP RESISTOR RG 39,2KDHM+-1%T RESISTOR CHIP	K100 1206	i i			DC2 39,2KOHM 1%TK100		
R956	RG 475 OHM+-1%TK	100 1206	RG	0007.5695.00	ROEDERSTEI	DC2 4750HM 1%TK100		
R957	RESISTOR CHIP RG 4,75KOHM+-1%T RESISTOR CHIP	K100 1206	RG	0007.5820.00	ROEDERSTEI	DC2 4,75KDHM 1%TK100		
R95B	RG 4,75KOHM+-1%T	K100 1206	RG	0007.5820.00	ROEDERSTEI	DC2 4,75KOHM 1%TK100		
R960	RESISTOR CHIP RG 379 OHM+-0,1% RESISTOR	TK25 1206		0010.4009.00	MIKRO-TEK-	CMF 1206		
R961	RG 154 OHM+-0,1%	TK25 1206		0010.3983.00	MIKRD-TEK-	CMF 1206		
R962	RG 1,82KOHM+-1%TI RESISTDR CHIP NICHT BESTUECKT	K100 1206	RG	0007.5720.00	ROEDERSTEI	DC2 1,82KDHM 1%TK100		
R963	NOT FITTED RG 234 OHM+-0,1%	TK25 1206		0010.3990.00	MIKRD-TEK-	CMF 1206		
968 R969	RESISTOR RG 1040HM+-0,1%TH			0009.8910.00	PHILIPS_CO	MPC 01		
973 R974	SMD-RESISTOR EIA	TK25 1206		0009.8779.00	MIKRD-TEK-	CMF 1206		
R975	SMD-RESISTDR EIA: RG 156 OHM+-0,1%1		1	0009.8779.00				
R9B0	SMD-RESISTOR EIA1 RG 47,5 OHM+-1%TK		ļ		ŀ	DC2 47,50HM 1%TK100		
R9B6	RESISTOR CHIP RG 10.0 OHM+-1%TK			0006.8649.00		CR(B) 1206		
R9B7	CHIP -RESISTOR RG 4,750HM+-1%TK1			0007.8420.00		RC 02		111
R990	CHIP-RESISTOR RG 4,75KOHM+-1%TK	- 1				DC2 4,75KOHM 1%TK100		
R991	RESISTOR CHIP RG 15,OKDHM+-1%TK		0			0C2 15,0K0HM 1%TK100		
R993	RESISTOR CHIP RG 22.1 OHM+-1%TK					DC2 22,10HM 1%TK100		
R994	RESISTOR CHIP RG 2,21KOHM+-1%TK					0C2 2,21K0HM 1%TK100		
R995	RESISTOR CHIP RG 3,32KOHM+-1%TK					OC2 3,32KOHM 1%TK100		
R996	RESISTOR CHIP RG 4.75KOHM+-1%TK					DC2 4,75KOHM 1%TK100		
1/00	RESISTOR CHIP							
V20	AK 8CP68-16 N 20 TRANSISTOR BCP68			0008.2019.00		8CP68-25		
V110	AD BAS32 75V OIODE			0006.7288.00		BAS32 (L)		
V120 V200	ZENER OIOOE					BZV55B5V1 (GEG)		
V200	AK BCB6OB P 45 TRANSISTOR NUR VAR/ONLY MDD:		AK (	0007.7975.00	MOTOROLA i	BC860B		
V200	AK BCX17 P 45 TRANSISTOR	V 500MA	AK (	0007.2080.00	PHILIPS E	3CX17		
V205		04 V 30MA	C	0350.9985.00	PHILIPS E	3FS19		
V2 10		V 100MA	AK C	0007.3434.00	PHILIPS E	3SV52		
V212		CHOTTKY	AE C	0836.8421.00	HEWLETT_PA H	HSMS-2800		
V215		V 30MA	C	0350.9985.00	PHILIPS E	BFS 19		
V216		V 100MA	AK C	0007.3434.00	PHILIPS E	3SV52		
V220		СНОТТКҮ	AE C	0836.B421.00	HEWLETT_PA H	ISMS-2B00		
V235	DIODE AE BAT18 BER.SCH	.DI.VHF	C	0820.3260.00	VALVD E	BAT 1B		
V240	DIODE AD BAS32 75V	ומט ו	AD C	0006.7288.00	PHILIPS E	BAS32 (L)		
V245		.5W ZDI	AE C	0006.9845.00	PHILIPS E	3ZV55B5V6		ľ
V247	ZENER DIODE AD BAV7O 7OV DUAL DIODE COMMON	DUD UDI CATHDDE	c	0007.9278.00	PHILIPS E	8AV70		
MENP5	413 3PUA Ä	Datum		Schafttalille		Sachnummer		Blatt-Nr.
		Date		Parts list	TOT	Stock No.		Page
ROHDE	E&SCHWARZ 31	16.09.97	EE	SYNTHESIZER		1062.6409.01	SA	21+

SYNTHESIZER

095.0026-0693

Kennz. Comp. No.	Banennung Designation	Sachnummer Hersteller Stock No. Manufacturer	Bezeichnung Designation	inthelten in contained in
V255	AD BAV70 70V DUO UDI	0007.927B.00 PHILIPS	BAV70	
V260	DUAL DIODE COMMON CATHODE AE BZV55/10V O,5W ZDI	AE 0006.9BB0.00 PHILIPS_SE	BZV55C10	
V265	ZENER DIODE AE HSMS2BOO SCHOTTKY	AE 0836.B421.00 HEWLETT_PA	į	
v300	DIODE AE BB535 1B,7/2,1P CDI	1039.3107.00 SIEMENS	BB535/Q62702-B651	
V305	TUNING DIODE AK NEB5639 N 12V 100MA	1027.4161.00 NEC	2SC4093 T1	
V3 10	TRANSISTOR AK BCB60B P 45V 200MA	AK 0007.7975.00 MOTOROLA	ВСВ60В	
V330	TRANSISTOR AM CF739 10V DG MESF	4017.0604.00 SIEMENS	CF739 E7B45	
V340	DUAL-GATE GAAS MESFET AK BCB60B P 45V 200MA	AK 0007.7975.00 MOTOROLA	всв6ов	
V345	TRANSISTOR AK BCB50B N 45V 200MA	AK 0007.7969.00 VALVO	всв5ов	
V347	TRANSISTOR AE HSMS2B10 SCHOTTKY	0520.7340.00 HEWLETT_PA	HSMS2B10	
V370	DIODE AK BSV52 N 12V 100MA	AK 0007.3434.00 PHILIPS	BSV52	
V400	TRANSISTOR AE BB535 1B,7/2,1P CDI	1039.3107.00 SIEMENS	BB535/Q62702-B651	
403 V404	TUNING DIODE AK BFG540X N 15V 120MA	1062.6496.00 PHILIPS	BFG540/X	
V406	TRANSISTOR AK BCX19 N 45V 500MA	6014.2567.00 PHILIPS_SE	BCX19	
V40B	TRANSISTOR AK BCB50B N 45V 200MA TRANSISTOR	AK 0007.7969.00 VALVO	BCB50B	
V410	AK BCB60B P 45V 200MA TRANSISTOR	AK 0007.7975.00 MOTOROLA	ВСВ6ОВ	
V42B	AE BB535 18,7/2,1P CDI TUNING DIODE	1039.3107.00 SIEMENS	BB535/Q62702-B651	
V429	NUR VAR/ONLY MOD: 43 AE BB535 18,7/2,1P CDI	1039.3 107.00 SIEMENS	BB535/062702-B651	
. ,20	TUNING DIODE NUR VAR/ONLY MOD: 43	JOSEPH STERNERS	BB535/Q62702-B651	
V430 431	AE BB535 18,7/2,1P CDI TUNING OLODE	1039.3107.00 SIEMENS	BB535/Q62702-B651	
V432	AE BB535 18,7/2,1P CDI TUNING DIODE	1039.3107.00 SIEMENS	BB535/Q62702-B651	
V433	AE BB535 18,7/2,1P CDI TUNING OIODE	1039.3107.00 SIEMENS	BB535/Q62702-B651	
V434	NUR VAR/ONLY MOD: 02 AK BFG540X N 15V 120MA	1062.6496.00 PHILIPS	BFG540/X	
V436	TRANSISTOR AK BCX19 N 45V 500MA	6014.2567.00 PHILIPS_SE	BCX19	
V43B	TRANSISTOR AK BCB50B N 45V 200MA	AK 0007.7969.00 VALVO	BC850B	
V440	TRANSISTOR AK BCB60B P 45V 200MA	AK 0007.7975.00 MOTOROLA	всв6ов	
V4BO	TRANSISTOR AK BCB60B P 45V 200MA TRANSISTOR	AK 0007.7975.00 MOTORDLA	всв60в	
V490	AE BAR64 PIN PIN DIODE	1039.3059.00 SIEMENS	BAR64 (Q62702A1041)	
V492	AE BAR64 PIN PIN DIODE	1039.3059.00 SIEMENS	BAR64 (Q62702A1041)	
V500 502	AE BAR64 PIN PIN DIODE	1039.3059.00 SIEMENS	BAR64 (Q62702A1041)	
V510	AK BCB60B P 45V 200MA TRANSISTOR	AK 0007.7975.00 MOTOROLA	ВСВ6ОВ	
V520	AK BCB60B P 45V 200MA TRANSISTDR	AK 0007.7975.00 MOTOROLA	ВСВ6ОВ	
V532	AE BAR64 PIN PIN DIODE	1039.3059.00 SIEMENS	BAR64 (Q62702A1041)	
V550	AE BAR64 PIN PIN DIODE	1039.3059.00 SIEMENS	BAR64 (Q62702A1041)	
V551	AE BAR64 PIN PIN DIODE	1039.3059.00 SIEMENS	BAR64 (Q62702A1041)	
V553	AE BAR64 PIN PIN DIODE	1039.3059.00 SIEMENS	BAR64 (Q62702A1041)	
V555	AE HSMS2B10 SCHOTTKY DIODE	D520.7340.00 HEWLETT_PA	HSMS2B10	
V600	AK BFQB1 N 16V 30MA TRANSISTOR	0920.1717.00 SIEMENS	Q62702-F1049	
MENP5	413 3PUA ÄI Datum Date	Scheitteilliste für Parts ilst for	Sachnummer Stock No.	Blett-Nr. Page
<b>∮</b>	31 16.09.97	FF CVNTHECTZED	1062.6409.01 SA	
RÖHDE	E&SCHWARZ	EE SYNTHESIZER	1002.0403.01 3	22+
		SYNTHESIZER		

Kønnz, Comp. No.	gener Desig	nung natio	n		Sachnummer Stock No.	Hersteller Manufacturer		gezelchnung Designetion		heiten In Iteined In
V695	AK BCP6B-16 N	2	OV TRANS		0008.2019.00		B	CP6B-25		
V696	TRANSISTOR BO AE 1N827 REFERENCE DIO	6,	2V REFDI	AE	0418.0029.00	COMPENSATI	E 11	1827(A)		
V700	AD BAV70	70	V DUO UDI		0007.9278.00	PHILIPS	ВА	AV70		
V719	DUAL DIODE CO AE BZV55/C4V7 ZENER DIODE		O.5W ZDI	AE	0006.9B22.00	PHILIPS	BZ	ZV55B4V7		
V750		45	V 500MA		6014.2567.00	PHILIPS_SE	Е ВС	CX 19	ŧ	
V755	AK BCX17 P	4	5V 500MA	AK	0007.2080.00	PHILIPS	ВС	X17		
V757	AD BAS32 DIODE	75	V IOU	AD	0006.728B.00	PHILIPS	ВА	S32 (L)		
V765 76B	AD BAV99 DIODE	70	V DUO UDI	AD	0911.0092.00	VALVO	ВА	.V99		
V780		-Е	100V MOSF		0815.7961.00	SIEMENS	BS	S 123 E-6327		
V781	AD BAS32 DIODE	75	V UDI	AD	0006.7288.00	PHILIPS	ВА	S32 (L)		
V7B7	AE BZV55/C5V1 ZENER DIODE	(	D.5W ZDI	AE	0006.9B39.00	PHILIPS_SE	BZ	V55B5V1 (GEG)		
V800	AD BAV99 DIODE	70	V DUO UDI	AD	0911.0092.00	VALVO	BA	V99		
V902	AD BAS32 DIODE	75	V UDI	AD	0006.7288.00	PHILIPS	BA	S32 (L)		
V946	AD BAV99 DIODE	70\	ומט סטמ /	ŀ	0911.0092.00	1	BA	V99		
V947	AD BAV99 DIODE	70\	/ DUO UDI	AD	0911.0092.00	VALVO	BA	V99		
V951	AD BAV99 DIODE		/ DUO UDI	ļ	0911.0092.00		BA	V99		
V952	AD BAV99 DIODE		/ DUO UDI		0911.0092.00		8A'	V99		
V955	AK BC860B P TRANSISTOR		SV 200MA	AK	0007.7975.00		8CI	860B		
V960	JEET TRANSISTO		25V JFET		6007.3949.00			T108		
V961	AE 8ZV55/C5V1 ZENER DIODE	C	0.5W ZDI	AE	0006.9839.00	PHILIPS_SE	8Z\	/55B5V1 (GEG)		
X1	FP STECKERLEIS	TE	32POL.	FP	0008.5718.00	SIEMENS	V42	2254-81200-B611		
X20	CONNECTOR 32P. FP STIFTLEISTE PIN CONNECTOR	36	P.R2,54	FΡ	0242.3600.00	BINDER	742	2-11-0179-00-36		
X75	3-POLIG FP STIFTLEISTE PIN CONNECTOR 3-POLIG	36	P.R2,54	<b>F</b> P	0242.3600.00	BINDER	742	2-11-0179-00-36		
X8O	FP STIFTLEISTE PIN CONNECTOR 3-POLIG	36	P.R2,54	FP	0242.3600.00	BINDER	742	2-11-0179-00-36		
X84	FP STIFTLEISTE PIN CONNECTOR 3-POLIG	36	P.R2,54	FP	0242.3600.00	BINDER	742	2-11-0179-00-36		
X124	FJ EINBAUWINKE ANGLE CONNECTO	LST R	. SMC	FJ	0249.9684.00	ROSENBERGE	398	-205-400 <b>-</b> D3		
X125	FJ EINBAUWINKE ANGLE CONNECTO	LST R		FJ	0249.9684.00	ROSENBERGE	398	-205-400-D3		
X127	FJ EINBAUSTECK	ER I		FJ (	0602.8804.00	IMS	81.	1524.201		
X12B	FJ EINBAUSTECK	ER R	1	FJ (	0602.8804.00	IMS	81.	1524.201		
X300	ER KERAMIK RESORTER		TOR 700M		1062.6421.00	SIEMĖNS	B69	610-G7006-A612		
Z1 14	LD SMD-T-FILTER	R 3	,3NF		1039.1362.00	MURATA	NFM	61R2OT332T1		
Z102	SMD-FILTER LD SMD-T-FILTER SMD-FILTER	R 16	DOPF		1039.1356.00	MURATA	NFM	61R00T101T1		
Z104	LD SMD-T-FILTER SMD-FILTER	R 16	OOPF		1039.1356.00	MURATA	NFM	61R00T101T1		İ
Z106	LD SMD-T-FILTER SMD-FILTER	R 10	OOPF		1039.1356.00	MURATA	NFM	61R00T101T1		
Z1OB	LD SMD-T-FILTER SMD-FILTER	₹ 16	DOPF		1039 . 1356 . 00	MURATA	NFM	61R00T101T1		
Z110	LD SMD-T-FILTER	₹ 10	DOPF		1039.1356.00	MURATA	NFM	61R00T101T1		
MENP5	413 3PUA	Äi	Datum Date		Schaltteillis Perts list			Sachnummer Stock No.		9latt-Nr. Pege
ROHDE	&SCHWARZ	31	16.09.97	E	SYNTHESIZER	,		1062.6409.01	SA	23+

SYNTHESIZER

095.0026-0693

j	Kennz. Comp. No.		Bananr Designa	ung ation		Sachn Stor	ummar k No.	Hersteller Manufacturar	Bazai Đesis	chnung ination		anth: conta	ilten in lined in
	Z180	LD SMD SMD-FI	-T-FILTE		OOPF		1356.00			ROOT 101T1			
	Z202		-T-FILTE	R 3	,3NF	l	1362.00		NFM61	R20T332T1			
	2800	SMD-T-	-T-FILTE FILTER 3	3PF		ļ	6744.00		NFM61	ROOT330			
	Z801	SMD-T-	-T-FILTE FILTER 3	13PF		Į.	6744.00			ROOT330			
	Z880	SMD-FI					1356.00			ROOT 10 1T 1	1		
	Z882	LD SMD- SMD-FI	-T-FILTE LTER	R 1	OOPF	1039	1356.00	MURATA	NFM61	ROOT 101T1			
	MENP5	413	ЗРИА	Āt	Datum Date		Schalttailli Parts Ksi				nnummar ock No.		Biatt-Nr. Page
		E&SCH			16.09.97	EE SYN	THESIZER		1	062.64		SA	24-



## XY-Liste

# **XY List**

## Erklärung der Spaltenbezeichnungen:

Part: Bauelement-Kennzeichen.

Leiterplatten-Seite, auf der sich das Bauelement befindet. Side: \_\_

Koordinaten (Millimeter) des Bauelementes auf der Leiterplatte X/Y:

bezogen auf den Nullpunkt.

SQR, PG: Planquadrat und Seite des Schaltbildes für das jeweilige Bauelement.

#### Explanation of column designations:

Part: Identification of instrument part.

Side of the PC board on which instrument part is positioned. Side:

Coordinates (millimeter) of the component on the PC board in reference X/Y:

to zero point.

SQR, PG: Square and page of the diagram for the respective instrument part.

! <b>+</b>		Serv	ice	-Re	leva	nte Bat	ıtei	le /	Ser	vice	-Rel	evant (	Comp	onen	ts	
Part S	Side	<b>-</b> - Х	Y	Sqr	Pg	Part	Sid	e X	Y	Sqr	Pg	Part	Sid	е Х	Y	Sq
L346	В 2	50	20	8E	3	P600	В	161	107	7E	6	X20	В	270	123	12
P20	В	78	20	4B	9	P610	В	229	119	11E	6	X75	В	71	137	10
P21	В	88	30	6B	9	P700		199		5D		X80	В	168	45	2
P201	B 2		44	4E	2			144		7D		X84	В	78	71	9
P202	B 2		64	7E	2	•										
						P840		164	69			X124	В	19		
P203	B 2			10E	2	R930		119		8C	8	X125	В		15	11
P204	B 2		72	8C	2	X1A	В	189	11	1E	8	X127	В	283	15	11
P354 +	В 2	62	46 	10C	3	X1D	В	189	11			X128	В	296	15	11
+   Ni	cht-	Serv	 ice	 -Rel	 Leva	nte Bau		 le /	Non	Ser	 vice	 -Pelevs	nt (	Omn		
+						+						t				
FALC 5		<u> </u>			-g 	Part +	210	=	1 	5qr	-Pg	Part 	S106	• X	Y 	Sq
B360	B 2.	53 .	50	7B	3	C230	Α	297	96	10E	2	C361	Α	257	51	80
C1	B 1	L2 :	24	2D	9	C232	В	273	16	2D	2	C370		252	44	8]
C2	B 1		23	2C	9	C234		296	21	2D	2	C373		262	36	90
C3	B 14		24	2C	9	C235		296	27	2D	2	C400				
C4	B 10		22	2B	9	C235							A		138	11
C5	B 14		22 17	2B		C236		299	81	3C	2	C402	В		141	11
					9	,		276	17	5C	2	C404	Α		114	21
C20			22	3B	9	C245		286	80	8E	2	C406	В		112	21
C21			L7	4B	9	C250		276			2	C408	В	24	115	21
C25			L6	5B	9	C252	В	286	137	11D	2	C410	В	19	105	31
C26	A 6	30 2	27	6B	9	C254	Α	291	123	11C	2	C412	В		104	31
C27	A 8	0 3	31	6B	9	C255		293			2	C414	В	23	95	31
C30	A 10		į 5	4E	9	C256		273			2	C416	A			30
C31	A 1.		3	4E	9	C258		270			2	C418				
C32	B 24		71	6E	9	C250		279					A		125	21
C32	A 15					•					2	C425	A	18	86	30
			37	6D	9	C261		283			2	C430	A		133	5E
C34	A 7		39	6C	9	C286		282			2	C432	В		136	5E
C35	A 12		50	3D	9	C300		2.53		2E	3	C434	Α	40	113	6E
C36	A 27		36	7E	9	C302	В	259	110	2E	3	C436	В	49	112	6E
C100	A 19	5 6	9	4A	9	C304	В	255	105	2E	3 j	C438	В		115	6E
C110	B 20	0 5	9 :	LOB	9	C306	В	250	98	3D	з і	C440	В		105	70
C120	A 19	5 5	54	3A	9	C308		254				C442	В			71
C200	A 28		1	5A	2	C310		262	91	3D	3	C444	В	48		70
C202	A 28		7	2E	2	C312		245							95	
C204	A 29		9			•			90	3C	3	C446	A		100	70
				2E	2	C314		259	89	3C	3	C448	Α		125	5D
C205	A 29		:0	2E	2	C316		254	88	4D	3	C455	Α	44	88	70
C206	A 30		6	3E	2	C320		258	74	4 E	3	C490	Α	58	77	4 B
C208	B 29		2	3E	2	C324	В	254	75	5D	3	C491	Α	47	79	4 B
C210	A 29	4 6	9	6A	2	C331	В	254	56	5D	3 j	C492	В	37	95	9D
C214	A 27		2	6E	2	C335		246	51	7D	3	C493	В	37	82	9D
C217	B 27		1	5D	2	C336		246	27	8D	3	C494	A	27	81	9E
C218	B 27		8	6D	2	C338		243	32							
C218	B 28									7E	3	C500	В	37	75	1D
			9	6D	2	C342		259	27	9E	3	C501	В	37	62	2D
C220	A 29		9	7A	2	C344		258	24	9E	3	C502	A	28	66	2D
C221	A 29		9	7A	2	C345		250	32	7F	3	C505	Α	55	67	1F
C222	A 27		5	6C	2	C346	В	247	20	8E	3	C506	Α	12	58	2F
C224	A 26	9 7	4	7C	2	C347	В	252	15	9D	з ј	C507	A	31	46	2B
C225	A 27	1 4	2	7C	2	C348		247	13		3	C510	В	29	55	3E
	A 27		1	7C	2	C349		247	17		3	C511	A	18	48	3E
C228	A 27		4	7C	2	C360		259		7B	3	C512	A	18	55	3E
<del></del> -	⊦   ÄI		+  Da	tum	+ 			 XY-	 List	e fü	+ r	Sach-l	Vumme	 er		-+-  B
ROHDE				te	j				list			Stock				P
			ナーー		1						+					-+-
& +			i			DD 01111	171	*						<b>-</b>		- :
				.04		EE SYNT		IZER IZER			Ì	1062.6				Ĺ



	Side X	Y S	Sqr Pg	-+   Part	Side X	Y	Sqr	Pg	+   Part Side X	 У	Sqr	Pg	+
C513	A 19	 42	4E 5	-+   C719	A 168	138	7B	 7	+		10D		+
C514	B 18	42	4E 5		B 167		7D	7	C954 A 8			8 8	-
C515	A 12	35	4E 5		B 156		7D	7	C959 A 13		12C	8	ł
C516	B 18	29	5E 5	C722	A 160		7 D	7	C960 B 7		10E	8	i
C517	B 25	25	5E 5	•	B 149		7C	7	C962 A 9	3 47	5D	8	İ
C520	B 37		4C 5	C750	B 142		8D	7	C980 A 14		12B	8	
C521 C522	A 46		4C 5	C753		138		- 7	C989 A 10			8	
C523	A 40 A 56		4C 5 4C 5	C760	B 106		9D	7	•			8	!
C524	B 53		4C 5	C765	B 82 B 86	132	9C 9C	7 7	C995 A 9:   D20 B 7:			8 9	
C525	A 61		5D 5	C779		139		7	D65A B 19			6	! !
C526	B 49		5C 5		A 130		8B	7	D110-A B 224			9	ł
C527	B 46		6C 5		A 133		8B	7	D110-B		4A	9	¦
C530	A 31	43	5D 5	C782	A 116		10C	7	D115-A B 220	55	8E	9	İ
C532	B 25		5D 5	C784	A 101			7	D115-B		5A	9	j
C550	B 42		9C 5		A 107			7		62	3D	9	1
C551	B 27	18 1		C787	A 184		5B	7	D125-B		8E	9	!
C552 C553	A 20 A 12	20 1 23 1		C788   C789	A 244		3B	7	D125-C		10B	9	ļ
C555	B 24	12 1		C789	A 252 A 252		3B 3B	7 7	D125-D   D125-E		10B	9	!
C556	A 41	11 1		C791	A 252		3B	7	D123-E   D200-A B 283	3 39	5A 6D	9	1
C557	A 52	11 1		•	A 201		6B	7	D200-R B 28.	כנ .	5E	2	i
C570	A 34	39	8D 5	C793	A 220		5B	7	D200-C		5D	2	İ
C571	A 61		8D 5	C800	A 175	59	3F	8	D200-D		6E	2	ĺ
C580	A 55	13 1		C830	B 182	48	2E	8	D200-E		5A	2	ĺ
C600	B 70		2E 6	C840	B 109	72	8E	8	D205-A B 283	67	5E	2	
C601 C602	B 73 A 68		2E 6 2E 6	C841   C842	A 116	69	7F	8	D205-B		8C	2	
C604	B 146		6E 6	C843	A 127 A 177	64 70	6F 5F	8	D205-C		5A	2	
C605	B 79		3E 6	C844	A 128	73	6F	8	D210-A B 297 D210-B	67	7E 7D	2	<u> </u> 
C610	A 91		3E 6	C845	A 167	68	5F	8	D210-B		6A	2	; i
C615	B 97	114 4	4E 6	C846	B 124	62	6E	8	D215-A B 279	87	9E	2	, !
C616	B 110		4E 6	C850	A 126	59	6E	8	D215-B		6A	2	ı
C620	A 124		4E 6	C860	B 233	40	3C	8	D220 B 288		2C	2	
C621 C625	A 119		4B 6	C861	B 231	32	3C	8	D255-A B 291	135	10D	2	
C630	B 118 . A 141		5E 6	C862	A 233		4C	8			10C	2	
C631	A 135		4B 6	C865 C866	A 230 A 210	36 33	5B 5Λ	8   8	D255-C D510 B 23	5.0	10B	2	
C633	B 132		6E 6	C870	A 218	17	5C	8	D510 B 23 D520 B 43		3E 4C	5	
2640	A 151		6 B	C871	A 225	20	5B	8	D585-A A 46		11F	5	
C645	A 166		3B 6	C884	A 216	28	5B	8 İ	D585-B		11B	5	
C650	A 166			C885	A 224	15	5B	8 j	D620-A B 116	114	4 E	6	
2655	A 225		5B 6	C890	B 95	62	4B	8	D620-B		4B	6	
0661 0662	A 181 A 173	86 10		C891	B 93	70	5A	8	D630-A B 132	114		6	
2690	A 175 .		7E 6 9F 6	:	B 171 B 168	60 53	3B 3A	8	D630-B	100	4B	6	
691	A 185		9F 6	C911	A 150	55 60	5F	8   8	D640-A B 170 D640-B	TOR	7E 1B	6	
3692	A 197		9F 6	C913		62	5F	8	D640-C		5B	6	
2693	A 209	99 9	9F 6	C940		96	8D	8	D640-D		7B	6	
2698	A 167		5C 6	C941	A 91 1		9C	8	D640-E		3B	6	
2701	B 232		D 7	C942		99	9C	8 j	D655-A B 223	116	11E	6	
2702	A 232		4C 7	C949		83	9D	8	D655-B		6B	6	
0705 0710	B 259 1 A 204 1		2B 7	C950		83	8D	8			5B	6	
5710 5712	A 212 1			C951   C952	B 88 1 A 105 1				D660-A B 232	85			
	+			U9J2 	I	.00	90	O	D660-B		2B	,	
	ÄI	Dat	um	. == <b>==</b> . 	XY-L	iste	für	7 - 1	Sach-Nummer		-+  B1a	<del> </del>	
ROHDE	j		:e	İ					Stock-Nr		Pag		
&	+	+		+				+	**		-+	+	
CHWAR 2		ļ		EE SYNT	HESI 2ER			-					
	1 (	04105.	04.95	SYNT	HTCT7TD			- 1	1062.6409.01	3737	1 .	2+ İ	

Part S	id	le X	Y	Sqr	Pg	Part S	Sid	le X	Y	Sqr	Pg	Part S	Sid	le X	Y	Sqr	Pg
D665-A		232	97		6	L29		252			9	N220-A		297	83	3C	2
D665-B				2B	6	L33		154			9	N220-E				4C	2
D670-A		152	90		6	L35		121			9	N220-C	;			9E	2
D670-E				3B	6	L200		277			2	N220-D	)			8E	2
D700-A		246	139		7	L202		278			2	N220-E				7A	
D700-B				3C	7	L204		286			2	N250-A		283	127		
D700-C				3B	7	L227		269			2	N250-B				11B	2
D710-A		91	131		7	L300	В		115		3	N300	В				3
D710-B		100		6B	7	L302	В		102		3	N490	В				4
D720-A		180	135		7	L306	В	_	74		3	N500	В				5
D720-B		156		5B	7	L400	В		138		4	N510	В				5
D800-A D800-B		130	66	6 4E 4E	8 8	L402   L404	B B		112		4	N520	В				5
D800-B				4E 4D	8	L404	В		121		4	N560	В				5
D800-D				4D 4E	8	L400	В		109 133		4	N600	В		97		6
D800-E				2B	8	L430	В		112		4 4	N610   N705	В		114		6 7
D820-A		181	52		8	L434	В		121		4	N705   N710-A		255		2B 5D	7
D820-B	_		-	2B	8	L436	В				4	N710-R   N710-B		212	133	5B	7
D840	В	103	70		8	L492	В		99		4	N710-B   N720-A		166	125	эв 7D	7
D855-A			55		8	L494	В		82		4	N720-A   N720-B	מ	T00	TOO	7D 7B	7
D855-B				2B	8	L500	В	43	59		5	N780-A	Δ	125	127	8B	7
D870-A	В	225	14		8	L502	В	31	62		5	N780-R		163	137	9B	7
D870-B				5C	8	L505	В	52	57	2F	5	N780-C				6B	7
D870-C				5A	8	L506	В	26	58	2E	5	N800-A	R	181	58	3F	8
D950-A	В	131	99	11D	8	L507	В	33	51	2C	5	N800-B	-			3B	8
D950-B				11D	8	L515	В	12	29	4E	5	N840-A	В	89	64	8E	8
D950-C				12B	8	L516	В	15	21	5E	5	N840-B	_	-	- ,	4B	8
D960-A	В	90	53	9F	8	L525	В	56	34	5C	5	N842-A	В	131	65	6F	8
D960-B				5D	8	L530	В	28	31	5D	5	N842-B			•	4B	8
D965-A	В	128	88	9C	8	L550	В	45	21	9C	5	N845-A	В	178	67	5 <b>E</b>	8
D965-B				9B	8	L551	В	30	22	10C	5	N845-B				3B	В
D965-C				9B	8	L570	В	32	26	8D	5	N850-A	В	131	55	6E	8
D965-D				9C	В	L571	В	52	27	8C	5	N850-B				4B	8
K240-A	В	273	23		2	L600	В		105	2E	6	N860-A	В	219	42	4C	8
K240-B				5B	2	L610	В		118	3E	6	N860-B				4C	8
K910-A	В	150	58	5 <b>F</b>	8	L621		114		4B	6	N860-C				5A	8
K910-B	_			6D		L631		131		4B	6	N940-A	В	91	99	9C	8
L1		116	20		9	L645		163		3B	6	N940-B				11B	8
L2		155	18		9	L655		222		5B	6	N950-A	В	104	99	9C	8
L3		142	20		9	L695		166	98	6D	6	N950-B				10C	8
L4		101	15		9	L800		165	43	2E	8	N950-C				8C	8
L5		142	15	2B	9	L801		161	43	2E	8	N950-D				8B	8
L6 L8		273	89	6E	9	N20-A	В	81	20	4B	9	N950-E	_			11B	8
L8		270		6E	9	N20-B				5B	9	N960-A	В	114	103		8
L9 L12	A	246 91	79 86	6E	9	N20-C	p	210	E 4	3A	9	N960-B		1.0-	•	11B	8
L12 L13		218		6D	9	N100-A	Ħ	Z10	ΣŢ	10E	9	R5		137	25	2B	9
L13 L14		107	46	6D 4E	9	N100-B				10E	9	R20	В	75	16	4B	9
L14 L15		248	71	4E 6E	9	N100-C N105-A	D	100	E 1	3A	9	R21	A	79	22	3B	9
L13	В	71	88	6D	9	N105-A N105-B	Ω	TAQ	ΣŢ	10D	9	R22	A	74	15	4B	9
L13		145	43	4E	9	N105-B				10C 3A	9   9	R23 R24	A	74	17	4B	9
L20		299	79	6E	9	N110-A		192	69	9C	9	R24 R25	A A	83	22	5B	9
		110	86	6D	9	N110-A N110-B		17L	09	90 9B	9 I	R25 R26	A B	83 79	29	5B	9
		190		6D		N110-B				9B 4A	9	R25 R27	В	79 88	12 12	5B	9
		180		6D	9 1	N200	В	297	52	2E	2 1		A	86	22	5B 6B	9
+			+-		+						- l +	1120	n 	00		_+ un	
	Ä	I	İI	Datum	į			XY-	List	e fü	, _	Sach-Nu	Limin	er		B1	2 f +
ROHDE	-			Date	i				list			Stock-N				Pa	
& +			+-		<del>!</del>						- 1 +	1-7000	· ~			-+	ਰਦ ==-
CHWAR2			1		1	EE SYNTE	ES	I2ER			i		_			i	
				05.04		SYNTE	-									1	

Part S	Side X	Y	Sqr	Pg	Part	Side X	Y	Sqr	Pg	Part	Side X	Y	Sqr	Pg	
R29	A 89			9	R224		6 39			R326	B 254		5D	3	ı
R30	A 270			9	R225	B 27			2	R328	B 260	65	5D	3	
R31	B 144		8 6D	9	R226	A 28				R330	B 251	61	5D	3	
R100	A 199	7	2 4A	9	R227	B 27	2 44	7E	2	R331	B 254	63	5D	3	
R110	B 187	2	4 2E	9	R228	A 28	0 54	7D	2	R332	B 260	59	5D	3	
R111	B 187	3	9 3E	9	R229	A 27	3 34	6C	2	R335	B 247	54	7D	3	
R112	B 192	2	4 2E	9	R230	A 29	0 94	10E	2	R336	B 247	24	8D	3 İ	
R113	B 192	3	9 3E	9	R232	A 30	0 98	10E	2	R337	B 244			3 j	
R114	B 177	2		9	R234	A 29			2	R338	A 243			3	
R115	B 177	3		9	R236	A 27			2	R339	A 245			3	
R116	B 171			9	R238	A 27			2	R340	A 250			3	
R117	B 171			9	R239	A 27			2	R341	A 253			3	
R118	A 196			9	R240	A 27			2	R342	A 262			3	
R119	B 197			9	R241	A 29			2	R343	A 252			3	
R120	A 192			9	R242	A 29			2	R344	A 257			3	
R125	A 207			9	R243	B 29			2	R345	A 252		7F	3	
R142	A 219			9	R244	B 28:			2	R346	B 253		8D	3	
R144	A 210			9	R245	B 29:		8E	2	R347	B 247		9D	3	
R145	A 207			9	R246	A 29		8E	2	R348	A 250			3	
R146	A 226			9	R247	B 288		8E	2	R361	A 253		8C	3	
R150	A 207		1 10F	9	R248	B 280		8D	2	R370	B 259		9B	3	(
R152	A 210		3 10E	9	R251	A 27		2C	2	R371	B 262		9C	3	,
R154	A 204		3 10E	9	R253	A 274		2C	2	R372	B 255		9C	3	
R156	A 197		1 10D	9	R255	A 28		2B	2	R373	A 256		9C	3	
R158	A 198		7 10D	9	R258	B 292		3C	2	R375	B 252		8B	3	
R160	A 192		4 10C	9	R260	B 298		4B	2	R400		132	1E	4	
R162	A 198		6 9B	9	R264	B 285			2	R402		110	2E	4	
R164	A 192		9 9C	9	R266	B 275			2	R404		112	2E	4	
R166	A 190		6 9B	9	R267	B 269			2	R406		122	2D	4	
R167	A 193	6:		9	R269	B 278		5B	2	R408		128	2D	4	
R170	A 188		6 11D	9	R270	B 198		5B	2	R410		108	3E	4	
R172	A 187		2 10C	9	R276	A 297			2	R412		105	3D	4	
R174	A 204		5 10B	9	R277	A 291			2	R414	A 19		3D	4	
R178	B 207		9 10B	9		B 294				R416	A 16		2D	4	
R180	B 182		2 11C	9	R280	B 287			2	R418		97	3D	4	
R181			7 11C			B 284				R420	A 34			,	
R201	A 283	44	4 5B	2	R282	A 294	126	10C	2	R422		101	3D	4	
R202	A 295	42		2	R283	B 287			2	R424	B 29	96	3D	4	
R204	A 300	29		2	R284	B 278			2	R425	A 20	86	3C	4	
R206	B 292	36		2	R285	B 273			2	R426	A 28	90	3C	4	
R207	B 297	33		2	R286	B 282			2	R427	A 31	92	4C	4	ť
R208	A 290	36		2	R287	B 276			2	R430		131	5E	4	
R209	A 294	62		2	R288	A 281			2	R431		121	6E	4	
R210	B 297	4(		2	R289	A 284			2	R432		113	6E	4	
R212	B 288	4]		2	R290	A 294			2	R434		112	6E	4	
R213	B 290	34		2	R291	A 281			2	R436		124	6D	4	
R214	A 292	33		2	R302	B 253		3D	3	R438		129	6D	4	
R215	B 280	78		2	R304	B 247		3D	3	R440		108	7E	4	
R216	A 285	35		2	R306	B 244		2D	3	R442		105	7D	4	
R218	B 297	29		2	R308	A 250		3D	3	R444	A 44	99	7D	4	
R219	B 292	30		2	R310	B 262		3D	3	R446	A 41	94	6D	4	
R220	A 275	59		2	R312	A 252			3	R448	A 50	99	7D	4	
R221	A 285	64		2	R314	B 254			3	R450		106	7D	4	
R222	A 274		7C	2	R316	A 258			3	R452		102		4	
R223	A 276		8C		R324	B 260			3	R454		92	_	4	
	+	·1			+					+				+	
	ÄI		Datum		!					Sach-				att	
ROHDE	ļ		Date		Į.					Stock			Pa	ge	
. 3	+ '	٠١								<del></del>			-+	<del>+</del>	
CHWARZ		,	0F 0'		EE SYN							100-	ļ	[	
	1	U4	05.04	. 95	SYN	THESIZE	A.			I 1062.	6409.01	XY	- 1 -	4+	

Part	sid	е X	Y	Sqr	Pg	Part	S <b>i</b> de X	Y	Sqr	Pg	Part	Side X	Y	Sqr	Pg
R455	Α			0 70	4	R637				6	R705	B 25	2 129	2B	7
R456	A			0 70		R638	A 217			6	R706		5 130		7
R457	A			2 80		R639	A 219			6	R707		7 135		7
R483	В			8 10D		R640	A 145		6F	6	R708		3 137		7
R490	A					R643	B 149		6E	6	R709		3 140		7
R491 R495	A B			1 9E 5 11D		R644	B 151			6	R710		5 137		7
R495	В	39		5 11D		R647	B 155 A 168		6E	6	R712		9 140		7
R497	В			9 10D		R650	A 189	88	7E 8F	6 6	R713   R719		3 133		7
R499	В	31		5 11D		R651	A 189	91	8F	6	R720	A 164 A 18			7 7
R500	В	43				R652	A 189	93	8F	6	R721	B 19			7
R502	Ā					R653	A 188	96	8F	6	R722	B 19			7
R505	В	52				R654	A 200		7D	6	R723	B 19		6D	7
R506	В	19				R655	B 177	99	8E	6	R724	B 19			7
R507	В	27				R656	A 170		18	6	R725	B 17		6D	7
R510	Α	33	5	0 3E	5	R658	A 187	84	10B	6	R726	B 17		6D	7
R511	Α	16	4.	2 4E	5	R659	A 165		5B	6	R727	B 17		6D	7
R515	Α	15	2	6 4F	5	R660	A 205	96	7E	б	R728	B 175		6D	7
R520	Α	45	6.	3 4D	5	R661	A 205	93	7E	6	R729	B 175		6D	7
R521	Α				5	R662	A 175		7E	6	R730	B 167	130	7D	7
R525	В	40	3.		5	R663	A 160	114	7B	6	R733	A 159	128	7D	7
R526	В	43			5	R664	A 202		7D	6	R750	B 135	135	8D	7
R527	В	40			5	R665	A 204		7D	6	R751	B 129	135	8D	7
R528	A	59				R666	A 207		7D	6	R752	A 99		8D	7
R530	В	31	4:			R667	A 188		7D	6	R753		138	8D	7
R531	В	29	4:		5	R668	A 176		7D	6	R762	B 112		9D	7
R550	В	44	1:		5	R669	A 188		7D	6	R763	B 103		9D	7
R552	A	23		3 10D	5	R670	A 176		7D	6	R764		136	9D	7
R555	В	37		10B	5	R671	A 188		7C	6	R777		140	10D	7
R556	В	37		3 10C	5	R672	A 176		7C	6	R780	A 139		8B	7
R557	A	45		3 100	5	R673	A 188		7C	6	R781	A 133		8B	7
R570   R571	B B	32 52	32 30		5	R674	A 176		7C	6	R782	A 128		8B	7
R571	A	60		3 11B	5 5	R675	A 178		7C	б	R783	A 107			7
R581	A	58		5 11F	5	R677	A 184 A 187		7C 7C	6	R784 R785	A 104			7
R600				6E	6		A 189		7C	6	R786	A 116		9B	7
R603	A		115		6	R679	A 192		7C	6	R787	A 114 A 177		9B	7
R605	В		114		6	R680	A 194		7C	6	R792	A 193		5B 6B	7 7
R606	В		120		6	R681	A 191		7B	6	R793	A 216		6B	7
R607	В		117		6	R686	A 222	85	ic	6	R800	A 169		2E	8
R610	Α		120		6	R687	A 225	98	3C	6	R802	B 167		3E	8
R611	Α	235	109		6	R688	A 142	89	4 C	6	R803	A 165		2E	8
R612	Α	235	111	. 6B	6	R690		94	9F	6	R804	A 175		2E	8
R613		234			6	R691	A 190		9F	6	R812	B 164	54	2E	8
R614		234			6	R692	A 194		9 F	6	R813	B 184		3E	8
R615		102			6	R693	A 203	102	9 F	6	R820	A 175		<b>2</b> B	8
R616		106			6	R695		94	5D	6	R821	A 175	50	2A	8
R617		108			6	R696	A 170	91	5D	6	R822	A 168		2B	8
R620		121			6	R697	A 1.57	87	6D	6	R823	A 160		2A	8
R621		123			6	R698		87	6D	6	R824	A 169		3B	8
R630		137			6	R700	A 249		3D	7	R825	A 180	65	3A	8
R631		140			6	R701	A 247		3D	7	R826	A 171	64		8
R633		139			6	R702	B 245		3D	7	R827	A 177		3A	
R635		173				R703	B 235		3D	7	R828	A 123		4B	
R636	T R			10E		R704	B 211			7	R829	A 133		4A	8
1	+. Ä			Datum		T	vv				Cook N			-+	
ROHDE	A	_		Datum Date		1	XI-	∟⊥ST 11~+	e IU:	[ ]	Sach-N	ummer		Bla	
KUNDE	!					 <del> </del> -	- I A				Stock-	INI		Pa	ge
SCHWARZ	;		- <del>-</del> ;				THESIZER			T					
			04	05.04	.95	i syn	THESIZER			1	1062 6	409.N1	χv		54
	1		- 1							- 1			414		- 1

+					+						<del>+</del>						+
Part :	Side X	Y	Sqr	Pg	Part	Side	• X	Y	Sqr	Pg	Part	Side 2	Κ	Y	Sqr	Pg	1
R830	A 130	5:	3 4B	8	R956	В	114	83	8C	8	V402	В 2	23 ]	 L20	2E	4	1
R831	A 133				R957			106		8	V403		24 ]			4	İ
R832	A 85				R958		101		10D	8	V404		26 ]			4	ļ
R833   R834	A 92 A 98				R960	В	76		10E	8	V406		34 ]		3D	4	
R835	A 98			8 8	R961	B B	73 73		10D 10D	8 8	V408		32 23	95 90	4C 3C	4 4	1
R836	A 165				R963	В			10E	8	V410		.3 50 1		5D	4	1
R837	B 164				R964	В			10E	8	V431		8 1		5E	4	ł
R840	A 121			8	R965	В		52	11E	8	V432		0 1		6D	4	İ
R841	A 120			8	R966	В			11E	8	V433		8 1		6E	4	Ì
R842	A 121			8	R967	В			11E	8	V434		1 1		7E	4	ļ
R843   R844	B 177 A 130			8 8	R968   R969	B B	79 73		11E 10D	8 8	V436		9 1 6	.08	7D	4	
R845	A 183			8	R970	В			11D	8	V438		0	95 90	8C 7C	4 4	
R846	B 103			8	R971	В	73		11D	8	V480			85	4B	4	1
R847	A 121	. 57	7 7F	8	R972		73		11D	8	V490			94	8D	4	İ
R848	B 134			8	R973		73.		11D	8	V492		4	96	7C	4	İ
R849	B 127			8	R974	В	73		12D	8	V500		9	59	2E	5	1
R850   R851	A 101 B 131			8 8	R975	В	73 140		12D 12B	8	V501		2	56	2E	5	
R853	A 127			8	R986		109		12B	8 8	V502 V510		8 7	53 47	2D 3E	5 5	1
R857	A 120			8	R987	A	91		11B	8	V510	A 4		56	4D	5	<u>'</u>
R860	A 233		4C	8	R990	Α	86	46	9F	8	V532	В 2		28	5E	5	j
R861	B 204			8	R991	Α	94	43	5D	8	V550	B 4	2	27	8C	5	ļ
R862	B 211	37		8	R993	A	97	54	5D	8	V551	В 3		24	8C	5	
R863   R864	B 214 A 229			8 8	R994 R995	A	78	59 5/	8E	8	V553	B 5		23	9C	5	ļ
R865	A 223	39		8	R995	A A	89 84	54 51	8F 8F	8 8	V555 V600	B 2 B 15		12 06	10C 6E	5 6	<u> </u> 
R866	A 213	37		8	V20	В	85	26	6B	9	V695	A 15		89	6D	6	! 
R870	B 231	13		8	V110		199		11C	9	V696	B 17		94	5D	6	
R871	A 210	15		8	V120	Α	216	44	5A	9	V700		9 1		3D	7	
R872	A 212	22		8	V200		285	51	2E	2	V719	A 16			7B	7	
R873	A 234	19		8	V205		295	40	3E	2	V750	B 13:			8D	7	
R874 R875	B 231 A 212	15 24		8 8	V210   V212		285 279	35	4E	2	V755	B 13			8D	7	
R880	B 214	14		8	V212   V215		279	36 49	6E 7C	2	V757 V765	B 147 B 107			8D 9D	7	
R881	B 198	13		_	V216		270		7C	2		B 11			9E	7	
R882	B 214	18	5B	8	V220		269	30	6B	2	V767	B 11:			9D	7	
R883	B 198	18		8	V235		300	24	2D	2	V768	B 11			9C	7	
R884	A 223	30		8	V240		278	21	5B	2	V780	A 11.				7	,
R885 R931	A 221 B 114	23 96		8	V245 V247		279	89	9E	2	V781	A 114				7	(
R932	A 114	89		8 8	V247		285 293	74 124	8E 10D	2	V787 V800	A 180 A 153		28 50	5B 2E	7	i.
R933	A 114	98		8	V260			136		2	V902	A 14		60	6D	8	
R938	A 97	84	8C	8	V265	A :	275	121		2	V946	B 100			10D	8	
R939	A 104	84		8	V300	В :	257	115	2E	з ј	V947	B 100	0 1	87	10D	8	
R940	B 86	90		8	V305		256	99	3E	3	V951		9 1		9D	8	
R943 R949	A 131 A 133		11D 11D	8	V310   V330		256 247	91	3C	3	V952	A 102			9D	8	
R950	B 83	83	8D	8	V330		24 <i>1</i> 247	29 24	8D 8E	3	V955 V960	A 78		53 45	9E 9E	8	
R951	B 85	98	8D	8	V345		262	20	8E	3	V961	A 90		50	9E 5D	8	
R952	B 108	84	8C	8	V347		247	11	9D	3	X300	B 248			2D	3	
R953	B 92	89		8	V370		258	41	9B	з ј	21	B 116	5 3	30	2D	9	
R954	A 111	93		8	V400		23		2E	4	<b>Z2</b>	B 146		30	2C	9	
R955	A 93	93 	8C	8	V401	В	24	122	2E	4 ]	23	B 141	1 :	30	2C	9	
	+   ÄI	T	 Datum	1	<b></b>		 	 [.ie+	e fu:	+ r	Sech-1	Nummer		<b></b> -	-+	<del> </del> 1tt	•
ROHDE		•	Date						fo:		Stock				Pag		
& 4	<del></del>	+								+					-+	t	,
SCHWARZ	!				EE SYN'					- 1						- 1	
	!	04	05.04	.95	SYN'	THES:	LZER			ĺ	1062.	6409.01	L X	Z	6	5+	
	+	+			- <b></b>					+					-+	+	


Part	Side	X	- <b>Y</b>	Sqr	Pg	Part	Side	×	Y	Sqr	Pg	Part	Side	> X	Y	Sqr	]
Z4	В	110	30	2C	9	Z12	В	68	74	- 5C	9	I Z180	В	182	36	11C	
Z5	В	136	30	2B	9	Z13	В	68	43	5C	9	Z202		201	23	5B	
Z6	В	99	28	2B	9	214	В	68	53	5C	9	Z800		166	30	1E	
27	В	237	74	5E	9	Z102	В	187	30	2E	9	Z801	В	161	30	1E	
Z8	В	237	69	5E	9	Z104	В	192	30	2E	9	Z880	В	208	13	6C	
Z9	В	72	75	5D	9	Z106	В	177	30	2E	9	Z882		208	18	6B	
Z10	В	237	58	5E	9	Z108	В	171	30	2D	9						
211	В	154	75	5D	9	Z110	В	197	30	2F	9						


ROHDE	ÄI	Datum  Date	XY-Liste für XY-list for	Sach-Nummer Stock-Nr	Blatt  Page
SCHWARZ			EE SYNTHESIZER	 	϶╊╼╼╼╼┤ ╎


•





Stromläufe
Bestückungspläne
Circuit diagrams
Components plans
Schémas de circuit
Plans des composants



















5.
















3


2


ഗ

062,6409.01










#### STUECKT

ER VARIANTEN, BERTE UND TEILE SIEHE SA. TON ON MODELS, TYS VALUES AND

SEE PARTS LIST.



			The same of	THE RESERVE AND ADDRESS OF THE PERSON	Name and Address of the Owner, where the Party of the Owner, where the Party of the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, where the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, which is the Owner, wh	A H S A S S S S S S S S S S S S S S S S	-
04/02		21.02.97	ΕI	MENP	TAG	NAME	В
				BEARD.		ΕI	
				GEPR.			
				NORM			
				PLOTT	21.02.97		
		1		6			Z
04/01		02.12.95	WH	(R)			
AEND.	HENDERUNGS-	DATUH	NAME	RUF	IDEASL	HUARZ	1
IND.	AITTEILUNS	DHION	MHIIL	ZU GERAE	T SMY		R
	Q		-	T	1	n	



#### NICHT BESTUECKT

NOT FITTED

5

BINDENDE ANGABEN UEBER VARIANTEN, TRIMMUERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SR. FOR BINDING INFORMATION ON MODELS, TRIMMING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.




ACHTUNG: EGB! ELEKTROSTATISCH GEFAEHRDETE BAUELEMENTE ERFORDERN EINE BESONDERE HANDHABUNG.

ATTENTION ESD! ELECTROSTATIC SENSITIVE DEVICES
REQUIRE A SPECIAL HANDLING 04/01 RENI AEND HIT.

04/02

6




NOT FITTED

BINDENDE ANGABEN UEBER VARIANTEN, TRIMMWERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA FOR BINDING INFORMATION ON MODELS, TRIMMING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.

3

5




\*


TRI NIC FOR TRI NON


2

3

4








## \* NICHT BESTUECKT

NOT FITTED



8

04/82		21.02.97	EI	MENP	TAG	NAME	BENENNUN
			Ī	BEARB.		£Ι	]
				GEPR.			<u> </u>
				NORM			SY
	· · · · · · · · · · · · · · · · · · ·			PLOTT	21.02.97		
							ZEICHN.
84/01		82.12.96	WH	(RS)			
BEND.	RENDERUNGS-	DATUM	NONE	ROH			
IND.	HITTEILUNG	1 ""10"	1144117	ZB GERAE	T SMY		REG.I.V.



## \* NICHT BESTUECKT

NOT FITTED

BINDENDE ANGABEN UEBER VARIANTEN, TRIMMWERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA. FOR BINDING INFORMATION ON MODELS, TRIMMING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.

5

ACHTUNG: EGB!

ELEKTROSTATISCH GEFAEHRDETE
BAUELEMENTE ERFORDERN EINE
BESONDERE HANDHABUNG.


ATTENTION ESD!


ELECTROSTATIC SENSIFIUE DEVICES
REQUIRE A SPECIAL HANDLING

04/01
AEND. AENDERUNGS

6

7







BINDENDE
TRIMMWERT
NICHT BES
FOR BIND?
TRIMMING


NONFITTED

3

4








\* NICHT BESTUECKT NOT FITTED



ARTS LIST.

ACHTUNG: EGB! ELEKTROSTATISCH GEFREHRDETE BRUELEHENTE ERFORDERN EINE BESONDERE HANDHRBUNG.
ATTENTION ESD! ELECTROSTATIC SENSITIVE DEVICES REQUIRE B SPECIAL BANDLING

AEND. IND.	MENDEKONGS-	DATUM	NAME	ZU GERRE		
04/01	RENDERUNGS-	02.12.96	WH	∜\$) ROH	DE&SC	HWARZ
				PLOTT	21.02.97	
				NORM		
				GEPR.		
				BEARB.		ΕI
04/02		21.02.97	Εl	MENP	TAG	NAME



\* NICHT BESTUECKT

BINDENDE ANGABEN UEBER VARIANTEN, TRIMMWERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA.

FOR BINDING INFORMATION ON MODELS.

TRIMMING AND COMPONENTS VALUES AND
NONFITTED COMPONENTS SEE PARTS LIST.



04/02

04/01


REND RENDER HITTE!

5

б

7

- 8



\* NICHT BE

TRIMMERTE, BAUTEILWERTE UND
NICHT BESTUECKTE BAUTEILE SIEHE SA.

BINDENDE ANGABEN UEBER VARIANTEN,


FOR BINDING INFORMATION ON MODELS,
TRIBBING AND COMPONENTS VALUES AND
NONFITTED COMPONENTS SEE PARTS LIST.

S.

5

...

б




BINDENDE ANGABE Trimmwerte, bau Nicht Bestueckt


FOR BINDING INFO TRIMMING AND CO NONFLITTED COMPO


l l


2

3










P600


BINDENDE RNGABEN UEBER VARIANTEN;
TRINKWERTE, BAUTEILWERTE UND
NICHT BESTUECKTE BAUTEILE SIEHE SA;
FOR BINDING INFORMATION ON MODELS,
TRINKING AND COMPONENTS VALUES AND
NONFITTED COMPONENTS SEE PARTS LIST


ACHTUNG: EG8!
ELEKTROSTATISCH GEFRERPDETE
BAUELEHENTE ERFORDERN EINE
BESONDERE HANDHABUNG.
ATTENTION ESD!


ELECTROSTATIC SENSITIVE DEVICES
REQUIRE A SPECIAL HANDLING



BINDENDE ANGABEN UEBER VARIANTEN,
TRIMMERTE, BAUTEILWERTE UND
NICHT BESTUECKTE BAUTEILE SIEHE SA.
FOR BINDING INFORMATION ON MODELS,
TRIMMING AND COMPONENTS VALUES AND
NONFILTED COMPONENTS SEE PARTS L (ST.







ROHDE&SCHUARZ

10

1062.5502

1062.5502

₽EG. 1. Ø.


AENDERUNGS-HITTEILUNG


9


DATUM


NAME


AEND.










































94/02	- 1	21.02.97	EI	MENP TOG	HANE	BEREHMANE	
				DEORD.	ΕI		
				GEPR		SYNTHESIZER	Z
				KORR		SYNTHESIZER	
				PEOTT : 21.02.97			
				62		ZEICHNMR.	BIBIT-BI
92/92			.,**:	\$2		1062.6409.01 EE	1+
AEND. BE	HOERUNGS-	DATES.	Nane	ROHDE&S	CHURRZ		v. 2 !
IND. BI	ITEILUNG	Pates.	ROBL	ZI SERRET SMY	Strate in the	PER LY 1052 5502 PRINT 062.55	502



NHUERIC, BRUTEILVERTE UND


HT BESTUECKTE BRUTEILE SIEHE SA.

I BINDING INFORMATION ON MODELS,
HINING AND COMPONENTS VALUES AND
FIITED COMPONENTS SEE PARIS LIST.

6

V

5



TE B




BINDENDE ANGABEN WEBER VARIANTEN, TRINNUERTE, BAUTEILVERTE UND DIENT BESTUECKTE BAUTEILE SIEME SA.


FOR BINDING INFORMATION OM MODELS, TRINKING AND COMPONENTS VALUES AND NORFITTED COMPONENTS SEE PARTS LIST.

0





07/04		61.05.31	141	HERI	ino }	THEFT	ACHEMIANO.	miles 111	
				SERRO.		εı			
				GEPR.			SYNTHESIZER		
				HORN			SYNTHESIZER		
			Ι	PLOTE	21.02.97			500	BLAT
	•			(8)			ZERCRNNR.		2
02/02				152.			1062.64	ng:01 EE	e. 2
REND.	RENDERBN65-	DRIBS	NRME	ROF	HDE&SC	HAHKY			2
1NO.	RELLETENCE	5-D ratt	HABIT	20 GERNE	ET SMY		REG. 1002-3382	CASTE CONTRACTOR OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY OF THE PARTY O	7. 7. 10. 10.
	0				1	n	11		2019




TRINHUERIC, BAUTEILUERTE UNO
NICHT BESTUECKTE BRUTEILE SIEHE SR.

FOR BINOING INFORMATION ON MODELS,
TRINHING AND COMPONENTS VALUES AND
NONFITTED COMPONENTS SEE PARTS LIST.

REND. ACRO.
189. HITT

| 102.97 E1 | MENP | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | BEARB | B



IG SEITE A De a

300




1

250

BIRDENDE ANGRBEN DEBER VARIANTEN, TRINBUERTE, BAUTEILDERTE UND NICHT BESTUECKTE BRUTEILE SIENE SA.

200

FOR BINDING INFORMATION ON MODELS, TRINGING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.



DARSTELLUNG SEITE A VIEW ON SIDE A

A



BINDENDE RIGABEN BEBER URRIARTEN, TRIMHUERTE, BRUTEILBERTE UND MICHT BESTBECKTE BRUTEILE SIEHE SA.

FOR BINDING INFORMATION ON MODELS, TRIMMING AND COMPONENTS VALUES AND NOMFITTED COMPONENTS SEE PARTS LIST.



DARSTELLUNG SEITE A VIEW ON SIDE A

А



BINDENDE ANSABEN DEBER VARIBUTEN, TRIMMERTE, BAUTEILDERTE UND NICHY BESIUECKIE BAUTEILE SIEHE SR.

FOR BINDING INFORMATION ON HODELS, TRIDDING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PRRTS LIST



SERVICEUNTERLAGEN Ausgangsteil 1.04 GHz 1062.6209.01

# Inhaltsverzeichnis

7 Prüfen und Instandsetzen der Baugruppe	5
7.1 Funktionsbeschreibung 5	5
7.1.1 RF-Signalverarbeitung5	;
7.1.2 Mischer mit LO-, RF- und ZF-Filtern 6	
7.1.3 Ausgangsverstärker6	
7.1.4 AM-Signalzweig und RF-Pegel-Sollwert 6	,
7.1.5 RF-Pegelregelung6	J
7.1.6 serielle Schnittstelle 7	
7.1.7 Schaltung zur Diagnoseauswahl	
7.2 Meßgeräte und Hilfsmittel 7	
7.3 Fehlersuche 7	
7.3.1 Fehler nur im Bereich $f_{RF} < 10 \text{ MHz} \dots 7$	
7.3.2 Fehler nur im Bereich f <sub>RF</sub> < 65 MHz 8	
7.3.3 Fehler im Bereich 5 kHz $\leq$ f <sub>RF</sub> $\leq$ 1040 MHz	
7.3.4 Spektrale Reinheit, delta_f < 10 MHz vom Träger 9	
7.4 Prüfen und Abgleich9	
7.4.1 Prüfen der Datenübertragung9	
7.4.2 Prüfen der Ausgangsspannung des Regelverstärkers 9	
7.4.3 Prüfen der LEVEL PRESET-Steuerspannung 10	
7.4.4 Prüfen der Arbeitspunkte der Verstärkerstufen 10	
7.4.5 Prüfen der Ansteuerung der Filterbank 10	
7.4.6 Prüfen des RF-Pegels nach der Filterbank 11	
7.4.7 Abgleich der ZF-Verstärkung11	
7.4.8 Abgleich der ZF-Detektor-Linearität	
7.4.9 Abgleich der Detektor-Linearität am Ausgang FOPU 12	
7.4.10 Abgleich des AM-Modulationsgrades	
7.5 Zerlegung und Zusammenbau	
7.6 Endprüfung	
7.6.1 Prüfen des maximalen Ausgangspegels	
7.6.2 Prüfen des Oberwellenabstandes	
7.6.3 Prüfen des Nebenwellenabstandes	
7.7 Externe Schnittstellen	
Schaltteilliste Koordinatenliste Stromlauf Bestückungsplan	

# 7 Prüfen und Instandsetzen der Baugruppe

Bei Geräten ohne Option SMY-B40 hat die Baugruppe die Variante VAR02.

Bei Geräten mit Option SMY-B40 hat die Baugruppe die Variante VAR03.

### 7.1 Funktionsbeschreibung

Das Ausgangsteil 1.04 GHz erhält über den Eingang FSYN von der Baugruppe Synthese das RF-Signal (6 dBm ... 12 dBm) im Frequenzbereich 65 MHz  $\leq f_{SYN} \leq 1040$  MHz. Dieses RF-Signal wird über einen Amplitudenmodulator und ein Amplitudenstellglied auf schaltbare Tiefpaßfilter gegeben. Im Signalzweig wird durch Umschalter der Ausgangsfrequenzbereich 5 kHz  $\leq f_{RF} \leq 65$  MHz durch Abmischen mit einem 640 MHz-LO realisiert.

Die Baugruppe enthält folgende Funktionseinheiten:

- Einen AM-Modulator zur Pegelregelung und Amplitudenmodulation,
- einen AM-Modulator zur Pegelvoreinstellung (LEVEL PRESET),
- schaltbare Tiefpässe zur Unterdrückung von Harmonischen,
- einen Mischer mit LO-, RF- und ZF-Filtern,
- einen Pegeldetektor im RF-Zweig vor dem Mischer,
- einen Ausgangsverstärker,
- einen Pegeldetektor am Ausgang FOPU,
- einen Signalzweig zur Einstellung des RF-Pegelsollwertes und des Amplitudenmodulationsgrades,
- die RF-Pegelregelung,
- eine serielle Schnittstelle und
- eine Schaltung zur Diagnoseauswahl.

Im weiteren Text enthaltene Pegelangaben gelten für einen Geräteausgangspegel von +13 dBm (+19 dBm mit Option SMY-B40).

# 7.1.1 RF-Signalverarbeitung

Dem Eingang X224 FSYN ist ein Dämpfungsglied zur Temperaturkompensation nachgeschaltet. Anschließend folgt der AM MODULATOR.

Er ist das Stellglied der Pegelregelung im Bereich  $f_{RF} \leq 1.04~{\rm GHz}$ . Das RF-Signal wird durch RF AMPLIFIER 1 und RF AMPLIFIER 2 verstärkt und auf den PIN-Modulator LEVEL PRESET gegeben. Dieser Modulator wird durch gespeicherte Kalibrierdaten mittels D/A-Wandler so eingestellt, daß das Stellglied der Pegelregelung in einem optimalen Arbeitspunkt betrieben werden kann (vergl. Bedienhandbuch "Kalibrierung LEVEL PRESET").

Das RF-Signal wird durch den RF AMPLIFIER 3 verstärkt und auf schaltbare Tiefpässe HARMONIC FILTERS gegeben. Diese werden abhängig von der Eingangsfrequenz an X224 FSYN durch den Rechner eingeschaltet. Die Tiefpässe TP0 bis TP3 sind wie die Tiefpässe TP4 bis TP8 in Kette geschaltet. Filter in der Kette mit höherer Grenzfrequenz als der Grenzfrequenz des gewählten Tiefpasses bleiben eingeschaltet.

Im "Normalbetrieb" wird das RF-Signal über den PIN-Schalter SWITCHD (OFF) und den GaAs-Umschalter SWITCHB (OFF) auf den Ausgangsverstärker gegeben. Im "Mischerbetrieb" wird das RF-Signal über PIN-Schalter SWITCHD (ON) und den RF AMPLIFIER 4 auf den Detektor vor dem Mischer geschaltet.

#### 7.1.2 Mischer mit LO-, RF- und ZF-Filtern

Das RF-Signal vom Detektor vor dem Mischer wird über den RF-Tiefpaß und ein Dämpfungsglied zur Pegelanpassung auf den RF-Eingang des Mischers geschaltet (Pegel ca. -5 ... -10 dBm). Das Signal von REF640 gelangt über einen Tiefpaß auf den LO-Eingang des Mischers. Über den ZF-Verstärker und den ZF-Tiefpaß wird das ZF-Signal auf den RF-Schalter SWITCHB (ON) vor dem Ausgangsverstärker geschaltet (5 kHz  $\leq$   $f_{\rm ZF}$  < 65 MHz, Pegel ca. 0 dBm).

### 7.1.3 Ausgangsverstärker

Der dreistufige lineare Breitbandverstärker verstärkt das Eingangssignal um ca. 19 dB. Die Kollektorströme der Stufen werden geregelt.

# 7.1.4 AM-Signalzweig und RF-Pegel-Sollwert

Das Signal der Leitung AMMOD wird auf den D/A-Wandler zur Modulationsgradeinstellung gegeben und gelangt auf den D/A-Wandler RFLEV zur RF-Pegeleinstellung.

#### 7.1.5 RF-Pegelregelung

Bei Geräten ohne Option SMY-B40 wird der Pegeldetektor am Ausgang X226 FOPU bei Gerätefrequenzen  $f_{RF} \geq 10$  MHz verwendet. Der RF-Pegel an der Diode beträgt ca.

+19 dBm. Die Linearisierungsschaltung ermöglicht einen Dynamikbereich von ca. 30 dB bei guter Linearität (wichtig für geringen AM-Klirrfaktor).

Bei Geräten mit Option SMY-B40 wird für die Pegelregelung bei Gerätefrequenzen ≥ 10 MHz der Detektor auf der Option SMY-B40 verwendet. Dessen Ausgangsspannung gelangt über das Kabel W125 zum Motherboard und von dort auf den Eingang X2.A5 DETEXT dieser Baugruppe.

Der Pegeldetektor im RF-Zweig vor dem Mischer wird bei Gerätefrequenzen  $f_{\rm RF} < 10$  MHz anstelle des Detektors am Ausgang X226 FOPU verwendet. Der RF-Pegel an der Diode beträgt ca. +15 dBm.

Die Pegelregelung erfolgt durch den PI-Regler N235. Der Führungswert wird vom D/A-Wandler RFLEV geliefert und mit dem Istwert von einem der drei Detektoren (VDET, DETEXT oder VDETMIX) je nach Frequenzbereich verglichen. Die Ausgangsspannung des PI-Reglers regelt den AM-Modulator nach.

Die 3dB-Bandbreite der Regelschleife kann durch AMSLOW von ca. 300 kHz auf ca. 50 kHz reduziert werden (siehe Spezialfunktion 13).

Das Aktivieren von KLEMM-N durch den Prozessor steuert den AM-Modulator auf maximale Dämpfung, dies wird z.B. bei Frequenzwechseln zur Vermeidung von Pegelspikes verwendet.

### 7.1.6 serielle Schnittstelle

Die ankommenden Daten werden in die Schieberegister und die D/A-Wandler LEVEL PRESET, RFLEV und AM getaktet.

# 7.1.7 Schaltung zur Diagnoseauswahl

Über den Diagnosemultiplexer kann eine von 8 Gleichspannungen auf die Diagnoseleitung gelegt werden. Der Spannungswert kann im Gerätedisplay angezeigt werden.

101	0.00 V ±10 mV	Referenz 10 kOhm nach Masse
102	0.00 V 6 V	Detektorspannung Ausgang FOPU
103	0.00 V 6 V	Detektorspannung Mischer
104	0.01 V 3 V	RF-Pegel nach Filterbank
105	-6.00 V 0 V	Führungswert der Pegelregelung
106	-1.00 V 10 V	Ausgangsspannung des Regelverstärkers
107	-1.00 V 10 V	Steuerspannung des AM-Modulators
108	0.50 V 13 V	Steuerspannung des Stellgliedes LEVEL
		PRESET

## 7.2 Meßgeräte und Hilfsmittel

- Spektrumanalysator (z.B. FSBS)
- Oszilloskop (z.B. BOL)
- Gleichspannungsmeßgerät (Multimeter, z.B. UDL33)
- Netzwerkanalysator (z.B. ZVR)
- RF-Pegelmesser (z.B. NRVD mit Meßkopf NRV-Z51)
- 10dB-N-Dämpfungsglied (z.B. DNF)

#### 7.3 Fehlersuche

Vor dem Öffnen des Gerätes ist es zweckmäßig, zuerst einmal die Kalibrierroutine LEVEL PRESET zu starten und an Hand der Diagnosespannungen mögliche Fehlerquellen zu lokalisieren.

# 7.3.1 Fehler nur im Bereich $f_{RF}$ < 10 MHz

falscher RF-Pegel an X226

Der Detektor im Mischbereich liefert eine falsche Spannung oder der PI-Regler wird nicht richtig angesteuert.

Spannung VDETMIX mit Spezialfunktion 103 prüfen.

schlechter AM-Klirrfaktor Linearisierungsschaltung des Detektors prüfen.

#### 7.3.2 Fehler nur im Bereich f<sub>RF</sub> < 65 MHz

falscher RF-Pegel an X226 Eingang REF640, ZF-Verstärker, RF-

Verstärker 4 und die Ansteuerung SBDON-P und SBDON-N der Umschalter

prüfen.

Oberwellen zu groß Prüfe ZF-Verstärker, ZF-Tiefpaß

und RF-Schalter SWITCHB.

Nebenwellen zu groß Der Mischer ist defekt oder er

wird mit zu hohem RF-Pegel

angesteuert (Sollpegel am Mischer-RF-Eingang < -5 dBm). Prüfe ZF-

Verstärker, ZF-Tiefpaß, RF-

Schalter SWITCHB und

den RF-Tiefpaß.

#### 7.3.3 Fehler im Bereich 5 kHz $\leq$ f<sub>RF</sub> $\leq$ 1040 MHz

kein RF-Pegel an X226 Die Steuerspannung des AM-

Modulators muß jetzt > 12 V sein, sonst arbeitet die Pegelregelung

nicht richtig oder der

Führungswert vom RFLEV-D/A-Wandler ist falsch. Pegel nach Filterbank prüfen (Spezialfunktion 104). Mit Spektrumanalysator mit RF-Tastkopf

mit DC-Trennung die RF-Kette

kontrollieren (die Sollverstärkung einzelner Verstärkerstufen beträgt

ca. 7 dB)

Oberwellen zu groß Prüfe Filterbank und folgende RF-

Verstärker-Kette, prüfe

Arbeitspunkte des Endverstärkers.

Stör-Phasenmodulation bei AM Prüfe die Ansteuerspannung des AM-

zu groß

Modulators.

Kalibrierung LEVEL PRESET am Gerät

durchführen.

AM-Klirrfaktor zu groß Prüfen und Abgleich von Detektor

und Linearisierungsschaltung,

Kontrolle der AMSLOW-Ansteuerung.

Seitenlinien in ca. 1 MHz Abstand vom Träger

Pegel-Regelschleife schwingt; Prüfe Detektor und Linearisierungsschaltung. Kalibrierung LEVEL PRESET durchführen.

#### 7.4 Prüfen und Abgleich

Vorbemerkung: Neben den Koppelkondensatoren bzw. -widerständen der RF-Kette befinden sich Massedurchkontaktierungen. An einer solchen Stelle kann ein Koaxialkabel eingelötet und über einen Koppelkondensator oder eine externe DC-Trennung ein Meßgerät (z.B. Netzwerk- oder Spektrumanalysator) angeschlossen werden. Hierzu wird das Koaxialkabel durch das Loch gesteckt, der Außenleiter des Koaxialkabels an der Durchkontaktierung und der Innenleiter am gewünschten Anschlußfleck des Kondensators

angelötet.

#### 7.4.1 Prüfen der Datenübertragung

Die Prüfung wird bei den in der Tabelle angegebenen Einstellungen am Gerät durchgeführt.

\_ Prüfen der Spannungen an D120: "1" = +5 V, "0" = 0 V

RF-Frequenz	-Frequenz D120/14		nz D120/14 D120/6 Hinweis			4-1-	A STATE OF THE STATE OF				1.5
RF 1MHz	0	1		DETMIXON							
RF 10MHz	1	0		DETON							

# Prüfen der Ausgangsspannung des Regelverstärkers

Um den Amplitudenmodulator optimal betreiben zu können ist die LEVEL PRESET-Kalibrierung erforderlich. Dieser optimale Arbeitspunkt ist unabhängig von der RF-Frequenz. Die Ausgangsspannung des Regelverstärkers soll bei einem Ausgangspegel von 13dBm (+19 dBm mit Option SMY-B40) 6.3V betragen. Bei elektronischer Pegelabsenkung auf 7dBm (+13 dBm mit Option SMY-B40) soll diese Spannung auf 3.9V absinken und bei weiterer elektronischer Pegelabsenkung bis zu -6dBm (0 dBm mit Option SMY-B40) konstant auf 3.9V bleiben.

- ullet Den Geräteausgang RF 50 $\Omega$  mit 50 $\Omega$  abschließen.
- LEVEL 13 dBm (+19 dBm mit Option SMY-B40) einstellen und
- Spezialfunktion 1 (unterbrechungsfreie Pegeleinstellung) einschalten.
- \_ Über die Spezialfunktion 106 kann die Ausgangsspannung des Regelverstärkers gemessen werden.

### 7.4.3 Prüfen der LEVEL PRESET-Steuerspannung

- ullet Den Geräteausgang RF  $50\Omega$  mit  $50\Omega$  abschließen.
- LEVEL 13 dBm (+19 dBm mit Option SMY-B40) einstellen
- Spezialfunktion 1 (unterbrechungsfreie Pegeleinstellung) einschalten.
- \_ Über die Spezialfunktion 108 kann die LEVEL PRESET-Spannung gemessen werden.

Die Spannung ist abhängig von der RF-Frequenz und vom RF-Pegel. Der Rechner sendet die berechneten Werte in den LEVEL PRESET-D/A-Wandler.

Typische Spannungswerte sind in folgender Tabelle dargestellt:

	SMY01 ob	ne Option	SMY-B40		SMY01 mit Option SMY-B40				
RF-Frequenz	13dBm	7dBm	0.dBm	-6dBm	19đBm	13dRm	6dBm	0dBm	
25MHz	1.2V	1.2V	0.8V	0.6V	1.2V	1.2V	0.8V	0.6V	
100MHz	1.7V	1.7V	1.2V	0.8V	1.7V	1.70	1.2V	0.8V	
300MHz	1.2V	1.2V	0.9V	0.6V	1.2V	1.2V	0.9V	0.6V	
500MHz	1.3V	1.3V	0.9V	0.6V	1.3V	1.3V	0.9V	0.6V	
750MHz	2.0V	2.0V	1.4V	1.0V	2.0V	2.07	1.4V	1.0V	
800MHz	1.5V	1.5V	1.0V	0.8V	1.5V	1.5V	1.0V	0.8V	
1040MHz	2.0V	2.0V	1.4V	1.0V	2.0V	2.0V	1.4V	1.0V	

## 7.4.4 Prüfen der Arbeitspunkte der Verstärkerstufen

Prüfpunkt	Sollspannung	Bemerkung
N360/3	5.50 ± 1.1V	RF AMPLIFIER 2
N410/3	$5.50 \pm 1.1V$	RF AMPLIFIER 3
V602 Kollektor	$8.90 \pm 0.3V$	RF AMPLIFIER 4
V612 Kollektor	5.90 ± 0.3V	IF AMPLIFIER
V802 Kollektor	$9.60 \pm 0.3V$	OUTPUT AMPLIFIER 1
V817 Kollektor	$8.70 \pm 0.3V$	OUTPUT AMPLIFIER 2
V822 Kollektor	8.80 ± 0.3V	OUTPUT AMPLIFIER 3

### 7.4.5 Prüfen der Ansteuerung der Filterbank

\_ Prüfen von LPSELECT-0 ... LPSELECT-3 und der Schaltleitungen TPO ... TP8.

RF-Frequenz 3 D111/8	LPSEL 2 D111/	7 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	0 6 D111	73	Hinweis
780.00 MHz	0	0	0	1	Tiefpaß 1
520.00 MHz	O.	0	1	0	Tiefpaß 2
390.00 MHz	0	0	1	1	Tiefpaß 3
260.00 MHz	0	1	0	0	Tiefpaß 4
195.00 MHz	0	1	0	1	Tiefpaß 5
130.00 MHz	0	1	1	0	Tiefpaß 6
97.50 MHz	0	1	1	1	Tiefpaß 7
65.00 MHz	1	0	0	0	Tiefpaß 8
64.00 MHz	0	0	1	0	Tiefpaß 2, Mischerbereich

### 7.4.6 Prüfen des RF-Pegels nach der Filterbank

ullet Den Geräteausgang RF  $50\Omega$  mit  $50\Omega$  abschließen.

• Einstellung: RF LEVEL 13 dBm (+19 dBm mit Option SMY-B40)

\_ Über die Spezialfunktion 104 kann die gleichgerichtete RF-Spannung gemessen werden.

Typische Spannungswerte sind in folgender Tabelle dargestellt:

RF-Frequenz	Diagnosespannung	THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY O
10 MHz	0.2V	
100 MHz	0.7V	
200 MHz	1.1V	
300 MHz	1.0V	
400 MHz	1.3V	
500 MHz	1.4V	
600 MHz	1.4V	
700 MHz	1.0V	
800 MHz	1.4V	į
900 MHz	0.6V	
1000 MHz	1.5V	
1040 MHz	2.5V	

# 7.4.7 Abgleich der ZF-Verstärkung

ullet Spektrumanalysator an Geräteausgang RF  $50\Omega$  anschließen

• Einstellung: RF

10 MHz

LEVEL

13 dBm (+19 dBm mit Option SMY-B40)

- \_ RF-Signal messen, RF-Pegel merken
- \_ RF-Frequenz um 1 Hz erniedrigen
- \_ Mit Pot R645 den RF-Pegel auf den gleichen Wert einstellen
- \_ Nach dem Abgleich sollte die Kalibrierroutine LEVEL PRESET aufgerufen werden.

# 7.4.8 Abgleich der ZF-Detektor-Linearität

• Einstellung:

RF

9.9 MHz

LEVEL

0.1 dBm (6.1 dBm mit Option SMY-B40)

- \_ Ausgangspege1 am RF-Ausgang des Gerätes messen und merken (= Referenzpegel)
- Einstellung:

Spezialfunktion 1 einschalten

(unterbrechungsfreie Pegeleinstellung)

LEVEL -19.9 dBm (-13.9 dBm mit Option SMY-B40

\_ Mit POT R619 so abgleichen, daß der gemessene Pegel 20 dB unter dem zuvor gemessenen Referenzpegel liegt. Abgleich einmal wiederholen, da sich der Referenzwert mit R619 geringfügig ändert; die Genauigkeit der 20dB-Absenkung soll nach dem Abgleich ± 0.1 dB erreichen.

# 7.4.9 Abgleich der Detektor-Linearität am Ausgang FOPU

• Dieser Abgleich darf nur dann durchgeführt werden, wenn keine Option SMY-B40 eingebaut ist!

• Einstellung:

RF

100 MHz

LEVEL

13 dBm

\_ Ausgangspegel am RF-Ausgang des Gerätes messen und merken (= Referenzpegel)

• Einstellung:

Spezialfunktion 1 einschalten

(unterbrechungsfreie Pegeleinstellung)

LEVEL -7 dBm

\_ Mit POT R851 so abgleichen, daß der gemessene Pegel 20 dB unter dem zuvor gemessenen Referenzpegel liegt. Abgleich einmal wiederholen, da sich der Referenzwert mit R851 ändert; die Genauigkeit der 20dB-Absenkung soll nach dem Abgleich ± 0.1 dB erreichen.

# 7.4.10 Abgleich des AM-Modulationsgrades

• Einstellung:

PRESET

LEVEL 7 dBm (+13 dBm mit Option SMY-B40)

AM EXT DC 100%

Spezialfunktion 105 einschalten (Führungswert der Pegelregelung)

- Eine Gleichspannung U = -1.000 V an AM EXT anlegen.
- \_ Mit POT R280 auf 0 V abgleichen.

#### 7.5 Zerlegung und Zusammenbau

Oberen Gerätedeckel entfernen. Die Baugruppe ist links und rechts an der Auflage festgeschraubt. Nach dem Entfernen dieser Schrauben und dem Lösen der Koax-Verbindungen an X224, X225 und X226 kann die Baugruppe aus ihrem Steckplatz entnommen werden.

#### 7.6

#### Endprüfung

# 7.6.1 Prüfen des maximalen Ausgangspegels

• Einstellung:

LEVEL

19 dBm (25 dBm mit Option SMY-B40)

\_ An X226 FOPU einen Leistungsmesser anschließen, dabei muß ggf. ein geeignetes RF-Dämpfungsglied vorgeschaltet werden, um den Meßkopf nicht zu überlasten.

\_ RF-Frequenz von 5kHz bis 1040 MHz variieren.

Der RF-Pegel muß > 15dBm (20 dBm mit Option SMY-B40) bleiben.

Typische Pegelwerte sind in folgender Tabelle dargestellt:

	SMY01 ohne Option SMY-B40	SMY01 mit Option SMY-B40		
RF-Frequenz	Ausgangspegel	Ausgangspegel		
10 MHz	16 dBm	21 dBm		
100 MHz	19 dBm	24 dBm		
200 MHz	19 dBm	26 dBm		
250 MHz	19 dBm	25 dBm		
400 MHz	20 dBm	24 dBm		
500 MHz	18 dBm	25 dBm		
600 MHz	18 dBm	26 dBm		
750 MHz	17 dBm	26 dBm		
800 MHz	19 dBm	26 dBm		
1000 MHz	18 dBm	26 dBm		

# 7.6.2 Prüfen des Oberwellenabstandes

- Gerät ohne Option SMY-B40:
- Einstellung: LEVEL 10 dBm
- \_ An X226 FOPU einen Spektrumanalysator anschließen.
- \_ Der Pegel der Harmonischen muß < -30 dBc sein.
- Gerät mit Option SMY-B40:
- Einstellung:

LEVEL 16 dBm

Spezial 21 (ALC aus)

Da für die Messung die Verbindung von FOPU zum Powermodul aufgetrennt wird, muß die Pegelregelung auf den Sample-and-Hold-Betrieb geschaltet werden. Vor jeder Änderung der Geräteeinstellung muß diese Verbindung wieder geschlossen werden!

- \_ Meßfrequenz einstellen.
- \_ An X226 FOPU einen Spektrumanalysator anschließen.
- \_ Der Pegel der Harmonischen muß <-25 dBc sein.

# Typische Meßwerte sind in folgender Tabelle dargestellt:

	SMY01 ohne Opt	on SMY-B40	SMY01 mit Option SMY-B40			
RF-Frequenz	2*f <sub>RF</sub>	3*f <sub>RF</sub>	2*f <sub>RF</sub>	3*f <sub>RP</sub>		
1 MHz	-50 dBc	-40 dBc	-45 dBc	-50 dBc		
10 MHz	-50 dBc	-45 dBc	~50 dBc	-50 dBc		
100 MHz	-50 dBc	-40 dBc	-50 dBc	-50 dBc		
200 MHz	-45 dBc	-45 dBc	-50 dBc	-50 dBc		
350 MHz	-50 dBc	-40 dBc	-50 dBc	-50 dBc		
650 MHz	-50 dBc	-40 dBc	-45 dBc	-50 dBc		
900 MHz	-35 dBc	-45 dBc	-40 dBc	-50 dBc		
1040 MHz	-45 dBc	-45 dBc	-40 dBc	-50 dBc		

#### 7.6.3 Prüfen des Nebenwellenabstandes

· Einstellung:

RF

63 MHz

LEVEL

13 dBm (+19 dBm mit Option SMY-B40)

- \_ An X226 FOPU einen Spektrumanalysator anschließen.
- Nebenwellen bei folgenden Frequenzen prüfen:
  703 MHz, 640 MHz, 136 MHz, 73 MHz, 10 MHz
  Der Pegel der Nebenwellen muß < -70 dBc sein (typ. < -100 dBc).

#### 7.7 Externe Schnittstellen

Pin	Name	Ein/Ausgang	Herkunft/Ziel	Wertebereich	Signalbeschreibung
X2A.01	BLANK	Eingang	Rückwanne	HCMOS-Pegel	RF-Pegelaustastung
X2A.05	DETEXT	Eingang	Pmod	0 10 V	Detektorspg. Option SMY-B40
X2A.07	AMMOD	Eingang	CPU X3.3	4-1 V bis 1 V	AM-Signal
X2A.12	SERCLK	Eingang	CPU X3.2	HCHOS-Pegel	Clock
X2A.14	SERDAT	Eingang	CPU X3.4	HCHOS-Pegel	serielle Daten
X2A.15	AT1STB	Eingang	CPU X3.16	HCMOS-Pegel	Strobe 1
X2A,17	HFINT	Ausgang	CPU X3.20	HCMOS-Pegel	Interrupt Pegelregelung
X2A.19	DIAG-5V	Ausgang	CPU X3.6	-5 V5 V	Diagnose
X2A.22	VA24-P	Eingang	Netzteil X21.22	23.4 V24.6 V	Versorgungsspannung analog
X2A.24	VA15-P	Eingang	Netzteil X21.13	14.80 V15.75 V	Versorgungsspannung analog
X2A.25					
X2A.28	VA-5P	Eingang	Netzteil X21.5	5.10 V5.25 V	Versorgungsspannung analog
X2A.30	VA15-N	Eingang	Netzteil X21.20	-15.75 V14.85 V	Versorgungsspannung analog
<b>X</b> 224	FSYN	Eingang	YSYN X124	6 - 12 dBm	65 - 1040 MHz
<b>X2</b> 25	REF640	Eingang	YSYN X125	9 - 12 dBm	640 MHz
X226	FOPU	Ausgang	Eichleitung X1	-620 dBm	5 kHz - 1.04 GHz



SERVICE INSTRUCTIONS
Output Module 1.04 GHz
1062.6209.01

### Contents

7 Testing and Repair of the Module 5
7.1 Function Description 5
7.1.1 RF Signa1 Processing 5
7.1.2 Mixer with LO, RF and IF Filters6
7.1.3 Output Amplifier 6
7.1.4 AM Signal Path and Nominal Value of RF Level 6
7.1.5 RF Level Control 6
7.1.6 Serial Interface 7
7.1.7 Circuit for Diagnostics Selection
7.2 Test Instruments and Utilities 7
7.3 Troubleshooting 7
7.3.1 Errors Occurring Only in the Range $f_{RF}$ < 10 MHz 7
7.3.2 Errors Occurring Only in the Range $f_{RF}$ < 65 MHz 8
7.3.3 Errors Occurring in Range 5 kHz $\leq$ f <sub>RF</sub> $\leq$ 1040 MHz 8
7.3.4 Spectral Purity, delta_f < 10 MHz from the Carrier 8
7.4 Testing and Adjustment9
7.4.1 Testing Data Transmission9
7.4.2 Testing the Output Voltage of the Control Amplifier 9
7.4.3 Testing the LEVEL PRESET Control Voltage 9
7.4.4 Testing the Operating Points of Amplifier Stages 10
7.4.5 Testing the Harmonic Filters Control 10
7.4.6 Testing the RF Level at the Harmonic Filters Output. 10
7.4.7 IF Gain Adjustment
7.4.8 IF Detector Linearity Adjustment
7.4.9 Detector Linearity Adjustment at the Output FOPU 12
7.4.10 AM Depth Adjustment
7.5 Disassembly and Assembly
7.6 Final Test
7.6.1 Maximum Output Level Check
7.6.2 Harmonics Suppression Check
7.6.3 Nonharmonics Suppression Check
7.7 External Interfaces

Parts list List of coordinates Circuit diagram Component layout diagram In instuments without fitted option SMY-B40, this module has the variant VAR 02.

In instuments with fitted option SMY-B40, this module has the variant VAR 03.

# 7.1 Function Description

The Output Module 1.04 GHz is provided with the RF signal (6 dBm to 12 dBm) in the frequency range 65 MHz  $\leq f_{\rm SYN} \leq$  1040 MHz by the synthesis module via the input FSYN. This RF signal is passed via an amplitude modulator and an amplitude control element to switchable harmonic filters. The output frequency range of 5 kHz  $\leq$   $f_{\rm RF} \leq$  65 MHz is realized in the signal path via changeover switches by means of downconversion with a 640 MHz LO.

The module consists of the subsequent function units:

- an AM modulator for level control and amplitude modulation,
- an AM modulator for level presetting (LEVEL PRESET),
- switchable harmonic filters,
- a mixer with LO, RF and IF filters,
- a level detector in the RF path preceding the mixer,
- an output amplifier,
- a level detector at the output FOPU,
- a signal path for processing the nominal value of the RF level and
  - the amplitude-modulation depth,
- the RF level control,
- a serial interface and
- a circuit for diagnostics selection.

Further information on levels apply for an instrument output level of +13 dBm (+ 19 dBm with option SMY-B40).

### 7.1.1 RF Signal Processing

The input X224 FSYN is followed by an attenuator for temperature compensation. The attenuator is followed by the AM MODULATOR. It is used as control element for level control in the range  $\rm f_{RF} \leq 1.04~GHz$ .

The RF signal is amplified by RF AMPLIFIER 1 and RF AMPLIFIER 2 and passed to the PIN modulator LEVEL PRESET. This modulator is set by means of stored calibration data via the D/A converter such that the control element for level control can be operated in an optimum operating point. (cf. operating manual "Calibrating LEVEL PRESET").

The RF signal is amplified by the RF AMPLIFIER 3 and routed to switchable HARMONIC FILTERS. These filters are switched on by the controller depending on the input frequency at X224 FSYN. Similar to the lowpass filters TP4 to TP8, the lowpass filters TP0 to TP3 are cascaded. Filters in the signal path which have a higher cutoff frequency than the cutoff frequency of the lowpass selected remain switched on.

In "normal operation", the RF signal passes via the PIN switch SWITCHD (OFF) and the GaAs changeover switch SWITCHB (OFF) to the output amplifier. In "mixer operation" the RF signal is passed via the PIN switch SWITCHD (ON) and the RF AMPLIFIER 4 to the detector preceding the mixer.

#### 7.1.2 Mixer with LO, RF and IF Filters

The RF signal supplied by the detector preceding the mixer is switched via the RF lowpass and an attenuator to the RF input of the mixer for level adjustment (level approx. -5 to -10 dBm). The signal of REF 640 passes via a lowpass to the LO input of the mixer. The IF signal reaches the RF switch SWITCHB (ON) preceding the output amplifier via the IF amplifier and the IF lowpass (5 kHz  $\leq f_{\rm ZF} < 65$  MHz, level approx. 0 dBm).

#### 7.1.3 Output Amplifier

The three-stage linear broadband amplifier amplifies the input signal by approx. 19 dB. The collector currents of the stages are controled.

### 7.1.4 AM Signal Path and Nominal Value of RF Level

The signal of the AMMOD line is passed to the D/A converter for setting of the modulation depth and then passes to the D/A converter RFLEV for RF-level adjustment.

#### 7.1.5 RF Level Control

For instruments without option SMY-B40, the level detector at the output X226 FOPU is used at instrument frequencies  $f_{RF} \geq 10$  MHz. The RF level at the diode is approx. +19 dBm. The linearization circuit allows for a dynamic range of approx. 30 dB with good linearity (important for low AM distortion).

For instruments with option SMY-B40, the detector of the option SMY-B40 is used for level control at instrument frequencies  $\geq 10$  MHz. Its output voltage is applied to the motherboard via cable W125 and then fed into the input X2.A5 DETEXT of this module.

The level detector in the RF path preceding the mixer is used with instrument frequencies  $f_{\rm RF} < 10$  MHz instead of the detector at the output X226 FOPU. The RF level at the diode is approx. +15 dBm.

The level is controlled via the PI regulator N235. The reference value is supplied by D/A converter RFLEV and compared to the actual value of one of the three detectors (VDET, DETEXT or VDETMIX) depending on the frequency range. The output voltage of the PI regulator adjusts the AM modulator.

The 3-dB bandwidth of the control loop can be reduced by AMSLOW from approx. 300 kHz to approx. 50 kHz. (see special function 13).

The processor activates KLEMM-N to set the AM modulator to maximum attenuation, which is used, e.g., for frequency changes in order to avoid level spikes.

### 7.1.6 Serial Interface

The incoming data are clocked into the shift registers and the D/A converters LEVEL PRESET, RFLEV and AM.

## 7.1.7 Circuit for Diagnostics Selection

One of eight dc voltages can be applied to the diagnostic line via the diagnostic multiplexer. The voltage can be displayed on the instrument display.

Special function	Nominal	voltage range	Remark
101	0.00 V	±10 mV	10-kOhm reference to ground
102	0.00 V	6 V	Detector voltage output FOPU
103	0.00 V	6 V	Detector voltage mixer
104	0.01 V	3 V	RF level at harmonic filter output
105	-6.00 V	0 V	Reference value of level control
106	-1.00 V	10 V	Output voltage of the control amplifier
107	-1.00 V	10 V	Control voltage of the AM modulator
108	0.50 V	13 V	Control voltage of the control element
			LEVEL PRESET

# 7.2 Test Instruments and Utilities

- Spectrum analyzer (e.g., FSBS)
- Oscilloscope (e.g., BOL)
- DC power meter (multimeter, e.g., UDL33)
- Network analyzer (e.g., ZVR)
- RF power meter (e.g., NRVD with sensor NRV-Z51)
- 10-dB-N-attenuator pad (e. g. DNF)

### 7.3 Troubleshooting

Before opening the instrument, it is useful to first start the calibration routine LEVEL PRESET and localize possible error sources using the diagnostic voltages.

# 7.3.1 Errors Occurring Only in the Range fRF < 10 MHz

Incorrect RF level at X226

Either the detector in the mixed range supplies an incorrect voltage or the PI regulator is not controlled correctly.

Check voltage VDETMIX using special function 103.

Bad AM distortion Check the linearization circuit of the detector.

#### 7.3.2 Errors Occurring Only in the Range $f_{RF}$ < 65 MHz

Incorrect RF level at X226 Check input REF640, IF amplifier,

RF amplifier 4 and control of SBDON-P and SBDON-N of the

changeover switches.

Harmonics too high Check IF amplifier, RF lowpass and

RF switch SWITCHB.

Spurious signals too high The mixer is either faulty or its

input RF level is too high (nominal level at the mixer RF input < -5 dBm). Check IF

amplifier, IF lowpass, RF switch

SWITCHB and the RF lowpass.

#### Errors Occurring in Range 5 kHz $\leq f_{RF} \leq 1040$ MHz 7.3.3

No RF level at X226 The control voltage of the AM

modulator must be > 12 V,

otherwise, the level control does

not work correctly or the reference value of RFLEV D/A converter is incorrect. Check level at harmonic filter output (special function 104). Check the RF signal path using a spectrum analyzer with RF probe providing dc isolation (the gain of the

amplifier stages is approx. 7 dB))

Harmonics too high Check harmonic filters and

> subsequent RF amplifiers, check operating points of the output

amplifier.

Incidential phase modulation

with AM too high

Check the control voltage of the AM modulator.

Perform LEVEL PRESET calibration .

AM distortion too high Adjust and check detector and

linearization circuit, check

AMSLOW control.

#### 7.3.4 Spectral Purity, delta\_f < 10 MHz from the Carrier

Spurious signals at approx. 1 ALC control loop oscillates; MHz from carrier check detector and linearization

circuit. Perform LEVEL PRESET

calibration.

### 7.4 Testing and Adjustment

Hints:

Ground via-holes have been fitted next to the coupling capacitors and resistors of the RF signal path. A coaxial cable can be soldered in at such a location and a test instrument can be connected via a coupling capacitor or an external dc isolation (e.g., a network or spectrum analyzer). Therefore, the coaxial cable is routed through the hole, the external conductor is soldered at the via-hole and the inner conductor at the desired location.

#### 7.4.1 Testing Data Transmission

The test is performed with the instrument settings listed in the table.

• Check the voltages at D120: "1" = +5 V, "0" = 0 V

RF	frequency	D120	/14 31	0120/6 Remark	· · · · · · · · · · · · · · · · · · ·
RF	1MHz	0	1	DETMIXON	
RF	10MHz	1	0	DETON	

# 7.4.2 Testing the Output Voltage of the Control Amplifier

The LEVEL PRESET calibration is required for optimum operation of the amplitude modulator. This optimum operating point is independent of the RF frequency. The nominal output voltage of the control amplifier is 6.3 V for an output level of 13 dBm (+19 dBm with option SMY-B40). When the level is decreased electronically to 7dBm (+13 dBm with option SMY-B40), this voltage should drop to 3.9V and should remain constant even with further electronic reduction of the level down to -6 dBm (0 dBm with option SMY-B40).

- Terminate the instrument output RF  $50\Omega$  with  $50\Omega$ .
- Set LEVEL to 13 dBm (+19 dBm with option SMY-B40) and
- switch on special function 1 (non-interrupting level setting)
- \_ The output voltage of the control amplifier can be measured using special function 106.

# 7.4.3 Testing the LEVEL PRESET Control Voltage

- Terminate the instrument output RF  $50\Omega$  with  $50\Omega$ .
- Set LEVEL to 13 dBm. (+19 dBm with option SMY-B40)
- Switch on special function 1 (non-interrupting level setting)

  \_ The LEVEL PRESET voltage can be measured using special function

The voltage depends on the RF frequency and the RF level. The controller transmits the calculated values to the LEVEL PRESET D/A converter.

Typical voltages are given in the table below:

	SMY01 wi	thout opt	ion SMY-E	40	SMY01 with option SMY=B40				
RF- frequency	13 dBm	7 dBm	0 dBm	-6 dBm	19. dBm	13 dBm	6 ∗dBm	0 dBm	
25 MHz	1.2 V	1.2 V	0.8 V	0.6 V	1.2 V	1.2 V	0.8 V	0.6 V	
100 MHz	1.7 V	1.7 V	1.2 V	0.8 V	1.7 V	1.7 V	1.2 V	0.8 V	
300 MHz	1.2 V	1.2 V	0.9 V	0.6 V	1.2 V	1.2 V	0.9 V	0.6 V	
500 MHz	1.3 V	1.3 V	0.9 V	0.6 V	1.3 V	1.3 V	0.9 V	0.6 V	
750 MHz	2.0 V	2.0 V	1.4 V	1.0 V	2.0 V	2.0 V	1.4 V	1.0 V	
800 MHz	1.5 V	1.5 <b>v</b>	1.0 V	0.8 V	1.5 V	1.5 V	1.0 V	0.8 V	
1040 MHz	2.0 V	2.0 V	1.4 V	1.0 V	2.0 V	2.0 V	1.4 V	1.0 V	

#### Testing the Operating Points of Amplifier Stages 7.4.4

Test point	Nominal voltage	Remark
N360/3	5.50 ± 1.1V	RF AMPLIFIER 2
N410/3	5.50 ± 1.1V	RF AMPLIFIER 3
V602 Collector	8.90 ± 0.3V	RF AMPLIFIER 4
V612 Collector	5.90 ± 0.3V	IF AMPLIFIER
V802 Collector	9.60 ± 0.3V	OUTPUT AMPLIFIER 1
V817 Collector	8.70 ± 0.3V	OUTPUT AMPLIFIER 2
V822 Collector	8.80 ± 0.3V	OUTPUT AMPLIFIER 3

#### 7.4.5 Testing the Harmonic Filters Control

\_ Testing LPSELECT-0 ... LPSELECT-3 and the lines TPO to TP8.

RF frequency	LPSELEC 2 D111/11	r_ 1 D111/6	0 D111/3		Remark
780.00 MHz	0	0	0	1	Lowpass 1
520.00 MHz	0	0	1	0	Lowpass 2
390.00 MHz	0	0	1	1	Lowpass 3
260.00 MHz	0	1	0	0	Lowpass 4
195.00 MHz	0	1	0	1	Lowpass 5
130.00 MHz	0	1	1	0	Lowpass 6
97.50 MHz	0	1	1	1	Lowpass 7
65.00 MHz	1	0	0	0	Lowpass 8
64.00 MHz	0	0	1	0	Lowpass 2, Mixer range

### Testing the RF Level at the Harmonic Filters Output

- Terminate the instrument output RF  $50\Omega$  with  $50\Omega$ . Setting: RF LEVEL 13 dBm (+19 dBm with option SMY-B40)
- \_ The rectified RF voltage can be measured using special function 104.

Typical voltages are given in the table below:

RF frequency	Diagnostic voltage	在在中国的影響等的影響的影響的影響的影響的影響的一样。—
10 MHz	0.2V	
100 MHz	0.7V	
200 MHz	1.10	
300 MHz	1.0V	
400 MHz	1.3V	
500 MHz	1.4V	
600 MHz	1.4V	
700 MHz	1.0V	
800 MHz	1.4V	•
900 MHz	0.6V	
1000 MHz	1.5V	
1040 MHz	2.5V	

### 7.4.7 IF Gain Adjustment

- ullet Connect a spectrum analyzer to the instrument output RF 50 $\Omega$ .
- Setting: RF 10 MHz LEVEL 13 dBm (+19 dBm with option SMY-B40)
- Measure RF signal, note RF level
- Decrease RF frequency by 1 Hz
- Adjust the RF level to the same value using the potentiometer R645
- Subsequent to adjustment, call the calibration routine LEVEL PRESET.

# 7.4.8 IF Detector Linearity Adjustment

- Setting: RF 9.9 MHz
  LEVEL 0.1 dBm (6.1 dBm with option SMY-B40)
- Measure and note the output level at the RF output (= reference level)
- Setting: Switch on special function 1 (non-interrupting level setting)

  LEVEL -19.9 dBm (-13.9 dBm with option SMY-B40)
- Adjust R619 that the measured level is 20 dB below the previously measured reference level. Repeat adjustment once, since the reference value slightly changes with use of R619; after the adjustment, the accuracy of the 20 dB reduction shall reach ± 0.1 dB.

# 7.4.9 Detector Linearity Adjustment at the Output FOPU

This adjustment must be carried out only if option SMY-B40 is **not** fitted!

• Setting: RF 100 MHz LEVEL 13 dBm

• Measure and note the output level at the RF output of the instrument (= reference level)

• Setting: Switch on special function 1

(non-interrupting level setting)

LEVEL -7 dBm

 Adjust R851 that the measured level is 20 dB below the previously measured reference level. Repeat adjustment once, since the reference value changes with use of R851; the accuracy of the 20 dB reduction shall reach ± 0.1 dB.

# 7.4.10 AM Depth Adjustment

• Setting: PRESET

LEVEL 7 dBm (+13 dBm with option SMY-B40)

AM EXT DC 100%

Switch on special function 105 (reference value of level control)

- Apply a dc voltage V = -1.000 V to AM EXT.
- Adjust to 0 V using R280.

# 7.5 Disassembly and Assembly

• Remove upper instrument cover.

The module is fixed to the support at the left and right sides. It can be taken out of its slot subsequent to undoing these screws and disconnecting the coaxial connections at X224, X225 and X226.

#### 7.6

#### Final Test

# 7.6.1 Maximum Output Level Check

• Setting:

LEVEL

19 dBm (25 dBm with option SMY-B40)

- Connect a power meter to X226 FOPU. This may require an adequate RF attenuator pad to be installed so that the power sensor is not overdriven.
- Vary the RF frequency from 5kHz to 1040 MHz.
   The RF level must remain > 15 dBm (> 20 dBm with option SMY-B40).

Typical levels are given in the table below:

	SMY01 without option SMY-B40	SMY01 with option SMY-B40				
RF-frequency	output level	output level				
10 MHz	16 dBm	21 dBm				
100 MHz	19 dBm	24 dBm				
200 MHz	19 dBm	26 dBm				
250 MHz	19 dBm	25 dBm				
400 MHz	20 dBm	24 dBm				
500 MHz	18 dBm	25 dBm				
600 MHz	18 dBm	26 dBm				
750 MHz	17 dBm	26 dBm				
800 MHz	19 dBm	26 dBm				
1000 MHz	18 dBm	26 dBm				

# 7.6.2 Harmonics Suppression Check

Instrument without option SMY-B40

• Setting:

LEVEL

10 dBm

- Connect a spectrum analyzer to X226 FOPU.
- The level of the harmonics must be < -30 dBc.

Instrument with option SMY-B40

• Setting:

LEVEL 16 dBm

Special 21 (ALC off)

As the connection from FOPU to the power module is undone for the measurement, the level control must be switched to sample-and-hold operation. This connection must be reestablished before any of the instrument settings are changed!

- Set measurement frequency:
- Connect spectrum analyzer at X226 FOPU. The level of the harmonic must be < -25 dBc.

Typical values are given in the table below:

	SMY01 without	option SMY-B40	SMY01 wih option SMY-B40			
RF-frequency	2*f <sub>RF</sub>		2*fpr			
1 MHz	-50 dBc	-40 dBc	-45 dBc	-50 dBc		
10 MHz	-50 dBc	-45 dBc	-50 dBc	-50 dBc		
100 MHz	-50 dBc	-40 dBc	-50 dBc	-50 dBc		
200 MHz	-45 dBc	-45 dBc	-50 dBc	-50 dBc		
350 MHz	-50 dBc	-40 dBc	-50 dBc	-50 dBc		
650 MHz	-50 dBc	-40 dBc	-45 dBc	-50 dBc		
900 MHz	-35 dBc	-45 dBc	-40 dBc	-50 dBc		
1040 MHz	-45 dBc	-45 dBc	-40 dBc	-50 dBc		

## 7.6.3 Nonharmonics Suppression Check

• Setting:

RF

63 MHz

LEVEL

13 dBm (+19 dBm with option SMY-B40)

• Connect a spectrum analyzer to X226 FOPU.

• Check spurious responses with the subsequent frequencies 703 MHz, 640 MHz, 136 MHz, 73 MHz, 10 MHz

The level of the spurious signals must be < -70 dBc (typ. < -100 dBc).

# 7.7 External Interfaces

Pin	Name	Input/Output	Origin/Dest.	Specified range	Signal description
X2A.01	BLANK	Input	Rear panel	HCMOS level	RF level blanking
X2A.05	DETEXT	Input	Pmod	0 to 10 V	detector voltage, option SME-B40
X2A.07	AMMOD	Input	CPU X3.34	-1V to 1V	AM signal
X2A.12	SERCLK	Input	CPU X3.2	HCMOS level	Clock
X2A.14	SERDAT	Input	CPU X3.4	HCMOS level	Serial data
X2A.15	AT1STB	Input	CPU X3.16	HCMOS level	Strobe 1
X2A.17	HFINT	Output	CPU X3.20	HCMOS level	Interrupt level control
X2A.19	DIAG-5V	Output	CPU X3.6	-5 to 5V	Diagnostics
X2A,22	VA24-P	Input	Power X21.22	23.4 to 24.6V	Analog supply voltage
X2A,24 X2A,25	VA15-P	Input	Power X21.13	14.80 to 15.75V	
X2A.28	VA-5P	Input	Power X21.5	5.10 to 5.25V	Analog supply voltage
X2A.30	<b>VA1</b> 5-N	Input	Power X21.20	-15.75to-14.85V	Analog supply voltage
X224	FSYN	Input !	YSYN X124	6 - 12 dBm	65 - 1040 MHz
X225	REF640	Input i	YSYN X125	9 - 12 dBm	640 MHz
X226	FOPU	Output :	Attenuator X1	-6 to 20 dBm	5 kHz - 1.04 GHz



Schaltteillisten
numerisch geordnet
Part lists
in numerical order
Listes des pièces détachées
par numéros de référence

Kennz. Comp. No.	Benennun Designatio		Sachnummer Stock No.	Harsteller Manufacturer	Bezeichnung Designation		halten in teined in
•	XX VARIANTENERKLIDENTIFICATION (	OF MODELS					
		MODEL .					
	VARO2   MOD 03 = SMY11+S   CDNVERT	SMY-B40 ED D.MDDO2					
	VAR 04 = SMY41 MOD 04 = SMY41 VAR 06 = MIT OP						
	VAR 04 MOD 06 = WITH DP						
C12	CC 47NF+-10%50V	X7R 1206	CC 0007.5195.00	PHILIPS_CO 2	238 581 15645		
C13	CERAMIC CHIP CAP CC 1NF+-1% 50V N SMD CERAMIC CAPA NICHT BESTUECKT	PO 1206	CC 0007.7398.00	1			
C14	NOT FITTED CC 100NF+-10%50V CERAMIC CHIP CAP		CC 0007.5237.00	PHILIPS_CO 2	238 581 15649		
C20	CE 220UF+-20%10V ELECTROLYTIC CAP	RM2,5	CE 0008.7927.00	PANASONIC E	CA-1AFG221I		
C21	CE 10UF+-20%35V ELECTROLYTIC CAP	RD5,5XH6	0803.0667.00	NAT_PANASO E	CE-A1VKS-100		
C22	CE 10UF+-20%35V ELECTROLYTIC CAP	RD5,5XH6	0803.0667.00	NAT_PANASO E	CE-A 1VKS-100		
C132	CC 100NF+-10%50V CERAMIC CHIP CAP		CC 0007.5237.00	PHILIPS_CO 22	238 581 15649		
C133	CC 100NF+-10%50V CERAMIC CHIP CAP		CC 0007.5237.00	PHILIPS_CO 22	238 581 15649		
C149 154	CC 100NF+-10%50V CERAMIC CHIP CAP	ACITOR	CC 0007.5237.00	PHILIPS_CO 22	238 581 15649		1
C156	CC 100NF+-10%50V CERAMIC CHIP CAP	ACITOR	CC 0007.5237.00	PHILIPS_CO 22	238 581 15649		
C157	CC 100NF+-10%50V CERAMIC CHIP CAPA	ACITOR	CC 0007.5237.00	PHILIPS_CO 22	238 581 15649		
C160 162	CC 100NF+-10%50V CERAMIC CHIP CAPA	X7R 1206 ACITOR	CC 0007.5237.00				- 1
C170	CC 100NF+-10%50V CERAMIC CHIP CAPA	X7R 1206	CC 0007.5237.00	PHILIPS_CO 22	238 581 15649		
C209	CC 22PF+-1%50V NE CERAMIC CHIP CAPA	ACITOR	CC 0099.8396.00	MURATA GR	RM42-6COG 220F 50PT		
C219	CC 15PF+-1% 50V CERAMIC CHIP CAPA NUR VAR/ONLY MODE	ACITOR : 02	CC 0099.8750.00		RM42-6COG 150F 50PT		
C219	CC 15PF+-1% 50V CERAMIC CHIP CAPA NUR VAR/ONLY MOD:		CC 0099.8750.00	MURATA GR	RM42~6COG 150F 50PT		
C219	CC 33PF+-1%50V NF CERAMIC CHIP CAPA NUR VAR/ONLY MOD:	PO 1206 CITDR	CC 0099.8780.00	MURATA GR	RM42-6COG 330F 50PT		
C220	CC 68PF+-1%50V NF CERAMIC CHIP CAPA	0 1206	CC 0099.8815.00	MURATA GR	M42-6COG 680F 50PT		
C221	CC 8,2PF+-0,25 50 CERAMIC CHIP CAPA NICHT BESTUECKT	VNP01206	CC 0007.8242.00	MURATA GR	M42-6COG 8R2 C5OPT		
C223	NOT FITTED CC 2,7PF+-0,25 50 CERAMIC CHIP CAPA NUR VAR/ONLY MOD:	CITOR	CC 0007.8188.00	MURATA GR	M42-6CDG 2R7 C50PT		
C223	CC 2,7PF+-0,25 50 CERAMIC CHIP CAPA	VNPO1206 CITOR	CC 0007.8188.00	MURATA GR	M42-6CDG 2R7 C50PT		
C223	NUR VAR/ONLY MOD: CC 2,7PF+-0,25 5C CERAMIC CHIP CAPA NUR VAR/ONLY MOD:	VNPO1206 CITDR	CC 0007.8188.00	MURATA GR	M42-6CDG 2R7 C50PT		
C240	NICHT BESTUECKT/N CC 22PF+-1%50V NP	OT FITTED	CC 0099.8396.00	MURATA GP	M42-6COG 220F 50PT		
C242	CERAMIC CHIP CAPA CC 100PF+-1%50V N	CITOR	CC 0099.8415.00		M42-6C0G 101F 50PT		
C244	CERAMIC CHIP CAPA CC 100NF+-10%50V	CITDR X7R 1206	CC 0007.5237.00				
	CERAMIC CHIP CAPA	CIIDK					
MENP5	413 3PUA äi	Datum Date	Schalttalli Parts lis		Sachnummer Stock No.		Blatt-Nr. Page
ROHDE	&SCHWARZ	16.09.97	EE AUSGANGSTEI		1062.6209.01	SA	1+

	Kennz. Comp. No.	Benann Designa			T		nummer ock No.	Rersteller Manufacturer	Bezeichnung Designation			eiten in eined in
	C245	CC 100NF+-10%5	ίον		CC				2238 581 15649	9		
	C250	CERAMIC CHIP C CC 100NF+-10%5			cc	0007	7.5237.00	PHILIPS CO	2238 581 15649	,		
	264 C275	CERAMIC CHIP C						MURATA	GRM42-6COG 8R2			
	C280	CERAMIC CHIP C	APA	CITOR								•
		CC 22PF+-1%50V CERAMIC CHIP C	APA	CITOR			.8396.00		GRM42-6COG 220			
	C300	CC 10PF+-0,25 CERAMIC CHIP C			cc	0099	.8480.00	MURATA	GRM42-6CDG 100	C50PT		
	C3O2	CC 82PF+-1%50V CERAMIC CHIP C			cc	0099	.8821.00	MURATA	GRM42-6COG 820	F 50PT		
	C3O3	CC 82PF+-1%50V CERAMIC CHIP C	NP	0 1206	cc	0099	.8821.00	MURATA	GRM42-6COG 820	F 50PT		
	C313	CC 100NF+-10%5	ov 3	X7R 1206	cc	0007	.5237.00	PHILIPS_CO	2238 581 15649			
١	C315	CERAMIC CHIP C CC 1NF+-1% 50V	NP	1206	СС	0007	.7398.00	PHILIPS_CO	2222 863 *8102	:		
	C316	SMD CERAMIC CA CC 1NF+-1% 50V			cc	0007	.7398.00	PHILIPS_CO	2222 863 *8102			
	C318	SMO CERAMIC CA CC 100NF+-10%5							2238 581 15649			
d	C319	CERAMIC CHIP C CC 100NF+-10%5	APA(	CITOR	1				2238 581 15649			
1		CERAMIC CHIP C	APA(	CITOR			_					
	C325	CC 100PF+-1%50			CC	0099	.8415.00	MURATA	GRM42-6COG 101	F 50PT		
	C327	CC 1NF+-1% 50V SMO CERAMIC CAI	_	_	CC	0007	.7398.00	PHILIPS_CO	2222 863 *8102			
	C328	CC 1NF+-1% 50V SMO CERAMIC CAI	NPO	1206	CC	0007	.7398.00	PHILIPS_CO	2222 863 *8102			
1	C329	CC 100NF+-10%50 CERAMIC CHIP CA	⟨ VC	(7R 1206	cc	0007	.5237.00	PHILIPS_CO	2238 581 15649			
	C330	CC 100NF+-10%50	C VC	K7R 1206	СС	0007	.5237.00	PHILIPS_CO	2238 581 15649			
ı	C340	CERAMIC CHIP CA	C VC	7R 1206	cc	0007	.5237.00	PHILIPS_CO	2238 581 15649			
ŀ	C356	CERAMIC CHIP CA			cc	0099	.8821.00	MURATA	GRM42-6C0G 820	F 50PT		
١	C357	CERAMIC CHIP CA					.8821.00		GRM42-6COG 820	1		- 1
ı	C359	CERAMIC CHIP CA	<b>APAC</b>	ITOR						3011		- 1
1	C360	CERAMIC CHIP CA	APAC	CITOR				_	2238 581 15649			- 1
		CC 220PF+-1%50\ CERAMIC CHIP CA	<b>APAC</b>	ITOR					2238 863 18221			- 1
Ţ	C361	CC 220PF+-1%50\ CERAMIC CHIP CA			CC	0099	.8850.00	PHILIPS_CO	2238 863 18221			
١	C362	CC 100NF+~10%50			CC	0007	.5237.00	PHILIPS_CO	2238 581 15649			
ı	C400	CC 100NF+-10%50 CERAMIC CHIP CA			CC	0007	.5237.00	PHILIPS_CO	2238 581 15649			
1	C401	CC 1NF+-1% 50V SMO CERAMIC CAP	NPC	1206	CC	0007	.7398.00	PHILIPS_CO	2222 863 *8102			
1	C402	CC 1NF+-1% 50V	NPC	1206	СС	0007	.7398.00	PHILIPS_CO	2222 863 *8102			
	C404	SMD CERAMIC CAP	)V X	7R 1206	СС	0007	.5237.00	PHILIPS_CO	2238 581 15649			
ı	C405	CERAMIC CHIP CA	)V X	7R 1206	СС	0007	.5237.00	PHILIPS_CO	2238 581 15649			
	C410	CERAMIC CHIP CA							2222 863 *8102			1
	C412	SMD CERAMIC CAP	ACI	TOR					2238 863 18221			
	C417	CERAMIC CHIP CA	PAC	ITOR					2238 581 15649			
		CERAMIC CHIP CA	PAC	ITOR								
	C440 442	CC 100NF+-10%50 CERAMIC CHIP CA	PAC	ITOR					2238 581 15649			
	C500	CC 1NF+-1% 50V SMO CERAMIC CAP	ACI	TOR				_	2222 863 *8102	7		
	C501	CC 100NF+-10%50 CERAMIC CHIP CA	_		СС	0007 .	5237.00	PHILIPS_CO	2238 581 15649			
	C504	CC 1NF+-1% 50V SMD CERAMIC CAP	NPO	1206	СС	0007.	7398.00	PHILIPS_CO	2222 863 *8102			
	C505	CC 2,7PF+-0,25 CERAMIC CHIP CA	50V	NPO 1206	СС	0007.	8188.00	MURATA	GRM42-6COG 2R7	C50PT		
	C506	CC 2,2PF+-0,25	50V	NPO 1206	СС	0007.	8171.00	MURATA	GRM42-6COG 2R2	C50PT		
	C507	CERAMIC CHIP CA	50V	NPO 1206	СС	0007.	8171.00	MURATA	GRM42-6COG 2R2	C50PT		
		CERAMIC CHIP CA	PAC	ITOR								
L												
	MENP5	413 3PUA	ìÄ	Datum Date			Schailteilli Parts Ils			hnummer ock No.		Blatt-Nr. Page
	<b>\$</b>		14	16.09.97	<b>E</b>	E VIII	CANCETE	L 1.04 GHZ	1062.62	<u> </u>	SΔ	2+
		&SCHWARZ	, 7	.0.00.01	_	_ 700	Junited Cl	- :.UT GRZ	10052102	JU.U I	<b>-</b>	2.
1			- 1						ī			

	Kennz. Comp. No.	Benennung Designation		Sachnummar Stock No.	Hersteller Manufecturer	Bezeichnung Designation		halten in teined in
	C509	CC 1NF+-1% 50V NPO 120	6 C	0007.7398.00		2222 863 *8102		
	C510	SMD CERAMIC CAPACITOR CC 3,3PF+-0,25 50VNPO12	06 C	0007.8194.00	MURATA (	GRM42-6COG 3R3 C5OPT		:
	C511	CERAMIC CHIP CAPACITOR CC 2,7PF+-0,25 50VNP012	06 CC	0007.8188.00	MURATA (	GRM42-6COG 2R7 C5OPT		ļ
	C512	CERAMIC CHIP CAPACITOR CC 2,7PF+-0,25 50VNPO12		0007.8188.00		GRM42-6COG 2R7 C5OPT		
	C514	CERAMIC CHIP CAPACITOR CC 1NF+-1% 50V NPO 120						
	C515	SMD CERAMIC CAPACITOR				2222 863 *8102		
		CC 4,7PF+-0,25 50VNPO12 CERAMIC CHIP CAPACITOR		0007.8213.00		GRM42-6COG 4R7C 5OPT		ļ
ı	C516	CC 3,9PF+-0,25 50VNPO12 CERAMIC CHIP CAPACITOR		0007.8207.00		GRM42-6COG 3R9 C5OPT		
1	C517	CC 3,9PF+-O,25 50VNPO12 CERAMIC CHIP CAPACITOR	06 CC	0007.8207.00	MURATA G	GRM42-6CDG 3R9 C5OPT		
	C518	CC 1NF+-1% 50V NPO 120 SMO CERAMIC CAPACITOR	3 cc	0007.7398.00	PHILIPS_CO 2	2222 863 *8102		
	C519	CC 1,5PF+-0,25 50VNPO12 CERAMIC CHIP CAPACITOR	D6 CC	0007.8159.00	MURATA G	RM42-6COG 1R5 C5OPT		
۱	C520	CC 1,2PF+-0,25 50VNPO12	o6   cc	0007.8142.00	MURATA G	RM42-6COG 1R2 C5OPT		
	C521	CERAMIC CHIP CAPACITOR CC 1,2PF+-0,25 50VNP012	o6 cc	0007.8142.00	MURATA G	RM42-6COG 1R2 C5OPT		
	C526	CERAMIC CHIP CAPACITOR CC 100NF+-10%50V X7R 12	o6   CC	0007.5237.00	PHILIPS_CO 2	238 581 15649		
	C527	CERAMIC CHIP CAPACITOR CC 1NF+-1% 50V NPO 120	cc	0007.7398.00	PHILIPS_CO 2	222 863 *8102		
ı	C530	SMO CERAMIC CAPACITOR CC 1NF+-1% 50V NPO 120		0007.7398.00		1		
	C531	SMD CERAMIC CAPACITOR CC 1NF+-1% 50V NPO 120	ĺ	0007.7398.00		}		
1	C532	SMO CERAMIC CAPACITOR CC 10PF+-0,25 50VNPO 12	' '	0099.8480.00		RM42-6COG 100 C50PT		
	C533	CERAMIC CHIP CAPACITOR CC 8.2PF+-0,25 50VNP012	ĺ	0007.8242.00				l
	C534	CERAMIC CHIP CAPACITOR				RM42-6COG 8R2 C5OPT		
		CC 8,2PF+-0,25 50VNP0120 CERAMIC CHIP CAPACITOR		0007.8242.00		RM42~6COG 8R2 C5OPT		
ı	C536	CC 1NF+-1% 50V NPO 1200 SMO CERAMIC CAPACITOR		0007.7398.00		222 863 *8102		1
ı	C537	CC 18PF+-1% 50V NPO 120 CERAMIC CHIP CAPACITOR		0099.8767.00		RM42-6CDG 180F 50PT		- 1
1	C538	CC 12PF+-1% 50V NPO 120 CERAMIC CHIP CAPACITOR		0099.8744.00		RM42-6CDG 120 F50PT		
1	C539	CC 12PF+-1% 50V NPO 120 CERAMIC CHIP CAPACITOR	6 CC	0099.8744.00	MURATA GI	RM42-6COG 120 F50PT		- 1
	C540	CC 1NF+-1% 50V NPO 1200 SMD CERAMIC CAPACITOR	cc	0007.7398.00	PHILIPS_CO 2:	222 863 *8102		
1	C545	CC 27PF+-1%50V NPO 1206 CERAMIC CHIP CAPACITOR	cc	0099.8409.00	MURATA GI	RM42-6COG 270F 50PT		
	C546	CC 18PF+-1% 50V NPO 120 CERAMIC CHIP CAPACITOR	6 CC	0099.8767.00	MURATA GI	RM42-6COG 180F 50PT		
	C547	CC 18PF+-1% 50V NPO 120 CERAMIC CHIP CAPACITOR	6 CC	0099.8767.00	MURATA GF	RM42-6CDG 180F 50PT		j
	C553	CC 1NF+-1% 50V NPO 1206 SMD CERAMIC CAPACITOR	cc	0007.7398.00	PHILIPS_CO 22	222 863 *8102		
ı	C560	CC 33PF+-1%50V NPO 1206	СС	0099.8780.00	MURATA GE	RM42-6COG 330F 50PT		l
	C562	CERAMIC CHIP CAPACITOR CC 27PF+-1%50V NPO 1206	СС	0099.8409.0D	MURATA GF	RM42-6COG 270F 50PT		
	C564	CERAMIC CHIP CAPACITOR CC 22PF+-1%50V NPO 1206	cc	0099.8396.00	MURATA GF	RM42-6CDG 220F 50PT		
	C568	CC 5,6PF+-0,25 50VNPO120	в СС	0007.8220.00		RM42-6COG 5R6 C50PT		
	C569	CERAMIC CHIP CAPACITOR CC 1NF+-1% 50V NPO 1206		0007.7398.00				
	C570	SMD CERAMIC CAPACITOR CC 10PF+-0,25 50VNPO 120	-	0099.8480.00		RM42-6COG 100 C50PT		
	C573	CERAMIC CHIP CAPACITOR CC 12PF+-1% 50V NPO 120	- 1	0099.8744.00		RM42-6COG 120 F50PT		
	C575	CERAMIC CHIP CAPACITOR CC 12PF+-1% 50V NPO 120	_	0099.8744.00		RM42-6C0G 120 F50PT		
	C580	CERAMIC CHIP CAPACITOR CC 12PF+-1% 50V NPO 120		0099.8744.00				
	C582	CERAMIC CHIP CAPACITOR CC 10PF+-0,25 50VNPO 120				RM42-6COG 120 F50PT		
	C582	CERAMIC CHIP CAPACITOR		0099.8480.00		RM42-6COG 100 C50PT		
	U304	CC 5,6PF+-0,25 50VNPO120 CERAMIC CHIP CAPACITOR		0007.8220.00	MUKATA GR	RM42-6COG 5R6 C5OPT		
Γ	MENP5	413 3PUA At Datum		Schelttelllis Parts list		Sachnummer Stock No.		Biett-Nr. Page
	<b>\$</b>						0.4	
		<b>&amp;SCHWARZ</b> 14 16.09.	97 E	E AUSGANGSTEIL	_ 1.04 GHZ	1062.6209.01	5A	3+
•		: :						, 1

	Kennz. Comp. No.				Sachnummer Stock No.		Harsteller Manufacturer		Bezeichnung Designation		iten in ined in
	C585	CC 100NF+-10%50			CC 00	07.5237.00	PHILIPS_CO	2238 58	1 15649		
	C600	CERAMIC CHIP CA	OV I	NPO 1206	CC 00:	99.8767.00	MURATA	GRM42-60	COG 180F 50PT		
	C601	CERAMIC CHIP CA CC 27NF+-10%50	/X7F	R 1206	CC 009	99.8473.00	PHILIPS_CO	2238 58	1 16633		
	C602	CERAMIC CHIP CA CC 100PF+-1%50V			CC 009	99.8415.00	MURATA	GRM42-60	OG 101F 50PT		
	C603	CERAMIC CHIP CA CC 18PF+-1% 50		CITOR NPO 1206	CC 009	99.8767.00	MURATA	GRM42-60	OG 180F 50PT		
	C604	CERAMIC CHIP CA			CC OOS	99.8480.00	MURATA	GRM42-60	00G 100 C50PT		
	C605	CERAMIC CHIP CA	APA(	CITOR		07.8213.00			COG 4R7C 5OPT		
	C606	CERAMIC CHIP CA	PA(	CITOR		07.8207.00			COG 3R9 C5OPT		
	C607	CERAMIC CHIP CA	PAC	CITOR		07.8194.00			COG 3R3 C5OPT		
	C608	CERAMIC CHIP CA	PA(	CITOR							
		CERAMIC CHIP CA	PA(	CITOR			PHILIPS_CO				
	C609	CC 100NF+-10%50 CERAMIC CHIP CA	PAC	CITOR			PHILIPS_CO				
	C610	CC 100NF+-10%50 CERAMIC CHIP CA	PAC	CITOR			PHILIPS_CO				
	C611	CC 10PF+-0,25 E			CC 009	99.8480.00	MURATA	GRM42-60	COG 100 C50PT		
	C617	CC 3,9PF+-0,25 CERAMIC CHIP CA				7.8207.00		GRM42-60	COG 3R9 C5OPT		
	C618	CC 6,8PF+-0,25 CERAMIC CHIP CA			CC 000	7.8236.00	MURATA	GRM42-60	COG 6R8 C5OPT		
	C6 19	CC 6,8PF+-0,25 CERAMIC CHIP CA	50V	/NPO1206	CC 000	7.8236.00	MURATA	GRM42-60	COG 6RB C5OPT		
	C620	CC 3,9PF+-0,25 CERAMIC CHIP CA	50	/NP01206	CC 000	7.8207.00	MURATA	GRM42-60	COG 3R9 C5OPT		
	C625	CC 10PF+-0.25 5 CERAMIC CHIP CA	OVN	IPO 1206	CC 009	9.8480.00	MURATA	GRM42-60	OG 100 C50PT		
ı	C627	CC 18PF+-1% 50 CERAMIC CHIP CA	V	PO 1206	CC 009	9.8767.00	MURATA	GRM42-60	OG 180F 50PT		
1	C628	CC 100NF+-10%50	V X	7R 1206	CC 000	7.5237.00	PHILIPS_CO	2238 581	15649		
ı	C629	CERAMIC CHIP CA	٥V	7343	CE 000	7.7300.00	SPRAGUE	2930 X9	010 02T		1.4
	C631	TANTALUM SMO-CA	V X	7R 1206	CC 000	7.5237.00	PHILIPS_CO	2238 581	15649		
		CERAMIC CHIP CA NICHT BESTUECKT	_	TIUK							
i	C632	NOT FITTEO CC 47PF+-1%50V			CC 009	9.8496.00	MURATA	GRM42-60	OG 470F 50PT		1
	C633	CERAMIC CHIP CA	V X	7R 1206	CC 000	7.5237.00	PHILIPS_CO	2238 581	15649		
	C634	CERAMIC CHIP CA	5V	7343	CE 000	7.7246.00	SPRAGUE	293D 106	X9 025 D2T		
	C635	TANTALUM SMO-CA	V X	7R 1206	CC 00C	7.5237.00	PHILIPS_CO	2238 581	15649		
	C636	CERAMIC CHIP CA	5V	7343	CE 000	7.7246.00	SPRAGUE	2930 106	X9 025 02T		
	C637	TANTALUM SMO-CA		7343	CE 000	7.7246.00	SPRAGUE	2930 106	X9 025 02T		1
	C638	TANTALUM SMO-CA			CC 00C	7.5237.00	PHILIPS_CO	2238 581	15649		1
	C639	CERAMIC CHIP CA					PHILIPS_CO				
	C640	CERAMIC CHIP CAPACITOR CC 4,7PF+-0,25 50VNPO1206				MURATA		OG 4R7C 50PT			
		CERAMIC CHIP CAPACITOR NICHT BESTUECKT									
	C641	NOT FITTED CC 47PF+-1%50V		1206	CC 009	9.8496.00	MURATA	GRM42-60	OG 470F 50PT		
	C642	CERAMIC CHIP CA	PAC	ITOR		9.8815.00			OG 680F 50PT		
	C643	CC 68PF+-1%50V NPO 1206 CERAMIC CHIP CAPACITOR CC 68PF+-1%50V NPO 1206			9.8815.00			OG 680F 50PT			
		CERAMIC CHIP CAPACITOR CC 4,7PF+-0,25 50VNP01206									
	C644	CERAMIC CHIP CAPACITOR			CC OOL	7.8213.00	MURATA	UKM4270U	OG 4R7C 50PT		
	22.45	NICHT BESTUECKT NOT FITTED			00 0000 0400 00 1110474			00440 00	WAR CORE 4505 505		
	C645	CC 47PF+-1%50V COG 1206 CERAMIC CHIP CAPACITOR			CC 0099.8496.00 MURATA GRN			GKM42~60	COG 470F 50PT		ĺ
Ī	MENP5	413 3PUA	Äl	Datum Date		Schattteil Parts II			Sachnummer Stock No.		Biatt-Nr. Page
				16 00 05				10	1062.6209.01 SA		
		eschwarz 1		16.09.97	EE AUSGANGSTEIL 1.04 GHZ			10	1002.0203.01 3A		4+
1						1					

Kennz. Comp. No.	Benennung Designation		Sachnummer Stock No.	Hersteller Menufecturer	Bazeichnung Dasignation	entheite contein	
C646	CC 8,2PF+-0,25 50VNPO		C 0007.8242.00	MURATA	GRM42-6COG BR2 C5OPT		
C647	CC 12PF+-1% 50V NPO	206 C	C 0099.8744.00	MURATA	GRM42-6COG 120 F50PT		
C650	CERAMIC CHIP CAPACITOR CC 100NF+-10%50V X7R 1	i	C 0007.5237.00	PHILIPS CO	2238 581 15649		
653 C654	CERAMIC CHIP CAPACITOR CC 10NF+-10%50V X7R 12			_			
	CERAMIC CHIP CAPACITOR		C 0099.8521.00	MUKATA	GRM42-6X7R103K 50PT		
C656	CC 1NF+-1% 50V NPO 12 SMO CERAMIC CAPACITOR	06 CC	0007.7398.00	PHILIPS_CO	2222 863 *8102		
C660	CC 100NF+-10%50V X7R 1	206 C	0007.5237.00	PHILIPS_CO	2238 581 15649		
663 C664	CERAMIC CHIP CAPACITOR CC 12PF+-1% 50V NPO 1		0099.8744.00	MURATA	GRM42-6COG 120 F50PT		
C668	CERAMIC CHIP CAPACITOR CC 10PF+-0,25 50VNPO 1		0099.8480.00	MURATA	GRM42-6COG 100 C50PT		
	CERAMIC CHIP CAPACITOR				1		
C670	CC 100NF+-10%50V X7R 1 CERAMIC CHIP CAPACITOR	- 1			2238 581 15649		
C671	CC 100NF+-10%50V X7R 1 CERAMIC CHIP CAPACITOR		0007.5237.00	PHILIPS_CO	2238 581 15649		
C700	CC 1PF+-0,25 50V NPO 1	206 CC	0099.8667.00	PHILIPS_CO	2238 863 15108		
C701	CERAMIC CHIP CAPACITOR CC 1NF+-1% 50V NPO 12	,	0007.7398.00	PHILIPS CO	2222 863 *8102		
C702	SMO CERAMIC CAPACITOR CC 1NF+-1% 50V NPO 12		11				
}	SMO CERAMIC CAPACITOR		i		2222 863 *8102		
C705	CC 56PF+-1%50V NPO 120 CERAMIC CHIP CAPACITOR	Б СС	0099.8809.00	MURATA	GRM42-6COG 560F 50PT		
C707	CC 220PF+-1%50V NPO 12 CERAMIC CHIP CAPACITOR	06 CC	0099.8850.00	PHILIPS_CO	2238 863 18221		
C708	CC 82PF+-1%50V NPO 120	5 cc	0099.8821.00	MURATA	GRM42-6COG 820F 50PT		
C709	CERAMIC CHIP CAPACITOR CC 82PF+-1%50V NPO 120	s cc	0099.8821.00	MURATA	GRM42-6COG 820F 50PT		
C710	CERAMIC CHIP CAPACITOR CC 1NF+-1% 50V NPO 12						
-	SMO CERAMIC CAPACITOR				2222 863 *8102		
C714	CC 2,7PF+-0,25 50VNPO1: CERAMIC CHIP CAPACITOR		0007.8188.00	MURATA	GRM42-6COG 2R7 C5OPT		
C715	CC 220PF+-1%50V NPO 12 CERAMIC CHIP CAPACITOR	06 CC	0099.8850.00	PHILIPS_CO	2238 863 18221		
C720	CC 1NF+-1% 50V NPO 120	06 CC	0007.7398.00	PHILIPS_CO	2222 863 *8102		
C721	SMU CERAMIC CAPACITOR CC 82PF+-1%50V NPO 120	cc	0099.8821.00	MURATA	GRM42-6COG 820F 50PT		
C723	CERAMIC CHIP CAPACITOR CC 82PF+-1%50V NPO 120		0099.8821.00		GRM42-6COG 820F 50PT		
	CERAMIC CHIP CAPACITOR	1					
C724	CC 220PF+-1%50V NPO 120 CERAMIC CHIP CAPACITOR		0099.8850.00				
C727	CC 1NF+-1% 50V NPO 120 SMO CERAMIC CAPACITOR	)6 CC	0007.7398.00	PHILIPS_CO	2222 863 *8102		
C732	CC 220PF+-1%50V NPO 120	)6 CC	0099.8850.00	PHILIPS_CO	2238 863 18221		
C734	CERAMIC CHIP CAPACITOR CC 82PF+-1%50V NPO 1200	s cc	0099.8821.00	MURATA (	GRM42-6COG 820F 50PT		
C735	CERAMIC CHIP CAPACITOR CC 1NF+-1% 50V NPO 120		0007.7398.00		2222 863 *8102		
	SMO CERAMIC CAPACITOR	ľ					
C736	CC 82PF+-1%50V NPO 1200 CERAMIC CHIP CAPACITOR		0099.8821.00		GRM42-6COG 820F 50PT		
C738	CC 47PF+-1%50V COG 1200 CERAMIC CHIP CAPACITOR	S CC	0099.8496.00	MURATA	GRM42-6COG 470F 50PT		
2740	CC 220PF+-1%50V NPO 120	6 CC	0099.8850.00	PHILIPS_CO	2238 863 18221		
C743	CERAMIC CHIP CAPACITOR CC 220PF+-1%50V NPO 120	6   CC	0099.8850.00	PHILIPS_CO :	2238 863 18221		
2747	CERAMIC CHIP CAPACITOR CC 100PF+-1%50V NPO 120		0099.8415.00		GRM42-6COG 101F 50PT		
	CERAMIC CHIP CAPACITOR						
C748	CC 100PF+-1%50V NPO 120 CERAMIC CHIP CAPACITOR		0099.8415.00		GRM42-6COG 101F 50PT		
C <b>7</b> 50	CC 1NF+-1% 50V NPO 120 SMO CERAMIC CAPACITOR	)6  CC	0007.7398.00	PHILIPS_CO :	2222 863 *8102		
0751	CC 1NF+-1% 50V NPO 120	6 cc	0007.7398.00	PHILIPS_CO:	2222 863 *8102		
C762	SMD CERAMIC CAPACITOR CC 1NF+-1% 50V NPO 120	6 CC	0007.7398.00	PHILIPS_CO :	2222 863 *8102		
C800	SMD CERAMIC CAPACITOR CC 100NF+-10%50V X7R 12	206   CC	0007.5237.00	PHILIPS ON S	2238 581 15649		
C801	CERAMIC CHIP CAPACITOR CE 1UF +-10% 25V EIA39						
COU 1	TANTALUM SMD-CAPACITOR	20  CE	0007.7217.00	STRAUUE :	2930 105 X9 025 82T		
MEND	A12 CDUA . Det	m	Schaltteillis	ste für	Sachnummer	l es	att-i
MENP5	413 3PUA ÄI Dat		Parts list		Stock No.		Page
ROHDE	E&SCHWARZ	.97	EE AUSGANGSTEI	L 1.04 GHZ	1062.6209.01	SA	5+

Kennz. Comp. No.	Bananni Dasigna		Sechnummer Stock No.	Hersteller Manufacturer	Bezeichnung Designation	entheiten in contained in
C802	CC 1PF+-0,25 50 CERAMIC CHIP CONICHT BESTUECK	APACITOR	CC 0099.8667.0	PHILIPS_CO 2	2238 863 15108	
C805	NOT FITTED CC 2,7PF+-0,25 CERAMIC CHIP CA	50VNPO1206 APACITOR	CC 0007.8188.00	MURATA (	GRM42-6COG 2R7 C5OPT	
C806	NOT FITTED CC 100NF+-10%50		CC 0007.5237.00	PHILIPS_CO 2	2238 581 15649	
C807	CERAMIC CHIP CA	50VNP01206	CC 0007.8207.00	MURATA G	GRM42-6COG 3R9 C5OPT	
C8 <b>0</b> 9	CERAMIC CHIP CA	25V 7343	CE 0007.7246.00	SPRAGUE 2	293D 106 X9 025 D2T	
C811	TANTALUM SMD-CA	5V RD8X9,5	0803.0580.00	MATSUSHITA E	ECE-A1ESS-101	
C812	ELECTROLYTIC CA CC 1PF+-0,25 50 CERAMIC CHIP CA NICHT BESTUECKT	OV NPO 1206 APACITOR	CC 0099.8667.00	PHILIPS_CO 2	2238 863 15108	
C814	NOT FITTED CC 15PF+-1% 50		CC 0099.8750.00	MURATA G	GRM42~6COG 150F 50PT	
C816	CERAMIC CHIP CA CC 1PF+-0,25 5C CERAMIC CHIP CA NICHT BESTUECKT	OV NPO 1206 NPACITOR	CC 0099.8667.00	PHILIPS_CO 2	2238 863 15108	
C817	NOT FITTED CC 6,8PF+-0,25 CERAMIC CHIP CA NICHT BESTUECKT	APACITOR	CC 0007.8236.00	MURATA G	GRM42-6COG 6R8 C5OPT	
C818	NOT FITTED CC 3,9PF+-0,25		CC 0007.8207.00	MURATA G	RM42-6COG 3R9 C5OPT	
C819	CERAMIC CHIP CA	V X7R 1206	CC 0007.5237.00	PHILIPS_CO 2	238 581 15649	
C820	CERAMIC CHIP CA CE 10UF +-10% 2	5V 7343	CE 0007.7246.00	SPRAGUE 2	93D 106 X9 025 02T	
C821	TANTALUM SMD-CA	V RD8X9,5	0803.0580.00	MATSUSHITA E	CE-A1ESS-101	
C822	ELECTROLYTIC CA	V EIA3528	CE 0007.7217.00	SPRAGUE 2	930 105 X9 025 82T	
C824	TANTALUM SMO-CA	V X7R 1206	CC 0007.5237.00	PHILIPS_CO 2	238 581 15649	
C828	CERAMIC CHIP CA	V EIA3528	CE 0007.7217.00	SPRAGUE 2	930 105 X9 025 82T	
C829	TANTALUM SMO-CA CC 1PF+-0,25 50 CERAMIC CHIP CA NICHT BESTUECKT NOT FITTED	V NPO 1206 PACITOR	cc 0099.8667.00	PHILIPS_CO 2	238 863 15108	
C830	CC 3,9PF+-O,25 CERAMIC CHIP CA NICHT BESTUECKT NOT FITTED	PACITOR	CC 0007.8207.00	MURATA G	RM42-6COG 3R9 C50PT	
C831	CC 3,9PF+-0,25 CERAMIC CHIP CA		CC 0007.8207.00	MURATA G	RM42-6CDG 3R9 C50PT	
C832	CC 100NF+-10%50 CERAMIC CHIP CA	V X7R 1206	CC 0007.5237.00	PHILIPS_CO 2	238 581 15649	
C833	CE 10UF +-10% 2	5V 7343	CE 0007.7246.00	SPRAGUE 2	93D 106 X9 025 D2T	
C834	CE 100UF+-20%25	V RD8X9,5	0803.0580.00	MATSUSHITA E	CE-A1ESS-101	
C836	CE 1UF +~10% 25	V EIA3528	CE 0007.7217.00	SPRAGUE 2	93D 105 X9 025 82T	
C839	TANTALUM SMD-CA CE 1UF +-10% 25	V EIA3528	CE 0007.7217.00	SPRAGUE 2	93D 105 X9 025 B2T	
C840	TANTALUM SMD-CA CC 100NF+-10%50	V X7R 1206	CC 0007.5237.00	PHILIPS_CO 2:	238 581 15649	
843 C844	CERAMIC CHIP CA	NPO 1206	CC 0099.8415.00	MURATA G	RM42-6COG 101F 50PT	
C846	CERAMIC CHIP CA CC 100NF+-10%50 CERAMIC CHIP CA NICHT BESTUECKT	V X7R 1206 PACITOR	CC 0007.5237.00	PHILIPS_CO 2:	238 581 15649	
C847	NOT FITTED CC 47PF+-1%50V		CC 0099.8496.00	MURATA G	RM42~6COG 470F 50PT	
C848	CERAMIC CHIP CA	NPO 0805	CC 0099.8321.00	MURATA G	RM40 COG100C 50 PT	
C849	CERAMIC CHIP CA CC 1PF+-0,25 50 CERAMIC CHIP CA	V NPO 1206	CC 0099.8667.00	PHILIPS_CO 2	238 863 15108	
MENP5	413 3PUA	Äl Datum	Schalttail Parts li		Sachnummer Stock No.	Blatt-Nr. Page
ROHDE	&SCHWARZ	14 16.09.97	EE AUSGANGSTE		1062.6209.01	

Kennz. Comp. No.	Benennung Designation	Sachnummer Stock No.		Bezeichnung Designation	enthalten in contained in
C850 852	CC 100NF+-10%50V X7R 1206 CERAMIC CHIP CAPACITOR	CC 0007.5237.00	PHILIPS_CD 22	238 5B1 15649	
CB53	CC 1NF+-1% 50V NPO 1206	CC 0007.739B.00	PHILIPS_CO 22	22 863 *8102	
C854	SMD CERAMIC CAPACITOR CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	PHILIPS CO 22	38 581 15649	
C855	CERAMIC CHIP CAPACITOR CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	[ _		
	CERAMIC CHIP CAPACITOR				
CB60	CC 100NF+-10%50V X7R 1206 CERAMIC CHIP CAPACITOR	CC 0007.5237.00	_		
C8 <b>7</b> 0	CC 100NF+-10%50V X7R 1206 CERAMIC CHIP CAPACITOR	CC 0007.5237.00	PHILIPS_CD 22	38 581 15649	
CB71	CC 100NF+-10%50V X7R 1206 CERAMIC CHIP CAPACITOR	CC 0007.5237.00	PHILIPS_CD 22	3B 581 15649	
C880	CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	PHILIPS_CO 22	38 581 15649	
C881	CERAMIC CHIP CAPACITOR CE 1UF +-10% 25V EIA3528	CE 0007.7217.00	SPRAGUE 29	3D 105 X9 025 B2T	
C883	TANTALUM SMD-CAPACITOR CE 1UF +-10% 25V EIA3528	CE 0007.7217.00	SPRAGUE 29	3D 105 X9 025 B2T	
C885	TANTALUM SMD-CAPACITOR CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	PHILIPS CO 22	38 581 15649	
C886	CERAMIC CHIP CAPACITOR CC 100NF+-10%50V X7R 1206	CC 0007.5237.00			
	CERAMIC CHIP CAPACITOR		_		
CB87	CC 22PF+-1%50V NPD 1206 CERAMIC CHIP CAPACITOR	CC 0099.8396.00		M42-6CDG 220F 50PT	•
CBB9	CC 100NF+-10%50V X7R 1206 CERAMIC CHIP CAPACITOR	CC 0007.5237.00	PHILIPS_CO 22	38 5B1 15649	
D10	BL PC74HCT4051T BCH.A.MUX	BL 0007.6B27.00	PHILIPS (PO	C)74HCT4051(T)	
D100	ANALDG MULTIPLEXER BL PC74HCT132T 4X2IN SCHM	BL 0007.6340.00	ì	C)74HCT132(D/T)	
D102	NAND SCHMITT TRIGGER 8L PC74HC4094T 8ST.8USREG	8L 0804.0977.00			
0105	8US REGISTER	ŀ			
	8L PC74HCO8T 4X2IN.ANOG QUAO 2INPUT AND GATE	BL 0007.34B6.00			
0110	8US REGISTER	BL 0804.0977.00			
D111	8L PC74HCO8T 4X2IN.ANOG QUAD 2INPUT ANO GATE	8L 0007.3486.00		- V	
D115	8L PC74HC86T 4X2IN EXOR QUAD 2INPUT EXOOR GATE	8L 0007.3511.00			
D120	8L PC74HC4094T 8ST.BUSREG BUS REGISTER	8L 0804.0977.00	PHILIPS_SE (PO	C)74HC4094(D/T)	
0140	8J OAC8143 1X12B-OAC 128 SERIAL D/A-CONVERTER	1012.9510.00	PMI DAC	C8143FS	
0141	BS DG413DY 2A2R ANALOGSCH	1004.7058.00	SILICONIX DG4	413DY	
0145	QUAO ANALOG CMOS.SWITCH BJ DAC8143 1X128-OAC	1012.9510.00	PMI OAC	C8143FS	
0150	128 SERIAL D/A-CONVERTER 8J DAC8143 1X12B-OAC	1012.9510.00	PMI OAC	C8143FS	
D200	12B SERIAL D/A-CONVERTER BS DG413DY 2A2R ANALOGSCH	1004.7058.00	SILICONIX DG4	113DY	
D210	QUAD ANALOG CMOS.SWITCH BS OG413DY 2A2R ANALOGSCH	1004.7058.00		113DY	
D220	QUAD ANALOG CMOS.SWITCH BS DG413DY 2A2R ANALOGSCH	1004.7058.00		113DY	
_	QUAD ANALOG CMOS.SWITCH				
D430	DECODER	BL 0007.6240.00	•	C)74HCT42(T)	
D431	BL PC74HCTO4T 6XINVERT HEXINVERTER	BL 0007.5372.00			
D432	BL PC74HCTO4T 6XINVERT HEXINVERTER	BL 0007.5372.00	PHILIPS_SE (PO	C)74HCTO4(D/T)	
D760	BM SW-239 GAAS SPDTSWITCH GAAS RF-SWITCH	OB53.5579.00	ANZAC SW2	239	
L20	LD 10 UH 10% 3R3 144 MA	LD 0026.41B4.00	DALE IM2	,	
L21	CHDKE				
	SMD-INDUCTOR	LD 0007.9926.00		2422-A3471-K100	
L22	SMD-INDUCTOR	LD 0007.9926.00		2422-A3471-K100	
L300	SMD-INDUCTOR	LD 0520.7911.00		2422-A3221-K100	
L301	LD 22NH 10% 0,60A 1210 SMD-INDUCTOR	1002.4897.00	SIEMENS B82	2422-A3220-K100	
MENP5	413 3PUA At Datum	Schaftteilli:		Sachnummer	Biett-Nr
	413 SPOA At Date	Parts list	for	Stock No.	Paga
ROHDE	14 16.09.97	EE AUSGANGSTEI	L 1.04 GHZ	1062.6209.01	<b>SA</b> 7+

Kennz. Comp. No.	Benennung Designetion			nummer ock No.	Hersteller Manufacturer		zeichnung signation		iten in ined in
L305	LD 1,00UH10%1,000	HMO.390A	LD 0067	.2863.00	DALE	IM2			
L325	CHOKE LD 1,00UH1D%1,00D	HMO,390A	LD 0067	.2863.00	DALE	IM2			
L340	CHDKE LD 1,00UH10%1,000	HMO,390A	LD 0067	.2863.00	DALE	IM2			
Ĺ351	CHDKE LD 1,00UH10%1,00D CHOKE NICHT 8ESTUECKT	HMO,390A	LD 0067	.2863.00	DALE	IM2			
L353	NOT FITTED LD 1,00UH10%1,000 CHOKE NICHT 8ESTUECKT	HMO,390A	LD 0067	.2863.00	DALE	IM2			
L355	NOT FITTED LD 220NH 10% O, SMD-INDUCTOR	28A 1210	LD 0520	.7911.00	SIEMENS	B824	422-A3221-K100		
L360	LD 1,00UH10%1,00D	HMO,390A	LD 0067	.2863.00	DALE	IM2			
L361	CHOKE LD 1,00UH10%1,00D	A088,0MH	LD 0067	.2863.00	DALE	IM2			
L400	CHOKE LD 0,82UH10%0,850	HMO,420A	LD 0067	.2857.00	DALE	IM2			- 1
L410	CHOKE LD 0,68UH10%0,600	HMO, 500A	LD 0067	.2840.00	DALE	IM2			- 11
L416	CHOKE LD 1,00UH10%1,000	A068,0MH	LD 0067	.2863.00	DALE	IM2			
L417	CHOKE LD 1,00UH10%1,000	HMO,390A	LD 0067	.2863.00	DALE	IM2			
L431		38A 1210	LD 6006	.0130.00	SIEMENS	8824	122-A 1 102-K 100		
L432		38A 1210	LD 6006	.0130.00	SIEMENS	8824	122-A1102-K100		
L500	SMD-INDUCTOR LD 1,20UH10%0,180	HMO,620A	LD 0067	.2870.00	DALE	IM2			
L505	CHDKE LD 100NH 10% 0,08	OHM 1,4A	LD 0067	.2740.00	DALE	IM2			
L510	CHOKE LD 0,33UH10%0,220	AOE8,OM	LD 0067	.2805.00	DALE	IM2			
L517	CHOKE LD 0,15UH10%0,100	-M1,230A	LD 0067	.2763.00	DALE	IM2	1		
L520	CHOKE LD 0,82UH10%0,850	-MO,420A	LO 0067	.2857.00	DALE	IM2			
L530	CHOKE LD 3,30UH10%0,850	-MO,285A	LD 0067	.2928.00	DALE	IM2			
L532 534	CHOKE LD 22NH 10% 0,0 SMD-INDUCTOR	60A 1210	1002	.4897.00	SIEMENS	8824	122-A3220-K100		
L536	LD 3,30UH10%0,850F	HMO,285A	LD 0067	.2928.00	DALE	IM2	1		j
L537		60A 1210	1002	.4897.00	SIEMENS	8824	122-A3220-K100		
L538		51A 1210	8000	.5976.00	SIEMENS	8824	122-A3470-K100		
L539		51A 1210	8000	.5976.00	SIEMENS	8824	122-A3470-K100		
L540 542		60A 1210	1002	.4897.00	SIEMENS	8824	122-A3220-K100		
L543	LD 3,30UH10%0,850	HMO,285A	LD 0067	.2928.00	DALE	IM2			
L544		50A 1210	1002	.4897.00	SIEMENS	8824	122-A3220-K100		
L545 547		51A 1210	8000	.5976.00	SIEMENS	8824	122-A3470-K100		
L548 551		60A 1210	1002	.4897.00	SIEMENS	B824	122-A3220-K100		
L553	LD 3,30UH1D%O,85DF	HMO,285A	LD 0067	.2928.00	DALE	IM2			
L559		SOA 1210	1002	.4897.00	SIEMENS	B824	122-A3220-K100		
L560		51A 121D	8000	.5976.00	SIEMENS	8824	122-A3470-K100		
L561		50A 1210	1002	.4897.00	SIEMENS	B824	122-A3220-K 100		
L562		44A 1210	LD 0007	.9249.00	SIEMENS	8824	122-A3101-K100		
L563		51A 1210	8000	.5976.00	SIEMENS	8824	122-A3470-K100		
L564	LD 100NH 1D% 0,4 SMD-INDUCTOR	44A 1210	LD 0007	.9249.00	SIEMENS	8824	122-A3101-K100		
MENP5	413 3PUA ÄI	Detum Dete		Schaitteill Parts lis			Sechnummer Stock No.		Blatt-Nr. Page
ROHD	E&SCHWARZ	16.09.97	EE AU		IL 1.04 GHZ		1062.6209.01	SA	8+

	Kennz. Comp. No.	Banen Dasign				Sachnummar Stock No.	Herstellar Manufacturar		lezeichnung Dasignation		altan in ainad in
	L565	LD 47NH 10% SMD-INDUCTOR	Ο,	51A 1210		0008.5976.00	SIEMENS		2422-A3470-K 100		
	L566	LD 47NH 10%	Ο,	51A 1210		0008.5976.00	SIEMENS	B8:	2422-A3470-K 100		
	L568	SMD-INDUCTOR LD 3,30UH10%0	850	HMO,285A	LE	0 0067.2928.00	OALE	IM:	2		
	L570	CHOKE LD 22NH 10%	Ο,	60A 1210		1002.4897.00	SIEMENS	B82	2422-A3220-K 100		
	572 L580	SMD-INDUCTOR LD 22NH 10%	0,	60A 1210		1002.4897.00	SIEMENS	B82	2422-A3220-K100		
ı	L583	SMD-INDUCTOR LD 22NH 10%	0,	60A 1210		1002.4897.00	SIEMENS	B82	2422-A3220-K 100		
	L584	SMD-INDUCTOR LD 22NH 10%	0,	60A 1210		1002.4897.00	SIEMENS	B82	2422-A3220-K100		
	L585	SMD-INDUCTOR LD 1UH 10%	0,	3BA 1210	LD	6006.0130.00	SIEMENS	B82	2422-A 1102-K 100		
ı	L600	SMD-INDUCTOR LD 1,00UH10%1,	000	HMO,390A	LD	0067.2863.00	DALE	IM2	2		
۱	602 L604	CHOKE LD 1UH 10%	0,3	38A 1210	LD	6006.0130.00	SIEMENS	B82	422-A1102-K100		
	L608	SMD-INDUCTOR LD 12NH 10%	0,	70A 1210		1002.4900.00	SIEMENS	B82	2422-A3120-K100		
	L610	SMD-INDUCTOR LD 12NH 10%	0,	70A 1210		1002.4900.00	SIEMENS	B82	422-A3120-K100		
	L630	SMD-INDUCTOR LD 47NH 10%	0,5	51A 1210		0008.5976.00	SIEMENS	B82	1422-A3470-K 100		
	L632	SMD-INDUCTOR LD 22NH 10%	0,6	50A 1210		1002.4897.00	SIEMENS	B82	422-A3220-K 100		
ı	L633	SMD-INDUCTOR LD 22NH 10%	0,6	50A 1210		1002.4897.00	SIEMENS	BB2	422-A3220-K 100		
۱	L642	SMD-INDUCTOR LD 1,00UH10%1,	0001	MO,390A	LD	0067.2863.00	DALE	IM2			
	L643	CHOKE LO 0,27UH10%0,	160H	MO,975A	LD	0067.2792.00	DALE	IM2			
١	L645	CHOKE LO 0,15UH10%0,	100H	M1,230A	LD	0067.2763.00	OALE	IM2			
	L647	CHOKE LD 0,18UH10%0,	120H	M1, 120A	LD	0067.2770.00	DALE	IM2			
T	L649	CHOKE LD 0,15UH10%0,	100H	M1,230A	LD	0067.2763.00	OALE	IM2			
I	L650	CHOKE LD 22NH 10%	0,6	SOA 1210		1002.4897.00	SIEMENS	B82	422-A3220-K100		
	L651	SMD-INDUCTOR LO 22NH 10%	0,6	OA 1210		1002.4897.00	SIEMENS	B82	422-A3220-K 100		1
١	L660	SMD-INOUCTOR LO 1UH 10%	0,3	8A 1210	LD	6006.0130.00	SIEMENS	8B2	422-A1102-K100		
ı	663 L668	SMD-INOUCTOR LD 1UH 10%	0,3	8A 1210	LD	6006.0130.00	SIEMENS	882	422-A1102-K100		1
I	L670	SMO-INDUCTOR LO 1UH 10%	0,3	8A 1210	LO	6006.0130.00	SIEMENS	B82	422-A 1102-K 100		
	L671	SMD-INDUCTOR LO 1UH 10% SMO-INOUCTOR	0,3	8A 1210	LO	6006.0130.00	SIEMENS	882	422-A1102-K100		
ı	L <b>7</b> 05	LD 220NH 10% SMD-INDUCTOR	0,2	BA 1210	LĐ	0520.7911.00	SIEMENS	B82	422-A3221-K100		
	L706	LD 220NH 10%	0,2	BA 1210	LD	0520.7911.00	SIEMENS	B82	422-A3221 <b>-</b> K100		
	L709	SMD-INDUCTOR LD 4,7UH 10% SMD-INDUCTOR	0,1	5A 1210	LD	000B.16B7.00	SIEMENS	B82	422-A 1472-K 100		
	L714	LD 100NH 10% SMD-INDUCTOR	0,4	4A 1210	LD	0007.9249.00	SIEMENS	B82	422-A3101-K100		
	L720	LD 4,7UH 10% SMD-INDUCTOR	0,1	5A 1210	LD	0008.1687.00	SIEMENS	BB2	422-A 1472-K 100		
	L727	LD 1UH 10% SMD-INDUCTOR	0,3	8A 1210	LD	6006.0130.00	SIEMENS	B82	422-A1102-K100		
	L730	LD 100NH 10% SMD-INDUCTOR	0,4	4A 1210	LD	0007.9249.00	SIEMENS	BB2	422-A3101-K100		
	L732	LD 4,7UH 10% SMD-INDUCTOR	0,1	5A 1210	LD	0008.1687.00	SIEMENS	B82	422-A 1472-K 100		
	L73B	LD 100NH 10% SMD-INDUCTOR	0,4	4A 1210	LD	0007.9249.00	SIEMENS	B82	422-A3101-K100		
	L739	LD 100NH 10% SMD-INDUCTOR	0,4	4A 1210	LD	0007.9249.00	SIEMENS	BB2	422-A3101-K100		
	LBOO	LD 12NH 10% SMD-INDUCTOR	0,7	OA 1210		1002.4900.00	SIEMENS	B82	422-A3120-K100		
		NICHT BESTUECK	T								İ
	L801	LD 1,20UH10%0, CHDKE	180H	MO,620A	LD	0067.2870.00	DALE	IM2			
		TIPINE									
+	MENP5	413 3PUA	Äl	Datum		Schaitteillis			Sachnummer		Blatt-Nr.
-	Δ			Date		Paris list	tor		Stock No.		Page
	ROHDE	&SCHWARZ	14	16.09.97	E	E AUSGANGSTEI	L 1.04 GHZ		1062.6209.01	SA	9+

095,0026-0693

Kennz.	9 an ar	ากแกด	<del></del>	T	Sachnummer	Hersteller		Reseicheung		haite- 1-
Comp. No.	Desig	nation	1	+	Stock No.	Manufecturer		Bezeichnung Designation		haiten in Itainad in
L816	LD 12NH 10% SMD-INDUCTOR		,70A 1210		1002.4900.0		88	32422-A3120-K100		
L819	LD 220NH 10% SMD-INDUCTOR	0	,28A 1210	LC	0520.7911.0	O SIEMENS	В8	32422-A3221-K100		
L828	LD 12NH 10% SMD-INDUCTOR NICHT 8ESTUEC		,70A 1210		1002.4900.0	OO SIEMENS	88	2422-A3120-K100		
L830	NOT FITTED LD 220NH 10%	0	,28A 1210	LD	0520.7911.0	SIEMENS	88	2422-A3221-K100		
L840	SMD-INDUCTOR LD 1UH 10%	0	,38A 1210	LD	6006.0130.0	SIEMENS	в8	2422-A1102-K100	l f	
L841	SMD-INDUCTOR LD 1UH 10%	0.	.38A 1210	LD	6006.0130.0	OSIEMENS	88	2422-A 1 102-K 100	ı	
L843	SMD-INDUCTOR LD 47NH 10%	0,	51A 1210		0008.5976.0	OSIEMENS		2422-A3470-K100		
	SMD-INDUCTOR NICHT BESTUEC	KT								
L845	NOT FITTED LD 100UH 10%	0,	O6A 1210	LD	0007.9261.0	O SIEMENS	88	2422-A1104-K100		
L880	SMD-INDUCTOR LD 1,20UH10%0	, 180	HMO,620A	LD	0067.2870.0	O DALE	IM	2		
L885	LD 1UH 10% SMD-INDUCTOR	٥.	38A 1210	LD	6006.0130.0	O SIEMENS	88	2422-A1102-K100		
N20	80 TLO74ACD		ET OPAMP		0007.7823.0	O TEXAS	TL	074A(CD)		
N130	OPERATIONAL AM 80 NE5532D	2X	LN OPAMP		0007.7798.0			5532D		
N223	OPERATIONAL AN BO TLO72ACD	2XF	ET OPAMP		0803.1057.0	TEXAS	TL	O72 ACDR		
N228	OPERATIONAL AM 80 TLO72ACD	2XF	ET OPAMP		0803.1057.0			O72 ACDR		
N235	OPERATIONAL AM BO NE5534D		OPAMP		0815.7555.00			5534(D)		
N275	OPERATIONAL AN 80 TLO72ACD		FIER ET OPAMP		0803.1057.00			O72 ACDR		
N276	OPERATIONAL AN 80 TLO72ACD	2XF	ET OPAMP		0803.1057.00			O72 ACDR		
N300	OPERATIONAL AN 8M MSAO486 DC-	1PLI 3.2	FIER G MMIC		0846.4293.00			1-0486		1
	8ROAD8AND AMPL NICHT 8ESTUECK	IFI	ER							İ
из60			.3G MMIC		1051.4051.00	AVANTEK	MSA	A-1105-TR1		1
N410	IC MICROWAVE M 8M MSA1105 O	5-1	.3G MMIC		1051.4051.00	AVANTEK	MSA	-1105-TR1		
N600		4XF	ET OPAMP		0007.7823.00	TEXAS	TLC	74A(CD)		
N610	OPERATIONAL AM 80 AD744KR		FIER ET OPAMP		0854.1754.00	ANALOG_DEV	(AD	)744KR		
N840			ET OPAMP		0007.7823.00	TEXAS	TLO	74A(CD)		
N845	OPERATIONAL AM 80 AD744KR BIFET OPAMP		FIER ET OPAMP		0854.1754.00	ANALOG_DEV	(AD	)744KR		
P300	VL EINPRESSSTI	FT L	_=6,8	VL	0010.7250.00	AMP	1-9	28776-5		
P305	VL EINPRESSSTI		·	٧L	0010.7250.00	AMP	1-9	28776-5		
P306	VL EINPRESSSTI		ĺ	VL	0010.7250.00	AMP	1-9	28776-5		
P352	VL EINPRESSSTI			٧L	0010.7250.00	AMP	1-9	28776-5		
P353	VL EINPRESSSTI			VL	0010.7250.00	AMP	1-9	28776-5		
P3 <b>7</b> 5	VL EINPRESSSTI	FT L	-=6.8	VL	0010.7250.00	AMP	1-9	28776-5		
P380	VL EINPRESSSTI	FT L	<b>-</b> =6,8	VL -	0010.7250.00	AMP	1-9	28776-5		
P385	VL EINPRESSSTI			VL (	0010.7250.00	AMP	1-9	28776-5		l
P600	VL EINPRESSSTI	FT L	. <b>=</b> 6,8	VL (	0010.7250.00	AMP	1-9	28776-5		
P601	VL EINPRESSSTI	FT L	- <b>=</b> 6,8	VL (	0010.7250.00	AMP	1-9	28776-5		
P620	VL EINPRESSSTI	FT L	6.8 Ĵ	VL (	0010.7250.00	AMP	1-9	28776-5		
MENP5	413 3PUA	Äl	Datum :		Scheitteli			Sachnummer		Blatt-Nr.
			Date	_	Parts li	st for		Stock No.		Page
ROHDE	ROHDE&SCHWARZ 14 16.09.97 EE AUSGANGSTEIL 1.04 GHZ 1062.6209.01 SA 10+									

Kannz, Comp. No.	Banannung Dasignation	Sachnummer Stock No.		Bezeichnung Designation	enthalten in containad in
P621	VL EINPRESSSTIFT L=6,8	VL 0010.7250.00	1	928 <b>77</b> 6-S	
P628	PIN VL EINPRESSSTIFT L=6,8	VL 0010.7250.00	AMP 1-	928776-S	
P866	PIN VL EINPRESSSTIFT L=6,8 PIN	VL 0010.7250.00	AMP 1-	928 <b>7</b> 76-S	
R9	RG 10,0K0HM+-1%TK100 1206 RG CHIP RESISTOR	RG 0007.0793.00	ROEOERSTEI OC	2 10,0KOHM 1%TK100	
R10	RG 10,0K0HM+-1%TK100 1206 RG CHIP RESISTOR	RG 0007.0793.00	ROEOERSTEI OC	2 10,0KOHM 1%TK100	
R11	RG 182 KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5989.00	ROEOERSTEI OC:	2 182KOHM 1%TK100	
R12	RG 121,0KOH+-1%TK100 1206 CHIP RESISTOR	RG 0007.1960.00	RESISTA OC	2 121KOHM 1% TK100	
R13	RG 121,0KOH+-1%TK100 1206 CHIP RESISTOR	RG 0007.1960.00	RESISTA OC	2 121KOHM 1% TK100	
R14	RG S6,2KOHM+-1%TK100 1206 CHIP RESISTOR	RG 0007.1883.00	ROEOERSTEI OC	2 56,2KOHM 1%TK100	
R1S	RG 27,4KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.589S.00	ROEOERSTEI OC	2 27,4KOHM 1%TK100	
R16	RG 1,0M0HM+-1%TK100 1206 CHIP RESISTOR	RG 0815.7S32.00	ORALORIC CRO	1206	
R17	RG 100 OHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.8884.00	ROEOERSTEI OC2	2 1000HM 1%TK100	
R18	RG 100 0HM+-1%TK100 1206 CHIP RESISTOR	RG 0006.8884.00	ROEOERSTEI OC2	1000HM 1%TK100	
R20	RG 47,5 OHM+-1%TK100 1206 RESISTOR CHIP			47,50HM 1%TK100	
R21	RG 100 DHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.8884.00			
R22 2S	RG 47,S OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5566.00	ROEOERSTEI OC2	47,SOHM 1%TK100	,
R26	RG 10,0K0HM+-1%TK100 1206 RG CHIP RESISTOR	i }		10,0K0HM 1%TK100	
R27 32	RG 47,S OHM+-1%TK100 1206 RESISTOR CHIP			47,50HM 1%TK100	
R33	RG 100 DHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.8884.00		1	
R34	RG 100 OHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.8884.00			
R35	RG 2,0 KOHM+-1%TK100 1206 RESISTOR CHIP			2,0KOHM 1%TK100	
R36	RG 100,0K0H+-1%TK100 1206 CHIP RESISTOR			100K0HM 1%TK100	
R38	RG 10,0K0HM+-1%TK100 1206 RG CHIP RESISTOR			10,0KOHM 1%TK100	
R41	RG CHIP RESISTOR			10,0KOHM 1%TK100	
R50 56	RG 20,0K0HM+-1%TK100 1206 RESISTOR CHIP			20,0KOHM 1%TK100	
R116	RG 10,0K0HM+-1%TK100 1206 RG CHIP RESISTOR			10,0K0HM 1%TK100	
R119	RG 825 OHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.7259.00			
R120 122	RG 100,0KOH+-1%TK100 1206 CHIP RESISTOR	RG 0007.1948.00			
R123	RG 10,0K0HM+-1%TK100 1206 RG CHIP RESISTOR			10,0KOHM 1%TK100	
R124	RG 10,0KDHM+-1%TK100 1206 RG CHIP RESISTOR			10,0K0HM 1%TK100	
R130 132	RG 10,0KDHM+-1%TK100 1206 RG CHIP RESISTOR			10,0K0HM 1%TK100	
R133	RG O-OHM WIOERSTANO-CHIP RESISTOR CHIP O-OHM	RG 0007.5108.00		1206	
R149	RG 10,0K0HM+-1%TK100 1206 RG CHIP RESISTOR			10,0K0HM 1%TK100	
R160	RG 100,0K0H+-1%TK100 1206 CHIP RESISTOR	RG 0007.1948.00			
R161 R162	RG 100,0K0H+-1%TK100 1206 CHIP RESISTOR	RG 0007.1948.00			
R163	RG 1,0 KO +-1%TK100 1206 CHIP RESISTOR RG 1,0 KO +-1%TK100 1206	RG 0006.7271.00			
R16S	RG 1,0 KO +-1%TK100 1206 CHIP RESISTOR RG 100,0K0H+-1%TK100 1206	RG 0006.7271.00			
	CHIP RESISTOR	5557. 1346.00	NOLULINSTEI VUZ	TORGING TATE TO	
MENP5	413 3PUA Äi Datum	Schaltteillis Parts list		Sachnummer Stock No.	Blatt-Nr.
<u></u>	14 16.09.97	EE AUSGANGSTEI		1062.6209.01	

	Kennz. omp. No.	Benennung Designation			Sachnummer Stock <b>No</b> .	Harsteller Manufecturer	Bezeichnung Designation		anth: conta	ilten in inad in
	R166	RG 100,0KOH+-1%TK	100 1206	RG	0007.1948.00	ROEDERSTEI	DC2 100K0HM	1%TK 100		
	R167	CHIP RESISTOR RG 1,0 KO +-1%TK1 CHIP RESISTOR	00 1206	RG	0006.7271.00	ROEDERSTEI	DC2 1,OKOHM	1%TK 100		
	R168	RG 1,0 KO +-1%TK1	00 1206	RG	0006.7271.00	ROEDERSTEI	DC2 1,OKOHM	1%TK 100		
	R170	CHIP RESISTOR RG 100,0KOH+-1%TK CHIP RESISTOR	100 1206	RG	0007.1948.00	ROEDERSTEI	DC2 100KOHM	1%TK 100		
1	R171	RG 100,0KOH+-1%TK	100 1206	RG	0007.1948.00	ROEDERSTEI	DC2 100KOHM	1%TK 100		
	R172	RG 1,0 KO +-1%TK1	00 1206	RG	0006.7271.00	ROEDERSTEI	DC2 1,OKOHM	1%TK 100		
1	R173	CHIP RESISTOR RG 1,0 KO +-1%TK1	00 1206	RG	0006.7271.00	ROEDERSTEI	DC2 1,OKOHM	1%TK 100		
	R208	CHIP RESISTOR RG 9,09KOHM+-1%TK	100 1206	RG	0007.0787.00	ROEDERSTEI	DC2 9,09KOH	M 1%TK100		
F	R209	CHIP RESISTOR RG 10,0KOHM+-1%TK RG CHIP RESISTOR NICHT BESTUECKT	100 1206	RG	0007.0793.00	ROEDERSTEI	DC2 10,OKOH	M 1%TK100		
F	R211	NOT FITTED  RG 3,01KOHM+-1%TK  RESISTOR CHIP	100 1206	RG	0007.5772.00	ROEDERSTEI	DC2 3,01KOH	1%TK 100		
F	R211	NUR VAR/ONLY MOD: RG 3,01KOHM+-1%TK RESISTOR CHIP	100 1206	RG	0007.5772.00	ROEDERSTEI	DC2 3,01KOH	1%TK100		
F	R211	NUR VAR/ONLY MOD: RG 2,21KOHM+-1%TK RESISTOR CHIP NUR VAR/ONLY MOD:	100 1206	RG	0007.5743.00	ROEDERSTEI	DC2 2,21KOH	1%TK100		
F	212	RG 10,0KOHM+-1%TK1 RG CHIP RESISTOR		RG	0007.0793.00	ROEOERSTEI	DC2 10,0K0H	1%TK 100		
F	213	RG 10,0KOHM+-1%TK1	100 1206	RG	0007.0793.00	ROEDERSTEI	DC2 10, DKOHN	1%TK100		
R	214	RG CHIP RESISTOR RG 3,32KOHM+-1%TK1 RESISTOR CHIP	100 1206	RG	0007.5789.00	ROEDERSTEI	OC2 3,32KOHN	1 1%TK 100		
R	215	RG 20,0KOHM+-1%TK1 RESISTOR CHIP	100 1206	RG	0007.5866.00	ROEDERSTEI	OC2 20, OKOHN	1 1%TK 100		
R	216	RG 20,0KOHM+-1%TK1 RESISTOR CHIP NICHT 8ESTUECKT	100 1206	RG	0007.5866.00	ROEDERSTEI	DC2 20,OKOHM	1 1%TK 100		
R	218	NOT FITTEO RG 4,32KOHM+-1%TK1 RESISTOR CHIP	00 1206	RG	0007.5814.00	RESISTA	OC2 4,32KOHM	1 1%TK 100		
R	219	RG 10.0KOHM+-1%TK1 RG CHIP RESISTOR NICHT 8ESTUECKT NOT FITTEO	00 1206	RG	0007.0793.00	ROEDERSTEI	OC2 10, OKOHN	1 1%TK100		
R	221	RG 182 KOHM+-1%TK1 RESISTOR CHIP NICHT BESTUECKT	00 1206	RG	0007.5989.00	ROEOERSTEI	DC2 182KOHM	1%TK 100		
R	222	NOT FITTED  RG O-OHM WIDERSTAN  PESISTOR CHIR O-OH		RG	0007.5108.00	DRALORIC	CR 1206			
R	223	RESISTOR CHIP O-OH RG 10,0KOHM+-1%TK1 RG CHIP RESISTOR		RG	0007.0793.00	ROEDERSTEI	DC2 10,OKOHM	1%TK 100		
R	240	RG 10,0KOHM+-1%TK1	00 1206	RG	0007.0793.00	ROEDERSTEI	DC2 10,OKOHM	1%TK 100		
R	241	RG CHIP RESISTOR RG 20,0KOHM+-1%TK1 RESISTOR CHIP	00 1206	RG	0007.5866.00	ROEDERSTEI	DC2 20,OKOHM	1%TK 100		
R	259	RG 221 KOHM+-1%TK1 RESISTOR CHIP		RG	0007.6004.00	ROEDERSTEI	DC2 221KOHM	1%TK 100		
R	259	NUR VAR/ONLY MOD: RG 221 KOHM+-1%TK1 RESISTOR CHIP NUR VAR/ONLY MOD:	00 1206	RG	0007.6004.00	ROEDERSTEI	DC2 221KOHM	1%TK 100		
R	259	RG 56,2KOHM+-1%TK1 CHIP RESISTOR	00 1206	RG	0007.1883.00	ROEDERSTEI	DC2 56,2KOHM	1%TK 100		
R	271	NUR VAR/ONLY MOD: RG 10,0KOHM+-1%TK1		RG	0007.0793.00	ROEDERSTEI	DC2 10,OKOHM	1%TK 100		
R	272	RG CHIP RESISTOR RG 10,0KOHM+-1%TK1	00 1206	RG	0007.0793.00	ROEDERSTEI	DC2 10,OKOHM	1%TK 100		
R	275	RG CHIP RESISTOR RG 1,0 KD +-1%TK10	0 1206	RG	0006.7271.00	ROEDERSTEI	DC2 1,OKOHM	1%TK 100		
R	276	CHIP RESISTOR RG 10,0K0HM+-1%TK1 RG CHIP RESISTOR	00 1206	RG	0007.0793.00	ROEDERSTEI	DC2 10,OKOHM	1%TK 100		
R	278	RG 47,5KOHM+-1%TK1 RESISTOR CHIP NUR VAR/ONLY MOD:		RG	0007.595D.00	ROEDERSTEI	DC2 47,5KOHM	1%TK 10D		
<del> </del>	MENP5	/12 2DIV -	Datum		Schaltteilli	ste für		Sachnummer		Blatt-Nr.
-   <	<b>8</b>		Date 16.09.97	E	Parts Hsi E AUSGANGSTEI	t for	1062.0	Stock No.	SA	Page
ROHDE&SCHWARZ										

Kennz. Comp. No.	Benennung Designetion		Τ	Sechnummer Slock No.	Hersteller Manufecturer	Bezeichnung Designation		naiten in teinad in
R278	RG 30,1KOHM+-1%TF RESISTOR CHIP	(100 1206	RG		-	DC2 30,1KOHM 1%TK100		
R278	NUR VAR/ONLY MOD RG 30,1KOHM+-1%TH RESISTOR CHIP	(100 1206	RG	0007.5908.00	ROEDERSTEI	DC2 30,1KOHM 1%TK100		
R280	NUR VAR/ONLY MOD: RS 0,25W 5KOHM +- POTENTIOMETER		RS	0007.9632.00	SIEMENS	S4G-5KOHM		
R283	RG 20,0K0HM+-1%TK	(100 1206	RG	0007.5866.00	ROEDERSTEI	DC2 20,0KOHM 1%TK100		
285 R286	RESISTOR CHIP RG 10,0KOHM+-1%TK	100 1206	RG	0007.0793.00	ROEDERSTEI	DC2 10,0K0HM 1%TK100		
R299	RG CHIP RESISTOR RG 33,2KOHM+-1%TK RESISTOR CHIP		RG	0007.5914.00	ROEDERSTEI	DC2 33,2KOHM 1%TK100		
R299	NUR VAR/DNLY MOD: RG 33,2KOHM+-1%TK RESISTOR CHIP	100 1206	RG	0007.5914.00	RDEDERSTEI	DC2 33,2KOHM 1%TK100		
R299	NUR VAR/ONLY MOD: RG 15,OKOHM+-1%TK RESISTOR CHIP	100 1206	RG	0007.5843.00	ROEDERSTEI	DC2 15,0K0HM 1%TK100		
R300	NUR VAR/ONLY MDD: RG 0,05W 27R +-1% RESISTOR		RG	0007.8936.00	HONEST JAP	MR 08 M 27R 1% 0805		
R301 308	RK SMD-HEISSL.220 SMD-NTC-RESISTDR	R 0805		1039.1310.00	SIEMENS	857620-C221-K62		
R310	RG 68,1 OHM+-1%TK CHIP RESISTOR	100 1206	RG	0006.8849.00	ROEDERSTEI	DC2 68,10HM 1%TK100		
R312	RG 12,1 OHM+-1%TK	100 1206	RG	0006.8661.00	ROEDERSTEI	DC2 12,10HM 1%TK100		
R313	RG 56,2 OHM+-1%TK	100 1206	RG	0006.8826.00	ROEDERSTEI	DC2 56,20HM 1%TK100		
R314	RG 511 OHM+-1%TK10 CHIP RESISTOR	00 1206	RG	0006.9051.00	ROEDERSTEI	DC2 5110HM 1%TK100		;
R315	RL 0,60W 1,33KOHM RESISTOR	+-1%TK50	RL	0083.0684.00	RESISTA	MK2		
R316	RG 39.2 OHM+-1%TK	100 1206	RG	0007.5543.00	ROEOERSTEI (	OC2 39,20HM 1%TK100		
R317	RESISTOR CHIP RL 0.60W 1,33KOHM	+-1%TK50	RL	0083.0684.00	RESISTA I	MK2		
R318	RESISTOR RL 0,60W 1,33KOHM	+-1%TK50	RL	0083.0684.00	RESISTA I	MK2		
R319	RESISTOR RG 562 OHM+~1%TK10	00 1206	RG	0006.9068.00	ROEOERSTEI I	DC2 5620HM 1%TK100		
R320	CHIP RESISTOR RG 15,0 OHM+-1%TK	100 1206	RG	0007.5450.00	ROEDERSTEI (	OC2 15,00HM 1%TK100		
R321	RESISTOR CHIP RG 15,0 OHM+-1%TK	100 1206	RG	0007.5450.00	ROEDERSTEI (	DC2 15,00HM 1%TK 100		
R325	RESISTOR CHIP RG 2,0 KOHM+-1%TK	100 1206	RG	0007.5737.00	ROEDERSTEI 1	OC2 2,0KOHM 1%TK100		
R327	RESISTOR CHIP RG 562 OHM+-1%TK10	00 1206	RG	0006.9068.00	ROEDERSTEI (	DC2 5620HM 1%TK100		
R328	CHIP RESISTOR RG 56,2 OHM+-1%TK: CHIP RESISTOR	100 1206	RG	0006.8826.00	ROEDERSTEI [	DC2 56,20HM 1%TK100		
R329	RL 0,60W 1,33KOHM	-1%TK50	RL.	0083.0684.00	RESISTA A	MK2		
R330	RG 15,0 OHM+-1%TK1	100 1206	RG (	0007.5450.00	ROEDERSTEI [	DC2 15,00HM 1%TK100		
R332	RESISTOR CHIP RL 0,60W 1,33KOHM	1%TK50	RL (	0083.0684.00	RESISTA N	MK2		
R333	RESISTOR RG 15,0 OHM+-1%TK1	100 1206	RG (	0007.5450.00	RDEDERSTEI (	OC2 15,00HM 1%TK100		
R340	RESISTOR CHIP RG 511 OHM+-1%TK10	00 1206	RG (	0006.9051.00	ROEDERSTEI D	C2 511DHM 1%TK100		
R341	CHIP RESISTOR RL 0,60W 1,33KOHM*	-1%TK50	RL (	0083.0684.00	RESISTA N	1K2		
R342	RESISTOR RG 39,2 OHM+-1%TK1	00 1206	RG (	0007.5543.00	RDEDERSTEI D	DC2 39,2DHM 1%TK100		
R355	RESISTOR CHIP RG O-OHM WIDERSTAN		RG (	0007.5108.00	DRALDRIC C	CR 1206		
R356	RESISTOR CHIP O-OH RL 0,60W 100 OHM+-		RL (	0082.6543.00	RESISTA N	nK2		
R357	RESISTOR RL 0,60W 100 OHM+-	1%TK50	RL (	0082.6543.00	RESISTA N	iK2		
R358	RESISTOR RG O-OHM WIDERSTAN RESISTOR CHIP O-OH NICHT BESTUECKT NOT FITTED		RG (	0007.5108.00	DRALORIC C	CR 1206		
MENP5	413 3PUA äi	Datum		Schakteilis	ite für	Sachnummer		Blatt-Nr.
m=11C 3	TIO GEOM AI	Date		Parts list		Stock No.		Page
ROHDE	&SCHWARZ 14	16.09.97	Ei	E AUSGANGSTEII	L 1.04 GHZ	1062.6209.01	SA	13+

Kennz. Comp. No.	Benennung Designation	Sachnummer Stock No.		Bezeichnung Designation	enthalten in contained in
R360	RL 0,60W 100 0HM+-1%TK50	RL 0082.6543.00	RESISTA MK	2	
R361	RESISTOR RL 0,60W 100 OHM+-1%TK50 RESISTOR	RL 0082.6543.00	RESISTA MK	2	
R400	RG 511 OHM+-1%TK100 1206	RG 0006.9051.00	ROEDERSTEI DC	2 5110HM 1%TK100	
R401	CHIP RESISTOR RL 0,60W 1,33KOHM+-1%TK50 RESISTOR	RL 0083.0684.00	RESISTA MK	2	
R402	RG 39,2 OHM+-1%TK100 1206	RG 0007.5543.00	ROEDERSTEI DC	2 39,20HM 1%TK 100	
R404	RESISTOR CHIP RG 56,2 OHM+-1%TK100 1206	RG 0006.8826.00	ROEDERSTEI DC	2 56,20HM 1%TK100	
R405	CHIP RESISTOR RG 562 OHM+-1%TK100 1206	RG 0006.9068.00	ROEDERSTEI DC	2 5620HM 1%TK100	
R406	CHIP RESISTOR RG 15,0 OHM+-1%TK100 1206	RG 0007.5450.00	ROEDERSTEI DC	2 15,00HM 1%TK100	
R407	RESISTOR CHIP RG 15,0 OHM+-1%TK100 1206	RG 0007.5450.00	ROEDERSTEI DC:	2 15,00HM 1%TK100	
R408	RESISTOR CHIP RL 0,60W 1,33KOHM+~1%TK50	RL 0083.0684.00		1	
R409	RESISTOR RL 0,60W 1,33KDHM+-1%TK50	RL 0083.0684.00	RESISTA MK2	2	
R410	RESISTOR RG 39,2KOHM+-1%TK100 1206	RG 0007.5937.00	ROEDERSTEI DC2	2 39,2KDHM 1%TK100	
R411	RESISTOR CHIP RG 1,5 KOHM+-1%TK100 1206			2 1,5KOHM 1%TK100	
R412	RESISTOR CHIP RG 1,0 KO +-1%TK100 1206	4 1		2 1,0KDHM 1%TK100	
R416	CHIP RESISTOR RL 0,60W 100 OHM+-1%TK50	RL 0082.6543.00			
R417	RESISTOR RL 0,60W 100 DHM+-1%TK50	RL 0082.6543.00	RESISTA MK2	1	ì
R431	RESISTDR RG 10,0K0HM+-1%TK100 1206	RG 0007.0793.00	ROEDERSTEI OC2	10,0KDHM 1%TK100	
438 R440	RG CHIP RESISTOR RG 10,0K0HM+-1%TK100 1206	i i		10,0K0HM 1%TK100	
R442	RG CHIP RESISTOR RG 10,0K0HM+-1%TK100 1206			10,0KOHM 1%TK100	
R443	RG CHIP RESISTOR RG 10,0K0HM+-1%TK100 1206	l J		10,0K0HM 1%TK100	11
R450	RG CHIP RESISTOR RG 100 OHM+-1%TK100 1206	RG 0006.8884.00			
R451	CHIP RESISTOR RG 150 OHM+-1%TK100 1206	RG 0007.5589.00			
R452	RESISTOR CHIP RG 182 OHM+-1%TK100 1206	RG 0007.5595.00			
R453	RESISTOR CHIP RG 150 OHM+-1%TK100 1206	RG 0007.5589.00			
R454	RESISTOR CHIP RG 100 OHM+-1%TK100 1206	RG 0006.8884.00			
R455	CHIP RESISTOR RG 56,2 DHM+-1%TK100 1206	RG 0006.8826.00			
R500	CHIP RESISTOR RG 2,0 KOHM+-1%TK100 1206	RG 0007.5737.00			
502 R503	RESISTOR CHIP RG 392 DHM+-1%TK100 1206	RG 0007.5672.00			
R520	RESISTOR CHIP RG 1,21KOHM+-1%TK100 1206			1,21KOHM 1%TK100	
522 R530	CHIP RESISTDR RG 392 DHM+-1%TK100 1206	RG 0007.5672.00			
R600	RESISTOR CHIP RG 221 OHM+-1%TK100 1206	RG 0007.5614.00			
R601		RL 0083.0178.00			
R602	RESISTOR RG 27,4 OHM+-1%TK100 12D6	RG 0007.5508.00	RDEDERSTEI DC2	27,4DHM 1%TK100	
R603	RESISTOR CHIP RG 33,2 OHM+-1%TK100 1206	RG 0007.5520.00			
R604	RESISTOR CHIP RG 68,1 OHM+-1%TK100 1206	RG 0006.8849.00			
R605	CHIP RESISTOR RG 15,0 DHM+-1%TK100 1206	RG 0007.5450.00			
R606	RESISTOR CHIP RG 2,74KDHM+-1%TK100 1206	ĺ		2,74KDHM 1%TK100	
R607	RESISTOR CHIP RG 825 KOHM+-1%TK100 1206	RG 0007.6133.00			
R608	RESISTDR CHIP RG 100 OHM+-1%TK100 1206	RG 0006.8884.00 F			
	CHIP RESISTOR				
MENP5	413 3PUA ÄI Datum	Schaltteillis		Sachnummer	Blatt-Nr.
	Date	Parts list	tor	Stock No.	Page
ROHDE	<b>&amp;SCHWARZ</b> 14 16.09.97	EE AUSGANGSTEIL	_ 1.D4 GHZ	1062.6209.01	SA 14+

Kennz. Comp. No.	Bene: Desig	nnung natio				nummer ck No.	Hersteller Manufecturer		Sezelchnung Designation	halten in Itelned in
R609	RG 1,5 KOHM+- RESISTOR CHIP		K100 1206	RG	0007	.5714.0	ROEDERSTE		2 1,5KOHM 1%TK100	
R611	RG 392 OHM+-1	%TK	100 1206	RG	0007	.5672.0	ROEDERSTE	I DC	2 392DHM 1%TK100	
R612	RESISTOR CHIP RG 475 OHM+-1	%TK	100 1206	RG	0007	.5695.0	ROEDERSTE	I DC	2 4750HM 1%TK100	
R613	RESISTOR CHIP RG 3,01KOHM+-	1%T	K100 1206	RG	0007	.5772.0	ROEDERSTE	DC:	2 3,01KDHM 1%TK100	
R614	RESISTOR CHIP RG 2,74KOHM+-		K10D 1206				Ì		2 2,74KOHM 1%TK100	
R615	RESISTOR CHIP RG 1,2MDHM+-5		200 1206	ĺ			ROEDERSTE			
	CHIP RESISTOR NICHT BESTUEC NOT FITTED									
R616	RG 3,01KDHM+- RESISTDR CHIP	1%TI	(100 1206	RG	0007	5772.00	RDEDERSTE	DC	2 3,01KOHM 1%TK100	
R6 17	RG 1,2MOHM+-5 CHIP RESISTOR NICHT BESTUEC		200 1206		0007	.9949.00	ROEDERSTEI	D 2	25 .	
R618	NOT FITTED RG 100,0KDH+-	1%T#	(100 1206	RG	0007	1948 00	POEDEDSTET	DCS	! 100K0HM 1%TK100	
R619	CHIP RESISTOR RS 0.25W 5KDH			1			SIEMENS		1	
R620	POTENTIOMETER RG 100, OKOH+-			1					S-5KOHM	
R621	CHIP RESISTDR			1					100KDHM 1%TK 100	
	RG 475 DHM+~19 RESISTOR CHIP								4750HM 1%TK100	
R622	RG 100 DHM+-1% CHIP RESISTOR			RG	0006.	8884.00	ROEDERSTEI	0C2	1000HM 1%TK100	
R623	RK SMD-HEISSL. SMD-NTC-RESIST NICHT BESTUECK	ror	R 0805		1039.	1310.00	SIEMENS	857	620-C221-K62	
R624	NOT FITTEO RK SMD-HEISSL.		R 0805		1039.	1310.00	SIEMENS	857	620-C221-K62	
R625	SMD-NTC-RESIST RG 18,2 OHM+-1		100 1206	RG	0007.	5466.00	ROEOERSTEI	DC2	18,20HM 1%TK100	
R626	RESISTOR CHIP RG 100 OHM+-1%	TK 1	00 1206						1000HM 1%TK 100	
R627	CHIP RESISTOR RG 56,2 OHM+-1		-						56,20HM 1%TK100	
R628	CHIP RESISTOR RG 100 OHM+-1%								1000HM 1%TK100	
R629	CHIP RESISTOR RG 100 OHM+-1%									
R630	CHIP RESISTOR RG 825 OHM+-1%								1000HM 1%TK100	
R631	CHIP RESISTOR								8250HM 1%TK 100	
	RG 825 OHM+-1% CHIP RESISTOR								8250HM 1%TK100	
R632	RG O-OHM WIOER RESISTOR CHIP	0-0	HM				ORALORIC		1206	
R634	RG 5,620HM+-1% CHIP-RESISTOR						PHILIPS	RC (		
R635	RG 22,1KOHM+-1 RESISTOR CHIP								22,1KOHM 1%TK100	
R636	RG 10, OKDHM+-1'RG CHIP RESIST		100 1206	RG (	0007.	0793.00	ROEDERSTEI	DC2	10,0KOHM 1%TK100	
R637	RG 1,5 KOHM+-19 RESISTOR CHIP		100 1206	RG (	0007.	5714.00	ROEDERSTEI	DC2	1,5KOHM 1%TK100	
R638	RG 392 OHM+-1% RESISTOR CHIP	TK 10	00 1206	RG (	0007.	672.00	ROEDERSTEI	DC2	392DHM 1%TK1D0	
R639	RG 10,0KOHM+-19		100 1206	RG (	0007.	0793.00	ROEDERSTEI	DC2	10,0KOHM 1%TK100	
R640	RG O-OHM WIDER:	STAN		RG (	0007.	5108.00	DRALORIC	CR 1	206	
R641	RESISTOR CHIP I			RG (	0007.	5450.00	ROEDERSTEI	DC2	15,0DHM 1%TK100	İ
R642	RESISTOR CHIP RG 51,1 OHM+-1	%TK							51, 1DHM 1%TK100	
R644	CHIP RESISTOR RG 475 DHM+-1%	TK 10							4750HM 1%TK100	
R645	RESISTOR CHIP RS 0,25W200 OH							_	200 OHM	ļ
R646	POTENTIOMETER RL 0,60W 182 DE		. [						250 07(11)	
R647	RESISTOR RL D,60W 121 OF RESISTOR							MK2 MK2		
MENP5	413 3PUA	Äl	Datum Date			Schaltteilli Parts lis			Sachnummer Stock No.	9istt-Nr. Page
ROHDE&SCHWARZ 14 16.09.97 EE AUSGANGSTEIL 1.04 GHZ 1062.6209.01 SA 15+										

Kannz. Comp. No.	Banannung Designation	al 100 a	Sachnummar Stock No.	Harstaller Menufacturar	Bezeichnung Designation	anthaltan in containad in
R648	RG 100 OHM+-1%TK100	1206	RG 0006.8884.00	ROEDERSTEI	DC2 1000HM 1%TK100	
R649	RG 2,740HM+-1%TK100	1206	RG 0007.8365.00	PHILIPS	RC 02	
R650	CHIP-RESISTOR RG 1,0MOHM+-1%TK100	1206	RG 0815.7532.00	DRALORIC	CRC 1206	
R651	CHIP RESISTOR   RG 681 KOHM+-1%TK100   RESISTOR CHIP	1206	RG 0007.6110.00	ROEDERSTEI	DC2 681KOHM 1%TK100	
R652	RG 68,1 OHM+-1%TK100	1206	RG 0006.8849.00	ROEDERSTEI	DC2 68,10HM 1%TK100	
R653	RG 56,2 OHM+-1%TK100	1206	RG 0006.8826.00	ROEDERSTEI	DC2 56,2DHM 1%TK100	
R654	RG 56,2 DHM+-1%TK100 CHIP RESISTOR	1206	RG 0006.8826.00	ROEDERSTEI	DC2 56,20HM 1%TK100	
R655	RG 2,210HM+-1%TK100 CHIP-RESISTOR	1206	RG 0007.8342.00	PHILIPS F	RC 02	
R657	RG 10,0K0HM+-1%TK100 RG CHIP RESISTDR	1206	RG 0007.0793.00	ROEDERSTEI I	DC2 10,0KOHM 1%TK100	
R658	RG 10,0KOHM+-1%TK100 RG CHIP RESISTOR	1206	RG 0007.0793.00	ROEDERSTEI I	DC2 10,0KOHM 1%TK100	
R700	RG 82,5 OHM+-1%TK100 CHIP RESISTOR	1206	RG 0006.8861.00	ROEDERSTEI I	DC2 82,50HM 1%TK100	
R701	RG 1,0 KO +-1%TK100 CHIP RESISTOR	1206	RG 0006.7271.00	ROEDERSTEI (	DC2 1,0KOHM 1%TK100	
R702	RG 475 KOHM+-1%TK100 RESISTOR CHIP	1206			DC2 475KOHM 1%TK100	
R704	RG 1,0 KO +-1%TK100 CHIP RESISTDR	1206			DC2 1,0KOHM 1%TK100	
R705	RG 1,0M0HM+-1%TK100 CHIP RESISTOR	1206	RG 0815.7532.00		CRC 1206	1 16
R706	RG 1,21KOHM+-1%TK100 CHIP RESISTOR				DC2 1,21KOHM 1%TK100	
R707	RG 1,21KOHM+-1%TK100 CHIP RESISTOR		}		DC2 1,21KDHM 1%TK100	
R709	RG 100 OHM+-1%TK100 CHIP RESISTOR	1206			DC2 100DHM 1%TK100	
R710	RG 121 OHM+-1%TK100 CHIP RESISTOR	1206			DC2 1210HM 1%TK100	
R720	RG 100 OHM+-1%TK100 CHIP RESISTOR	1206			DC2 1000HM 1%TK100	
R721	RG 121 OHM+-1%TK100 CHIP RESISTOR	1206			DC2 1210HM 1%TK 100	4.11
R723	RG 1,21KOHM+-1%TK100 CHIP RESISTOR				OC2 1,21KOHM 1%TK100	
R724	RG 1,21KOHM+-1%TK100 CHIP RESISTOR				0C2 1,21K0HM 1%TK100	
R730	RG 332 OHM+-1%TK100 RESISTOR CHIP	1206			0C2 3320HM 1%TK100	
R731 R732	RG 1,21KOHM+-1%TK100 CHIP RESISTOR RG 1,21KOHM+-1%TK100				0C2 1,21KOHM 1%TK100	
R734	CHIP RESISTOR RG 121 OHM+-1%TK100				0C2 1,21K0HM 1%TK100 0C2 1210HM 1%TK100	
R735	CHIP RESISTOR RG 100 OHM+-1%TK100		1		0C2 1000HM 1%TK100	
R745	CHIP RESISTOR RG 10,0KOHM+-1%TK100				0C2 10,0K0HM 1%TK100	
R747	RG CHIP RESISTOR RG 8,25KOHM+-1%TK100				0C2 8,25K0HM 1%TK100	
R748	CHIP RESISTOR RG 8,25KDHM+-1%TK100		l i		0C2 8,25KOHM 1%TK100	
R750	CHIP RESISTOR RG 332 OHM+-1%TK100	1206			0C2 3320HM 1%TK100	
R751	RESISTOR CHIP RG 332 DHM+-1%TK100	1206			C2 3320HM 1%TK100	
R753	RESISTOR CHIP RG 475 DHM+-1%TK100	1206			C2 4750HM 1%TK100	
R754	RESISTOR CHIP RG 475 OHM+-1%TK100				C2 4750HM 1%TK100	
R760	RESISTOR CHIP RG 10,0KOHM+-1%TK100				C2 10,0KOHM 1%TK100	
R761	RG CHIP RESISTOR RG O-OHM WIDERSTAND-(		RG 0007.5108.00		R 1206	
R762	RESISTOR CHIP 0-0HM RG 47,5 DHM+-1%TK100	1206			0C2 47,50HM 1%TK100	
R801	RESISTOR CHIP RG O-OHM WIDERSTAND-(	CHIP	RG 0007.5108.00	DRALORIC C	CR 1206	
	RESISTOR CHIP O-OHM					
MENP5		Datum Date	Schaittailii Parts list		Sachnummar Stook Mo	Biatt-Nr.
		M-010	raits list		Stock No.	Page
** ROHDE&SCHWARZ   14   16.09.97   EE AUSGANGSTEIL 1.04 GHZ   1062.6209.01 SA   16+						

Kennz. Comp. No.		Benen Design					aummer ek No.	Harstellar Manufacturer	Bezelchnur Designatio			naitan in tainad in
R802		5 OHM+-	1%TK 100	1206	RG	0007	.5566.00	ROEDERSTEI	DC2 47,5	OHM 1%TK 100		
		DR CHIP BESTUEC	кт									
R803	NOT FI	TTED 2KOHM+-	1%TK 100	1206	<sub>PC</sub>	0007	. E700 AC	POEDEDCTET	DC0 0 00	KOHM 1%TK 100		
	RESIST	OR CHIP			1							
R804		1 OHM+- DR CHIP	1%TK 100	1206	RG	0007	.5489.00	ROEDERSTEI	DC2 22,1	DHM 1%TK 100		
R806	RG 1,0	KO +-1	%TK 100	1206	RG	0006	.7271.00	ROEDERSTEI	DC2 1,0K	DHM 1%TK100		
R807	RG 1,0	ESISTDR KO +-19	%TK 100	1206	RG	0006	.7271.00	ROEDERSTEI	DC2 1,0K	DHM 1%TK 100		
R808		ESISTOR OKOHM+~:	1%TK 100	1206						KOHM 1%TK 100		
R809	RG CHI	P RESIST	FOR		ł			1				
		OHM+-19 ESISTOR	6 IK 100	1206	IKG	0006	.9068.00	ROEDERSTEI	DC2 5620F	IM 1%TK 100		
R811		50HM+-1% ESISTOR	TK 100	1206	RG	0007	.8488.00	PHILIPS	RC 02			
R812 815	RG 12,	1 OHM+-1 ESISTOR	I%TK 100	1206	RG	0006	.8661.00	ROEDERSTEI	DC2 12,10	OHM 1%TK100		
R816	RG 27,4	4 OHM+-1	1%TK 100	1206	RG	0007	.5508.00	ROEDERSTEI	DC2 27,4	HM 1%TK 100		
R817		DR CHIP 5 OHM+-1	1%TK 100	1206	RG	0007	.5566.00	  ROEDERSTEI	DC2 47.50	HM 1%TK100		
R819		OR CHIP KO +∽1%	(TK 100	1206				ROEDERSTEI				
	CHIP RE	ESISTOR		_				J				
R8 20	CHIP RE			1206	ŀ			ROEOERSTEI				
R821		OKOHM+-1 P RESIST	_	1206	RG	0007	.0793.00	RDEDERSTEI	DC2 10,0K	OHM 1%TK100		
R822		OHM+-1%		1206	RG	0006	.9068.00	ROEDERSTEI	DC2 5620H	M 1%TK100		
R823	RG 6,81	IOHM+-1%	TK100	1206	RG	0007	.8465.00	PHILIPS	RC 02			
R824	CHIP-RE	:SISTOR 50HM+-1%	TK 100	1206	RG	0007	.8488.00	PHILIPS	RC 02			
82 <b>7</b> R828	CHIP-RE	SISTOR OHM+-1%	TK 100	1206				ROEDERSTEI		W 19/TV 100		
11020	RESISTO	OR CHIP		1200	I.G	0007	. 5505 . 00	KOLDEKSTET	DC2 1900F	IM TATK TOO		
	NOT FIT											
R829	RG 182 RESISTO	OHM+-1% OR CHIP	TK 100	1206	RG	0007	.5595.00	ROEDERSTEI	DC2 1820H	M 1%TK100		
R830	RG 1,0	KO +-1%	TK 100	1206	RG	0006	.7271.00	ROEOERSTEI	OC2 1,0KO	HM 1%TK100		
R831		KO +-1%	TK 100	1206	RG	0006	7271.00	ROEDERSTEI	OC2 1,0KO	HM 1%TK100		
R832	RG 10,0	:SISTOR  KOHM+-1	%TK 100	1206	RG	0007	0793.00	ROEDERSTEI	DC2 10.0K	OHM 1%TK100		
R833		RESIST						ROEOERSTEI				
R834	CHIP RE									# 1/11K100		
838	CHIP-RE	SISTOR						PHILIPS	RC 02			
R839	RL 0,40 RESISTO	W 2 <b>7</b> 0 0 R	HM2% U	VGEW.	RL.	0092	6000.00	RESISTA	MK1 2700H	M 2% UNGEW.		
R841	RG 100 CHIP RE	OHM+-1%	TK 100	1206	RG	0006	8884.00	ROEDERSTEI	DC2 1000H	M 1%TK100		
DO 44	NUR VAR	/ONLY M		1000			0004.00					
R841	CHIP RE			1206	KG	0006.	8884.00	ROEDERSTEI	DC2 1000H	M 1%TK100		
R841		/DNLY MOONLY MOONLY MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE MARKET TO THE		1206	RG	0006	8884.00	ROEDERSTEI	DC2 1000Hi	M 1%TK100		
	CHIP RE						2 . 3 . 3 . 3					
D0 40	NICHT 8	ESTUECK	T/NOT £	ITTED	50	0000	0000					I
R842	CHIP RE			1206	KĞ	OOO6.	8884.00	RDEDERSTEI	DC2 100DH	M 1%TK 100		
R842	NUR VAR RG 100			1206	RG	0006	.8884.00	ROEDERSTEI	DC2 1000H	M 1%TK 100		
	CHIP RE	SISTOR					22300		- 01 (OOD)	1/1/18/100		ļ
R842	RG O-OH	M WIDER	STAND-0	HIP	RG	0007.	5108.00	DRALORIC	CR 1206			
		R CHIP (		06								
R843	RG 182 RESISTD	OHM+-1%	TK 100	1206	RG	0007.	5595.00	RDEDERSTEI	DC2 182DH	M 1%TK 100		
	NICHT B	ESTUECK'	т									
	NOT FIT	IEU										
MENP5	A19	3PUA	, , ; E	atum			Schaltteill	ste für		Sachnummar	-	Blatt-Nr.
mLNY5	413	OFUA		Data			Parts IIs			Stock No.		Page
<b>®</b>			14 16.	09.97	Е	E AUS	GANGSTEI	L 1.04 GHZ	106	2.6209.01	SA	17+
ROHDE	E&SCHV	WARZ										

Kennz. Comp. No.	Banennung Designation		Sachnummer Stock No.	Hersteller Manufacturer	Bezeichnung Designation	enthalten in contained in
R844	RG 3,92KOHM+~1%TK1	00 1206	RG 0007.5808.00	<del>                                     </del>	OC2 3,92KOHM 1%TK100	
R845	RESISTOR CHIP RG 3,92KOHM+-1%TK1	00 1206	RG 0007.5808.00	RESISTA	DC2 3,92KOHM 1%TK100	
R846	RESISTOR CHIP RG 100 OHM+-1%TK10	0 1206	RG 0006.8884.00	ROEOERSTEI (	DC2 1000HM 1%TK100	
R847	CHIP RESISTOR RG 2,210HM+-1%TK10	0 1206	RG 0007.8342.00	PHILIPS I	RC 02	
R848	CHIP-RESISTOR RG 681 DHM+-1%TK10	0 1206	RG 0006.9080.00	ROEOERSTEI (	DC2 6810HM 1%TK100	
R849	CHIP RESISTOR   RG O-OHM WIDERSTAN		RG 0007.5108.00	ORALORIC (	CR 1206	
R850	RESISTOR CHIP O-OH		RG 0007.1948.00	ROEDERSTEI (	DC2 100KOHM 1%TK100	
R851	CHIP RESISTOR   RS 0,25W 2KOHM +-20	o% SMO	RS 0007.9626.00		S4G-2KOHM	
R852	POTENTIOMETER RG 100,0KOH+-1%TK10	00 1206			DC2 100K0HM 1%TK100	
R853	CHIP RESISTOR RG 10,0KOHM+-1%TK10	00 1206	1		DC2 10,0K0HM 1%TK100	
R854	RG CHIP RESISTOR RG 1,0MOHM+-1%TK100		RG 0815.7532.00		CRC 1206	
	CHIP RESISTOR NICHT BESTUECKT			J.V.LO.V.LO	3.00 1200	
R855	NOT FITTEO RG 3,92KOHM+-1%TK10	00 1206	RG 0007.5808.00	RESISTA O	JC2 3,92KOHM 1%TK100	
R856	RESISTOR CHIP RG 3,32KOHM+-1%TK10				C2 3,32KOHM 1%TK100	
R857	RESISTOR CHIP RG 3,92KOHM+-1%TK10					
R858	RESISTOR CHIP RG 56,2 OHM+-1%TK10		RG 0007.5808.00		0C2 3,92KOHM 1%TK100	
	CHIP RESISTOR				0C2 56,20HM 1%TK100	
R859	RG 56,2 OHM+-1%TK10 CHIP RESISTOR				0C2 56,20HM 1%TK100	
R860	RG 1,0MOHM+-1%TK100 CHIP RESISTOR		RG 0815.7532.00		RC 1206	
R861	RG 475 OHM+-1%TK100 RESISTOR CHIP				IC2 4750HM 1%TK100	
R862	RG 8,250HM+-1%TK100 CHIP-RESISTOR	1206	RG 0007.8488.00		C 02	
R863	RG 392 OHM+-1%TK100 RESISTOR CHIP	1206	RG 0007.5672.00	ROEOERSTEI O	0C2 3920HM 1%TK100	
R864	RG 6,810HM+-1%TK100 CHIP-RESISTOR	1206	RG 0007.8465.00	PHILIPS R	C 02	
R865	RG 6,810HM+-1%TK100 CHIP-RESISTOR	1206	RG 0007.8465.00	PHILIPS R	C 02	
R866	RG 681 KOHM+-1%TK1C RESISTOR CHIP	00 1206	RG 0007.6110.00	ROEGERSTEI O	C2 681KOHM 1%TK100	
R867	RG 3,92KOHM+-1%TK1C RESISTOR CHIP	00 1206	RG 0007.5808.00	RESISTA O	C2 3,92KOHM 1%TK100	
R868	RG 121 OHM+-1%TK100 CHIP RESISTOR	1206	RG 0006.8903.00	ROEGERSTEI D	C2 1210HM 1%TK100	
R869	RG 825 KOHM+-1%TK10 RESISTOR CHIP	00 1206	RG 0007.6133.00	ROEDERSTEI O	C2 825KOHM 1%TK100	
R870	RG 22, 1KOHM+-1%TK10	0 1206	RG 0007.5872.00	ROEOERSTEI O	C2 22,1KOHM 1%TK100	
R871	RESISTOR CHIP RG 10,0KOHM+-1%TK10	0 1206	RG 0007.0793.00	ROEDERSTEI O	C2 10,0KOHM 1%TK100	
874 R875	RG CHIP RESISTOR RG 1,5 KOHM+-1%TK10	0 1206	RG 0007.5714.00	ROEDERSTEI O	C2 1,5KOHM 1%TK100	
R876	RESISTOR CHIP RG 392 OHM+-1%TK100	1206	RG 0007.5672.00	ROEOERSTEI O	C2 3920HM 1%TK100	
R882	RESISTOR CHIP RG 82,5 DHM+-1%TK10	0 1206	RG 0006.8861.00	ROEOERSTEI O	C2 82,50HM 1%TK100	
R883	CHIP RESISTOR RG 68,1 OHM+-1%TK10		1		C2 68,10HM 1%TK100	
R884	CHIP RESISTOR RL 0,40W 180 OHM2%	l	RL 0092.5985.00		K1 1800HM 2% UNGEW.	
R889	RESISTOR RG 47,5 OHM+-1%TK10				C2 47,50HM 1%TK100	
	RESISTOR CHIP NICHT BESTUECKT					
R899	NOT FITTEO RG 1,0MOHM+-1%TK100 CHIP RESISTOR NICHT BESTUECKT NOT FITTEO	1206	RG 0815.7532.00	ORALORIC C	RC 1206	
MENP5	413 3PUA ÄI	Datum Date	Schalttailli Parts list		Sachnummer Stock No.	Blatt-Nr. Page
ROHDE	&SCHWARZ 14 1	6.09.97	EE AUSGANGSTEI	L 1.04 GHZ	1062.6209.01	<b>SA</b> 18+

Für diesa Unterlage behalten wir uns eile Rechto vor,

Kennz. Comp. No.	Benenn Designe				Sachnummer Stock No.	Hersteller Manufacturer		ezeichnung esignetion		alten in eined in
U600	BM LRMS-2 HYBRID MIXER	MIXE	R 1GHZ		1062.6273.00	MINI-CIRCU	LRI	NS-2		
V11		75V	UDI	AD	0006.72B8.00	PHILIPS	BAS	532 (L)		
V12		75V	UDI	AD	0006.728B.00	PHILIPS	BAS	32 (L)		
V13	DIODE AK BCX70H N	45V	200MA	AK	0007.3105.00	VALVO	всх	( <b>7</b> 0 Н		
V14		75V	UDI	AD	0006.72BB.00	PHILIPS	BAS	i32 (L)		
	DIODE NICHT BESTUECK	T								
V15	NOT FITTED AD BAS32 DIODE NICHT BESTUECK	75V T	UDI	AD	0006.728B.00	PHILIPS	BAS	32 (L)		
V25	NOT FITTED	75V	UDI	AD	0006.72BB.00	PHILIPS	BAS	32 (L)		
V26	DIODE AD BAS32	75V	IDU	l	0006.72BB.00			32 (L)		
V35	DIODE AE BZV55/C5V1	٥.	5W ZDI	ΑE	0006.9B39.00	PHILIPS_SE	BZV	55B5V1 (GEG)		
V110	ZENER DIODE AE 1N827 (	6,2V	REFDI	AE	0418.0029.00	COMPENSATE	1N8	27(A)		
V130	REFERENCE DIODE AD BAV99		זמט סטס	AD	0911.0092.00	VALVO	BAV	99		
V310	DIODE AE BAR61 3X(PI)		OOV PIN		4001.5082.00		BAR	61(Q62702A120)		
V315	PIN DIODE ARRAY AE BAR61 3X(PI)	) 1	OOV PIN		4001.5082.00	SIEMEN5	BAR	61 (Q62702A 120)		
V31B	PIN DIODE ARRAY AD BAV99			AD	0911.0092.00	VALV0	BAV	99		
V319		70V I	זמט סטמ	AD	0911.0092.00	VALV0	BAV	99		
V330		70V I	נסט סטכ	AD	0911.0092.00	VALV0	8AV	99		
V333		70V I	נסט סטס	ΑO	0911.0092.00	VALV0	8AV	99		
V335		70V I	ono noi	ΑO	0911.0092.00	VALV0	8AV	99		
337 V400	OIOOE AE 8AR61 3X(PI)		OOV PIN		4001.5082.00	SIEMENS	8AR	61(Q62702A120)		
V404				AD	0911.0092.00	VALVO	BAV	99		
V405	OIOOE AD BAV99 7 DIOOE	70V I	זמט סטכ	ΑO	0911.0092.00	VALVO	BAV	99		
V411		75V	UDI	AD	0006.72B8.00	PHILIPS	BAS	32 (L)		
V431 438		45V	200MA	ΑK	0007.3105.00	VALVO	всх	70 H		
V500	AE BAR64-04 CA OUAL PIN 0100E	DOP	PEL PIN		1039 . 1327 . 00	SIEMENS	BAR	6404 (Q62702-A101		
V511	AE BAR64-04 CA DUAL PIN DIODE	DOP	PEL PIN		1039.1327.00	SIEMEN5	BAR	6404 (Q62702-A101		
V512	AE BAR64-04 CA DUAL PIN DIODE	DOP	PEL PIN		1039.1327.00	SIEMENS	BAR	6404 (Q62702-A101		
V514 516	AE BAR64-04 CA DUAL PIN DIODE	DOP	PEL PIN		1039.1327.00	SIEMENS	BAR	6404 (Q62702-A101		
V520	AE BAR64-04 CA DUAL PIN DIODE				1039.1327.00	SIEMENS	BAR	6404 (Q62702-A101		
V523	AE BAR64-04 CA DUAL PIN DIODE		ļ		1039.1327.00		BAR	6404 (Q62702-A101		
V530	AE BAR64-04 CA DUAL PIN DIODE		1		1039.1327.00		BAR	6404 (Q62702-A101		
V532	AE BAR64-04 CA DUAL PIN DIODE				1039.1327.00			6404 (Q62702-A101		
V535	AE BAR64-04 CA DUAL PIN DIODE				1039.1327.00			6404 (Q62702-A101		
V536	AE BAR64-04 CA DUAL PIN DIODE				1039.1327.00			6404 (Q62702-A101		
V539	AE BAR64-04 CA DUAL PIN DIODE				1039.1327.00			6404 (Q62702-A101		
V540	AE BAR64-04 CA DUAL PIN DIODE		_		1039.1327.00			6404 (Q62702-A101		
V543	AE BAR64-04 CA DUAL PIN DIODE	DUP	-CL PIN		1039.1327.00	STEMEND	DAK	6404 (Q62702-A101)		
MENP5	413 3PUA	ÄI	Datum Dete		Schaftteilli Parts IIs			Sechnummer Stock No.		Biett-Nr. Pegs
<b>*</b>	E&SCHWARZ		16.09.97	E	E AUSGANGSTEI			1062.6209.01	SA	19+

Kennz. Comp. No.	Benennung Designation		nummer ck No.	Hersteller Manufacturer	Bezeichnung Designation	enthaiten in contained in
V544	AE BAR64-04 CA DOPPEL F	IN 1039	. 1327.00	SIEMENS	BAR6404 (Q62702-A101	
V548	AE BAR64-04 CA DOPPEL F	N 1039	. 1327.00	SIEMENS	BAR6404 (Q62702-A101	
V600	DUAL PIN DIODE AE BZX55/B6V2 0,5W ZI	AE 0012	.2161.00	PHILIPS	BZX79B6V2	
V602	ZENER DIODE AK BFQ34T N 18V 150N	0801	.8283.00	PHILIPS	BFQ34T	
V604	TRANSISTOR   AE HSMS2825   1+1 SCHDTT	Y 1010	.6214.00	HEWLETT_PA	HSMS2825 L31	
V606	SCHOTTKY DIODE PAIR   AE HSMS2825 1+1 SCHOTT				HSMS2B25 L31	
V608	SCHOTTKY DIODE PAIR AD BAS32 75V U		.7288.00	_	BAS32 (L)	
V610	DIODE AE BZV55/C5V1 0.5W ZD	i			BZV55B5V1 (GEG)	
V612	ZENER DIODE  AK BFQ34T N 1BV 150N		.8283.00	1		
V635	TRANSISTOR				BFQ34T	
V636	DIODE		.7288.00		BAS32 (L)	
	AE 1N827 6,2V REFD		1	COMPENSATE		
V650	DIODE		.7288.00		BAS32 (L)	
V700	AE HSMS2825 1+1 SCHOTT SCHOTTKY DIODE PAIR	1.1		HEWLETT_PA	HSMS2B25 L31	
V705	AE BAR64-04 CA DOPPEL P DUAL PIN DIODE	1	. 1327.00	SIEMENS	BAR6404 (Q62702-A101	
V707	AE BAR64-04 CA DOPPEL P DUAL PIN DIOOE	N 1039	. 1327 . 00	SIEMENS	BAR6404 (Q62702-A101	
V720	AE BAR64-04 CA DOPPEL P OUAL PIN DIODE	N 1039	. 1327.00	SIEMENS	8AR6404 (Q62702-A101	
V725	AE BAR64-04 CA DOPPEL P DUAL PIN OIODE	N 1039	. 1327.00	SIEMENS	BAR6404 (Q62702-A101	
V730	AE BAR64-04 CA DOPPEL P DUAL PIN DIODE	N 1039	. 1327.00	SIEMENS	BAR6404 (Q62702-A101	
V735	AE 8AR64-04 CA DOPPEL P	N. 1039	. 1327 . 00	SIEMENS	BAR6404 (Q62702-A101	
V745	DUAL PIN OIODE AE BZV55/C6V2 0.5W ZO	AE 0006	.9851.00	PHILIPS	BZV55B6V2	
V746	ZENER DIODE AE BZV55/C6V2 0,5W ZO	AE 0006	.9851.00	PHILIPS	8ZV55B6V2	
V747	ZENER OIODE AD BAS32 75V U	I AD 0006	7288.00	PHILIPS	8AS32 (L)	
V748	0100E AD 8AS32 75V U	I AD 0006.	7288.00		8AS32 (L)	
V800	OIOOE AD 8AS32 75V U	1	7288.00		BAS32 (L)	
V801	OIOOE AK BCX71J P 45V 200M		2096.00		BCX71J GEGURTET	
V802	TRANSISTOR AK BFQ34T N 18V 150M	ł	8283.00		8FQ34T	
V815	TRANSISTOR AD BAS32 75V UI		7288.00		BAS32 (L)	
V8 16	DIODE AK BCX71J P 45V 200MJ		2D96.00		BCX71J GEGURTET	
VB 17	TRANSISTOR AK BFQ34T N 1BV 150M		- 1			
	TRANSISTOR		82B3.00		BFQ34T	
VB30	AD BAS32 75V UI DIODE		72BB.00		BAS32 (L)	
V831	AK BCX71J P 45V 200M/ TRANSISTOR		2096.00		BCX71J GEGURTET	
V832	AK BFQ34T N 18V 150M/ TRANSISTOR		B2B3.00		BFQ34T	
V844	AE HSMS2B25 1+1 SCHOTTE SCHOTTKY DIODE PAIR		J	_	HSMS2B25 L31	
V850	AE HSMS2825 1+1 SCHOTTH SCHOTTKY DIODE PAIR	/ 1010.	6214.00	HEWLETT_PA	HSMS2825 L31	
V851	AD BAS32 75V UI DIODE	AD 0006.	72BB.00	PHILIPS	BAS32 (L)	
VB57	AD BAS32 75V UI	AD 0006.	72BB.00	PHILIPS	BAS32 (L)	
V870	AD BAS32 75V UI	I AD 0006.	72BB.00	PHILIPS	BAS32 (L)	
V871	AE 1NB27 6,2V REFDI REFERENCE DIODE	AE 0418.	0029.00	COMPENSATE	1N827(A)	
MENP5	413 3PUA Äl Datum Date		Schallteilli: Parts list		Sachnummer Stock No.	Biatt-Nr Paga
ROHDE	14 16.09.	EE AUS	GANGSTE1	L 1.04 GHZ	1062.6209.01	<b>SA</b> 20+

bshelten	A Var
Unterlage	Alle Bachte
FOr diese	Wir nos

	Kennz. Comp. No.	Baner Dasig	nnung nation		Sachnummer Stock No.	Harstaller Manufacturar	Bezeichnung Designation		naiten in tained in
j	X2	FP STECKERLEI CONNECTOR 32P		FP	0008.5718.00	SIEMENS	V42254-B1200-B611		
	X205	FP STIFTLEIST	E 4P.R2,54	FP	0009.6147.00			ŀ	
	X224 226	FJ EINBAUWINK ANGLE CONNECT	ELST. SMC	FJ (	0249.9684.00	ROSENBERGE	39S-205-400-D3		
	<b>Z1</b>	LD SMD-T-FILT SMD-FILTER	ER 3,3NF		1039.1362.00	MURATA	NFM61R2OT332T1		
	Z2	LD SMD PI-FIL SURFACE-MOUNT NICHT BESTUEC	-FILTER	LD (	0008.5901.00	OXLEY	SLT/P/22000/SM3		
	Z3	NOT FITTED LD SMD-T-FILT SMD-FILTER			1039.1362.00		NFM61R20T332T1		
	Z4 	LD SMD-T-FILT		ļ	1039.1362.00		NFM61R2OT332T1		
	Z5 9	LD SMD-T-FILT			1039.1356.00		NFM61ROOT101T1		
	Z10	LD SMD-T-FILT			1D39.1362.00		NFM61R20T332T1		
	Z11	LD SMD-T-FILT			1039 . 1356 . 00		NFM61ROOT101T1		
	Z20	LD SMD PI-FIL SURFACE-MOUNT		LD (	0008.5901.00	OXLEY	SLT/P/2200D/SM3		
H	MENP5	413 3PUA	Äl Datum		Schaltteillis		Sachnummer		Blatt-Nr.
-			14 16.09.97	EE	Parts list AUSGANGSTEII		1062.6209.01	SA	21-
I	ROHDE	&SCHWARZ							



## XY-Liste

## **XY List**

## Erklärung der Spaltenbezeichnungen:

Part: Bauelement-Kennzeichen.

Side: ... Leiterplatten-Seite, auf der sich das Bauelement befindet.

XY: Koordinaten (Millimeter) des Bauelementes auf der Leiterplatte

bezogen auf den Nullpunkt.

SQR, PG: Planquadrat und Seite des Schaltbildes für das jeweilige Bauelement.

## Explanation of column designations:

Part: Identification of instrument part.

Side: Side of the PC board on which instrument part is positioned.

XY: Coordinates (millimeter) of the component on the PC board in reference

to zero point.

SQR, PG: Square and page of the diagram for the respective instrument part.

		S∈ 	rvi	.ce	-xe.		nte Ba			ser 	Arce	 -xer	evant +	comp	oner 	its 		
Part 	sid	e X	Y	: :	Sqr	Pg	Part	Sid	e X	Y	Sqr	Pg	Part	sid	e X	¥	Sqr	P
P300	В	88	3	6	6C	3	P600	В	186	62	3C	7	R645	В	252	80	9D	
P305	В	67	3	9 :	10C	3	P601		199	76	3C	7	X2A	В	189	11	2C	
P306	В			1 :	10D	3	P620	В	222	72	4B	7	X2B	В	189	11		
P352	В	59	2	1 :	11D	3	P621	В	223	70	4A	7	X205	В	69	40	10B	
P353	В	53	2	0 :	12E	3	P628	В	177	64	4C	7	X224	В	17	15	1D	
P375		153			2D	3	P866		293	16	8B	9	X225	В	258	15	5B	
P380		114		1	4C	3	R280	В	123	42	3C	3	X226	В	283	15	11D	
P385	B 	104	5 	3 	5C	3	R619	В	198		2C		ļ	<b></b>				
 N:	 icht	 :-Se	 rvi	 ce-	 -Re1	.eva	nte Bau	tei.	le /	Non-	 -Ser	vice	-Releva	ant (	 Comp	onen	 ts	
Part S	 Side	 • X	<b>-</b>	 S	 Sqr	Pg	Part	side	 ∋ X	Y	Sqr	Pg	+   Part	side	 ∋ X		Sqr	 P
303	- <b>-</b>	 18	 5	 3	9D	4	+   C22	В	 116	32	 3E	2	   C275	В	 173	 42	 1D	
309	В	30			LOD	4	C132		229	36	9B		C280	В			3C	
310	В	22			L1D	4	C133		235	38	88		C300	В	39		3D	
413	В	50	6	9	5D	5	C149		215	43	3A	10	C302	В	24		4D	
414	В	40	7(	0	5D	5	C150		179	43	1A		C303	В	34		4D	
506	В	81	83	3	3E	6	C151	A	164	51	2A	10	C313	В	45	29	5 C	
507	В		102	2	3D	6	C152	A	83	58	3A	10	C315	В	18	24	5D	
509	В	92	8:	3	4D	6	C153	В	123	60	6A	10	C316	В	22	34	60	
514	В	96	9!	5	5D	6	C154	A	130	56	6A	10	C318	A	12	37	5C	
515		111	9	5	50	6	C156		203	43	4A	10	C319	A	15	41	6¢	
516		112	88	8	50	6	C157	A	152	50	5A	10	C325	В	30	38	60	
518		123	89		60	6	C160	A	130	42	6E	10	C327	В	17	48	60	
519		125	81		60	6	C161	A	97	46	9E	10	C328	В	19	41	70	
520		135	95		70	6	C162	A	76	22	10E	10	C329	A	39	41	7C	
522		137	75		7E	6	C170	A	192	43	4A	10	C330	A	43	38	7C	
528		148	82		8D	6	C209	A	86	43	6C	3	C340	В	45	50	8¢	
529		148	91		8D	6	C219	В	85	43	8C	3	C356	В	31	46	80	•
542	В	46	98		2B	6	C220	A		39	9E	3	C357	В	31	53	9D	
543		20			2B	6	C221		57	34	90		C359	A	41	60	10E	4
544	В	23	116		3B	6	C223	В	79	46	8C	3	<b>C</b> 360	В	31	67	10D	4
545	В	37			4B	6	C240	В	57		10E	3	C361	В	23	83	12D	4
548	В		132		6B	6	C242	В	66		11F	3	C362	A	48	86	12E	4
550		144			8B	6	C244	A	77	39	4A	3	C400	A	48	84	2C	
600		178	70		2E	7	C245	A	72	49	4A	3	C401	В	42	81	3D	
607 608		215	83		4D	7	C250	A	58	62	2A	3	C402	В	30	78	4D	5
608 512		208 218	86 62		5D	7	C251	A	64	62	2A	3	C404	A	34	88	3C	5
560		218	62		3D 3D	7	C252 C253	A	55 50	57 E1	2A	3	C405	A	35	91	4C	:
561		218	62		4D	7	C253	A A	59 63	51 51	2A 3A	3	C410	A	42	76	5E	:
705		210 150			4D 2C	8	C254	A A	55			1	C412	В	37	72	5D	;
351		283	20		20 10	9	C255		163	47 43	3A 5A	3	C417	A	70	70	7E	5
212		210	51		8C	2	C256	A	57	18	6A	3	C440 C441		126 133	123 138	9B	
213		197	30		3E	2	C257	A	53	15	5A	3	C441			109	9B 10B	5
214		230	43		5A	2	C259		161	33	5A	3	C442	В	63	86	10B	
215		237	45		5A	2	C259		109	51	6A	3	C500	В	64	77	1C 2E	6
216		234	22		6A	2	C261	A	59	28	3A	3	C501	A	83	83	2E 2F	6
C17		239	14		6A	2	C262	A	64	31	3A	3	C501	В	70	88	2F 2D	6
220		109	16		2D	2	C263	A	55	25	4A	3	C504	В	78	86	3D	6
221		122	32		3E	2	C264		107	44	6A	3	C505	В	79	94	3E	6
	†   -	 I	1		tum	<del>-</del> 					e fª	- 1	Sach-	 Numm	 er	.=	-+  B1	at
ROHDE &	 +		<u> </u>	Da	te 	 +			XY-:	list 	fo 	r   +	Stock	-Nr			Pa	ge
CHWARZ						I	EE AUS	GANG	STEI	ե_1.	046G	нz				_	i	
	1		04		_					_							1	



C564 B 116 130 9B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C568 8 92 112 10B 6 C660 A 157 91 4F 7 C830 8 286 66 8D 9 C569 A 90 114 10C 6 C661 A 171 86 4F 7 C831 B 283 66 8D 9 C570 B 102 110 10B 6 C662 A 157 80 4E 7 C832 B 280 61 8E 9 C571 B 102 119 10C 6 C663 A 178 75 4E 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C575 B 119 110 11B 6 C668 A 153 72 5F 7 C836 B 291 41 9D 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C839 B 289 59 8D 9 C582 B 135 106 11D 6 C671 A 264 97 7F 7 C840 A 154 102 2B 9 C583 B 135 119 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C584 B 144 113 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C589 B 140 106 9D 6 C705 B 166 137 3C 8 C842 A 153 121 2A 9 C600 B 170 86 1D 7 C707 B 170 124 4C 8 C846 B 280 29 7C 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C848 B 284 38 8C 9 C603 B 167 73 2D 7 C710 A 168 114 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9	+					-+						·+				
CSD07	Part +	Side >	· · · ·	Y Sqr	Pg	Part	Side	Х 	Y	Sqr	Pg	Part	Side X	Y	Sqr	Pg
C507	C506	в 9	91 9	97 3E	6	C605	В	217	67	4E	7	C715	В 170	98	5C	8
C511	C507	В 9	1	88 4E	6	C606	В	220	76	4E	7	1				8
C511 B 112 99 SE 6 C609 A 181 86 2E 7 C724 B 184 129 4E 8 C512 B 100 85 SE 6 C610 A 202 77 2C 7 C727 A 169 104 5E 8 8 C513 B 104 74 5E 6 C611 A 168 64 4C 7 C727 A 169 104 5E 8 6 C514 A 117 83 6F 6 C611 A 168 64 4C 7 C732 B 184 99 6D 8 C514 A 117 83 6F 6 C611 A 268 64 27 5C 7 C732 B 184 99 6D 8 C514 A 117 83 6F 6 C617 B 264 27 5C 7 C734 B 177 100 7C 8 C515 B 121 85 6E 6 C618 B 256 30 5C 7 C734 B 177 100 7C 8 C515 B 133 90 7E 6 C620 B 255 40 6C 7 C735 A 180 102 6C 6 C517 B 133 90 7E 6 C620 B 255 40 6C 7 C736 A 177 93 7C 8 C517 B 133 90 7E 6 C620 B 255 40 6C 7 C738 B 191 103 7D 8 C519 B 146 77 8E 6 C627 B 260 74 7D 7 C740 B 192 113 8D 8 C519 B 146 77 8E 6 C627 B 260 74 7D 7 C743 B 213 138 90 8 C521 B 146 77 8E 6 C629 B 265 76 8D 7 C747 A 230 133 10D 8 C521 B 146 77 8E 6 C629 B 265 82 8D 7 C748 A 234 128 10D 8 C522 B 140 77 8E 6 C632 B 189 79 3D 7 C747 A 230 133 10D 8 C524 B 141 94 8E 6 C633 B 260 88 9D 7 C762 A 183 211 73 10D 8 C524 B 141 94 8E 6 C633 B 260 88 9D 7 C762 A 183 211 72 8 C525 B 147 102 9E 6 C634 B 254 87 8D 7 C800 A 255 124 2F 9 C527 B 150 111 11E 6 C636 B 238 98 10D 7 C801 B 274 135 2D 9 C530 A 59 93 2C 6 C637 B 245 83 9E 10D 7 C801 B 274 135 2D 9 C531 B 72 96 2C 6 C638 A 223 85 10D 7 C801 B 274 135 2D 9 C531 B 72 96 2C 6 C638 A 223 85 3A 7 C806 B 271 127 3E 0 C533 B 19 104 28 6 C641 B 223 95 10D 7 C802 B 286 129 3D 9 C533 B 19 104 28 6 C640 B 227 19 10 T 7 C802 B 286 129 3D 9 C534 B 43 104 3B 6 C644 B 220 95 10D 7 C802 B 286 129 3D 9 C534 B 31 13 10 8 6 C644 B 221 9T 10 T 7 C808 B 283 132 3D 9 C653 A 220 85 3A 7 C809 A 251 113 2E 0 C805 B 238 133 10 D 9 C805 B 238 133 10 D 9 C805 B 238 133 10 D 9 C805 B 238 133 10 D 9 C805 B 238 133 10 D 9 C805 B 238 133 10 D 9 C806 B 271 127 3E 0 C807 B 238 13 13 10 D 9 C806 B 271 127 3E 0 C805 B 238 133 10 D 9 C806 B 271 127 3E 0 C805 B 238 133 10 D 9 C806 B 271 127 3E 0 C805 B 238 133 10 D 9 C806 B 271 127 3E 0 C805 B 238 133 10 D 9 C806 B 271 127 3E 0 C805 B 281 133 10 D 9 C806 B 27 C806 B 27 C806 B 27 C806 B 27 C806 B 27 C806 B 27 C806 B 27 C806 B 27 C806 B 27					_	1			86	5E	7	C721	B 177	131	4D	8
C5112 B 110 85 SE 6 C610 A 202 77 2C 7 C727 A 169 104 EE 8 C5114 A 107 45 E 6 C611 A 168 64 4C 7 C732 B 184 99 6D 8 C514 A 117 83 6F 6 C617 B 264 27 5C 7 C734 B 177 100 7C 8 C515 B 121 85 6F 6 C618 B 256 30 5C 7 C734 B 177 100 7C 8 C516 B 122 99 6E 6 C619 B 264 37 6C 7 C735 A 180 102 6C 8 C517 B 133 90 7E 6 C620 B 255 40 6C 7 C736 A 177 93 7C 8 C518 A 135 87 7F 6 C625 B 250 69 7D 7 C740 B 191 103 7D 8 C518 A 135 87 7F 6 C625 B 250 69 7D 7 C740 B 191 103 7D 8 C519 B 146 77 8E 6 C627 B 260 74 7D 7 C740 B 192 113 8D 8 C519 B 146 77 8E 6 C627 B 260 74 7D 7 C740 B 191 103 7D 8 C520 B 146 86 8E 6 C627 B 260 74 7D 7 C740 B 192 113 8D 8 C521 B 146 86 8E 6 C627 B 260 74 7D 7 C740 B 191 103 7D 8 C520 B 146 86 8E 6 C627 B 260 74 7D 7 C740 B 191 103 7D 8 C520 B 146 86 8E 6 C627 B 260 74 7D 7 C740 B 191 103 7D 8 C521 B 146 94 8E 6 C623 B 189 79 3D 7 C740 E 191 126 10D 8 C522 B 140 78 E 6 C631 B 183 76 2D 7 C750 A 217 133 10D 8 C524 B 141 94 8E 6 C633 B 260 88 9D 7 C751 A 217 133 10E 8 C525 B 147 102 9E 6 C634 B 254 87 8D 7 C760 A 217 133 10E 8 C525 B 147 102 9E 6 C634 B 254 87 8D 7 C760 A 217 133 10E 8 C525 B 150 111 11E 6 C636 B 238 98 10D 7 C680 A 255 124 2F 8 C637 B 245 83 9E 7 C800 A 59 93 2C 6 C637 B 245 83 9E 7 C800 A 59 93 2C 6 C637 B 245 83 9E D7 7 C801 B 274 135 2D 9 C530 A 59 93 2C 6 C637 B 245 83 9E D7 7 C800 A 255 124 2F 8 C637 B 245 83 9E 7 C802 B 268 129 3D 9 C530 A 59 93 2C 6 C637 B 245 83 9E D7 7 C800 A 257 1127 3E 9 C530 A 59 93 2C 6 C637 B 245 83 9E D7 7 C800 A 257 1127 3E 9 C530 A 59 93 2C 6 C637 B 245 83 9E D7 7 C800 A 257 1127 3E 9 C530 A 59 93 2C 6 C637 B 245 83 9E D7 7 C800 A 257 1127 3E 9 C530 A 59 93 2C 6 C637 B 245 83 9E D7 7 C800 B 271 112 7 3E 9 C530 A 59 93 2C 6 C637 B 245 83 9E D7 7 C800 B 271 112 7 3E 9 C530 A 59 93 2C 6 C637 B 245 83 9E D7 7 C800 B 271 112 7 3E 9 C630 A 258 84 115 48 6 C640 B 227 95 10D 7 C801 B 274 135 2D 9 C803 A 258 132 3D 9 C803 A 258 132 3D 9 C803 A 258 132 3D 9 C803 A 258 132 3D 9 C803 A 258 132 3D 9 C803 A 258 132 3D 9 C803 A 258 132 3D 9 C803 A 258 132 3D 9 C803 A 258											7				4D	8
C513						3						1				
C514 A 117 83 6F 6 C617 B 264 27 5C 7 C734 B 177 100 7C 8  C515 B 121 85 6E 6 C618 B 255 30 5C 7 C735 A 180 102 6C 8  C516 B 122 99 6E 6 C619 B 264 37 6C 7 C736 A 177 93 7C 8  C517 B 133 90 7E 6 C620 B 255 40 6C 7 C736 A 187 93 7C 8  C518 A 135 87 7F 6 C625 B 250 69 7D 7 C740 B 192 113 8D 9  C519 B 146 77 8E 6 C627 B 260 74 7D 7 C743 B 213 138 90 8  C519 B 146 86 8E 6 C628 B 269 76 8D 7 C747 A 230 133 10D 8  C520 B 146 86 8E 6 C628 B 269 76 8D 7 C747 A 230 133 10D 8  C521 B 140 77 8E 6 C627 B 260 74 7D 7 C743 B 213 138 90 8  C522 B 140 77 8E 6 C629 B 265 82 8D 7 C747 A 230 133 10D 8  C522 B 140 77 8E 6 C631 B 183 76 2D 7 C750 A 217 133 10D 8  C523 B 140 86 8E 6 C628 B 189 79 3D 7 C751 A 219 126 10E 8  C524 B 141 94 8E 6 C633 B 260 88 9D 7 C751 A 219 126 10E 8  C525 B 140 13 9F 6 C634 B 254 87 8D 7 C762 A 183 121 7E 8  C526 A 140 113 9F 6 C636 B 238 98 10D 7 C800 A 255 124 2F 8  C526 A 140 113 9F 6 C636 B 238 98 10D 7 C800 A 255 124 2F 8  C527 B 150 111 11E 6 C636 B 238 98 10D 7 C800 A 258 132 3D 9  C530 A 55 93 2C 6 C637 B 245 83 9E 7 C805 B 281 132 3D 9  C531 B 72 96 2C 6 C638 A 223 85 3A 7 C806 B 271 127 3E 9  C532 B 52 97 28 6 C639 A 219 77 3B 7 C806 B 271 127 3E 9  C533 B 19 104 28 6 C640 B 220 92 10E 7 C807 B 288 132 2D 9  C534 B 43 104 38 6 C644 B 223 95 10D 7 C812 B 268 129 3D 9  C537 B 54 115 48 6 C644 B 223 95 10D 7 C812 B 268 129 3D 9  C538 B 38 118 48 6 C642 B 207 95 10D 7 C812 B 276 87 60 9  C537 B 54 115 48 6 C644 B 221 91 10 7 C814 B 271 127 3E 9  C538 B 38 118 48 6 C648 B 221 109 110 7 C814 B 271 127 5E 9  C545 B 65 132 68 6 C644 B 221 109 110 7 C814 B 271 127 5E 9  C546 B 37 131 68 6 C650 A 183 69 7A 7 C820 A 251 132 5E 9  C547 B 59 137 78 6 C651 A 187 64 7A 7 C821 B 266 101 50 9  C548 B 8 38 118 48 6 C648 B 221 109 110 7 C818 B 288 100 59 9  C546 B 16 130 98 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9  C557 B 19 10 10 10 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9  C547 B 59 137 78 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9  C548 B 8 39 131 7C 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9  C558 B 19 10 10 1						1										
C516 B 121 85 6E 6 C618 B 256 30 5C 7 C735 A 180 102 6C 8 C516 B 122 99 6E 6 C619 B 255 40 6C 7 C736 A 177 93 7C 8 C518 B 133 90 7E 6 C620 B 255 40 6C 7 C736 A 177 93 7C 8 C518 B 136 77 F 6 C625 B 250 69 7D 7 C740 B 192 113 8D 8 C520 B 146 77 8E 6 C627 B 260 74 7D 7 C740 B 192 113 8D 8 C520 B 146 86 8E 6 C629 B 265 82 8D 7 C747 A 230 133 10D 8 C521 B 146 94 8E 6 C629 B 265 82 8D 7 C747 A 230 133 10D 8 C522 B 140 77 8E 6 C629 B 265 82 8D 7 C747 A 230 133 10D 8 C523 B 140 86 8E 6 C629 B 265 82 8D 7 C750 A 217 133 10E 8 C524 B 141 94 8E 6 C632 B 189 79 3D 7 C751 A 219 126 10E 8 C525 B 147 102 9E 6 C631 B 183 76 2D 7 C761 A 217 133 10E 8 C526 A 140 113 9F 6 C636 B 236 95 10D 7 C527 B 150 111 11E 6 C636 B 236 95 10D 7 C528 B 140 11 11E 6 C636 B 238 98 10D 7 C529 B 150 111 11E 6 C636 B 238 98 10D 7 C521 B 124 94 8E 6 C639 B 236 95 10D 7 C521 B 124 94 8E 6 C639 B 236 95 10D 7 C521 B 124 94 8E 6 C639 B 236 95 10D 7 C522 B 124 124 94 8E 6 C639 B 236 95 10D 7 C524 B 140 113 9F 6 C636 B 238 98 10D 7 C525 A 124 123 3D 9 C527 B 150 111 11E 6 C636 B 238 98 10D 7 C630 A 59 93 2C 6 C637 B 226 83 9E 7 C531 B 72 96 2C 6 C638 A 223 85 3A 7 C860 B 228 132 3D 9 C531 B 72 96 2C 6 C638 A 223 95 10D 7 C802 B 286 129 3D 9 C531 B 72 96 2C 6 C638 A 223 95 10D 7 C802 B 286 129 3D 9 C533 B 19 104 28 6 C640 B 220 95 10D 7 C811 B 262 120 4E 9 C534 B 43 104 3B 6 C641 B 223 95 10D 7 C812 B 276 87 60 9 C536 A 78 109 3C 6 C642 B 207 95 10D 7 C818 B 227 135 5C 9 C537 8 54 115 48 6 C644 B 220 95 10D 7 C818 B 276 173 E 9 C538 B 38 118 4B 6 C644 B 220 95 10D 7 C818 B 277 13 E 9 C539 8 56 123 58 6 C646 B 227 109 11D 7 C818 B 277 13 E 9 C540 A 86 120 5C 6 C646 B 227 109 11D 7 C818 B 278 115 5C 9 C547 B 59 137 78 6 C660 A 187 91 14 11E 7 C816 B 280 104 50 80 90 90 90 90 90 90 90 90 90 90 90 90 90						1						I .				
C511 B 132 99 6E 6 C619 B 264 37 6C 7 C736 A 177 93 7C 8 C517 B 133 90 7E 6 C620 B 255 40 6C 7 C738 B 191 103 7D 8 C518 A 135 87 7F 6 C625 B 250 69 7D 7 C740 B 192 113 8D 8 C519 B 146 77 8E 6 C627 B 260 74 7D 7 C743 B 191 133 10D 8 C521 B 146 86 8E 6 C628 B 269 76 8D 7 C744 A 234 123 130 D0 8 C521 B 146 94 8E 6 C628 B 269 76 8D 7 C747 A 230 133 10D 8 C521 B 140 77 8E 6 C631 B 183 76 2D 7 C748 A 224 128 10D 8 C522 B 140 86 8E 6 C628 B 269 78 D7 C748 A 224 128 10D 8 C523 B 140 86 8E 6 C628 B 269 82 8D 7 C750 A 217 133 10E 8 C524 B 141 94 8E 6 C633 B 260 88 9D 7 C751 A 219 126 10E 8 C525 B 141 102 9E 6 C634 B 254 87 8D 7 C800 A 255 124 2F 9 C526 A 140 113 9F 6 C633 B 236 95 10D 7 C802 B 286 129 3D 9 C527 B 150 111 11E 6 C636 B 238 98 10D 7 C802 B 286 129 3D 9 C530 A 59 93 2C 6 C638 A 223 85 3A 7 C806 B 271 127 3E 9 C531 B 72 96 2C 6 C638 A 223 85 3A 7 C806 B 271 127 3E 9 C533 B 19 104 28 6 C640 B 220 92 10E 7 C802 B 286 129 3D 9 C533 B 19 104 28 6 C641 B 223 95 10D 7 C802 B 286 129 3D 9 C534 B 43 104 38 6 C644 B 220 92 10E 7 C802 B 286 129 3D 9 C538 B 38 118 4B 6 C644 B 227 10D 7 C802 B 286 100 50 9 C537 8 54 115 48 6 C644 B 227 109 110 7 C812 B 266 101 50 9 C545 8 65 132 68 6 C646 B 227 109 110 7 C812 B 266 101 50 9 C545 8 65 132 68 6 C646 B 227 109 110 7 C812 B 266 101 50 9 C546 8 131 140 8B 6 C652 A 216 64 6A 7 7 C824 B 280 101 5D 9 C5560 B 13 140 0B 6 C652 A 157 80 4F 7 7 C820 A 261 132 5E 9 C557 B 102 110 10B 6 C662 A 157 80 4F 7 7 C830 B 286 101 5D 9 C5580 B 102 110 10B 6 C662 A 157 80 4F 7 7 C830 B 286 100 7 C821 B 280 100 9 C581 B 102 110 10B 6 C662 A 157 80 4F 7 7 C830 B 286 100 9 C830 B 286 100 7 C802 B 280 100 9 C860 B 131 140 B 6 C671 A 264 97 7F 7 C830 B 280 97 5E 9 C5560 B 102 110 10B 6 C662 A 157 80 4F 7 7 C830 B 280 97 5E 9 C5573 B 119 110 11B 6 C666 A 213 109 100 7 C844 B 291 130 20 9 C845 B 280 100 9 C860 B 133 100 B 6 C660 A 157 19 100 7 C840 A 286 100 9 C860 B 130 100 B 6 C660 A 157 100 9 100 7 C840 A 286 100 9 C860 B 100 110 10 6 C662 A 157 80 40 7 7 7 C840 A 280 100 9 C860 B 100 110 10 B 6 C6						i i										
C511 B 133 90 7E 6 C620 B 255 40 6C 7 C738 B 191 103 7D 8 C518 A 135 87 7F 6 C625 B 250 69 7D 7 C740 B 192 113 8D 8 C520 B 146 86 8E 6 C627 B 260 74 7D 7 C740 B 192 113 8D 8 C520 B 146 86 8E 6 C628 B 269 76 8D 7 C747 A 230 133 10D 8 C521 B 146 94 8E 6 C629 B 265 82 8D 7 C748 A 234 128 10D 8 C522 B 140 77 8E 6 C632 B 189 79 3D 7 C748 A 234 128 10D 8 C523 B 140 86 8E 6 C632 B 189 79 3D 7 C750 A 217 133 10E 8 C524 B 141 94 8E 6 C632 B 189 79 3D 7 C751 A 219 126 10E 8 C525 B 147 102 9E 6 C634 B 254 87 8D 7 C800 A 255 124 2F 9 C526 A 140 113 9F 6 C635 B 236 95 10D 7 C801 B 274 135 2D 9 C527 B 150 111 11E 6 C636 B 238 98 10D 7 C802 B 286 129 3D 9 C531 B 72 96 2C 6 C638 A 223 85 3A 7 C806 B 271 127 3E 9 C532 B 19 104 28 6 C640 B 220 92 10E 7 C809 A 255 114 3E 9 C534 B 19 104 28 6 C640 B 220 92 10E 7 C809 A 255 114 3E 9 C534 B 13 104 3B 6 C644 B 220 92 10E 7 C809 A 255 114 3E 9 C536 A 78 109 3C 6 C642 B 207 95 10D 7 C811 B 262 120 4E 9 C537 8 56 123 58 6 C644 B 220 79 5 10D 7 C812 B 276 87 60 9 C538 B 38 118 4B 6 C644 B 220 79 5 10D 7 C812 B 276 87 60 9 C540 A 86 120 5C 6 C645 B 211 131 11E 7 C816 B 277 135 5C 9 C545 B 66 132 68 6 C644 B 227 109 110 7 C812 B 276 87 60 9 C546 B 37 131 68 6 C655 A 183 69 7A 7 C800 A 255 114 5C 9 C547 B 59 137 78 6 C651 A 187 64 7A 7 C820 B 280 104 50 9 C540 B 161 330 9B 6 C655 A 213 65 2B 7 C829 B 280 97 5E 9 C547 B 19 110 10B 6 C660 A 157 91 4F 7 C820 B 280 104 50 9 C550 B 128 133 9B 6 C654 B 220 79 5 10D 7 C812 B 280 104 50 9 C540 B 162 110 10B 6 C660 A 157 91 4F 7 C820 B 280 104 50 9 C550 B 128 133 9B 6 C655 A 213 65 2B 7 C829 B 280 61 8E 9 C550 B 128 133 9B 6 C655 A 213 65 2B 7 C829 B 280 69 89 9 C568 B 126 100 10 6 C660 A 157 91 4F 7 C834 B 281 100 8 B 9 C571 B 102 110 10B 6 C660 A 157 91 4F 7 C834 B 281 100 8 B 9 C580 B 126 100 10 6 C660 A 157 91 4F 7 C834 B 284 100 8 B 9 C581 B 161 100 100 6 C655 A 213 65 2B 7 C834 B 294 137 9E 9 C560 B 162 110 10B 6 C660 A 157 91 4F 7 C834 B 284 100 99 C83 B 280 99 70 9 C560 B 164 100 6 C660 A 157 100 94 C8 C844 B 280 29 70 9 C660 B 170 86 1D 7 C												1				
C519 B 146 77 8E 6 C625 B 250 69 7D 7 C740 B 192 113 8D 8 C519 B 146 77 8E 6 C627 B 260 74 7D 7 C743 B 213 138 90 8 C520 B 146 86 8E 6 C628 B 269 76 8D 7 C747 A 230 133 13D D 8 C521 B 146 94 8E 6 C628 B 269 76 8D 7 C748 A 234 128 10D 8 C521 B 140 77 8E 6 C629 B 265 82 8D 7 C748 A 234 128 10D 8 C523 B 140 78 8E 6 C631 B 183 76 2D 7 C750 A 217 133 10E 8 C523 B 140 78 8E 6 C631 B 183 76 2D 7 C750 A 217 133 10E 8 C524 B 141 94 8E 6 C632 B 189 79 3D 7 C751 A 219 126 10E 8 C526 A 140 113 9F 6 C633 B 250 88 9D 7 C800 A 255 124 2F 9 C526 A 140 113 9F 6 C636 B 238 82 10D 7 C802 B 286 129 3D 9 C527 B 150 111 11E 6 C636 B 238 9E 10D 7 C802 B 286 129 3D 9 C531 B 72 96 2C 6 C636 B 238 9E 10D 7 C802 B 286 129 3D 9 C531 B 72 96 2C 6 C636 B 238 89 10D 7 C802 B 286 129 3D 9 C531 B 72 96 2C 6 C636 B 238 89 10D 7 C802 B 286 129 3D 9 C532 B 52 97 28 6 C639 A 219 77 3B 7 C807 8 283 132 3D 9 C534 B 43 104 38 6 C641 B 220 92 10E 7 C802 B 286 129 3D 9 C534 B 43 104 38 6 C641 B 220 92 10E 7 C802 B 286 120 20 4E 9 C534 B 43 104 3B 6 C641 B 220 92 10E 7 C811 B 262 120 4E 9 C538 B 38 118 48 6 C644 B 223 95 10D 7 C812 B 276 87 60 9 C537 B 38 118 48 6 C644 B 223 113 110 7 C814 B 220 120 4E 9 C538 B 38 118 46 6 C644 B 223 113 110 7 C814 B 220 120 4E 9 C538 B 38 118 46 6 C644 B 213 113 11E 7 C816 B 220 104 50 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C812 B 276 87 60 9 C546 B 37 131 68 6 C653 A 183 69 7A 7 C822 B 280 101 50 9 C546 B 271 131 10 7 C814 B 280 101 50 9 C546 B 271 131 10 6 C652 A 216 64 6A 7 C822 B 283 108 6D 9 C550 B 128 133 9B 6 C654 B 220 91 107 7 C828 B 283 101 5D 9 C564 B 128 133 9B 6 C654 B 227 109 110 7 C812 B 280 97 5E 9 C553 B 131 10 10 B 6 C653 A 183 69 7A 7 C828 B 283 101 5D 9 C564 B 128 133 9B 6 C654 B 220 95 10D 7 C828 B 283 101 5D 9 C564 B 128 133 9B 6 C654 A 183 69 7A 7 C828 B 283 101 5D 9 C656 B 113 100 10 B 6 C652 A 216 64 6A 7 C822 B 283 108 60 9 9 C564 B 128 133 9B 6 C654 A 183 69 7A 7 C828 B 283 104 50 9 C655 B 128 133 9B 6 C655 A 183 75 97 C828 B 283 104 50 9 C656 B 128 133 19 10 C 6 C664 B 220 95 10D 7 C834 B				_		i										
C521 B 146 77 8E 6 C627 B 260 74 7D 7 C743 B 213 138 90 8   C521 B 146 94 8E 6 C628 B 269 76 8D 7 C747 A 230 133 10D 8   C521 B 146 94 8E 6 C629 8 265 82 8D 7 C747 A 230 133 10D 8   C522 B 140 77 8E 6 C631 B 183 76 2D 7 C750 A 217 133 10E 8   C524 B 141 94 8E 6 C632 B 189 79 3D 7 C751 A 219 126 10E 8   C524 B 141 94 8E 6 C633 B 260 88 9D 7 C762 A 183 121 7E 8   C525 B 147 102 9E 6 C635 B 236 95 10D 7 C600 A 255 124 2F 9   C526 A 140 113 9F 6 C635 B 236 95 10D 7 C600 A 255 124 2F 9   C527 B 150 111 11E 6 C636 B 238 98 10D 7 C600 A 255 124 2F 9   C523 B 59 93 2C 6 C637 B 248 83 9E 7 C600 B 274 135 2D 9   C531 B 79 93 2C 6 C637 B 248 83 9E 7 C600 B 274 135 2D 9   C531 B 72 96 2C 6 C638 A 223 85 3A 7 C606 B 271 127 3E 9   C532 B 52 97 28 6 C639 A 219 77 3B 7 C807 8 283 132 3D 9   C533 B 19 104 28 6 C640 B 220 92 10E 7 C807 8 283 132 3D 9   C534 B 78 109 3C 6 C642 B 207 95 10D 7 C811 B 262 120 4E 9   C534 B 38 118 4B 6 C644 B 213 113 11E 7 C816 B 280 104 50 9   C537 8 54 115 48 6 C642 B 207 95 10D 7 C811 B 262 120 4E 9   C539 8 56 123 58 6 C645 B 219 113 110 7 C814 B 277 113 5C 9   C544 8 65 132 68 6 C647 B 207 114 11E 7 C816 B 280 104 50 9   C545 A 86 120 5C 6 C645 B 219 113 110 7 C817 B 286 101 50 9   C545 B 5132 68 6 C647 B 207 114 11E 7 C816 B 280 104 50 9   C556 B 131 140 8B 6 C652 A 213 65 2B 7 C820 A 261 132 5E 9   C556 B 131 140 8B 6 C653 A 123 65 2B 7 C820 A 261 132 5E 9   C557 B 102 110 10B 6 C652 A 216 64 6A 7 7 C821 B 280 69 8D 9   C556 B 213 130 16 6 C660 A 157 91 4F 7 C830 B 288 130 E 9   C557 B 102 110 10B 6 C660 A 157 91 4F 7 C834 B 294 137 9E 9   C558 B 124 130 1B 6 C660 A 157 91 4F 7 C834 B 294 137 9E 9   C558 B 124 130 1B 6 C660 A 157 91 4F 7 C834 B 294 137 9E 9   C558 B 124 100 11B 6 C660 A 157 91 4F 7 C834 B 294 137 9E 9   C557 B 102 110 10B 6 C660 A 157 91 4F 7 C834 B 294 137 9E 9   C560 B 126 106 11C 6 C660 A 157 91 4F 7 C834 B 294 137 9E 9   C560 B 126 106 11C 6 C660 A 157 91 4F 7 C834 B 294 137 9E 9   C560 B 126 106 11C 6 C660 A 157 91 4F 7 C834 B 294 137 9E 9   C560 B 126 106 11C 6 C660 A 1	C518	A 13	5 8	37 7F	6	C625			69							
C521 B 146 94 8E 6 C629 8 265 82 8D 7 C748 A 234 128 10D 8 C522 B 140 77 8E 6 C631 B 183 76 2D 7 C750 A 217 133 10E 8 C524 B 141 94 8E 6 C632 B 189 79 3D 7 C751 A 219 126 10E 8 C524 B 141 94 8E 6 C632 B 189 79 3D 7 C752 A 217 133 10E 8 C524 B 141 94 8E 6 C633 B 260 88 9D 7 C762 A 183 121 7E 8 C525 B 147 102 9E 6 C635 B 236 95 10D 7 C800 A 255 124 2F 9 C526 A 140 113 9F 6 C635 B 236 95 10D 7 C800 B 274 135 2D 9 C527 B 150 111 11E 6 C636 B 238 98 10D 7 C800 B 274 135 2D 9 C530 A 59 93 2C 6 C637 B 248 83 9E 7 C800 B 281 132 3D 9 C531 B 79 93 2C 6 C637 B 248 83 9E 7 C800 B 281 132 3D 9 C531 B 79 93 2C 6 C637 B 248 83 9E 7 C800 B 281 132 3D 9 C531 B 79 104 28 6 C640 B 220 92 10E 7 C809 B 281 132 3D 9 C533 B 19 104 28 6 C640 B 220 92 10E 7 C809 B 281 132 3D 9 C534 B 43 104 3B 6 C644 B 220 92 10E 7 C809 A 255 114 3E 9 C534 B 38 118 4B 6 C644 B 220 95 10D 7 C812 B 276 87 60 9 C538 B 38 118 4B 6 C644 B 220 95 10D 7 C812 B 276 87 60 9 C538 B 56 123 58 6 C645 B 219 113 110 7 C814 B 277 113 5C 9 C538 B 56 123 58 6 C645 B 219 113 110 7 C814 B 277 113 5C 9 C546 B 37 131 68 6 C650 A 183 69 7A 7 C816 B 280 104 50 9 C546 B 37 131 68 6 C650 A 183 69 7A 7 C822 B 280 105 50 9 C554 B 131 7C 6 C652 A 216 64 6A 7 C822 B 283 108 6D 9 C554 B 131 140 0E 6 C653 A 220 67 6A 7 C822 B 283 108 6D 9 C554 B 131 140 0E 6 C653 A 220 67 6A 7 C822 B 283 108 6D 9 C556 B 131 140 0E 6 C664 A 157 91 4F 7 C828 B 283 101 5D 9 C556 B 113 140 0E 6 C665 A 213 65 2B 7 C829 B 280 69 8D 9 C557 B 119 110 11B 6 C664 A 171 86 4F 7 C829 B 280 69 8D 9 C568 B 135 104 106 6 C661 A 171 86 4F 7 C831 B 286 104 50 9 C658 A 133 106 6 C661 A 171 86 4F 7 C831 B 286 0F 9 C700 B 151 119 2D 8 C844 B 244 113 12D 6 C664 A 187 7 C831 B 286 66 8D 9 C700 B 151 119 2D 8 C844 B 244 119 120 6 C661 A 171 86 4F 7 C833 B 286 66 8D 9 C658 A 133 106 6D 9 C700 B 151 119 2D 8 C844 B 244 131 12D 7 C860 B 136 100 6 C662 A 157 80 4E 7 C833 B 286 66 8D 9 C660 B 170 80 10 10 10 6 C664 A 157 80 4E 7 C833 B 286 60 8D 9 C660 B 170 80 10 10 10 6 C664 A 157 80 4E 7 C833 B 280 60 89 9 C660 B 170 80 10	C519	B 14	6 7	77 8E	6	C627	В 2	260	74	7D	7	C743				
C522 B 140 77 8E 6 C631 B 183 76 2D 7 C750 A 217 133 10E 8 C524 B 141 94 8E 6 C633 B 260 88 9D 7 C751 A 219 126 10E 8 C525 B 147 102 9E 6 C633 B 250 88 9D 7 C751 A 219 126 10E 8 C525 B 147 102 9E 6 C633 B 250 88 9D 7 C751 A 219 126 10E 8 C525 B 147 102 9E 6 C634 B 254 87 8D 7 C752 A 183 121 7E 8 C525 A 140 113 9F 6 C636 B 238 98 10D 7 C800 A 255 124 2F 9 C527 B 150 111 11E 6 C636 B 238 98 10D 7 C801 B 274 135 2D 9 C531 B 72 96 2C 6 C636 B 238 98 10D 7 C802 B 286 129 3D 9 C531 B 72 96 2C 6 C636 A 223 85 3A 7 C806 B 271 127 3E 9 C532 B 52 97 28 6 C640 B 220 92 10E 7 C807 B 245 83 9E 7 C807 B 245 122 3D 9 C534 B 43 104 28 6 C641 B 223 95 10D 7 C807 B 245 124 2F 9 C853 B 248 109 3C 6 C641 B 223 95 10D 7 C807 B 245 1132 3D 9 C534 B 43 104 3B 6 C641 B 223 95 10D 7 C807 B 245 114 3E 9 C534 B 43 104 3B 6 C641 B 223 95 10D 7 C807 B 245 114 3E 9 C534 B 43 104 28 6 C644 B 227 105 10 7 C811 B 262 120 4E 9 C538 B 38 118 4B 6 C644 B 227 110 11D 7 C814 B 276 87 60 9 C539 8 56 123 58 6 C646 B 271 113 11D 7 C814 B 276 113 5C 9 C546 B 37 131 68 6 C646 B 227 110 110 7 C814 B 276 113 5C 9 C546 B 37 131 68 6 C651 A 186 7A 7 C820 A 261 132 5E 9 C546 B 37 131 68 6 C651 A 187 64 7A 7 C820 A 261 132 5E 9 C550 B 113 140 B 6 C652 A 216 64 6A 7 C822 B 283 108 4D 9 C566 B 113 140 B 6 C660 A 187 91 4F 7 C822 B 283 108 4D 9 C566 B 113 140 B 6 C660 A 187 91 4F 7 C822 B 283 108 4D 9 C569 B 113 100 10 10 6 C660 A 157 91 4F 7 C822 B 283 108 4D 9 C573 B 111 110 11B 6 C662 A 157 80 4E 7 C822 B 283 108 4D 9 C580 B 135 109 120 6 C660 A 157 91 4F 7 C840 A 269 141 9D 9 C580 B 135 109 120 6 C660 A 157 91 4F 7 C840 A 154 102 2B 9 C560 B 136 100 10 6 C660 A 157 91 4F 7 C840 A 154 102 2B 9 C560 B 136 100 10 10 6 C660 A 157 91 4F 7 C840 A 154 102 2B 9 C580 B 135 109 120 6 C660 A 157 91 4F 7 C840 A 154 102 2B 9 C580 B 135 109 120 6 C660 A 157 91 4F 7 C840 A 154 102 2B 9 C580 B 135 109 120 6 C660 A 157 91 4F 7 C840 A 154 102 2B 9 C560 B 136 100 10 10 6 C660 A 157 91 4F 7 7 C840 A 154 102 2B 9 C580 B 135 109 120 6 C600 B 170 86 1D 7 7 C708 B 166 115 4 C 8 C84				86 8E	6	C628	B 2	269	76	8D	7	C747	A 230	133	10D	8
C523 B 140 86 8E 6 C632 B 189 79 3D 7 C751 A 219 126 10E 8 C524 B 141 94 8E 6 C633 B 260 88 9D 7 C762 A 183 121 7E 8 C525 B 147 102 9E 6 C634 B 254 87 8D 7 C762 A 183 121 7E 8 C526 A 140 113 9F 6 C635 B 236 95 10D 7 C800 B 274 135 2D 9 C527 B 150 111 11E 6 C636 B 238 98 10D 7 C800 B 274 135 2D 9 C530 A 59 93 2C 6 C637 B 245 83 9E 7 C805 B 281 132 3D 9 C531 B 72 96 2C 6 C638 A 223 85 3A 7 C806 B 271 127 3E 9 C531 B 72 96 2C 6 C638 A 223 85 3A 7 C806 B 271 127 3E 9 C532 B 52 97 28 6 C640 B 220 92 10E 7 C807 8 283 132 3D 9 C533 B 19 104 28 6 C641 B 223 95 10D 7 C809 A 255 114 3E 9 C534 B 43 104 3B 6 C641 B 223 95 10D 7 C809 A 255 114 3E 9 C534 B 78 109 3C 6 C642 B 207 95 10D 7 C811 B 262 120 4E 9 C536 A 78 109 3C 6 C644 8 213 113 11E 7 C838 B 38 118 4B 6 C644 8 213 113 11E 7 C846 B 280 104 50 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C541 B 65 132 68 6 C647 8 207 114 11E 7 C646 B 37 131 68 6 C650 A 183 69 7A 7 C620 A 261 132 5E 9 C553 B 131 140 BB 6 C651 A 187 64 7A 7 C650 B 113 140 BB 6 C652 A 216 64 6A 7 C622 B 283 108 4D 9 C5564 B 116 130 9B 6 C655 A 213 65 2B 7 C829 B 280 79 5E 9 C5664 B 116 130 9B 6 C656 A 213 65 2B 7 C829 B 280 66 8D 9 C571 B 102 110 10B 6 C662 A 157 80 4E 7 C831 B 283 66 8D 9 C580 B 126 106 11C 6 C664 A 157 80 4E 7 C832 B 283 108 8E 9 C581 B 135 106 11C 6 C664 B 210 95 10E 7 C834 B 294 137 9B 9 C600 B 170 86 1D 7 C601 B 175 79 1D 7 C600 B 170 86 1D 7 C781 B 102 110 11B 6 C668 A 153 72 5F 7 C836 B 294 137 9B 9 C600 B 170 86 1D 7 C781 B 102 110 11B 6 C668 A 153 72 5F 7 C836 B 294 137 9B 9 C600 B 170 86 1D 7 C781 B 102 110 11B 6 C668 A 153 72 5F 7 C836 B 294 137 9B 9 C600 B 170 86 1D 7 C709 A 166 115 4C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C709 A 166 125 4C 8 C849 B 284 38 6C 9 C600 B 170 86 1D 7 C709 A 166 125 4C 8 C849 B 284 38 6C 9 C600 B 170 86 1D 7 C709 A 166 125 4C 8 C849 B 284 38 6C 9 C710 A 168 114 4C 8 C849 B 276 51 9 9 C710 A 168 114 4C 8 C857 B 284 38 6C 9 C710 A 168 114 4C 8 C849 B 276 51 9 9 C710 A 168 114 4C 8 C849 B 276 51 9 9 C710 A 168 114 4C 8 C849 B 276 51 9 9 C710 A 168						t .				8D	7	C748	A 234	128	10D	8
C524 B 141 94 8E 6 C633 B 260 88 9D 7 C762 A 183 121 7E 8 C525 B 147 102 9E 6 C634 B 254 87 8D 7 C800 A 255 124 2F 9 C526 A 140 113 9F 6 C635 B 236 95 10D 7 C800 B 286 129 3D 9 C527 B 150 111 11E 6 C636 B 238 98 10D 7 C800 B 286 129 3D 9 C530 A 59 93 2C 6 C637 B 245 83 9E 7 C805 B 281 132 3D 9 C531 B 72 96 2C 6 C638 A 223 85 3A 7 C806 B 271 127 3E 9 C532 B 52 97 28 6 C639 A 219 77 3B 7 C806 B 271 127 3E 9 C533 B 19 104 28 6 C640 B 220 92 10E 7 C809 A 255 114 3E 9 C534 B 43 104 3B 6 C641 B 223 95 100 7 C811 B 262 120 4E 9 C536 A 78 109 3C 6 C642 B 207 95 10D 7 C811 B 262 120 4E 9 C536 A 78 109 3C 6 C642 B 207 95 10D 7 C812 B 276 87 60 9 C537 8 54 115 48 6 C644 8 213 113 11E 7 C814 8 277 113 5C 9 C530 B 38 118 4B 6 C644 8 213 113 11E 7 C816 B 280 104 50 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C816 B 280 104 50 9 C546 B 37 131 68 6 C647 8 207 114 11E 7 C819 B 286 101 50 9 C546 B 37 131 68 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9 C553 A 89 131 7 C 6 C652 A 216 64 6A 7 C822 B 283 108 4D 9 C556 B 113 140 BB 6 C654 A 223 709 110 7 C819 B 280 97 5E 9 C556 B 113 140 BB 6 C654 B 242 97 9D 7 C828 B 283 108 4D 9 C556 B 113 140 BB 6 C654 A 242 97 9D 7 C828 B 283 108 4D 9 C556 B 113 140 BB 6 C654 A 242 97 9D 7 C828 B 283 108 4D 9 C556 B 101 10 10 B 6 C654 A 117 86 4F 7 C830 B 286 66 BD 9 C554 B 116 130 9B 6 C655 A 183 65 2B 7 C829 B 280 69 8D 9 C554 B 116 110 11B 6 C664 B 210 95 10F 7 C831 B 285 106 105 6 C651 A 187 80 4E 7 C831 B 285 106 105 6 C652 A 186 4F 7 C831 B 285 106 105 6 C654 B 210 95 10F 7 C834 B 294 137 9E 9 C550 B 102 110 10B 6 C662 A 157 80 4E 7 C831 B 286 130 8B 9 C550 B 102 110 10B 6 C664 B 210 95 10F 7 C834 B 294 137 9E 9 C550 B 102 110 10B 6 C664 B 210 95 10F 7 C834 B 294 137 9E 9 C600 B 151 119 10C 6 C661 A 157 91 4F 7 C839 B 289 59 8D 9 C600 B 151 119 10C 6 C661 A 157 91 4F 7 C839 B 289 59 8D 9 C600 B 151 119 10C 6 C661 A 157 91 4F 7 C839 B 289 59 8D 9 C600 B 151 119 10C 6 C661 A 157 91 4F 7 C839 B 289 59 8D 9 C600 B 150 10C 6 C661 A 157 91 4F 7 C839 B 289 59 8D 9 C600 B 150 10C 6 C661 A 157 91 4F 7 C83					_	1						C750	A 217	133	10E	8
C525 B 147 102 9E 6 C634 B 254 87 8D 7 C800 A 255 124 2F 9 9 C526 A 140 113 9F 6 C635 B 236 95 10D 7 C801 B 274 135 2D 9 C530 A 59 93 2C 6 C637 B 245 83 9E 70 C802 B 286 129 3D 9 C531 B 72 96 2C 6 C638 A 223 85 3A 7 C806 B 271 127 3E 9 C532 B 52 97 28 6 C639 A 219 77 3B 7 C807 8 283 132 3D 9 C533 B 19 104 28 6 C640 B 220 92 10E 7 C809 A 255 114 3E 9 C534 B 43 104 3B 6 C641 B 223 95 10D 7 C811 B 262 120 4E 9 C534 B 43 104 3B 6 C641 B 223 95 10D 7 C812 B 266 87 60 9 A 255 114 3E 9 C534 B 43 104 3B 6 C644 B 223 95 10D 7 C812 B 267 87 60 9 C537 8 54 115 48 6 C644 8 213 113 11E 7 C812 B 276 87 60 9 C538 B 38 118 4B 6 C644 8 213 113 11E 7 C814 B 280 104 50 9 C538 B 38 118 4B 6 C644 8 213 113 11E 7 C814 B 280 104 50 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C812 B 276 87 60 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C818 B 283 101 5D 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C818 B 283 101 5D 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C818 B 283 101 5D 9 C540 A 86 130 66 C650 A 183 69 7A 7 C820 A 261 132 5E 9 C553 A 89 131 7C 6 C652 A 216 64 6A 7 7 C820 A 261 132 5E 9 C560 B 113 140 BB 6 C653 A 220 67 6A 7 C822 B 283 108 4D 9 C564 B 116 130 9B 6 C653 A 220 67 6A 7 C822 B 283 108 4D 9 C564 B 116 130 9B 6 C653 A 220 67 6A 7 C822 B 283 108 4D 9 C564 B 116 130 9B 6 C653 A 220 67 6A 7 C822 B 283 108 4D 9 C564 B 116 100 B 6 C660 A 157 91 4F 7 C830 B 266 68 B 9 C571 B 102 110 10B 6 C660 A 157 91 4F 7 C830 B 266 68 B 9 C573 B 111 110 11B 6 C660 A 157 91 4F 7 C830 B 266 68 B 9 C573 B 111 110 11B 6 C660 A 157 91 4F 7 C830 B 266 68 B 9 C573 B 111 110 11B 6 C660 A 157 91 4F 7 C830 B 268 66 6B D 9 C582 B 128 135 106 11D 6 C661 A 171 86 4F 7 C832 B 280 61 BB 9 C569 B 140 100 6 C660 A 157 91 4F 7 C839 B 280 69 8D 9 C559 B 140 100 6 C660 A 157 91 4F 7 C839 B 280 69 8D 9 C569 B 140 100 6 C660 A 157 91 4F 7 C839 B 280 69 8D 9 C600 B 170 86 1D 7 C706 B 166 117 7 C708 B 166 117 7 7 C839 B 280 69 8D 9 C600 B 170 86 1D 7 C706 B 166 120 4 C 8 C844 B 294 27 9 D 7 C708 B 166 120 4 C 8 C844 B 280 29 7C 9 C600 B 170 86 1D 7 C714 B 169 109 4C 8 C8					_	1					-					
C526 A 140 113 9F 6 C635 B 236 95 10D 7 C801 B 274 135 2D 9 C527 B 150 111 11E 6 C636 B 238 98 10D 7 C802 B 286 129 3D 9 C531 B 72 96 2C 6 C637 B 238 98 10D 7 C802 B 286 129 3D 9 C531 B 72 96 2C 6 C638 A 223 85 3A 7 C806 B 271 127 3E 9 C653 B 218 19 104 28 6 C640 B 220 92 10E 7 C807 8 283 132 3D 9 C534 B 43 104 3B 6 C641 B 223 95 100 7 C811 B 262 120 4E 9 C536 A 78 109 3C 6 C642 B 207 95 10D 7 C812 B 276 87 60 9 C537 8 54 115 48 6 C643 8 204 110 11D 7 C812 B 276 87 60 9 C538 B 38 118 4B 6 C644 B 223 95 100 7 C811 B 262 120 4E 9 C538 B 38 118 4B 6 C644 B 213 113 11E 7 C816 B 280 104 50 9 C539 8 56 123 58 6 C645 8 219 113 110 7 C817 B 286 101 50 9 C544 B 86 120 5C 6 C646 B 227 109 110 7 C818 B 280 104 50 9 C544 B 65 132 68 6 C647 B 207 114 11E 7 C818 B 280 101 5D 9 C546 B 37 131 68 6 C651 A 183 69 7A 7 C820 A 261 132 5E 9 C553 A 89 131 7C 6 C652 A 183 69 7A 7 C820 A 261 132 5E 9 C556 B 128 133 9B 6 C654 B 242 97 9D 7 C822 B 283 108 4D 9 C564 B 116 130 9B 6 C655 A 220 67 6A 7 C822 B 283 108 4D 9 C564 B 116 130 9B 6 C655 A 221 66 4 6A 7 C822 B 283 108 4D 9 C564 B 116 130 9B 6 C656 A 157 91 4F 7 C830 B 286 66 BD 9 C570 B 102 110 10B 6 C662 A 157 80 4E 7 C831 B 286 66 BD 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 291 41 9D 9 C688 B 135 106 11D 6 C662 A 157 80 4E 7 C832 B 280 61 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C600 B 151 19 12D 6 C663 A 178 87 4E 7 C830 B 288 130 8B 9 C660 B 175 79 1 D 7 C708 B 166 115 4C 8 C844 B 294 137 9E 9 C709 B 140 106 9D 6 C661 A 157 10 124 4C 8 C844 B 294 137 9E 9 C709 B 140 106 9D 6 C700 B 151 119 2D 8 C841 A 154 128 3A 9 C701 A 148 122 2E 8 C843 A 154 122 3A 9 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C700 B 151 119 2D 8 C841 A 154 122 3A 9 C700 B 151 119 2D 8 C841 A 154 122 3A 9 C700 B 156 117 79 1D 7 C708 B 166 115 4C 8 C849 B 276 51 9D 9 C70 B 166 115 4C												1				
C527 B 150 111 11E 6 C636 B 238 98 10D 7 C802 B 286 129 3D 9 C530 A 59 93 2C 6 C637 B 245 83 9E 7 C805 B 281 132 3D 9 C532 B 72 96 2C 6 C638 A 223 85 3A 7 C806 B 271 127 3E 9 C532 B 52 97 28 6 C639 A 219 77 3B 7 C807 8 283 132 3D 9 C533 B 19 104 28 6 C640 B 220 92 10E 7 C809 A 255 114 3E 9 C534 B 43 104 3B 6 C641 B 223 95 100 7 C811 B 262 120 4E 9 C534 B 43 104 3B 6 C641 B 223 95 100 7 C812 B 276 87 60 9 C537 8 54 115 48 6 C643 8 204 110 11D 7 C814 8 277 113 5C 9 C538 B 38 118 48 6 C644 8 213 113 11E 7 C816 B 280 104 50 9 C539 8 56 123 58 6 C646 B 227 109 110 7 C818 B 286 101 50 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C818 B 280 104 50 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C818 B 280 101 5D 9 C546 B 37 131 68 6 C651 A 187 64 7A 7 C820 A 261 132 5E 9 C553 A 89 131 7C 6 C651 A 187 64 7A 7 C821 B 280 108 4D 9 C550 B 128 133 9B 6 C654 B 242 97 9D 7 C822 B 283 108 4D 9 C564 B 116 130 9B 6 C656 A 213 65 2B 7 C822 B 283 108 4D 9 C564 B 116 130 9B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C571 B 102 110 10B 6 C660 A 157 91 4F 7 C830 8 286 66 8D 9 C571 B 102 110 10B 6 C661 A 171 86 4F 7 C831 B 283 66 8D 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C832 B 280 61 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C832 B 280 61 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C832 B 280 61 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C582 B 135 106 11D 6 C663 A 157 8D 4E 7 C832 B 280 61 8E 9 C583 B 135 119 12D 6 C700 B 151 119 2D 8 C841 A 158 10B 3B 9 C660 B 170 86 1D 7 C708 B 166 115 4C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C708 B 166 115 4C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C708 B 166 115 4C 8 C845 B 284 280 29 7C 9 C603 B 167 73 2D 7 C708 B 166 115 4C 8 C845 B 284 38 C9 9 C603 B 167 73 2D 7 C708 B 166 115 4C 8 C845 B 284 38 C9 9 C603 B 167 73 2D 7 C708 B 166 115 4C 8 C846 B 284 284 26 10D 9 C600 B 170 86 1D 7 C708 B 166 115 4C 8 C846 B 284 284 28 20 97 7C 9 C600 B 170 86 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C600 B 170 86 1D 7 C7						1										
C530 A 59 93 2C 6 C637 B 245 83 9E 7 C805 B 281 132 3D 9 C531 B 72 96 2C 6 C638 A 223 85 3A 7 C806 B 271 127 3E 9 C532 B 52 97 28 6 C639 A 219 77 3B 7 C806 B 271 127 3E 9 C533 B 19 104 28 6 C640 B 220 92 10E 7 C809 A 255 114 3E 9 C534 B 43 104 3B 6 C641 B 223 95 100 7 C811 B 262 120 4E 9 C536 A 78 109 3C 6 C642 B 207 95 10D 7 C812 B 276 87 60 9 C536 A 78 109 3C 6 C642 B 207 95 10D 7 C814 B 277 113 5C 9 C538 B 38 118 4B 6 C644 B 213 113 11E 7 C816 B 280 104 50 9 C539 8 56 123 58 6 C645 8 219 113 110 7 C817 B 286 101 50 9 C544 B 65 132 68 6 C647 B 207 114 11E 7 C816 B 280 104 50 9 C544 B 65 132 68 6 C647 B 207 114 11E 7 C819 B 280 97 5E 9 C546 B 37 131 68 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9 C553 A 89 131 7C 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9 C550 B 113 140 8B 6 C653 A 220 67 6A 7 C822 B 283 108 4D 9 C560 B 113 140 8B 6 C652 A 216 64 6A 7 C822 B 283 108 4D 9 C560 B 113 140 8B 6 C654 B 220 97 97 7 C820 A 261 132 5E 9 C564 B 116 130 9B 6 C655 A 213 65 2B 7 C824 B 283 108 4D 9 C564 B 116 130 9B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C564 B 116 130 9B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C566 B 122 100 10B 6 C660 A 157 91 4F 7 C830 B 286 66 8D 9 C571 B 102 110 10B 6 C660 A 157 91 4F 7 C831 B 283 66 8D 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C583 B 126 106 11C 6 C670 A 269 111 7F 7 C830 B 289 59 8D 9 C583 B 126 106 11C 6 C670 A 269 111 7F 7 C830 B 289 59 8D 9 C584 B 144 113 12D 6 C700 B 151 119 2D 8 C844 B 294 137 9E 9 C600 B 170 86 1D 7 C700 B 151 119 2D 8 C844 B 294 137 9E 9 C600 B 170 86 1D 7 C708 B 166 115 4C 8 C847 B 294 35 7C 9 C603 B 167 73 2D 7 C709 A 166 115 4C 8 C847 B 294 38 60 9 C709 A 166 115 4C 8 C847 B 297 37 7 C709 A 166 115 4C 8 C847 B 297 37 7 C709 A 166 115 4C 8 C847 B 297 37 7 C709 A 166 115 4C 8 C847 B 297 37 7 C709 A 166 115 4C 8 C847 B 297 37 7 C709 A 166 115 4C 8 C847 B 297 37 7 C709 A 166 115 4C 8 C847 B 297 37 7 C709 A 166 115 4C 8 C847 B 297 37 7 C709 A 166 115 4C 8 C847 B 297 37 7 C709 A 166 115 4C 8 C847 B 297 37 7 C709 A 166 115 4C 8 C847 B 297 37 7 C7						1										
C531 B 72 96 2C 6 C638 A 223 85 3A 7 C806 B 271 127 3E 9 C532 B 52 97 28 6 C639 A 219 77 3B 7 C807 8 281 132 3D 9 C533 B 19 104 28 6 C640 B 220 92 10E 7 C809 A 255 114 3E 9 C534 B 43 104 3B 6 C641 B 223 95 100 7 C811 B 262 120 4E 9 C536 A 78 109 3C 6 C642 B 207 95 10D 7 C811 B 262 120 4E 9 C537 8 54 115 48 6 C644 8 231 113 11E 7 C816 B 280 104 50 9 C539 8 56 123 58 6 C645 8 219 113 11D 7 C814 8 277 113 5C 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C812 B 280 104 50 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C818 8 283 101 5D 9 C546 8 37 131 68 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9 C546 8 37 131 68 6 C651 A 187 64 7A 7 C820 A 261 132 5E 9 C556 8 113 140 8B 6 C653 A 220 67 6A 7 C824 A 299 85 6E 9 C560 8 113 140 8B 6 C654 8 242 97 9D 7 C828 B 283 108 4D 9 C560 8 113 140 8B 6 C655 A 213 65 2B 7 C828 B 283 108 4D 9 C566 8 113 100 9B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C568 8 9 2112 10B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C568 8 9 2 112 10B 6 C666 A 213 65 2B 7 C830 B 286 66 8D 9 C570 B 102 110 10B 6 C661 A 171 86 4F 7 C831 B 280 61 8E 9 C571 B 102 110 10B 6 C662 A 157 91 4F 7 C830 B 286 66 8D 9 C571 B 102 110 10B 6 C662 A 157 80 4F 7 C831 B 280 61 8E 9 C571 B 102 110 10B 6 C662 A 157 80 4E 7 C831 B 280 61 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C582 B 135 106 11D 6 C661 A 171 86 4F 7 C831 B 280 61 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C583 B 135 119 120 6 C700 B 151 119 2D 8 C841 A 158 10B 3B 9 C585 A 103 71 2A 6 C702 A 148 122 2E 8 C843 A 154 128 3A 9 C585 A 103 71 2A 6 C702 A 148 122 2E 8 C843 A 154 128 3A 9 C560 B 170 86 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C600 B 170 86 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C600 B 170 86 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C600 B 170 86 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C600 B 170 7 3 2D 7 C710 A 168 114 4C 8 C847 B 279 39 7C 9 C600 B 170 7 3 2D 7 C710 A 168 114 4C 8 C847 B 279 39 7C 9 C600 B 170 86 1D 7 C714 B 169 109 4C 8 C848 B 284 38 6C 9 C709 A 166 120 4C 8 C848 B 284 38 6C 9 C709						1						I				-
C532 B 52 97 28 6 C639 A 219 77 3B 7 C807 8 283 132 3D 9 C533 B 19 104 28 6 C640 B 220 92 10E 7 C809 A 255 114 3E 9 C534 B 43 104 3B 6 C641 B 223 95 100 7 C811 B 262 120 4E 9 C536 A 78 109 3C 6 C642 B 207 95 10D 7 C812 B 276 87 60 9 C537 8 54 115 48 6 C643 8 207 95 10D 7 C812 B 276 87 60 9 C538 B 38 118 4B 6 C644 8 213 113 11E 7 C814 8 277 113 5C 9 C538 B 38 118 4B 6 C645 8 219 113 110 7 C814 8 277 113 5C 9 C538 B 38 118 4B 6 C645 8 219 113 110 7 C817 B 286 101 5D 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C818 8 283 101 5D 9 C546 8 37 131 68 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9 C546 8 37 131 68 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9 C553 A 89 131 7C 6 C651 A 187 64 7A 7 C821 B 266 138 6E 9 C550 B 113 140 BB 6 C653 A 220 67 6A 7 C822 B 283 108 4D 9 C562 B 128 133 9B 6 C654 8 242 97 9D 7 C828 B 283 72 60 9 C564 B 116 130 9B 6 C654 A 213 65 2B 7 C820 B 280 69 8D 9 C566 B 116 130 9B 6 C660 A 157 91 4F 7 C831 B 283 66 8D 9 C570 B 102 110 10B 6 C661 A 171 86 4F 7 C831 B 283 66 8D 9 C571 B 102 110 10B 6 C663 A 178 75 4E 7 C831 B 283 66 8D 9 C570 B 102 110 10B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C580 B 126 106 11C 6 C661 A 171 86 4F 7 C831 B 283 66 8D 9 C571 B 102 110 10B 6 C666 A 157 91 4F 7 C831 B 283 66 8D 9 C571 B 102 110 10B 6 C666 A 157 91 4F 7 C831 B 283 66 8D 9 C573 B 111 110 11B 6 C666 A 157 91 7F 7 C830 B 284 130 8E 9 C580 B 126 106 11C 6 C660 A 157 91 7F 7 C830 B 286 130 8E 9 C580 B 126 106 11C 6 C660 A 157 91 7F 7 C830 B 284 130 8E 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C830 B 284 130 8E 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C830 B 284 130 8E 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C830 B 284 130 8E 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C830 B 284 130 8E 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C830 B 284 130 8E 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C830 B 284 131 120 A 9 C580 B 136 10 10 6 C661 B 170 7 C707 B 170 124 4C B C844 A 154 128 3A 9 C580 B 135 106 11D 6 C701 A 148 122 E B C844 B 284 26 10D 9 C600 B 170 86 1D 7 C708 B 166 115 4C B C849 B 276 51 9D 9 C600 B 170 86						1						1				
C533 B 19 104 28 6 C640 B 220 92 10E 7 C809 A 255 114 3E 9 C534 B 43 104 3B 6 C641 B 223 95 100 7 C811 B 262 120 4E 9 C536 A 78 109 3C 6 C642 B 207 95 10D 7 C812 B 276 87 60 9 C537 8 54 115 48 6 C643 8 204 110 11D 7 C814 8 277 113 5C 9 C538 B 38 118 4B 6 C644 8 213 113 11E 7 C816 B 280 104 50 9 C539 8 56 123 58 6 C645 8 219 113 110 7 C818 8 283 101 5D 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C818 8 283 101 5D 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C818 8 283 101 5D 9 C546 A 8 37 131 68 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9 C547 B 59 137 78 6 C651 A 187 64 7A 7 C821 B 286 103 5C 9 C553 A 89 131 7C 6 C652 A 216 64 6A 7 C822 B 283 108 4D 9 C560 8 113 140 8B 6 C653 A 220 67 6A 7 C824 A 299 85 6E 9 C562 B 128 133 9B 6 C654 8 242 97 9D 7 C828 B 283 72 60 9 C566 B 116 130 9B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C566 B 116 130 9B 6 C656 A 213 65 2B 7 C830 8 286 66 8D 9 C570 B 102 110 10B 6 C662 A 157 80 4E 7 C831 B 286 61 8E 9 C573 B 111 110 11B 6 C662 A 157 80 4E 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C583 B 135 119 12D 6 C666 A 157 91 4F 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C583 B 135 119 12D 6 C701 A 148 129 2D 8 C841 A 158 108 3B 9 C584 B 144 113 12D 6 C701 A 148 129 2D 8 C842 A 153 121 2D 9 C600 B 170 86 1D 7 C708 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C708 B 166 115 4C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C708 B 166 115 4C 8 C844 B 284 28 36 6A 9 C600 B 170 86 1D 7 C708 B 166 115 4C 8 C848 B 284 38 8C 9 C603 B 167 73 2D 7 C708 B 166 115 4C 8 C848 B 284 38 8C 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C846 B 286 38 6A 9						1						i				
C534 B 43 104 3B 6 C641 B 223 95 100 7 C811 B 262 120 4E 9 C536 A 78 109 3C 6 C642 B 207 95 10D 7 C812 B 276 87 60 9 C537 8 54 115 48 6 C643 8 204 110 11D 7 C814 8 277 113 5C 9 C538 B 38 118 4B 6 C644 8 213 113 11E 7 C816 B 280 104 50 9 C539 8 56 123 58 6 C645 8 219 113 110 7 C818 B 283 101 50 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C818 B 283 101 5D 9 C548 8 65 132 68 6 C647 8 207 114 11E 7 C818 B 283 101 5D 9 C548 8 37 131 68 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9 C546 8 37 131 68 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9 C556 8 113 140 8B 6 C653 A 220 67 6A 7 C821 8 266 138 6E 9 C556 8 113 140 8B 6 C653 A 220 67 6A 7 C821 8 266 138 6E 9 C556 B 128 133 9B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C568 8 92 112 10B 6 C660 A 157 91 4F 7 C830 8 286 66 8D 9 C570 B 102 110 10B 6 C660 A 157 91 4F 7 C830 8 286 66 8D 9 C571 B 102 110 10B 6 C660 A 157 80 4E 7 C831 B 283 66 8D 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C580 B 126 106 11C 6 C660 A 157 7 7 7 7 C830 A 288 130 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C583 B 135 109 11D 6 C670 A 269 111 7F 7 C830 B 286 66 8D 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C830 B 284 130 8B 9 C6584 B 144 113 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C6584 B 144 113 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C6584 B 144 113 12D 6 C700 B 151 119 2D 8 C842 A 153 121 2A 9 C600 B 170 86 1D 7 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C600 B 170 86 1D 7 C700 B 151 119 2D 8 C842 A 153 121 2A 9 C600 B 170 86 1D 7 C700 B 166 137 3C 8 C644 B 284 26 10D 9 C600 B 170 86 1D 7 C700 B 166 120 4C 8 C848 B 284 38 60 9 C600 B 170 86 1D 7 C700 B 166 120 4C 8 C849 B 276 51 9D 9 C600 B 170 86 1D 7 C700 B 166 120 4C 8 C849 B 276 51 9D 9 C600 B 170 86 1D 7 C700 B 166 120 4C 8 C849 B 276 51 9D 9 C600 B 170 86 1D 7 C700 B 166 120 4C 8 C849 B 276 51 9D 9 C600 B 170 86 1D 7 C714 B 169 109 4C 8 C849 B 276 51 9D 9 C600 B 170 7 C714 B 169 109 4C 8 C840 B 284 285 6A A 194 C604 B 194 74 3D 7 C710 A 168 114 4C 8 C849 B 276 51 9D 9 C600 B 180 67 3 2D 7 C710 A 168	C533	B 19	9 10		6	1										
C536 A 78 109 3C 6 C642 B 207 95 10D 7 C812 B 276 87 60 9 C537 8 54 115 48 6 C644 8 213 113 11E 7 C538 B 38 118 48 6 C644 8 213 113 11E 7 C539 8 56 123 58 6 C645 8 219 113 110 7 C540 A 86 120 5C 6 C646 B 227 109 110 7 C541 8 277 113 5C 9 C546 8 37 131 68 6 C657 A 183 69 7A 7 C546 8 37 131 68 6 C657 A 183 69 7A 7 C547 B 59 137 78 6 C651 A 187 64 7A 7 C553 A 89 131 7C 6 C652 A 216 64 6A 7 C5560 8 113 140 8B 6 C653 A 220 67 6A 7 C5562 B 128 133 9B 6 C654 8 242 97 9D 7 C5564 B 116 130 9B 6 C656 A 213 65 2B 7 C5568 8 92 112 10B 6 C666 A 157 91 4F 7 C5570 B 102 110 10B 6 C662 A 157 80 4E 7 C571 B 102 119 10C 6 C663 A 178 75 4E 7 C573 B 111 110 11B 6 C666 A 157 91 4F 7 C583 B 121 10 11B 6 C666 A 157 91 4F 7 C583 B 121 10 11B 6 C666 A 157 91 4F 7 C583 B 121 10 11B 6 C666 A 157 91 4F 7 C583 B 121 10 11B 6 C666 A 157 91 4F 7 C583 B 135 106 11D 6 C666 A 157 79 1 4F 7 C583 B 121 10 10B 6 C662 A 157 80 4E 7 C575 B 119 110 11B 6 C666 A 157 91 4F 7 C583 B 121 10 11B 6 C666 A 157 91 4F 7 C583 B 121 10 10B 6 C662 A 157 80 4E 7 C575 B 119 110 11B 6 C666 A 157 91 4F 7 C583 B 121 10 10B 6 C662 A 157 80 4E 7 C583 B 121 10 10B 6 C662 A 157 80 4E 7 C583 B 121 10 10B 6 C666 A 157 75 4E 7 C583 B 121 10 10B 6 C666 A 157 75 4E 7 C583 B 121 10 10B 6 C666 A 157 75 7 C583 B 121 10 10B 6 C666 A 157 75 7 C583 B 121 10 10B 6 C666 A 157 75 7 C583 B 121 10 10B 6 C666 A 157 75 7 C583 B 121 10 10B 6 C666 A 157 75 7 C583 B 121 10 10B 6 C666 A 157 75 7 C584 B 135 109 12D 6 C700 B 151 119 2D 8 C585 A 103 71 2A 6 C702 A 148 129 2D 8 C586 B 126 106 11C 6 C701 A 148 129 2D 8 C587 B 140 106 9D 6 C705 B 166 137 3C 8 C580 B 126 107 86 1D 7 C709 A 166 120 4C 8 C584 B 144 113 12D 6 C700 B 157 79 1D 7 C708 B 166 120 4C 8 C584 B 144 173 2D 6 C709 A 166 120 4C 8 C584 B 144 173 2D 6 C709 A 166 120 4C 8 C584 B 124 173 2D 6 C709 A 166 120 4C 8 C584 B 124 173 2D 6 C709 A 166 120 4C 8 C584 B 124 174 3D 7 C710 A 168 114 4C 8 C584 B 124 174 3D 7 C710 A 168 114 4C 8 C584 B 124 174 3D 7 C710 A 168 114 4C 8 C586 A 280 29 7C 9 C500 B 160 67 73 2D 7 C710 A 168 114 4C 8 C58	C534	B 4	3 10	4 3B	6	C641						ſ				
C537 8 54 115 48 6 C643 8 204 110 11D 7 C814 8 277 113 5C 9 C538 B 38 118 4B 6 C644 8 213 113 11E 7 C816 B 280 104 50 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C818 8 283 101 5D 9 C545 8 65 132 68 6 C645 8 207 114 11E 7 C816 B 280 101 5D 9 C545 8 65 132 68 6 C647 8 207 114 11E 7 C818 8 283 101 5D 9 C546 8 37 131 68 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9 C5547 B 59 137 78 6 C651 A 187 64 7A 7 C820 A 261 132 5E 9 C553 A 89 131 7C 6 C652 A 216 64 6A 7 C550 8 113 140 8B 6 C653 A 220 67 6A 7 C560 8 113 140 8B 6 C653 A 220 67 6A 7 C564 B 116 130 9B 6 C656 A 213 65 2B 7 C566 B 90 114 10C 6 C666 A 157 91 4F 7 C820 A 261 132 5E 9 C570 B 102 110 10B 6 C662 A 157 80 4E 7 C571 B 102 119 10C 6 C663 A 178 75 4E 7 C831 B 283 66 8D 9 C573 B 111 110 11B 6 C666 A 153 72 5F 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C666 A 153 72 5F 7 C836 B 126 106 11C 6 C670 A 269 111 7F 7 C836 B 289 59 8D 9 C582 B 135 106 11D 6 C701 A 148 129 2D 8 C584 B 144 113 12D 6 C700 B 151 119 2D 8 C584 B 144 113 12D 6 C700 B 151 119 2D 8 C585 A 103 71 2A 6 C702 A 148 122 2E 8 C600 B 170 86 1D 7 C700 B 166 120 4C 8 C601 B 175 79 1D 7 C700 B 166 120 4C 8 C647 B 29 7 C600 B 180 69 2E 7 C709 A 166 120 4C 8 C648 B 284 284 28 79 C709 A 166 120 4C 8 C648 B 284 284 28 79 C709 A 166 120 4C 8 C648 B 284 285 80 C701 A 168 114 4C 8 C648 B 284 285 80 C701 A 168 114 4C 8 C648 B 284 285 80 C701 A 168 114 4C 8 C648 B 284 285 80 C701 A 168 114 4C 8 C648 B 284 285 80 C701 A 168 114 4C 8 C648 B 284 285 80 C701 A 168 114 4C 8 C648 B 284 285 80 C701 A 168 114 4C 8 C648 B 284 285 80 C701 A 168 114 4C 8 C648 B 284 285 80 C701 A 168 114 4C 8 C648 B 284 285 80 C701 A 168 114 4C 8 C649 B 270 A 285 83 C701 A 168 114 4C 8 C640 B 294 74 3D 7 C701 A 168 114 4C 8 C640 B 294 74 3D 7 C701 A 168 114 4C 8 C640 B 294 74 3D 7 C701 A 168 114 4C 8 C640 B 294 74 3D 7 C701 A 168 114 4C 8 C640 B 294 74 3D 7 C701 A 168 114 4C 8 C640 B 294 74 3D 7 C701 A 168 114 4C 8 C640 B 294 74 3D 7 C701 A 168 114 4C 8 C640 B 294 74 3D 7 C701 A 168 114 4C 8 C640 B 294 74 3D 7 C701 A 168 114 4C 8 C640 B 294 7	C536	A 7	8 10	9 3C	6	C642	B 2	07			7					
C539 8 56 123 58 6 C645 8 219 113 110 7 C817 B 286 101 50 9 C540 A 86 120 5C 6 C646 B 227 109 110 7 C818 8 283 101 5D 9 C545 8 65 132 68 6 C647 8 207 114 11E 7 C819 B 286 101 5D 9 C546 8 37 131 68 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9 C547 B 59 137 78 6 C651 A 187 64 7A 7 C821 8 266 138 6E 9 C553 A 89 131 7C 6 C652 A 216 64 6A 7 C822 B 283 108 4D 9 C560 8 113 140 8B 6 C653 A 220 67 6A 7 C824 A 299 85 6E 9 C554 B 116 130 9B 6 C654 8 242 97 9D 7 C828 B 283 72 60 9 C564 B 116 130 9B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C568 8 92 112 10B 6 C660 A 157 91 4F 7 C830 8 286 66 8D 9 C569 A 90 114 10C 6 C661 A 171 86 4F 7 C831 B 283 66 8D 9 C570 B 102 110 10B 6 C662 A 157 80 4E 7 C832 B 280 61 8E 9 C571 B 102 119 10C 6 C663 A 178 75 4E 7 C833 B 280 61 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C575 B 119 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C830 B 289 59 8D 9 C582 B 135 106 11D 6 C671 A 264 97 7F 7 C840 A 154 102 2B 9 C583 B 135 119 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C584 B 144 113 12D 6 C701 A 148 122 2E 8 C843 A 154 128 3A 9 C699 B 140 106 9D 6 C705 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C707 B 170 124 4C 8 C846 B 280 29 7C 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C846 B 280 29 7C 9 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C848 B 284 38 8C 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C848 B 284 38 8C 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9					6	C643	8 2	04	110	11D	7	C814		113	5 <b>C</b>	9
C540 A 86 120 5C 6 C646 B 227 109 110 7 C818 8 283 101 5D 9 C545 8 65 132 68 6 C647 8 207 114 11E 7 C819 B 280 97 5E 9 C546 8 37 131 68 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9 C553 A 89 131 7C 6 C652 A 216 64 6A 7 C822 B 283 108 4D 9 C560 8 113 140 8B 6 C653 A 220 67 6A 7 C822 B 283 108 4D 9 C560 B 128 133 9B 6 C654 8 242 97 9D 7 C828 B 283 72 60 9 C564 B 116 130 9B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C568 8 92 112 10B 6 C660 A 157 91 4F 7 C830 8 286 66 8D 9 C570 B 102 110 10B 6 C661 A 171 86 4F 7 C831 B 283 66 8D 9 C571 B 102 110 10B 6 C662 A 157 80 4E 7 C832 B 280 61 8E 9 C571 B 102 110 10B 6 C663 A 178 75 4E 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C582 B 135 106 11D 6 C668 A 153 72 5F 7 C836 B 291 41 9D 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C830 B 289 59 8D 9 C582 B 135 106 11D 6 C671 A 264 97 7F 7 C840 A 154 102 2B 9 C584 B 144 113 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C599 B 140 106 9D 6 C701 A 148 129 2D 8 C842 A 153 121 2A 9 C659 B 140 106 9D 6 C702 A 148 122 2E 8 C843 A 154 128 3A 9 C6599 B 140 106 9D 6 C705 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 28						C644					7	C816	B 280	104	50	9
C545 8 65 132 68 6 C647 8 207 114 11E 7 C819 B 280 97 5E 9 C546 8 37 131 68 6 C650 A 183 69 7A 7 C547 B 59 137 78 6 C651 A 187 64 7A 7 C521 B 266 138 6E 9 C553 A 89 131 7C 6 C652 A 216 64 6A 7 C553 A 89 131 7C 6 C652 A 216 64 6A 7 C562 B 128 133 9B 6 C654 8 242 97 9D 7 C564 B 116 130 9B 6 C654 8 242 97 9D 7 C568 B 92 112 10B 6 C660 A 157 91 4F 7 C630 B 286 66 8D 9 C569 A 90 114 10C 6 C661 A 171 86 4F 7 C631 B 283 66 8D 9 C570 B 102 110 10B 6 C662 A 157 80 4E 7 C671 B 102 119 10C 6 C663 A 178 75 4E 7 C673 B 111 110 11B 6 C664 B 210 95 10E 7 C575 B 119 110 11B 6 C668 A 153 72 5F 7 C630 B 294 137 9E 9 C580 B 126 106 11C 6 C667 A 269 111 7F 7 C630 B 126 106 11C 6 C667 A 269 111 7F 7 C630 B 289 59 8D 9 C581 B 135 106 11D 6 C671 A 264 97 7F 7 C820 B 289 59 8D 9 C582 B 135 106 11D 6 C671 A 264 97 7F 7 C820 B 289 59 8D 9 C583 B 135 119 12D 6 C700 B 151 119 2D 8 C584 B 144 113 12D 6 C701 A 148 129 2D 8 C585 A 103 71 2A 6 C702 A 148 122 2E 8 C841 A 158 108 3B 9 C601 B 170 86 1D 7 C707 B 170 124 4C 8 C844 B 284 26 10D 9 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C847 B 279 39 7C 9 C604 B 194 74 3D 7 C710 A 168 114 4C 8 C847 B 279 39 7C 9 C604 B 194 74 3D 7 C710 A 168 114 4C 8 C847 B 279 39 7C 9 C604 B 194 74 3D 7 C710 A 168 114 4C 8 C840 A 154 102 C840 CHWARZ   EE AUSGANGSTEIL 1.046GHZ						Į.					7	C817	B 286	101	50	9
C546 8 37 131 68 6 C650 A 183 69 7A 7 C820 A 261 132 5E 9 C547 B 59 137 78 6 C651 A 187 64 7A 7 C821 8 266 138 6E 9 C553 A 89 131 7C 6 C652 A 216 64 6A 7 C822 B 283 108 4D 9 C560 8 113 140 8B 6 C653 A 220 67 6A 7 C824 A 299 85 6E 9 C562 B 128 133 9B 6 C654 8 242 97 9D 7 C828 B 283 72 60 9 C564 B 116 130 9B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C568 8 92 112 10B 6 C660 A 157 91 4F 7 C830 8 286 66 8D 9 C569 A 90 114 10C 6 C661 A 171 86 4F 7 C831 B 283 66 8D 9 C570 B 102 110 10B 6 C662 A 157 80 4E 7 C832 B 280 61 8E 9 C571 B 102 119 10C 6 C663 A 178 75 4E 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C580 B 126 106 11C 6 C660 A 153 72 5F 7 C836 B 291 41 9D 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C839 B 289 59 8D 9 C583 B 135 119 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C584 B 144 113 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C585 A 103 71 2A 6 C702 A 148 122 2E 8 C843 A 154 128 3A 9 C599 B 140 106 9D 6 C705 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C708 B 166 137 3C 8 C844 B 284 26 10D 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C849 B 270 51 9D 7 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 CHWARZ						1									5D	9
C547 B 59 137 78 6 C651 A 187 64 7A 7 C821 8 266 138 6E 9 C553 A 89 131 7C 6 C652 A 216 64 6A 7 C822 B 283 108 4D 9 C566 8 113 140 8B 6 C653 A 220 67 6A 7 C824 A 299 85 6E 9 C564 B 116 130 9B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C568 8 92 112 10B 6 C660 A 157 91 4F 7 C830 8 286 66 8D 9 C569 A 90 114 10C 6 C661 A 171 86 4F 7 C831 B 283 66 8D 9 C570 B 102 110 10B 6 C662 A 157 80 4E 7 C832 B 280 61 8E 9 C571 B 102 119 10C 6 C663 A 178 75 4E 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C839 B 289 59 8D 9 C580 B 126 106 11C 6 C671 A 264 97 7F 7 C840 A 154 102 2B 9 C583 B 135 119 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C584 B 144 113 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C599 B 140 106 9D 6 C705 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C708 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C708 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C708 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C708 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C708 B 166 120 4C 8 C849 B 276 51 9D 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C849 B 276 51 9D 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C849 B 276 51 9D 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C849 B 276 51 9D 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C846 B 280 29 7C 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C846 B 284 38 8C 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C846 B 284 38 6C 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C846 B 284 38 6C 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C846 B 284 38 6C 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C846 B 284 38 6C 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C846 B 284 38 6C 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C846 B 284 38 6C 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C846 B 284 38 6C 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C846 B 284 38 6C 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C846 B 284 38 6C 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C846 B 284 38 6C 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C846 B 284 38						4										-
C553 A 89 131 7C 6 C652 A 216 64 6A 7 C822 B 283 108 4D 9 C560 8 113 140 8B 6 C653 A 220 67 6A 7 C824 A 299 85 6E 9 C562 B 128 133 9B 6 C654 8 242 97 9D 7 C828 B 283 72 60 9 C564 B 116 130 9B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C568 8 92 112 10B 6 C660 A 157 91 4F 7 C830 8 286 66 8D 9 C569 A 90 114 10C 6 C661 A 171 86 4F 7 C831 B 283 66 8D 9 C570 B 102 110 10B 6 C662 A 157 80 4E 7 C832 B 280 61 8E 9 C571 B 102 119 10C 6 C663 A 178 75 4E 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C575 B 119 110 11B 6 C668 A 153 72 5F 7 C836 B 291 41 9D 9 C570 B 126 106 11C 6 C670 A 269 111 7F 7 C839 B 289 59 8D 9 C580 B 126 106 11C 6 C671 A 264 97 7F 7 C840 A 154 102 2B 9 C583 B 135 119 12D 6 C700 B 151 119 2D 8 C840 A 154 102 2B 9 C584 B 144 113 12D 6 C700 B 151 119 2D 8 C842 A 153 121 2A 9 C585 A 103 71 2A 6 C702 A 148 122 2E 8 C843 A 154 128 3A 9 C599 B 140 106 9D 6 C705 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C707 B 170 124 4C 8 C846 B 280 29 7C 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C602 B 180 69 2E 7 C709 A 166 110 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C860 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C860 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C860 A 285 83 6A 9											- 1				-	-
C560 8 113 140 8B 6 C653 A 220 67 6A 7 C824 A 299 85 6E 9 C562 B 128 133 9B 6 C654 8 242 97 9D 7 C828 B 283 72 60 9 C564 B 116 130 9B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C568 8 92 112 10B 6 C660 A 157 91 4F 7 C830 8 286 66 8D 9 C570 B 102 110 10B 6 C661 A 171 86 4F 7 C831 B 283 66 8D 9 C571 B 102 119 10C 6 C663 A 178 75 4E 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C668 A 153 72 5F 7 C836 B 291 41 9D 9 C570 B 102 110 10B 6 C667 A 269 111 7F 7 C839 B 289 59 8D 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C839 B 289 59 8D 9 C582 B 135 106 11D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C584 B 144 113 12D 6 C700 B 151 119 2D 8 C842 A 153 121 2A 9 C585 A 103 71 2A 6 C702 A 148 122 2E 8 C843 A 154 128 3A 9 C599 B 140 106 9D 6 C705 B 166 137 3C 8 C846 B 280 29 7C 9 C600 B 170 86 1D 7 C707 B 170 124 4C 8 C846 B 280 29 7C 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9  CHWARZ   EE AUSGANGSTEIL 1.046GHZ   EE AUSGANGSTEIL 1.046GHZ					_											-
C562 B 128 133 9B 6 C654 8 242 97 9D 7 C828 B 283 72 60 9 C564 B 116 130 9B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C568 8 92 112 10B 6 C660 A 157 91 4F 7 C830 8 286 66 8D 9 C569 A 90 114 10C 6 C661 A 171 86 4F 7 C831 B 283 66 8D 9 C570 B 102 110 10B 6 C662 A 157 80 4E 7 C832 B 280 61 8E 9 C571 B 102 119 10C 6 C663 A 178 75 4E 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C833 A 288 130 8E 9 C575 B 119 110 11B 6 C668 A 153 72 5F 7 C836 B 291 41 9D 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C839 B 289 59 8D 9 C582 B 135 106 11D 6 C671 A 264 97 7F 7 C840 A 154 102 2B 9 C583 B 135 119 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C584 B 144 113 12D 6 C701 A 148 129 2D 8 C842 A 153 121 2A 9 C585 A 103 71 2A 6 C702 A 148 122 2E 8 C843 A 154 128 3A 9 C600 B 170 86 1D 7 C707 B 170 124 4C 8 C846 B 280 29 7C 9 C601 B 175 79 1D 7 C708 B 166 137 3C 8 C848 B 284 38 8C 9 C603 B 167 73 2D 7 C710 A 168 114 4C 8 C848 B 284 38 8C 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C848 B 284 38 8C 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C846 B 280 29 7C 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C848 B 284 38 8C 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C848 B 284 38 8C 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C848 B 284 38 8C 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C848 B 284 38 8C 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C848 B 284 38 8C 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C848 B 284 38 8C 9 C605 B 166 175 C714 B 169 109 4C 8 C848 B 284 38 8C 9 C606 B 170 C714 B 169 109 4C 8 C848 B 284 38 8C 9 C607 C714 B 169 109 4C 8 C848 B 284 38 8C 9 C718 C718 C718 C718 C718 C718 C718 C718						1										-
C564 B 116 130 9B 6 C656 A 213 65 2B 7 C829 B 280 69 8D 9 C568 8 92 112 10B 6 C660 A 157 91 4F 7 C830 8 286 66 8D 9 C569 A 90 114 10C 6 C661 A 171 86 4F 7 C831 B 283 66 8D 9 C570 B 102 110 10B 6 C662 A 157 80 4E 7 C832 B 280 61 8E 9 C571 B 102 119 10C 6 C663 A 178 75 4E 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C573 B 111 110 11B 6 C668 A 153 72 5F 7 C836 B 291 41 9D 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C839 B 289 59 8D 9 C582 B 135 106 11D 6 C671 A 264 97 7F 7 C840 A 154 102 2B 9 C583 B 135 119 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C584 B 144 113 12D 6 C701 A 148 129 2D 8 C842 A 153 121 2A 9 C585 A 103 71 2A 6 C702 A 148 122 2E 8 C843 A 154 128 3A 9 C599 B 140 106 9D 6 C705 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C707 B 170 124 4C 8 C846 B 280 29 7C 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C849 B 276 51 9D 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C849 B 276 51 9D 9 C600 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C864 B 280 29 7C 9 C714 B 169 109 4C 8 C864 B 280 29 7C 9 C714 B 169 109	C562					E .					- 1					
C568 8 92 112 10B 6 C660 A 157 91 4F 7 C830 8 286 66 8D 9 C569 A 90 114 10C 6 C661 A 171 86 4F 7 C831 B 283 66 8D 9 C570 B 102 110 10B 6 C662 A 157 80 4E 7 C832 B 280 61 8E 9 C571 B 102 119 10C 6 C663 A 178 75 4E 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C575 B 119 110 11B 6 C668 A 153 72 5F 7 C836 B 291 41 9D 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C839 B 289 59 8D 9 C582 B 135 106 11D 6 C671 A 264 97 7F 7 C840 A 154 102 2B 9 C584 B 144 113 12D 6 C700 B 151 119 2D 8 C585 A 103 71 2A 6 C702 A 148 129 2D 8 C841 A 158 108 3B 9 C599 B 140 106 9D 6 C705 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C707 B 170 124 4C 8 C846 B 280 29 7C 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C848 B 284 38 8C 9 C603 B 167 73 2D 7 C710 A 168 114 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9  CHWARZ   EE AUSGANGSTEIL 1.046GHZ   EE AUSGANGSTEIL 1.046GHZ	C564															
C569 A 90 114 10C 6 C661 A 171 86 4F 7 C831 B 283 66 8D 9 C570 B 102 110 10B 6 C662 A 157 80 4E 7 C832 B 280 61 8E 9 C571 B 102 119 10C 6 C663 A 178 75 4E 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C575 B 119 110 11B 6 C668 A 153 72 5F 7 C836 B 291 41 9D 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C839 B 289 59 8D 9 C582 B 135 106 11D 6 C671 A 264 97 7F 7 C840 A 154 102 2B 9 C583 B 135 119 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C584 B 144 113 12D 6 C701 A 148 129 2D 8 C842 A 153 121 2A 9 C585 A 103 71 2A 6 C702 A 148 122 2E 8 C843 A 154 128 3A 9 C599 B 140 106 9D 6 C705 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C707 B 170 124 4C 8 C846 B 280 29 7C 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9  CHWARZ   EE AUSGANGSTEIL 1.046GHZ   EE AUSGANGSTEIL 1.046GHZ	C568	8 92	11:	2 10B	6	Ĭ.					- 1					
C570 B 102 110 10B 6 C662 A 157 80 4E 7 C832 B 280 61 8E 9 C571 B 102 119 10C 6 C663 A 178 75 4E 7 C833 A 288 130 8E 9 C573 B 111 110 11B 6 C664 B 210 95 10E 7 C834 B 294 137 9E 9 C575 B 119 110 11B 6 C668 A 153 72 5F 7 C836 B 291 41 9D 9 C580 B 126 106 11C 6 C670 A 269 111 7F 7 C839 B 289 59 8D 9 C582 B 135 106 11D 6 C671 A 264 97 7F 7 C840 A 154 102 2B 9 C583 B 135 119 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C584 B 144 113 12D 6 C701 A 148 129 2D 8 C842 A 153 121 2A 9 C585 A 103 71 2A 6 C702 A 148 122 2E 8 C843 A 154 128 3A 9 C599 B 140 106 9D 6 C705 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C708 B 166 115 4C 8 C846 B 280 29 7C 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C848 B 284 38 8C 9 C603 B 167 73 2D 7 C710 A 168 114 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9  CHWARZ   EE AUSGANGSTEIL 1.046GHZ   EE AUSGANGSTEIL 1.046GHZ	C569	A 90	11	4 10C	6	C661				4F	- 1					
C571  B 102 119 10C 6	C570				6	C662			80		- 1					
C573 B 111 110 11B 6   C664 B 210 95 10E 7   C834 B 294 137 9E 9   C575 B 119 110 11B 6   C668 A 153 72 5F 7   C836 B 291 41 9D 9   C580 B 126 106 11C 6   C670 A 269 111 7F 7   C839 B 289 59 8D 9   C582 B 135 106 11D 6   C671 A 264 97 7F 7   C840 A 154 102 2B 9   C583 B 135 119 12D 6   C700 B 151 119 2D 8   C841 A 158 108 3B 9   C584 B 144 113 12D 6   C701 A 148 129 2D 8   C842 A 153 121 2A 9   C585 A 103 71 2A 6   C702 A 148 122 2E 8   C843 A 154 128 3A 9   C599 B 140 106 9D 6   C705 B 166 137 3C 8   C844 B 284 26 10D 9   C600 B 170 86 1D 7   C707 B 170 124 4C 8   C846 B 280 29 7C 9   C601 B 175 79 1D 7   C708 B 166 115 4C 8   C847 B 279 39 7C 9   C602 B 180 69 2E 7   C709 A 166 120 4C 8   C848 B 284 38 8C 9   C603 B 167 73 2D 7   C710 A 168 114 4C 8   C849 B 276 51 9D 9   C604 B 194 74 3D 7   C714 B 169 109 4C 8   C849 B 276 51 9D 9   C604 B 194 74 3D 7   C714 B 169 109 4C 8   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154 128 3A 9   C840 A 154	C571				6					4E	7	C833				
C580 B 126 106 11C 6 C670 A 269 111 7F 7 C839 B 289 59 8D 9  C582 B 135 106 11D 6 C671 A 264 97 7F 7 C840 A 154 102 2B 9  C583 B 135 119 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9  C584 B 144 113 12D 6 C701 A 148 129 2D 8 C842 A 153 121 2A 9  C585 A 103 71 2A 6 C702 A 148 122 2E 8 C843 A 154 128 3A 9  C599 B 140 106 9D 6 C705 B 166 137 3C 8 C844 B 284 26 10D 9  C600 B 170 86 1D 7 C707 B 170 124 4C 8 C846 B 280 29 7C 9  C601 B 175 79 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9  C602 B 180 69 2E 7 C709 A 166 120 4C 8 C848 B 284 38 8C 9  C603 B 167 73 2D 7 C710 A 168 114 4C 8 C849 B 276 51 9D 9  C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9  CHWARZ   EE AUSGANGSTEIL 1.046GHZ   EE AUSGANGSTEIL 1.046GHZ						1					7	C834		137		9
C582 B 135 106 11D 6 C671 A 264 97 7F 7 C840 A 154 102 2B 9 C583 B 135 119 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C584 B 144 113 12D 6 C701 A 148 129 2D 8 C842 A 153 121 2A 9 C585 A 103 71 2A 6 C702 A 148 122 2E 8 C843 A 154 128 3A 9 C599 B 140 106 9D 6 C705 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C707 B 170 124 4C 8 C846 B 280 29 7C 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C848 B 284 38 8C 9 C603 B 167 73 2D 7 C710 A 168 114 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9  CHWARZ   EE AUSGANGSTEIL 1.046GHZ   EE AUSGANGSTEIL 1.046GHZ						1									9D	9
C583 B 135 119 12D 6 C700 B 151 119 2D 8 C841 A 158 108 3B 9 C584 B 144 113 12D 6 C701 A 148 129 2D 8 C842 A 153 121 2A 9 C585 A 103 71 2A 6 C702 A 148 122 2E 8 C843 A 154 128 3A 9 C599 B 140 106 9D 6 C705 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C707 B 170 124 4C 8 C846 B 280 29 7C 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C848 B 284 38 8C 9 C603 B 167 73 2D 7 C710 A 168 114 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9  C606 C607 C708 C709 A 166 120 4C 8 C849 B 276 51 9D 9 C608 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C609 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 C709 A 168 115 A C849 B 276 51 9D 9 C709 C709 A 168 115 A C849 B 276 51 9D 9 C709 C709 A 168 115 A C849 B 276 51 9D 9 C709 C709 A 168 115 A C849 B 276 51 9D 9 C709 A 168 115 A C849 B 276 51 9D 9 C709 A 168 115 A C849 B 276 51 9D 9 C709 A 168 115 A C849 B 276 51 9D 9 C709 A 168 115 A C849 B 276 51 9D 9 C709 A 168 115 A C849 B 276 51 9D 9 C709 A 168 115 A C849 B 276 51 9D 9 C709 A 168 115 A C849 B 276 51 9D 9 C709 A 168 137 A C849 B 276 51 9D 9 C709 A 168 137 A C849 B 276 51 9D 9 C709 A 168 137 A C849 B 276 51 9D 9 C709 A 168 137 A C849 B 276 51 9D 9 C709 A 168 137 A C849 B 276 51 9D 9 C709 A 168 137 A C849 B 276 51 9D 9 C709 A 168 137 A C849 B 276 51 9D 9 C709 A 168 137 A C849 B 276 51 9 C709 A 168 137 A C849 B 276 51 9 C709 A 168 137 A C849																
C584 B 144 113 12D 6 C701 A 148 129 2D 8 C842 A 153 121 2A 9 C585 A 103 71 2A 6 C702 A 148 122 2E 8 C843 A 154 128 3A 9 C599 B 140 106 9D 6 C705 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C707 B 170 124 4C 8 C846 B 280 29 7C 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C848 B 284 38 8C 9 C603 B 167 73 2D 7 C710 A 168 114 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9  C606 C807 C708 C709 A 166 120 4C 8 C849 B 276 51 9D 9 C607 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C608 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C609 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 A 168 114 4C 8 C849 B 276 51 9D 9 C709 A 168 115 4C 8 C849 B 276 51 9D 9 C709 A 168 115 4C 8 C849 B 276 51 9D 9 C709 A 168 115 4C 8 C849 B 276 51 9D 9 C709 A 168 115 4C 8 C849 B 276 51 9D 9 C709 A 168 115 4C 8 C849 B 276 51 9D 9 C709 A 168 115 4C 8 C849 B 276 51 9D 9 C709 A 168 115 4C 8 C849 B 276 51 9D 9 C709 A 168 115 4C 8 C849 B 276 51 9D 9 C709 A 168 115 4C 8 C849 B 276 51 9D 9 C709 A 168 115 4C 8 C849 B 276 51 9D 9 C709 A 168 115 4C 8 C849 B 276 51 9D 9 C709 A 168 115 4C 8 C849 B 276 51 9D 9 C709 A 168 115 4C 8 C849 B 270 9 C709 A 168 115 4C 8 C849 B 270 9 C709 A 168 115 4C 8 C849 B 270 9 C709 A 168 115 4C 8 C849 B 270 9 C709 A 168 115 4C 8 C849 B 270 9 C709 A 168 115 4C 8 C849 B 270 9 C709 A 168 115 4C 8 C849 B 270 9 C709 A 168 115 4C 8 C849 B 270 9 C709 A 168 115 4C 8 C849 B 270 9 C709 A 168 115 4C 8 C849 B 270 9 C709 A 168 115 4C 8 C849 B 270 9 C709 A 168 1											- 1					
C585 A 103 71 2A 6 C702 A 148 122 2E 8 C843 A 154 128 3A 9 C599 B 140 106 9D 6 C705 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C707 B 170 124 4C 8 C846 B 280 29 7C 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C848 B 284 38 8C 9 C603 B 167 73 2D 7 C710 A 168 114 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C800 B 167 73 C710 A 168 114 4C 8 C850 A 285 83 6A 9 C800 B 167 73 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C800 B 167 73 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C800 B 167 73 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C800 B 167 73 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C800 B 167 73 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C800 B 167 73 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C800 B 167 73 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C800 B 167 73 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C800 B 167 73 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C800 B 167 73 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C800 B 167 73 C714 B 169 109 4C 8 C850 A 285 83 6A 9 C800 B 167 73 C714 B 169 109 4C 8 C850 B 167 73 C714 B 169 109 4C 8 C850 B 167 73 C714 B 169 109 4C 8 C850 B 167 73 C714 B 169 109 4C 8 C850 B 167 73 C714 B 169 109 4C 8 C850 B 167 73 C714 B 169 109 4C 8 C850 B 167 73 C714 B 169 109 4C 8 C849 B 276 51 9D 9 C850 B 167 73 C714 B 169 109 4C 8 C849 B 276 51 9D 9 C850 B 167 73 C714 B 169 109 4C 8 C849 B 276 51 9D 9 C850 B 160 100 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 160 B 1						Ī					- 1					
C599 B 140 106 9D 6 C705 B 166 137 3C 8 C844 B 284 26 10D 9 C600 B 170 86 1D 7 C707 B 170 124 4C 8 C846 B 280 29 7C 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C848 B 284 38 8C 9 C603 B 167 73 2D 7 C710 A 168 114 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9  C71											· · · · · · · · · · · · · · · · · · ·					
C600 B 170 86 1D 7 C707 B 170 124 4C 8 C846 B 280 29 7C 9 C601 B 175 79 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C848 B 284 38 8C 9 C603 B 167 73 2D 7 C710 A 168 114 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9  C710 Datum XY-Liste fr Sach-Nummer Stock-Nr Page  CHWARZ E EE AUSGANGSTEIL 1.046GHZ	C599										- 1					
C601 B 175 79 1D 7 C708 B 166 115 4C 8 C847 B 279 39 7C 9 C602 B 180 69 2E 7 C709 A 166 120 4C 8 C848 B 284 38 8C 9 C603 B 167 73 2D 7 C710 A 168 114 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9	C600										- 1					
C602 B 180 69 2E 7 C709 A 166 120 4C 8 C848 B 284 38 8C 9 C603 B 167 73 2D 7 C710 A 168 114 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9	C601															
C603 B 167 73 2D 7 C710 A 168 114 4C 8 C849 B 276 51 9D 9 C604 B 194 74 3D 7 C714 B 169 109 4C 8 C850 A 285 83 6A 9	C602										1					
C604 B 194 74 3D 7   C714 B 169 109 4C 8   C850 A 285 83 6A 9	C603															
To Datum	C604					ĺ										
ROHOE Date XY-list for Stock-Nr Page & +		+							<b></b>		+				-+	
& +	<b>DAME</b> =	<u>-</u> I		ĺ							- 1				81a	tt
CHWARZ EE AUSGANGSTEIL 1.046GHZ	ROHOE			Date			3	(Y-:	list	for	:	Stock-	Nr		Pag	e
		+ 				BD 37700					+				-+	
1 04 11.07.30  00FF0T_0RIT_1.046GHZ   1062.6209.01 XY   2+	CHWAKZ		ام	11 07								1000 -	000 01	****		
, , , , , , , , , , , , , , , , , , ,		! <b>+</b>						· I I _		*0GHZ	·	1002.6	703.01	XX	2	+

!

Part	Sid	ie X		. Sq	r Pç	Part	Sie	de X	Y	Sqr	Pg	Part	Sid	e X	Y	Sqı	Pç
C851		296			A 9	1		3 57	55			1		114			
C852		280		75 6		I				5E		L517		13			
C853		291		58 6		1				5E		L520			7 119		
C854		292 280		34 8						5E		L530					
C858		253		38 8;		1			40	1A		L532	В				
C860		297						3 57	42			L533	В		101		
C870		296		17 91 79 111						7E		L534	В		103	_	
C871		300		6 11						7D		L536	В		109		
C880		279				1				7E		L537	В		115		
C881		289		5 61				57	22	2A 10C		L538	В		116		
C883		289				1 -		, 5,	23	7D		1	В		122		
C885		152								7D	3	L540	В		118		
C886		155				1				10C	_	L541 L542	В		119		
C887		289				1				3A		L542	B B		123		
C889		294						120	111			L543			119		
D10-A		230				1		120	1 4 1	8B		L545	В		134		
D10-B	Ĭ		_	61		D431-		109	111		_	L546	В		129		
D100-	A B	213	Δ					103	<b>T</b> T T	10B		L546	В		129 134		
D100-1			7	90		D431-				10E	5 5	L547	B B		134 129		
D100-0				100		D431-1				10D		L548			130		
D100-I					10	D431-1				10D	5	L550	В				
D100-I					10	D431-1				10D	5	1	В		129		
D102-7		177	4		10	D431-0				10B		L551	В		137		
D102-E		-,,	•		10	D432-2		130	120			L553	8		135		6
D105-2		190	4		10	D432-1		130	120	10C	5 5	L559 L560	8		135		6
D105-8			•		10	D432-0				10C	5	}			138		6
D105-0					10	D432-I				118	5	L561			137		6
D105-E					10	D432-1					5	L562			137		6
D105-E					10	D432-1				118 10B	5	L563 L564			133		6
D110-A		161	5		10	D432-0				9B	5	1			130		6
D110-8			Ī		10	D760		236	1 22		8	L565			128		6
D111-2		146	5		10	L20		124	15	2D	2	L566			128	98	6
D111-8		2.10	٠		10	L21		105	16	2D	2	L568 L570	8		114		6
D111-0					10	L22	В	96	28						110		6
D111-D					10	L300	В	27	23	3D 4D	2 4	L571 L572				11B	
D111-E					10	L301	8		23	3D	4	L572				11B	6
D115-A						L305	В		32	5D	4	L583				11C	6
D115-B			•		10	L325	В		39	6D	4	L583			117		6
D115-C					10	L340	В		44	8D	4	L584 L585			110		6
D115-D					10	L350	В			10D				99	74	2A	6
D115-E					10	L350	В			10D	4	L600		175	86	2F	7
D120-A		79	51		10	L351	В			10E		L601		180	82	2E	7
D120-B			. ر		10	L355	8			9D	4	L602		171		2D	7
D140-A		137	30			L360		34 19		9D 11D	4	L604		171		4C	7
D140-B		,	<b>.</b>		3	L361		55		11E	4	L608		218	73	4E	7
D141-A		144	4			L380	В			12D	4	L610 L630		220	82	5E	7
D141-B			-		3	L400	В		83	2D	5	L630 L632		257		7D	7
D141-C					3	L410	В			4D	5	L632 L633		266	69	8D	7
D141-D					3	L416	В		73	4D 6D	5	L633 L642		243	70	7D	7
D141-E					3	L417		62		6E	5	L642 L643			100	9E	7
D145-A		94	30			L431		97		0E 11E	5			239	77	9E	7
D145-B	_	J-7	<b>.</b>		3	L431		118		11E		L645		213	98		7
D150-A	B	71	1 5			L500		81			5	L647			107		7
D150-A	_	/ *±	т:			L500		94		2E	6	L649				11D	
†	+					+						L650				11D	7 
POUR	-:	I	,	Datu				XY-I	List	e fr	r	Sach-N	lumme			ві	
ROHDE &	 		 +	Date		 +			List 	fo: 	r   +	Stock-	Nr 		. <b></b>	Pa	ge
SCHWARZ	1					EE AUSG	ANG	STEII	. 1.	046GI	HZ İ						
			04	11.07								1062.6	209	.01	XY		3+
						•	_		_ ~								

+						-+					+					
Part	Sid	le X	Y	. Sqi	c Pg	Part	Side X	Y	Sqr	Рg	Part	Sid	e X	Y	Sqr	Pg
<del></del>						-+					+					
L651	E	233	10	8 120	7	N600-	A A 210	70	2C	7	R55	Е	222	17	9E	2
L660		. 157		38 31	? 7	N600-	В		2 A	7	R56	В	222	19	9E	2
L661		171		33 41		N600-	С		3B	7	R116	В	202	50	3F	10
L662		157		33 31		N600-	D		3A	7	R119	В	242	47	8B	10
L663		175		5 41		N600-	•		6A	7	R120	В	177	50	2 F	
L668		. 157		'5 5I		1	A A 193	70	3 <b>C</b>	7	R121	В	170	51	4E	10
L670		265				N610-			5A	7	R122	В		61		10
L671		264		3 71			A A 286	73	6B	9	R123		204	54		10
L705	В	_				N840-			10B	9	R124		197	54		10
L706	В					N840-			11B	9	R130	В		57		
L709	В					N840-1			11C	9	R131	В		38		1
L714		169				N840-1		22	6A	9	R132	В		36		10
L720		181 170					A A 283	33	7B	9	R133		239	47		10
L730	В				_	N845-1	A 229	55	7A 7D	9 2	R149	В		38		10
L732	В			7 70		R10	B 225	49	7C	2	R160 R161	В	118 133	45	5E	10
L738	В					R11	A 233	51	7D	2	R162	В	118	47 48	5E	10
L739	_	192				R12	B 223	49	7C	2	R163	В	144	48	5E	10
L800		286				R13	B 223	53	8C	2	R165	В	97	57	5E 8E	10 10
L801		251				R14	B 210	53	8B	2	R166	В	102	57	SE SE	10
L816		280				R15	B 223	46	7C	2	R167	В	99	57	8E	10
L819		287	7		-	R16	A 220	33	10C	2	R168	В	105	34	8E	10
L828		280	6			R17	B 201	32	3F	2	R170	В	67	20	9E	10
L830		294	4			R18	A 186	16	2F	2	R171	В	86	23	9E	10
L840		158	10			R20	B 143	17	20	2	R172	В	85	30	9E	10
L841	A	157	12	4 3A	9	R21	B 144	31	30	2	R173	В	86	19	9E	10
L843	8	294	2	7 100	9	R22	B 182	16	2C	2	R208	В	72	53	6E	3
L845	8	277	1	7 98	9	R23	B 182	29	3C	2	R209	В	54	30	8D	3
L880	В	282	14	0 8F	9	R24	B 198	17	2¢	2	R211		70	53	6E	3
L885	A	156	13	5 38	9	R25	8 204	27	3C	2	R212	8	85	41	7C	3
N20-A	В	228	4	1 9B	10	R26	8 204	30	3C	2	R213	В	68	47	8D	3
N20-B				108	10	R27	8 164	17	2C	2	R214	8	74	31	8E	3
N20-C				70	2	R28	B 178	34	3C	2	R215	A	60	37	9E	3
N20-0				7C	2	R29	8 156	17	2B	2	R216	В	60	37	8E	3
N20-E				5A	2	R30	B 176	34	38	2	R218	В	71	28	9D	3
N130-A		137	5:	2 10D	10	R31	B 172	17	2B	2	R219	В	69	28	10¢	3
N130-B				10C	10	R32	B 181	34	38	2	R221	В	63	34	9D	3
N130-C	:			6A	10	R33	B 150	17	2A	2	R222	8	189	34	1D	3
N223-A		88	39	9 6C	3	R34	B 144	29	3A	2	R223	8	140	40	6D	3
N223-B				7В	3	R35	A 241	21	7A	2	R240	В	55	12	11E	3
N223-C				7A		R36	A 179	16	2C	2	R241	В	66	13	11E	3
N228-A		60	1:	1 10E		R38	A 222		10C	2	∘R259 %	В	81	46	8C	3
N228-B				11E	3	R41	B 234	29	8E	2	R271		164	36	2D	3
N228-C			_	5A		R42	B 231	29	8E	2	R272		157	39	3D	3
N235-A		76	4 (		3	R43	B 229	29	8E	2	R275		170	39	1C	3
N235-B		1	_	4A		R44	B 236	29	8E	2	R276		173	33	2D	3
N275-A		167	36	_	3	R45	B 229	14	8E	2	R278		170	36	2D	3
N275-B				2D	3	R46	B 236	14	8E	2	R283		114	43	4B	3
N275-C		100	A •	5A	3	R47	B 231	14	8E	2	R284		118	53	4C	3
N276-A N276-B		TUR	42		3	R48	B 234	14	8E	2	R285		112	53	4C	3
N276-B				4B	3	R50	B 239	32	9E	2	R286	A	91	49	7B	3
N276-C	В	17	55	6A 5 9D	3 4	R51	B 222	27	9E	2	R299		60	39	9E	3
N360	В			3 11D	4	R52 R53	B 222	24	9E	2	R300	В	42	17	2D	4
N410	В		72			R53	B 222 B 222	14 22	9E 9E	2	R301	В	39	17	2D	4
N410 	+ <b>-</b> -	<b>-</b> -		. OD		. K54		22	JE	2	R302	В	37	17	2D	4
	İ _	-I	- 1	Datur	n	<b>_</b>	YV_T	.ie+	e fr	+ r	Sach-l	Juma			101	att
ROHDE		-		Date					fo		Stock-		ICT.		I	ge
&	' +		1			ı }				-   +					Fa	+
SCHWARZ			[			EE AUSG	ANGSTEII	1.	046GI	HZ I					i	Ī
	1		04	11.0			UT_UNIT				1062.	5209	.01	XY		4+
+	+				- <b>-</b>	+				+					·- <b>+-</b> -	- :

(

-(-

Part S	 Side	 e X	 Y	Sq	r Pg	Part	 Sid	 e X		 Sgr	 Pq	+   Part	Side	 e X	 Y	 Sgr	 Pg
R303	В	34			D 4	R440			130		5	R641		269			 7
R304	В	32			D 4	R442			108		5	R642		243			7
R305	В	29			D 4	R443	A	67		11c	5	R644		264			7
R306	В	27			D 4	R450	A			110	5	R646		249		9D	7
R307	В	24			D 4	R451	A	60	102		5	R647		241		9E	7
R308	В	22			D 4	R451		88	102			1					-
		42					A				5	R648		241			7
R310	В				D 4	R453	A	95	119		5	R649		247			7
R312	В	37				R454	A	95	135		5	R650		190		2C	7
R313	A	18			C 4	R455	A	81	114		5	R651		187		2C	7
R314	В	41				R500	A	80	83	2F	6	R652		184	78	2C	7
R315	В	46				R501	A	77	83	2F	6	R653		206		1C	7
R316	В	45				R502	A	75	83	2F	6	R654		202	79	1B	7
R317	В	12				R503	В	75	83	3E	6	R655	В			9D	7
R318	В	15			_	R520	A		113	9F	6	R657	A	221	BO	3B	7
R319	A	21				R521		143		9F	6	R658	Α		75	3B	7
R320	Α	15	3			R522		148		9F	6	R700	В		111	2D	8
R321	A	20	3			R530	В	69	93	2C	6	R701	В		121	2D	8
R325	В	34	4			R600		164	79	2D	7	R702	В	153	124	3D	8
R327	Α	21	4	8 7	D 4	R601	В	178	82	2E	7	R704	Α	150	126	2D	8
R328	A	23	4	1 7	D 4	R602	A	184	79	2E	7	R705	A	141	121	2E	8
R329	В	46	4	1 6	C 4	R603	A	181	75	2E	7	R706	В	169	128	4C	8
R330	A	21	5	0 7	C 4	R604	В	189	72	2D	7	R707	В	169	118	4C	8
R332	В	46	3	8 7	C 4	R605	В	164	73	2D	7	R709	Α	166	114	3C	8
R333	A	26	4	4 7	C 4	R606	Α	213	67	2B	7	R710	Α		120	4C	8
R340	В	41	4	4 8	C 4	R607		193	83	3D	7	R720	A		139	3D	8
R341	В	43	5	3 80	C 4	R608		192	74	2D	7	R721	A		130	4D	8
R342	8	44	4			R609		187	82	2D	7	R723			132	4E	8
R355	8	17	5			R611		1B0	64	4C	7	R724			123	4E	8
R356	8	38	5			R612		178	67	4C	7	R730	8	177	112	5C	8
R357	8	36	5'			R613		197	66	3C	7	R731	В	183	102	6D	8
R358	8	17	7			R614		194	78	3C	7	R731		183	93	7D	8
R360	8	42	8			R615		197	77.	3C	7	R734		177	97	6C	
R361	8	55	8			R616		203	69		7	R735					8
R400	В	45	8:			R617				28		-		182	105	6C	8
R401						R618		213	62	2C	7	R745		213		9C	В
	В	55	8			1		194	86	2C	7	R747			133		8
R402	8	48	79			R620		196	B1	28	7	R748			125		8
R404	A	37	84			R621		231	80	5E	7	R750			129		8
R405	A	28	82			R622		1B6	69	3E	7	R751			123		8
R406	A	33	8:			R623		231	77	6E	7	R753			134		8
R407	A	29	9:			R624		231	74	6E	7	R754			123		8
R408	В	42	80			R625		231	72	6E	7	R760			121		8
R409	В	32	9:			R626		228	69	6D	7	R761			109		8
R410	A	42	74			R627		230	66	6D	7	R762	A	182	113	7E	8
R411	A	44	69			R628		230	64	6D	7	R801	В	241	134	2D	9
R412	Α	37	68			R629	В	186	67	3E	7	R802	В	296	129	2D	9
R416	В	85	73	61	E 5	R630	В	264	24	5C	7	R803	A	28B	60	5C	9
R417	8	75	70	) 6E	5	R631	В	264	15	5B	7	RB04		278	132	3D	9
R431	A	99	10:	L 10I		R632		241	64	6D	7	R806		281		3D	9
R432	A			3 10E		R634		264	21	5 C	7	RB07		26B		3E	9
R433				2 10I		R635		206	72	2A	7	R808		258		3E	9
R434	Α			10I		R636		206	74	2B	7	RB09		248		3E	9
R435				2 101		R637		213	B5	3B	7	R811		258		4F	9
R436				100		R63B		213	83	3A	7	RB12		298		4E	9
R437				100		R639		217	83	3A	7	RB13		297		4E	9
R438	A			100		R640		25B	46	6C	7	RB14		297 294		4E 4E	9
	+					+						VDT4		∠ 74 	10/		7
	I —	I	Ì	Dati	ım	1		XV-	List	e fr	أسر	Sach-	Numm	er		101	att
ROHDE		-		Date					list			Stock		-1			
& -	! <b>+</b> :		4			ı +					-   		-111			Pa	ge
CHWARZ	ĺ		Ì			EE AUS	GANC	Sub i	T. 1	0460	н <sub>2</sub> I					- <del></del>	
-MIRRA			امم	11 0	7.96				1.0			1063	<u> </u>	01	<b>V*</b> *		_
	ŀ		~ 4	امتد	,,,,0	I OUT	LUI	OMITI	T+0	よいらせ	4	1062.	ರ∠∪ソ	• UI	AΥ	I	5+


+					-+						+					
Part	Side X	Y	Sqr	Pg	Part	Sid	e X	Y	Sqr	Pg	Part S	id	e X	Y	Sqr	Pg
R815	B 290	109	9 4E	9	R872	A	300	71	11B	9	V540	В	78	124	5B	 6
R816	B 277			9	R873		296		11B	9	V543	В				6
R817	B 288	101	L 5D	9	R874	A	296	69	11C	9	V544	В	96	127	7B	6
R819	B 281			9	R875		300		10C	9	V548	В	96	123	10B	6
R820	A 278			9	R876		276			9	V600		175			7
R821	A 262			9	R882		289		4E	9	V602		170			7
R822 R823	A 252 A 262			9	R883		288 287		4E	9	V604-A		187	72	2D	7
R824	B 300			9	R889		280		6E 6D	9	V604-B		203	64	2D 3C	7 7
R825	B 300			9	R899		280		7B	9	V606-B		203	04	2B	7
R826	B 298			9	ne00	В			6D	7	V608		199	62	3C	7
R827	В 296		7E	9	V11	В			7C	2	V610		260		8D	7
R828	8 276	75	7D	9	V12	В	216	51	8C	2	V612	В	242	95	9D	7
R829	B 288			9	V13	A	223	38	10C	2	V635	A	213	80	3A	7
R830	B 281			9	V14	В	194	30	3 <b>F</b>	2	V636		202	∙85	3A	7
R831	A 278			9	V15	8		34	3E	2	V650		206	65	2B	7
R832	A 290			9	V25	В		27	3C	2	V700-A		157	117	2D	8
R833	A 280 B 300			9	V26	В		30	3C	2	V700-B		100	124	2D	8
R835	B 300	30		9	V35 V110		241 228	11 51	6A 8B	2 10	V705 V707		169 169		4C 5C	8
R836	B 297	29		9	V110	В		59	10C	10	V720		182		4D	8 8
R837	B 296	31	_	9	V310	В		30	5D	4	V725		183		5E	8
R838	B 296	38		9	V315	В		44	7D	4	V730		181		6D	8
R839	8 287	50	9E	9	V318	A		23	5C	4	V735		190	96	70	8
R841	8 284	23	10D	9	V319	A	26	32	6C	4	V745		225		100	8
R842	8 284	21		9	V330	A	17	51	7C	4	V746	A	228	126	100	8
R843	8 295	23		9	V333	A	20	44	7C	4	V747	A	222	133	100	8
R844	8 278	26		9	V335	В	81	35	8C	3	V748			121	10D	8
R845	8 281	23		9	V336	8	77	36	8C	3	V800		251		3E	9
R846 R847	8 286 A 300	42	8C	9	V337	В	73	36	9C	3	V801		254		3E	9
R848	8 281	41 39	9E 8C	9	V400 V404	8 A	33 23	80 77	4D 4C	5 5	V802 V815		283		30	9
R849	8 280	47	9D	9	V405	A	22	91	4C	5	V815 V816		256 258		5E 5E	9
R850	A 295	103	5B	9	V411	A	40	66	4E	5	V817		283	85	60	9
R851	8 293	85	5B	9	V431		102		11E	5	V830		284		8E	9
R852	A 295	81	58	9	V432	A	124		11E	5	V831		288		8E	9
R853	B 291	23	10D	9	V433	A	132	96	110	5	V832		283	50	8D	9
R854	A 287	65	5B	9	V434	A		103		5	V844-A	8	284	31	9C	9
R855	A 287	63	6B	9	V435	A		109		5	V844-B				7C	9
R856	A 277	27	7B	9	V436			118		5	V850-A	A	285	45	78	9
R857	A. 288	41	7B	9	V437			134		5	V850-B	_			6B	9
R858 R859	A 297 A 292	99 103	5B 5B	9 9	V438 V500	A B	75	115 84		5	V851		286	70	6C	9
R860	A 279	35	7C	9	V500	В	99	77	2E 4E	6	V857 V870		288 277	30	7B	9
R861	A 295	41	8B	9	V512	_	103	77	5E	6	V870 V871		279	83 72	10B 10B	9
R862	B 290	70	7E	9	V514		109	75	6E	6	7371 Z1		118	20	2E	2
R863	A 295	44	8B	9	V515		123	77	6E	6	Z2		131	17	2D	2
R864	B 299	85	6E	9	V516		131	75	7E	6	z3		100	20	2D	2
R865	A 290	137	9F	9	V520		144	101	9E	6	24		141	20	2D	2
R866	A 276	42	6C	9	V523	В	. –		9D	6	<b>Z</b> 5		184	20	2C	2
R867	B 277	29	7C	9	V530	В	67	87	1C	6	<b>Z</b> 6		199	20	2C	2
R868	B 286	35	8C	9	V532	В	63	98	1B	6	27		169	20	2C	2
R869	A 282	45	8C	9	V535	В		105	3B	6	Z8		164	20	2B	2
R870 R871	A 277 A 278	77 80	9B 10B	9	V536	В		113 121	3B	6	Z9		174	20	2B	2
NO/1	. 2/0 +	۰. -+-	TOB	J	V539	В	12	T_T	5B 	6   +	Z10	<u> </u>	146	20	2A	2
	_I	Ī	Datum		<b> </b>		XV-	Lie+	 e f¤	+ -	Sach-Nu	1200	er		-ד ום	† att
ROHDE	_	1	)ate					list		•	Stock-N		ET		- 1	ge
& .	; <del> </del> -	+-								+					1-4	∍~ ] +
SCHWARZ	***************************************				EE AUSC											Ì
	ŧ	04 1	L1.07	.96	OUTI	PUT_	UNIT	_1.0	46GH	z	1062.62	209	.01	XY		6+
	+	÷-		<del>i</del>						:				<b>-</b>		+


Part	Side X	Y	Sqr	Pg	Part	Side X	Y	Sqr	Pg	Part	Side	х	Y	Sqr	Pg
Z11	в 194	20	2F	2	Z20		17	2E	2						

+	+	+	<u> </u>	+	44
ROHDE	-i	Datum Date	XY-Liste frr XY-list for	Sach-Nummer Stock-Nr	Blatt Page
SCHWARZ	I.	11.07.96	EE AUSGANGSTEIL_1.046GHZ OUTPUT_UNIT_1.046GHZ	1062.6209.01 XY	7-




Stromläufe
Bestückungspläne
Circuit diagrams
Components plans
Schémas de circuit
Plans des composants





O



NICHT BESTUECKTE BRUTEILE SIEHE SA.
FOR BINDING INFORMATION ON MODELS,

TRIMMING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.

6


BAUELEHENTE ERFORDERN EINE BESONDERE HANDHABUNG.


ATTENTION ESD! ELECTROSTATIC SENSITIVE DEVICES REQUIRE A SPECIAL HANDLING


D


5


4













BINDENDE ANGABEN BEBER VARIANTEN, TRIMMURTE, BAUTEILWERTE UND WICHT BESTBECKTE BRUTEILE STEHE SR. FOR BINDING INFORMATION ON TRIMMING AND COMPONENTS VA NONFITTED COMPONENTS SEE P


AENO.	HITTLILUNG	DRTUM	NAME	ZU SERAE	REG.I.			
04/ AENO. AENDERUNGS-		11.07.96	DR	ROHDE&SCHWARZ				
				PLOTT	10.03.97		ZEICI	
				NORH	40.00.07			
				GEPR.				
				BEARB.		Εl		
84/01		10.03.97	EI	MENP	TAG	NAME	BENE	


8


N.F. - NOT FITTED / NICHT BESTUECKT






























BINDENDE ANGABEN UEBER VARIANTEN, TRIMMWERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA. FOR BINDING INFORMATION ON MODELS, TRIMMING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.

AEND.	AENDERUNGS- MITTELLUNG	DATUM	Nane	ROH ZU GERRE		HUARZ	REG. 1. V. 1062.5582 ERSTE Z. 1062.5502	UAL BL.
04/		11.07.96	DR	<b>P</b> <sub>5</sub>			1062.6209.015	4+
				PLOTT	10,03.97			BLATT-NR.
				NORN			OUTPUT UNIT 1.046GHZ	
				GEPR.			AUSGANGSTEIL 1.046GHZ	
				BERRB.		El		100
04/01		10.03.97	[E1 ]	MENP	TAG	HANE	BENENNUNG	




N.F. - NOT FITTED / NICHT BESTUECKT

BINDENDE ANGABEN UEBER VARIANTEN, TRINHWERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA. FOR BINDING INFORMATION ON TRIMMING AND COMPONENTS VAL NONFITTED COMPONENTS SEE PA



IND.	MITTELLUNG			ZU GERAE	1 SMY	<u> </u>	REG. (.V.
AEMD.	AENDERUNGS-	DATUM	NAME	RUH	DE&SC	NWHKZ	
04/		11.07.96	DR	1 7 7			
				(PS)			ZEICHNN
				PLOTT	10.03.97		
				NORM			OUT
				BEP₽.			AU
				веяяв.		ΕΙ	
04/01		10.03.97	ΕI	MENP	TAG	NRME	BENENNUNG



N.F. - NOT FITTED / NICHT BESTUECKT


BINDENDE ANGABEN UEBE TRIMMWERTE, BAUTEILWE NICHT BESTUECKTE BAUT



8


24 (24	
04/01	
04/	
AEND.	AENDERUNGS-
IND.	HITTEILUNG
السبب ال	


5




N.F. ≈ NOT FIT









1062.5502

12

ERSTE Z.

1062,5502

REG. 1. 9.

10

AENDERUNGS-

MITTEILUNG


9

DRTUN

NAME

AEND.

IND.



D431-E 74HCTO4T-L 12 13 1 D431-F 74HCTO4T-L D432-A 74HCT04T-L 3 1 D432-B 74HCTO4T-L D432-C 74HCT04T-L \_ C442 100N L # C441 100N L 0432-6 74HCT04T-L D431-G D430-B 74HCT04T-L 74HCT42T~L FOR BINDING INFORMAT BINDENDE ANGABEN UEBER VARIANTEN, TRIMMING AND COMPONE TRINNWERTE, BRUTEILWERTE UND NONFITTED COMPONENTS HICHT BESTUECKTE BAUTEILE SIEHE SA.

D431-B 74HCT04T-L


D431-6 74HCT04T-L

D431-D 74HCT04T-L

## N.F. - NOT FITTED / NICHT BESTUECKT




	Ω				11	1
REND.	AENDERUNGS- Hitteilung	DATUM	NAME	ZU GERRE	0.1413	
04/	ACHACONNAC	11.07.96	DR		DE&SCI	HUARZ
				(R)s		
				PLOTT	10.03.97	
				NORH		
				GEPR.		
				BEARB.		Εŧ
04/01		10.03.97	Εl	MENP	TAG	NAME




4


6


 $\mathbf{c}$ 




.3











EGB!
H GEFREHRDETE
RFORDERN EINE
HANDHABUNG.
N ESD!
ENSITIVE DEVICES
CIAL HANDLING


BINDENDE ANGABEN UEBER VARIANTEN, TRIMMWERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA.

FOR BINDING INFORMATION ON MODELS, TRIMMING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.

04/ AERO. IND.	AENDERUNGS- Hitteilung	11.07.96 DATUM	DR NAME	1 3 7	DE&SC	HWARZ	REG.I.
				Rs			ZEICI
				PLOTT	30.03.97		
				NORM			
				GEPR.			
				BEARB.		ΕI	Į
04/01		10.03.97	Εl	MENP	TAG	NAME	BENEI







BINDENDE ANGABEN UEBER VARIANTEN, TRIMHWERTE. BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA.


FOR BINDING INFORMATION ON MODELS,
TRIMMING AND COMPONENTS VALUES AND
NONFITTED COMPONENTS SEE PARTS LIST.


8

04/0

04/

AEND IND.







ACHTUNG: EGB!


ELEKTROSTATISCH GEFREIRDETE
BRUELENENTE EBFORDLER EINE
BESONDERE HANDHABUNG
ATTENTION ESD!
ELECTROSTATIC SENSITIVE DEVICES
REQUIRE A SPECIAL HANDLING


6


PCB →PRINTED ON PCB →H \*PCB
























BINDENDE ANGABEN UEBER VARIANTEN, TR}HHUERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA. FOR BINDING INFORMATION ON MODELS.
TRIMMING AND COMPONENTS VALUES AND
NOMFITTED COMPONENTS SEE PARTS LIST.

E

04/01		10.03.97	EI	MENP	TAG	NAME	BENENNUN	6		4
				BEARB.		ΕI				14.
				GEPR.			Al	JSGANGSTEIL	1.046GHZ	
				NORM			่อข	TPUT UNIT 1.046GHZ		
				PLOTT	14.63.97				`	
							ZEICHN	NR,	BLAT	I-NI
04/		11.07.96	DR	\\ \'\ \'\				1062.6209	1 019	
AEN⊅.	AENDERUNGS-	DATUM	NAME	KOH	DE&SC	HUARZ		1002.020		1 8
IND.	MITTEILUNG	0111111	HANE	ZU GERBE	T SMY		REG. 1.0.	1062.5502 ER	STE Z. 1062:5502	
	9				1	0		11	12	



N.F. - NOT FITTED / NICHT BESTUECKT

BINDENDE ANGABEN UEBER VARIANTEN, TRIMMERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA.


9

FOR BINDING INFORMATION
TRIMMING AND COMPONENTS
NONFITTED COMPONENTS SE

10



							V
04/01		10.03.97	EΙ	MENP	TAG	NAME	BENEN
				BEARB.		ΕI	
				GEPR.			
			ï	NORM			(
				PLOTT	14.03.97		<u> </u>
				(A)			ZEICH
04/		11.07.96	DR	\$\$			
AEND.	AENDERUNGS-	DATUM	NAME	ROH	IDE&SC	HUARZ	
IND.	MITTEILUNG	0.0031	MUHE	ZU SERRE	I SMY		REG. L.



6



N.F. - NOT FITTED / NICHT BESTUECKT

BINDENDE ANG TRIMMUERTE, NICHT BESTUE

04/01

04/

AEND IND.

8

AENDE

## SWITCH D T C727 L727 18H L V720 BAR64-4 V725 BAR64-4 C724 220P 8 R723 1K21 B R724 1K21 B # C721 82P B 1720 407H 8 # C723 R721 121R L V730 BAR64-4 V735 BAR64-4 C732 220P B V707 BAR64-4 C707 220P B C715 220P B 11 S1680-2 | L730 | 100NH 8 V705 BAR64-4 C705 56P B R731 1K21 B \*PCB 2 11 + 13 C734 B2P B L732 4U7H B

L714 100NH B

R706 1K21 B

R710 121R L

L709 407H B

4

L705 220NH B

R709 100R L

C710

R707 B 2714 3K21 B 2P7 8

R730 332R B

N.F. - NOT

ኒ ? ኅር




5


6


R734 121R L


6735 1N L


R735 100R L





































NRME BEBEB. AUSGANGSTEIL 1.046GHZ Z GEPR. **OVTPUT UHIT 1.0486HZ** PLOTE ROHDE&SCHWARZ 1062.6209.01 EE







SEITE B




81 IDENDE ANGRBEN DEDER VARIANTEN. TRIMIDERTE, BAUTEILWERTE DUD RICHT BESTUEEKTE BAUTEILE SIENE SA.

TOR BINDING INFORMATION ON MODELS.
TRIUMING AND COMPONENTS VALUES AND MODELSTED COMPONENTS SEE PARTS LIST







Ι Λ


6

7

A I

RENDEPUNGS- DRIUM HANE

1




ELLUNG SEITE A On side a



BINDENDE QUENBEN BEBER VARIAKTEN. TRIMUSETE, BAUTEILBERTE UND NICHT BESTUECKTE BAUTEILE SIENE SA İ

FC9 BINDING (NYORUSTION ON MODELS, TRIANING AND COMPONENTS VALUES AND MONFITTED COMPONENTS SEE PARTS LIST




Signal-Name	Page-No.: Zones
+15VB1	02: 3F 06: 1A
+15VB2	06: 3A
+15VB4	OB: 2E
+15VHH	09: 3B 6A 7A
+15VHI	09: 3B 10C
+5VB	05: BC
+9V-I	07: 4A
-15VB1	02: 3E
-15VB3	05: 4E
-15VB4	08: 2D
-15VHI	09: 3A 6A 8A
-9V-I	07: 4B
ALCOFF	03: 1F 10: 7E
АМ	02: 4C 03: 1D
AMINVERS	03: 1B 10: 3E
AMSLOW	03: 1F 10: 7E
BLANK	02: 4C 10: 1C
BLANKENABLE	10: 3E
BLANKINVERS	10: 3E
CLK1	02: 4B 10: 1E
DETFILT	02: 6D 08: 1E
DETMIXON	03: 1E 10: 7E
DETON	03: 1E
Druck 11.07.96 Abt	.1GPK Name DR Dat.11.07.96 Ae.Mi. Aei. 04
ROHDE & SCHWARZ	Benennung AUSGANGSTEIL_1.046GHZ OUTPUT_UNIT_1.046GHZ 11+
Typ. SMY Rec	in Verz. 1062.5502 V Sachnummer 1062.6209 S

Signal-Name	Page-No.: Zones
DETON	10: 7E
DIAG-0	02: 7E 10: 3E
DIAG-1	02: 7E 10: 3E
DIAG-2	02: 7E 10: 3E
DIAG-3	02: 7E 10: 3E
DIAGON	10: 3E
HF-INT-ENABLE	02: 11C 10: 3E
KLEMM-N	03: 1F 10: 8C
LPSELECT-0	05: 80 10: 7C
LPSELECT-1	05: 8D 10: 7C
LPSELECT-2	05: 8D 10: 7B
LPSELECT-3	05: 8D 10: 7B
MODUFIX	03: 10C 10: 7E
RFLEVENABLE	10: 7E
RFLOLEV	04: 12D 05: 1D
SEDON	10: 5E
SBDON-N	08: 1E 10: 11C
SBDON-P	08: 1E 10: 11D
SEROUT	02: 4C 10: 1E
sigio	05: 7D
Druck 11.07.96 Abt.1GPK Name	e DR   Dat.11.07.96   Ae.Mi.   Aei. 04
ROHDE & SCHWARZ	g AUSGANGSTEIL_1.046GHZ OUTPUT_UNIT_1.046GHZ 12+
Typ. SMY Reg in Verz.	1062.5502 V   Sachnummer 1062.6209 S


Signal-Name 	Page-No.: Zones
sig10	06: 1E
SIG80-1	06: 12E 08: 1C
sig80-2	07: 1D 08: 5C
sig80-3	07: 12D 08: 10B
SIG80-4	08: 11D 09: 1D
TP1	05: 12E 06: 4F
TP2	05: 12E 06: 6F
TP3	05: 12D   06: 7F
TP4	05: 12D 06: 2C
TP5	05: 12D 06: 3C
TP6	05: 12D 06: 5C
TP7	05: 12C 06: 7C
TP8	05: 12C 06: 10C
ULPRE	02: 11E 03: 12E 05: 4E
UMODULATOR	02: 11E 03: 12C 04: 6E
UREF6	03: 9F 10: 11B
UREF6N	03: 4C 10: 11B
UREF9	09: 5C 12B
	PK Name DR  Dat.11.07.96 Ae.Mi.  Aei. 04
ROHDE & SCHWARZ	nennung AUSGANGSTEIL 1.046GHZ OUTPUT_UNIT_1.046GHZ 13+
·	Verz. 1062.5502 V   Sachnummer 1062.6209 S


Signal-Name	+	
UREGELVERST   02: 6C   03: 12B     URF-SOLL   02: 11E   03: 7C     VDET   02: 11E   03: 1E   09: 8B     VDETMIX   02: 11E   03: 1F     VDETMIXE   07: 4C     VDEXT   02: 4F   03: 1E     VDEXTON   03: 1E   10: 7E     WR1   02: 4B	Signal-Name +====================================	Page-No.: Zones
O3: 12B     URF-SOLL	UREF9N	09: 5A 6B 12C
VDET	UREGELVERST	
03: 1E   09: 8B	URF-SOLL	
03: 1F	VDET	03: 1E
VDEXT	VDETMIX	
03: 1E  VDEXTON	VDETMIXE	07: 4C
10: 7E	VDEXT	
327 .5	VDEXTON	
	WR1	

Druck 11.07.96 Abt	.1GPK Name DR	Dat.11.07.96	Ae.Mi.	Aei. 04
ROHDE & SCHWARZ	-	USGANGSTEIL_1. UTPUT_UNIT_1.(		14-
Typ. SMY Reg	in Verz. 1062	.5502 V Sac	chnummer 1062	2.6209 S





10PK TAG	NAME	BENEMLING 6.7. 140.
BEARD.	,N	SIGNALGENERATOR_SMY
GEPR.	ůN .	
NORM		SIGNALGENERATOR_SMY
PLOTT 27.00.94		top
(PS)		ZEIDHNNR.
ROHDE&SCH	WARZ	1062,5502,00 FS 11 B.
ZU GERMEY SMY	-	REG.I.V. 1062.5502 ERSTE Z.








10PK TAG	NAME	BENE
BEARD.	JN.	] SI
GEPR.	JN	
NORM		SIC
PLOTT 27.09.94		top
ROHDE&SCH	WARZ	ZEIO
ZU DEWET SMY		REG.I.






















### Servicehandbuch

# Signal Generator AM / FM / PHIM

SMY01

9 kHz - 1040 MHz 1062,5502.11

SMY02

9 kHz - 2080 MHz 1062.5502.12

SMY43

9 kHz - 2080 MHz 1062.5502.43

ENGLISH SERVICE MANUAL FOLLOWS FIRST COLOURED DEVIDER

Band 2 Servicehandbuch besteht aus 2 Bänden

Printed in the Federal Republic of Germany

## Inhaltsübersicht

		_	
Ba	n	а	1

#### Sicherheitshinweise Beiblatt

- 6 Serviceanleitung des Gesamtgerätes
- 7 Serviceanleitung der Baugruppen

Baugruppe		Register
A2	Rechner	
A1	Anzeige-Tastatur	
Α4	Synthesizer	
A5	Ausgangsteil 1.04 GHz	4

#### Band 2

#### Sicherheitshinweise

Baugruppe		Register
A5	Ausgangsteil 2.08 GHz	
A6	Eichleitung 1 GHz	2
A6	Eichleitung 2 GHz	3
A7	Netzteil	4
Α8	Referenzoszillator	5
A12	Power Modul	6



Test and Measurement Division

## **Service Manual**

**SMY01** 9 kHz to 1040 MHz 1062.5502.11

SMY02 9 kHz - 2080 MHz 1062.5502.12

SMY43 9 kHz to 2080 MHz 1062.5502.43

Volume 1 Service manual consists of 2 volumes

Printed in the Federal Republic of Germany

## **Contents**

Vol	um	e 1
V VI	uiii	<b>~</b> 1

# Safety instructions Supplement

- 6 Repair of Complete Instrument
- 7 Testing and Repair of Modules

N	Module	Tabbed Divider
A2	CPU	
<b>A1</b>	Display- Keyboard	
	Synthesizer	
<b>A5</b>	Output Unit 1.04 GHz	

### Volume 2

### Safety Instructions

N	lodule	Tabbed Divider	
<b>A5</b>	Output Unit 2.08 GHz		
A6	Attenuator 1 GHz		
A6	Attenuator 2 GHz	7	
	Power Supply		
	Reference Oscillator		
	Power Module		

### Safety Instructions

This unit has been designed and tested according to the standards outlined overleaf and has left the manufacturer's premises in a state fully complying with the safety standards.

In order to maintain this state and to ensure safe operation, observe the following instructions, symbols and precautions.

- When the unit is to be permanently cabled, first connect protective ground conductor betore making any other connections.
- 2) Built-in units should only be operated when properly fitted into the system.
- For permanently cabled units without built-in tuses, automatic switches or similar protective facilities, the AC supply line shall be titted with fuses rated to the units.
- 4) Before switching on the unit ensure that the operating voltage set at the unit matches the line voltage.
  - If a different operating voltage is to be set, use a fuse with appropriate rating.
- 5) Units of protection class I with disconnectible AC supply cable and plug may only be operated from a power socket with protective ground contact.

  The protective ground connection should not be made ineffective by an extension cable. Any breaking of the protective ground conductor within or outside of the unit or loosening of the protective ground connection may cause the unit to become electrically hazardous. The protective ground conductor shall not be interrupted intentionally.
- Adjustment and replacement of parts as well as maintenance and repair should be carried out only by specialists approved by R & S.

  Observe safety regulations and rules for the prevention of accidents.

  Use only original parts for replacing parts relevant to safety (e.g. power on/off switches, power transformers or fuses).
- Also observe the additional safety instructions specified in this manual.

### **Explanation of Symbols Used**



- Read operating manual, observe the safety symbols used



- Caution, shock hazard



- Protective ground connection



Unit ground



- Equipotential (floating ground)



- Ground

### **Patent Information**

This product contains technology licensed by Marconi Instruments LTD, under US patents 4609881 and 4870384 and under corresponding patents in Germany and elsewhere.



SERVICEUNTERLAGEN Ausgangsteil 2.08 GHz 1062.7005.01

### Inhaltsverzeichnis

7 Prüfen und Instandsetzen der Baugruppe	. 5
7.1 Funktionsbeschreibung	. 5
7.1.1 RF-Signalverarbeitung	. 5
7.1.2 Mischer mit LO-, RF- und ZF-Filtern	
7.1.3 Ausgangsverstärker	
7.1.4 AM-Signalzweig und RF-Pegel-Sollwert	. 6
7.1.5 RF-Pegelregelung	. 6
7.1.6 serielle Schnittstelle	. 7
7.1.7 Schaltung zur Diagnoseauswahl	. 7
7.2 Meßgeräte und Hilfsmittel	. 7
7.3 Fehlersuche	. 8
7.3.1 Fehler nur im Bereich f <sub>RF</sub> < 10 MHz	. 8
7.3.2 Fehler nur im Bereich f <sub>RF</sub> < 65 MHz	
7.3.3 Fehler im Bereich 5 kHz $\leq$ f <sub>RF</sub> $\leq$ 1040 MHz	
7.3.4 Fehler im Bereich 1040 MHz < $f_{RF} \le 2080$ MHz	
7.3.5 Spektrale Reinheit, delta_f < 10 MHz vom Träger	
7.4 Prüfen und Abgleich	10
7.4.1 Prüfen der Datenübertragung	11
7.4.2 Prüfen der Ausgangsspannung des Regelverstärkers	
7.4.3 Prüfen der LEVEL PRESET-Steuerspannung	
7.4.4 Prüfen der Arbeitspunkte der Verstärkerstufen	
7.4.5 Prüfen der Ansteuerung der Filterbank	12
7.4.6 Prüfen des RF-Pegels nach der Filterbank	13
7.4.7 Prüfen der Ansteuerung der Bandpaßschalter	13
7.4.8 Abgleich der ZF-Verstärkung	14
7.4.9 Abgleich der ZF-Detektor-Linearität	
7.4.10 Abgleich der Detektor-Linearität am Ausgang FOPU	
7.4.11 Abgleich des AM-Modulationsgrades	15
7.5 Zerlegung und Zusammenbau	15
7.6 Endprüfung	15
7.6.1 Prüfen des maximalen Ausgangspegels	15
7.6.2 Prüfen des Oberwellenabstandes	
7.6.3 Prüfen des Nebenwellenabstandes	16
7.6.4 Prüfen des Subharmonischenabstandes	17
7.7 Externe Schnittstellen	18

Schaltteilliste Koordinatenliste Stromlauf Bestückungsplan Bei Geräten ohne Option SMY-B40 hat die Baugruppe die Variante VAR02.

Bei Geräten mit Option SMY-B40 hat die Baugruppe die Variante VAR03.

### 7.1 Funktionsbeschreibung

Das Ausgangsteil 2.08 GHz erhält über den Eingang FSYN von der Baugruppe Synthese das RF-Signal (6 dBm ... 12 dBm) im Frequenzbereich 65 MHz  $\leq$   $f_{\rm SYN}$   $\leq$  1040 MHz. Dieses RF-Signal wird über einen Amplitudenmodulator und ein Amplitudenstellglied auf schaltbare Tiefpaßfilter gegeben. Im Signalzweig wird durch die Umschalter SWITCHB und SWITCHD der Ausgangsfrequenzbereich 5 kHz  $\leq$   $f_{\rm RF}$  < 65 MHz durch Abmischen mit einem 640 MHz-LO erzeugt. Über die Umschalter SWITCHA und SWITCHC kann der Verdopplerpfad eingeschaltet werden, um den Ausgangsfrequenzbereich 1040 MHz <  $f_{\rm RF}$   $\leq$  2080 MHz zu realisieren.

Die Baugruppe enthält folgende Funktionseinheiten:

- Einen AM-Modulator zur Pegelregelung und Amplitudenmodulation im Frequenzbereich 5 kHz  $\leq f_{\rm RF} \leq 1040$  MHz,
- einen AM-Modulator zur Pegelvoreinstellung (LEVEL PRESET),
- schaltbare Tiefpässe zur Unterdrückung von Harmonischen.
- einen Mischer mit LO-, RF- und ZF-Filtern,
- einen Pegeldetektor im RF-Zweig vor dem Mischer,
- einen Frequenzverdoppler,
- Einen AM-Modulator zur Pegelregelung und Amplitudenmodulation im Frequenzbereich 1040 MHz <  $f_{RF} \le 2080$  MHz,
- schaltbare Bandpässe zur Unterdrückung von Subharmonischen,
- einen Ausgangsverstärker,
- einen Pegeldetektor am Ausgang FOPU,
- einen Signalzweig zur Einstellung des RF-Pegelsollwertes und des Amplitudenmodulationsgrades,
- die RF-Pegelregelung,
- eine serielle Schnittstelle und
- eine Schaltung zur Diagnoseauswahl.

Im weiteren Text enthaltene Pegelangaben gelten für einen Geräteausgangspegel von +13 dBm (+19 dBm mit Option SMY-B40).

### 7.1.1 RF-Signalverarbeitung

Dem Eingang X224 FSYN ist ein Dämpfungsglied zur Temperaturkompensation nachgeschaltet. Anschließend folgt der AM MODULATOR.

Er ist das Stellglied der Pegelregelung im Bereich  $f_{\rm RF} \leq 1.04~{\rm GHz}.$  Das RF-Signal wird durch RF AMPLIFIER 1 und RF AMPLIFIER 2 verstärkt und auf den PIN-Modulator LEVEL PRESET gegeben. Dieser Modulator wird durch gespeicherte Kalibrierdaten mittels D/A-Wandler so eingestellt, daß das Stellglied der Pegelregelung in einem optimalen Arbeitspunkt betrieben werden kann (vergl. Bedienhandbuch "Kalibrierung LEVEL PRESET").

Das RF-Signal wird durch den RF AMPLIFIER 3 verstärkt und auf schaltbare Tiefpässe HARMONIC FILTERS gegeben. Diese werden abhängig von der Eingangsfrequenz an X224 FSYN durch den Rechner eingeschaltet. Die Tiefpässe TPO bis TP3 sind wie die Tiefpässe TP4 bis TP8 in Kette geschaltet. Filter in der Kette mit höherer Grenzfrequenz als der Grenzfrequenz des gewählten Tiefpasses bleiben eingeschaltet.

Im "Normalbetrieb" wird das RF-Signal über den PIN-Schalter SWITCHD (OFF) und den GaAs-Umschalter SWITCHB (OFF) auf den Ausgangsverstärker gegeben.

Im "Mischerbetrieb" wird das RF-Signal über PIN-Schalter SWITCHD (ON) und den RF AMPLIFIER 4 auf den Detektor vor dem Mischer geschaltet.

Im "Verdopplerbetrieb" wird das RF-Signal über den GaAs-Schalter SWITCHA (ON) auf den Verdoppler geschaltet. Dessen Ausgangssignal gelangt über den DOUBLER MODULATOR auf schaltbare Bandpässe und über den GaAs-Schalter SWITCHC (ON) zum Ausgangsverstärker.

#### 7.1.2 Mischer mit LO-, RF- und ZF-Filtern

Das RF-Signal vom Detektor vor dem Mischer wird über den RF-Tiefpaß und ein Dämpfungsglied zur Pegelanpassung auf den RF-Eingang des Mischers geschaltet (Pegel ca. -5 ... -10 dBm). Das Signal von REF640 gelangt über einen Tiefpaß auf den LO-Eingang des Mischers. Über den ZF-Verstärker und den ZF-Tiefpaß wird das ZF-Signal auf den RF-Schalter SWITCHB (ON) vor dem Ausgangsverstärker geschaltet (5 kHz  $\leq$   $f_{\rm ZF}$  < 65 MHz, Pegel ca. 0 dBm).

#### 7.1.3 Ausgangsverstärker

Der dreistufige lineare Breitbandverstärker verstärkt das Eingangssignal um ca. 19 dB. Die Arbeitspunkte der Stufen RF AMPLIFIER 12 und RF AMPLIFIER 13 werden geregelt.

#### 7.1.4 AM-Signalzweig und RF-Pegel-Sollwert

Das Signal der Leitung AMMOD wird auf den D/A-Wandler zur Modulationsgradeinstellung gegeben und gelangt auf den D/A-Wandler RFLEV zur RF-Pegeleinstellung.

#### 7.1.5 RF-Pegelregelung

Bei Geräten ohne Option SMY-B40 wird der Pegeldetektor am Ausgang X226 FOPU bei Gerätefrequenzen  $f_{RF} \geq 10$  MHz verwendet. Der RF-Pegel an der Diode beträgt ca. +19 dBm.

Die Linearisierungsschaltung ermöglicht einen Dynamikbereich von ca. 30 dB bei guter Linearität (wichtig für geringen AM-Klirrfaktor).

Bei Geräten mit Option SMY-B40 wird für die Pegelregelung bei Gerätefrequenzen ≥ 10 MHz der Detektor auf der Option SMY-B40 verwendet. Dessen Ausgangsspannung gelangt über das Kabel W125 zum Motherboard und von dort auf den Eingang X2.A5 DETEXT dieser Baugruppe.

Der Pegeldetektor im RF-Zweig vor dem Mischer wird bei Gerätefrequenzen  $f_{\rm RF} < 10$  MHz anstelle des Detektors am Ausgang X226 FOPU verwendet. Der RF-Pegel an der Diode beträgt ca. +15 dBm.

Die Pegelregelung erfolgt durch den PI-Regler N235. Der Führungswert wird vom D/A-Wandler RFLEV geliefert und mit dem Istwert von einem der drei Detektoren (VDET, DETEXT oder VDETMIX) je nach Frequenzbereich verglichen. Die Ausgangsspannung des PI-Reglers regelt das Stellglied nach:

Im Bereich  $f_{RF} \leq 1040$  MHz ist der AM MODULATOR in Betrieb. Im Bereich  $f_{RF} > 1040$  MHz ist der DOUBLER MODULATOR in Betrieb; zusätzlich wird durch das Steuersignal MODUFIX vom Rechner die Steuerspannung des AM MODULATORs auf einen festen Wert (ca. 14 V) geschaltet, um so minimale Dämpfung zu erreichen.

Die 3dB-Bandbreite der Regelschleife kann durch AMSLOW von ca. 300 kHz auf ca. 50 kHz reduziert werden (siehe Spezialfunktion 13).

Das Aktivieren von KLEMM-N durch den Prozessor steuert den AM-Modulator auf maximale Dämpfung, dies wird z.B. bei Frequenzwechseln zur Vermeidung von Pegelspikes verwendet.

### 7.1.6 Serielle Schnittstelle

Die ankommenden Daten werden in die Schieberegister und die D/A-Wandler LEVEL PRESET, RFLEV und AM getaktet.

### 7.1.7 Schaltung zur Diagnoseauswahl

Über den Diagnosemultiplexer kann eine von 8 Gleichspannungen auf die Diagnoseleitung gelegt werden. Der Spannungswert kann im Gerätedisplay angezeigt werden.

Spezialfunktion	Soll-Spannungsbereich	Hinweis
101	0.00 V 5 V	RF-Pegel vor Doubler Modulator
102	0.00 V 6 V	Detektorspannung Ausgang FOPU
103	0.00 V 6 V	Detektorspannung Mischer
104	0.01 V 3 V	RF-Pegel nach Filterbank
105	-6.00 V 0 V	Führungswert der Pegelregelung
106	-1.00 V 10 V	Ausgangsspannung des
		Regelverstärkers
107	-1.00 V 10 V	Steuerspannung des AM-Modulators
108	0.50 V 13 V	Steuerspannung des Stellgliedes
		LEVEL PRESET

### 7.2 Meßgeräte und Hilfsmittel

- Spektrumanalysator (z.B. FSBS)
- Oszilloskop (z.B. BOL)
- Gleichspannungsmeßgerät (Multimeter, z.B. UDL33)
- Netzwerkanalysator (z.B. ZVR)
- RF-Pegelmesser (z.B. NRVD mit Meßkopf NRV-Z51)
- 10dB-N-Dämpfungsglied (z.B. DNF)

#### 7.3 Fehlersuche

Vor dem Öffnen des Gerätes ist es zweckmäßig, zuerst einmal die Kalibrierroutine LEVEL PRESET zu starten und an Hand der Diagnosespannungen mögliche Fehlerquellen zu lokalisieren.

#### 7.3.1 Fehler nur im Bereich $f_{RF}$ < 10 MHz

falscher RF-Pegel an X226 Der Detektor im Mischbereich

liefert eine falsche Spannung oder der PI-Regler wird nicht richtig

angesteuert.

Spannung VDETMIX mit

Spezialfunktion 103 prüfen.

schlechter AM-Klirrfaktor Prüfe die Linearisierungsschaltung

des Detektors.

### Fehler nur im Bereich f<sub>RF</sub> < 65 MHz

falscher RF-Pegel an X226 Eingang REF640, ZF-Verstärker, RF-

> Verstärker 4 und die Ansteuerung SBDON-P und SBDON-N der Umschalter

prüfen.

Oberwellen zu groß Prüfe ZF-Verstärker, ZF-Tiefpaß

und RF-Schalter SWITCHB.

Nebenwellen zu groß Der Mischer ist defekt oder er

wird mit zu hohem RF-Pegel

angesteuert (Sollpegel am Mischer-RF-Eingang < -5 dBm). Prüfe ZF-

Verstärker, ZF-Tiefpaß, RF-

Schalter SWITCHB und

den RF-Tiefpaß.

#### 7.3.3 Fehler im Bereich 5 kHz $\leq$ f<sub>RF</sub> $\leq$ 1040 MHz

kein RF-Pegel an X226

Die Steuerspannung des AM-Modulators muß jetzt > 12 V sein, sonst arbeitet die Pegelregelung nicht richtig oder der

Führungswert vom RFLEV-D/A-Wandler ist falsch. Pegel nach Filterbank prüfen (Spezialfunktion 104). Mit Spektrumanalysator mit RF-Tastkopf mit DC-Trennung die RF-Kette

kontrollieren (die Sollverstärkung

einzelner Verstärkerstufen beträgt

ca. 7 dB)

Oberwellen zu groß

Prüfe Filterbank und folgende RF-

Verstärker-Kette, prüfe

Arbeitspunkte des Endverstärkers.

Stör-Phasenmodulation bei AM

zu groß

Prüfe die Ansteuerspannung des AM-

Modulators .

Kalibrierung LEVEL PRESET am Gerät

durchführen.

AM-Klirrfaktor zu groß

Prüfen und Abgleich von Detektor und Linearisierungsschaltung,

Kontrolle der AMSLOW-Ansteuerung.

AM-Klirrfaktor zu groß

Prüfen und Abgleich von Detektor

und Linearisierungsschaltung,

Kontrolle der

AMSLOW- AMSLOW-Ansteuerung.

### 7.3.4 Fehler im Bereich 1040 MHz $< f_{RF} \le 2080$ MHz

kein RF-Pegel an X226

Die Steuerspannung des AM-

Modulators muß jetzt > 12 V sein, sonst arbeitet die Pegelregelung

nicht richtig oder der

Führungswert vom RFLEV-D/A-Wandler ist falsch. Pegel nach Filterbank

prüfen (Spezialfunktion 104),

Pegel vor Douber Modulator prüfen (Spezialfunktion 101). Umschalter

SwitchA und SwitchC vor und nach

den Bandpässen prüfen. Mit

Spektrumanalysator mit RF-Tastkopf

mit DC-Trennung die RF-Kette

kontrollieren (die Sollverstärkung

einzelner Verstärkerstufen beträgt

ca. 7 dB)

Oberwellen zu groß

Prüfe Filterbank und folgende RF-Verstärker-Kette, prüfe schaltbare Bandpässe und die Umschalter SWITCHA und SWITCHC, prüfe Arbeitspunkt des Doubler Modulators, prüfe Arbeitspunkte

des Endverstärkers.

#### Subharmonische zu groß

Prüfe schaltbare Bandpässe und die Umschalter SWITCHA und SWITCHC, prüfe Arbeitspunkt des Doubler Modulators, prüfe LEVEL PRESET-Spannung, Kalibrierung von LEVEL PRESET (Spezialfunktion 45) durchführen.

# Stör-Phasenmodulation bei AM zu groß

Prüfe die Ansteuerspannung des AMModulators und die
Ansteuerspannung des Doubler
Modulators.

Kalibrierung LEVEL PRESET am Gerät durchführen.

### AM-Klirrfaktor zu groß

Prüfen und Abgleich von Detektor und Linearisierungsschaltung, Kontrolle der AMSLOW-Ansteuerung.

### 7.3.5 Spektrale Reinheit, delta\_f < 10 MHz vom Träger

Seitenlinien in ca. 1 MHz Abstand vom Träger

Pegel-Regelschleife schwingt; Prüfe Detektor und Linearisierungsschaltung. Kalibrierung LEVEL PRESET durchführen.

### 7.4 Prüfen und Abgleich

Vorbemerkung:

Neben den Koppelkondensatoren bzw. -widerständen der RF-Kette befinden sich Massedurchkontaktierungen. An einer solchen Stelle kann ein Koaxialkabel eingelötet und über einen Koppelkondensator oder eine externe DC-Trennung ein Meßgerät (z.B. Netzwerk- oder Spektrumanalysator) angeschlossen werden. Hierzu wird das Koaxialkabel durch das Loch gesteckt, der Außenleiter des Koaxialkabels an der Durchkontaktierung und der Innenleiter am gewünschten Anschlußfleck des Kondensators angelötet.

### 7.4.1 Prüfen der Datenübertragung

Die Prüfung wird bei den in der Tabelle angegebenen Einstellungen am Gerät durchgeführt.

\_ Prüfen der Spannungen an D120:
 "1" = +5 V, "0" = 0 V

RF	-Frequenz	D120	/14	D120/6 Hinweis
RF	1MHz	0	1	DETMIXON
RF	10MHz	1	0	DETON

#### 7.4.2 Prüfen der Ausgangsspannung des Regelverstärkers

Um die Amplitudenmodulatoren optimal betreiben zu können ist die LEVEL PRESET-Kalibrierung erforderlich. Dieser optimale Arbeitspunkt ist abhängig vom Bereich der RF-Frequenz.

Im Frequenzbereich  $f_{RF} \leq 1040$  MHz gilt: Die Ausgangsspannung des Regelverstärkers soll bei einem Ausgangspegel von 13dBm (19 dBm mit Option SMY-B40) 6.3V betragen. Bei elektronischer Pegelabsenkung auf 7dBm (13 dBm mit Option SMY-B40) soll diese Spannung auf 3.9V absinken und bei weiterer elektronischer Pegelabsenkung bis zu -6dBm (0 dBm mit Option SMY-B40) konstant auf 3.9V bleiben.

Im Frequenzbereich  $f_{RF} > 1040$  MHz gilt: Die Ausgangsspannung des Regelverstärkers soll bei einem Ausgangspegel von 13dBm (19 dBm mit Option SMY-B40) 7.5V betragen. Bei elektronischer Pegelabsenkung auf 7dBm (13 dBm mit Option SMY-B40) soll diese Spannung auf 5.4V absinken und bei weiterer elektronischer Pegelabsenkung bis zu -6dBm (0 dBm mit Option SMY-B40) konstant auf 5.4V bleiben.

- ullet Den Geräteausgang RF 50 $\Omega$  mit 50 $\Omega$  abschließen.
- LEVEL 13 dBm (19 dBm mit Option SMY-B40) einstellen und
- Spezialfunktion 1 (unterbrechungsfreie Pegeleinstellung) einschalten.
- \_ Über die Spezialfunktion 106 kann die Ausgangsspannung des Regelverstärkers gemessen werden.

### 7.4.3 Prüfen der LEVEL PRESET-Steuerspannung

- ullet Den Geräteausgang RF  $50\Omega$  mit  $50\Omega$  abschließen.
- LEVEL 13 dBm (19 dBm mit Option SMY-B40) einstellen
- Spezialfunktion 1 (unterbrechungsfreie Pegeleinstellung) einschalten.
- \_ Über die Spezialfunktion 108 kann die LEVEL PRESET-Spannung gemessen werden.
  - Die Spannung ist abhängig von der RF-Frequenz und vom RF-Pegel. Der Rechner sendet die berechneten Werte in den LEVEL PRESET-D/A-Wandler.

Typische Spannungswerte sind in folgender Tabelle dargestellt:

	SMY02 oh	ne Option	SMY-B40	i A. Barriya	SMY02 mi	t Option	SMY-B40	NEW TREET
RF-Frequenz	_13 dBm	7 dBm	0 dBm	-6 dBm	19 dBm	13 dBm	6 dBm	0 dBm
25 MHz	1.4 V	1.4 V	1.0 V	0.8 V	1.4 V	1.4 V	1.0 V	0.8 V
100 MHz	1.6 V	1.6 V	1.2 V	0.8 V	1.6 V	1.6 V	1.2 V	0.8 V
300 MHz	1.4 V	1.4 V	1.0 V	0.8 V	1.4 V	1.4 V	1.0 V	0.8 V
500 MHz	1.3 V	1.3 V	1.0 V	0.8 V	1.3 V	1.3 V	1.0 V	0.8 V
750 MHz	2.0 V	2.0 V	1.4 V	1.0 V	2.0 V	2.0 V	1.4 V	1.0 V
800 MHz	1.6 V	1.6 V	1.2 V	1.0 V	1.6 V	1.6 V	1.2 V	1.0 V
1040 MHz	2.2 V	2.2 V	1.5 V	1.2 V	2.2 V	2.2 V	1.5 V	1.2 V
1041 MHz	1.0 V	1.0 V	0.9 V	0.8 V	1.0 V	1.0 V	0.9 V	0.8 V
1200 MHz	1.2 V	1.2 V	1.0 V	0.9 V	1.2 V	1.2 V	1.0 V	0.9 V
1400 MHz	1.3 V	1.3 V	1.1 V	1.0 V	1.3 V	1.3 V	1.1 V	1.0 V
1600 MHz	1.4 V	1.4 V	1.1 V	1.0 V	1.4 V	1.4 V	1.1 V	1.0 V
1800 MHz	1.8 V	1.8 V	1.5 V	1.4 V	1.8 V	1.8 V	1.5 V	1.4 V
2000 MHz	2.1 V	2.1 V	1.6 V	1.5 V	2.1 V	2.1 V	1.6 V	1.5 V
2080 MHz	2.4 V	2.4 V	1.8 V	1.6 V	2.4 V	2.4 V	1.8 V	1.6 V

## 7.4.4 Prüfen der Arbeitspunkte der Verstärkerstufen

Prüfpunkt	Sollspannung Sollspannung	Bemerkung
N360/3	5.50 ± 1.1 V	RF AMPLIFIER 2
N410/3	5.50 ± 1.1 V	RF AMPLIFIER 3
V602 Kollektor	8.90 ± 0.3 V	RF AMPLIFIER 4
V612 Kollektor	5.90 ± 0.3 V	IF AMPLIFIER
V671 Kollektor	5.50 ± 1.1 V	RF AMPLIFIER 7
V874 Kollektor	5.20 ± 1.1 V	RF AMPLIFIER 8
V769 Kollektor	5.20 ± 1.1 V	RF AMPLIFIER 9
V801 Kollektor	5.20 ± 1.1 V	RF AMPLIFIER 11
V817 Kollektor	15.9 ± 0.3 V	RF AMPLIFIER 12
V832 Kollektor	15.9 ± 0.3 V	RF AMPLIFIER 13

## 7.4.5 Prüfen der Ansteuerung der Filterbank

\_ Prüfen von LPSELECT-0 ... LPSELECT-3 und der Schaltleitungen TPO ... TP8.

RF-Frequenz	LPSELEC	r-		the and the second	Hinweis
3	2	1	Ö		A CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR OF THE CONTRACTOR
D111/8	D111/11	D111/6	D111	1/3	
1560.00 MHz	0	Ç.	0	1	Tiefpaß 1, Verdopplerbereich
1040.01 MHz	0	0	1	0	Tiefpaß 2, Verdopplerbereich
780.00 MHz	0	С	0	1	Tiefpaß 1
520.00 MHz	0	c	1	0	Tiefpaß 2
390.00 MHz	0	ξ	1	1	Tiefpaß 3
260.00 MHz	0	ĭ	0	0	Tiefpaß 4
195.00 MHz	O	1	0	1	Tiefpaß 5
130.00 MHz	0	:	1	0	Tiefpaß 6
97.50 MHz	0	1	1	1	Tiefpaß 7
65.00 MHz	1	č	0	0	Tiefpaß 8
64.00 MHz	С		1	0	Tiefpaß 2. Mischerbereich

Bei Geräteausgangsfrequenzen 65 MHz  $\leq$   $f_{RF} \leq$  1040 MHz wird von der Baugruppe Synthese die Ausgangsfrequenz geliefert.

Bei Geräteausgangsfrequenzen  $f_{RF} > 1040$  MHz wird von der Baugruppe Synthese die halbe Ausgangsfrequenz geliefert (520 MHz <  $f_{SYN} \le 1040$  MHz).

### 7.4.6 Prüfen des RF-Pegels nach der Filterbank

- ullet Den Geräteausgang RF 50 $\Omega$  mit 50 $\Omega$  abschließen.
- Einstellung: RF LEVEL 13 dBm (19 dBm mit Option SMY-B40)
- \_ Über die Spezialfunktion 104 kann die gleichgerichtete RF-Spannung gemessen werden.

Typische Spannungswerte sind in folgender Tabelle dargestellt:

RF-Frequenz	Diagnosespannung =	AREA TO A STREET	Major may be indicated the	juga pari je sa
10 MH2	0.8 V		-	
100 MHz	0.6 V			
200 MHz	0.9 V	[		i
400 MHz	1.1 V			
600 MHz	1.2 V			
800 MHz	0.8 V			
1000 MHz	1.1 V			
1040 MHz	0.9 V			
1041 MHz	1.5 V			
1200 MHz	1.1 V			
1400 MHz	1.0 V			
1600 MHz	1.0 V			
1800 MHz	1.0 V			
2000 MHz	1.8 V			
2080 MHz	1.9 V			

## 7.4.7 Prüfen der Ansteuerung der Bandpaßschalter

\_ Prüfen von BP10N, BP20N und BP30N.

RF-Frequenz D112/3	BP10N D112/6	BP2ON D112/11	BP3ON "	Hinwels
1040.00 MHz	0	0	0	Bandpässe ausgeschaltet
1040.01 MHz	1	0	0	Bandpass 1 ein
1310.40 MHz	0	1	0	Bandpass 2 ein
1651.10 MHz	0	0	1	Bandpass 3 ein

### 7.4.8 Abgleich der ZF-Verstärkung

- ullet Spektrumanalysator an Geräteausgang RF  $50\Omega$  anschließen
- Einstellung: RF

10 MHz

LEVEL

13 dBm (19 dBm mit Option SMY-B40)

- \_ RF-Signal messen, RF-Pegel merken
- \_ RF-Frequenz um 1 Hz erniedrigen
- \_ Mit Pot R645 den RF-Pegel auf den gleichen Wert einstellen
- \_ Nach dem Abgleich sollte die Kalibrierroutine LEVEL PRESET aufgerufen werden.

### 7.4.9 Abgleich der ZF-Detektor-Linearität

• Einstellung: RF

9.9 MHz

LEVEL

5.1 dBm (11.1 dBm mit Option SMY-B40)

- \_ Ausgangspegel am RF-Ausgang des Gerätes messen und merken (= Referenzpegel)
- Einstellung: Spezialfunktion 1 einschalten

(unterbrechungsfreie Pegeleinstellung)

LEVEL -14.9 dBm (-8.9 dBm mit Option SMY-B40)

\_ Mit POT R619 so abgleichen, daß der gemessene Pegel 20 dB unter dem zuvor gemessenen Referenzpegel liegt. Abgleich einmal wiederholen, da sich der Referenzwert mit R619 geringfügig ändert; die Genauigkeit der 20dB-Absenkung soll nach dem Abgleich ± 0.1 dB erreichen.

### 7.4.10 Abgleich der Detektor-Linearität am Ausgang FOPU

- Dieser Abgleich darf nur dann durchgeführt werden, wenn keine Option SMY-B40 eingebaut ist!
- Einstellung:

RF

100 MHz

LEVEL

13 dBm

- \_ Ausgangspegel am RF-Ausgang des Gerätes messen und merken (= Referenzpegel)
- Einstellung:

Spezialfunktion 1 einschalten

(unterbrechungsfreie Pegeleinstellung)

LEVEL -7 dBm

\_ Mit POT R851 so abgleichen, daß der gemessene Pegel 20 dB unter dem zuvor gemessenen Referenzpegel liegt. Abgleich einmal wiederholen, da sich der Referenzwert mit R851 ändert; die Genauigkeit der 20dB-Absenkung soll nach dem Abgleich ± 0.1 dB erreichen.

### 7.4.11 Abgleich des AM-Modulationsgrades

• Einstellung:

PRESET

LEVEL 7 dBm (+13 dBm mit Option SMY-B40)

AM EXT DC 100%

Spezialfunktion 105 einschalten (Führungswert der Pegelregelung)

- Eine Gleichspannung U = -1.000 V an AM EXT anlegen.
- \_ Mit POT R280 auf 0 V abgleichen.

### 7.5 Zerlegung und Zusammenbau

Oberen Gerätedeckel entfernen. Die Baugruppe ist links und rechts an der Auflage festgeschraubt. Nach dem Entfernen dieser Schrauben und dem Lösen der Koax-Verbindungen an X224, X225 und X226 kann die Baugruppe aus ihrem Steckplatz entnommen werden.

### 7.6 Endprüfung

### 7.6.1 Prüfen des maximalen Ausgangspegels

• Einstellung:

LEVEL

19 dBm (25 dBm mit Option SMY-B40)

- An X226 FOPU einen Leistungsmesser anschließen, dabei muß ggf. ein geeignetes RF-Dämpfungsglied vorgeschaltet werden, um den Meßkopf nicht zu überlasten.
- RF-Frequenz von 5kHz bis 2080 MHz variieren.

  Der RF-Pegel muß > 15dBm (20 dBm mit Option SMY-B40) bleiben.

Typische Pegelwerte sind in folgender Tabelle dargestellt:

	SMY02_ohne Option SMY-B40	SMY02 mit Option SMY-B40
RF-Frequenz	Ausgangspegel	Ausgangspegel
10 MHz	19 dBm	21 dBm
200 MHz	19 dBm	25 dBm
400 MHz	19 dBm	24_dBm
600 MHz	20 dBm	25 dBm
800 MHz	18 dBm	26 dBm
1000 MHz	17 dBm	25 dBm
1200 MHz	19_dBm	24 dBm
1400 MHz	18 dBm	24 dBm
1600 MHz	17 dBm	24 dBm
1800 MHz	16 dBm	23 dBm
2000 MHz	16 dBm	24 dBm
2080 MHz	16 dBm	24 dBm

### 7.6.2 Prüfen des Oberwellenabstandes

- Gerät ohne Option SMY-B40:
- Einstellung:

LEVEL 10 dBm

- \_ An X226 FOPU einen Spektrumanalysator anschließen.
- \_ Der Pegel der Harmonischen muß < -30 dBc sein.
- Gerät mit Option SMY-B40:
- Einstellung:

LEVEL 16 dBm

Spezial 21 (ALC aus)

Da für die Messung die Verbindung von FOPU zum Powermodul aufgetrennt wird, muß die Pegelregelung auf den Sample-and-Hold-Betrieb geschaltet werden. Vor jeder Änderung der Geräteeinstellung muß diese Verbindung wieder geschlossen werden!

- \_ Meßfrequenz einstellen.
- \_ An X226 FOPU einen Spektrumanalysator anschließen.
- \_ Der Pegel der Harmonischen muß <-25 dBc sein.

Typische Meßwerte sind in folgender Tabelle dargestellt:

	SMY02 ohne Opt	lon SMY-B40	SMY02 mit Option SMY-B40		
RF-Frequenz	2*fRF	3*fRF	2*fRF	3*fRF	
1 MHz	-45 dBc	-40 dBc	-45 dBc	-48 dBc	
10 MHz	-50 dBc	-45 dBc	-48 dBc	-48 dBc	
200 MHz	-50 dBc	-45 dBc	-40 dBc	-50 dBc	
400 MHz	-45 dBc	-40 dBc	-35 dBc	-45 dBc	
600 MHz	-35 đBc	-40 dBc	-35 dBc	-50 dBc	
800 MHz	-35 dBc	-40 dBc	-35 dBc	-50 dBc	
1000 MHz	-35 dBc	-50 dBc	-32 dBc	-50 dBc	
1200 MHz	-35 dBc	-50 dBc	-32 dBc	-50 dBc	
1400 MHz	-40 dBc	-45 dBc	-32 dBc	-50 dBc	
1600 MHz	-45 dBc	-45 dBc	-32 dBc	-50 dBc	
1800 MHz	-45 dBc	-45 dBc	-32 dBc	-50 dBc	
2000 MHz	-35 dBc	-50 dBc	-35 dBc	-50 dBe	
2080 MH2	~45 dBc	-50 dBc	-45 dBc	-50 dBc	

## 7.6.3 Prüfen des Nebenwellenabstandes

- Gerät ohne Option SMY-B40:
- Einstellung:

RF

63 MHz

LEVEL

13 dBm

- \_ An X226 FOPU einen Spektrumanalysator anschließen.
- Nebenwellen bei folgenden Frequenzen prüfen: 703 MHz, 640 MHz, 136 MHz, 73 MHz, 10 MHz

Der Pegel der Nebenwellen muß < -70 dBc sein (typ. < -100 dBc).

• Gerät mit Option SMY-B40:

• Einstellung:

LEVEL 19 dBm

Spezial 21 (ALC aus)

Da für die Messung die Verbindung von FOPU zum Powermodul aufgetrennt wird, muß die Pegelregelung auf den Sample-and-Hold-Betrieb geschaltet werden. Vor jeder Änderung der Geräteeinstellung muß diese Verbindung wieder geschlossen werden!

- Nebenwellen bei folgenden Frequenzen prüfen: 703 MHz, 640 MHz, 136 MHz, 73 MHz, 10 MHz
- \_ RF-Frequenz einstellen.
- \_ An X226 FOPU einen Spektrumanalysator anschließen.
  Der Pegel der Nebenwellen muß < -70 dBc sein (typ. < -100 dBc).

### 7.6.4 Prüfen des Subharmonischenabstandes

- Gerät ohne Option SMY-B40:
- Einstellung:

LEVEL

13 dBm

- \_ An X226 FOPU einen Spektrumanalysator anschließen. RF-Frequenz am SMY einstellen und bei  $f_{\rm SUB1}$  und  $f_{\rm SUB2}$  (siehe Tabelle) den Pegel der Subharmonischen messen. Er muß < -40 dBc sein.
- Gerät mit Option SMY-B40:
- Einstellung:

EVEL 19 dBm

Spezial 21 (ALC aus)


Da für die Messung die Verbindung von FOPU zum Powermodul aufgetrennt wird, muß die Pegelregelung auf den Sample-and-Hold-Betrieb geschaltet werden. Vor jeder Änderung der Geräteeinstellung muß diese Verbindung wieder geschlossen werden!

\_ RF-Frequenz einstellen. An X226 FOPU einen Spektrumanalysator anschließen. Bei  $f_{\rm SUB1}$  und  $f_{\rm SUB2}$  (siehe Tabelle) den Pegel der Subharmonischen messen. Er muß < -40 dBc sein.

RF-Frequenz fsub1		fsub2	
1040.01 MHz	520.005 MHz	1560.015 MHz	
1310.39 MHz	655.195 MHz	1965.585 MHz	
1310.40 MHz	655.200 MHz	1965.600 MHz	
1559.99 MHz	779.995 MHz	2339.985 MHz	
1560.00 MHz	780.000 MHz	2340.000 MHz	
1651.09 MHz	825.545 MHz	2476.635 MHz	
1651.10 MHz	825.550 MHz	2476.650 MHz	
2080.00 MHz	1040.000 MHz	3120.000 MHz	

Pin	Name	Ein/Ausgang	Herkunft/Ziel	Wertebereich	Signalbeschreibung
X2A.01	BLANK	Eingang	Rückwanne	HCMOS-Pegel	RF-Pegelaustastung
X2A.05	DETEXT	Eingang	Pmod	0 10 V	Detektorspg. Option SMY-B40
X2A.07	AMMOD	Eingang	CPU X3.34	-1 V bis 1 V	AM-Signal
X2A.12	SERCLK	Eingang	CPU X3.2	HCMOS-Pegel	Clock
X2A.14	SERDAT	Eingang	CPU X3.4	HCMOS-Pegel	serielle Daten
X2A.15	AT1STB	Eingang	CPU X3.16	HCMOS-Pegel	Strobe 1
X2A.17	HFINT	Ausgang	CPU X3.20	HCMOS-Pegel	Interrupt Pegelregelung
X2A.19	DIAG-5V	Ausgang	СРИ ХЗ.6	-5 V5 V	Diagnose
X2A.22	VA24-P	Eingang	Netzteil X21.22	23.4 V24.6 V	Versorgungsspannung analog
X2A.24	VA15-P	Eingang	Netzteil X21.13	14.80 V15.75 V	Versorgungsspannung analog
X2A.25					
X2A.28	VA-5P	Eingang	Netzteil X21.5	5.10V5.25V	Versorgungsspannung analog
X2A.30	VA15-N	Eingang	Netzteil X21.20	-15.75V14.85V	Versorgungsspannung analog
X224	FSYN	Eingang	YSYN X124	6 - 12 dBm	65 - 1040 MHz
X225	REF640	Eingang	YSYN X125	9 - 12 dBm	640 MHz
X226	FOPU	Ausgang	Eichleitung X2	-620 dBm	5 kHz - 2.08 GHz







SERVICE INSTRUCTIONS
Output Module 2.08 GHz
1062.7005.01



### Contents

7	Tes	ting and Repair of the Module 5
	7.1	Function Description 5
		7.1.1 RF Signal Processing 5
		7.1.2 Mixer with LO, RF and IF Filters 6
		7.1.3 Output Amplifier 6
		7.1.4 AM Signal Path a. Nominal Value of RF Level 6
		7.1.5 RF Level Control
		7.1.6 Serial Interface 7
		7.1.7 Circuit for Diagnostics Selection
	7.2	Test Instrument and Utilities 7
	7.3	Troubleshooting 8
		7.3.1 Errors Occurring Only in the Range $f_{RF}$ < 10 MHz 8
		7.3.2 Errors Occurring Only in the Range $f_{RF}$ < 65 MHz 8
		7.3.3 Errors in the Range 5 kHz $\leq$ f <sub>RF</sub> $\leq$ 1040 MHz 8
		7.3.4 Errors in the Range 1040 MHz $\leq$ f <sub>RF</sub> $\leq$ 2080 MHz 9
		7.3.5 Spectral Purity, delta_f < 10 MHz from the Carrier 10
	7.4	Testing and Adjustment
		7.4.1 Testing Data Transmission
		7.4.2 Testing the Output Voltage of the Control Amplifier. 10
		7.4.3 Testing the LEVEL PRESET Control Voltage 11
		7.4.4 Testing the Operating Points of Amplifier Stages 11
		7.4.5 Testing the Harmonic Filter Control
		7.4.6 Testing the RF Level at the Harmonic Filter Output 12
		7.4.7 Testing Control of the Bandpass Filter Switches 13
		7.4.8 IF Amplification Adjustment
		7.4.9 IF Detector Linearity Adjustment
		7.4.10 Detector Linearity Adjustment at the Output FOPU 13
		7.4.11 AM Depth Adjustment
	7.5	Disassembly and Assembly
	7.6	Final Test
		7.6.1 Maximum Output Level Check
		7.6.2 Harmonics Suppression Check
		7.6.3 Nonharmonics Suppression Check
		7.6.4 Subharmonics Suppression Check
	7.7	External Interfaces

Parts list List of coordinates Circuit diagram Component layout diagram

#### 7 Testing and Repair of the Module

In instuments without fitted option SMY-B40, this module has the variant VAR 02.

In instuments with fitted option SMY-B40, this module has the variant VAR 03.

#### 7.1 Function Description

The Output Module 2.08 GHz is provided with the RF signal (6 dBm to 12 dBm) in the frequency range 65 MHz  $\leq f_{\rm SYN} \leq$  1040 MHz by the synthesis module via the input FSYN. This RF signal is passed via an amplitude modulator and an amplitude control element to switchable harmonic filters. The output frequency range of 5 kHz  $\leq$   $f_{\rm RF}$  < 65 MHz is realized in the signal path via the changeover switches SWITCHB and SWITCHD by means of downconversion with a 640 MHz LO.

The doubler path can be switched on via the changeover switches SWITCHA and SWITCHC to realize the output frequency range 1040 MHz <  $f_{\text{RF}} \leq$  2080 MHz.

The module consists of the following function units:

- an AM modulator for level control and amplitude modulation in the frequency range 5 kHz  $\leq f_{RF} \leq$  1040 MHz,
- an AM modulator for level presetting (LEVEL PRESET),
- switchable harmonic filters,
- a mixer with LO, RF and IF filters,
- a level detector in the RF path preceding the mixer,
- a frequency doubler,
- an AM modulator for level control and amplitude modulation in the frequency range 1040 MHz <  $f_{\rm RF} \leq$  2080 MHz,
- switchable bandpasses for suppression of subharmonics,
- an output amplifier,
- a level detector at the output FOPU,
- a signal path for setting the nominal value of the RF level and the amplitude-modulation depth,
- the RF-level control,
- a serial interface and
- a circuit for diagnostics selection.

Further information on levels apply for an instrument output level of +13 dBm (+19 dBm with option SMY-B40).

### 7.1.1 RF Signal Processing

The input X224 FSYN is followed by an attenuator for temperature compensation. The attenuator is followed by the AM MODULATOR. It is used as control element for level control in the range  $f_{\rm RF} \leq 1.04~{\rm GHz}$ .

The RF signal is amplified by RF AMPLIFIER 1 and RF AMPLIFIER 2 and passed to the PIN modulator LEVEL PRESET. This modulator is set by means of stored calibration data via the D/A converter such that the control element for level control can be openominal in an optimum operating point (cf. operating manual "Calibrating LEVEL PRESET").

The RF signal is amplified by the RF AMPLIFIER 3 and routed to switchable HARMONIC FILTERS. These filters are switched on by the controller depending on the input frequency at X224 FSYN. Similar to the lowpasses TP4 to TP8, the lowpasses TP0 and TP3 are cascaded. Filters which have a higher cutoff frequency than the cutoff frequency of the lowpass selected remain switched on. In "normal operation", the RF signal passes via the PIN switch SWITCHD (OFF) and the GaAs changeover switch SWITCHB (OFF) to the output amplifier.

In "mixer operation", the RF signal is passed via the PIN switch SWITCHD (ON) and the RF AMPLIFIER 4 to the detector preceding the mixer.

In "doubler operation", the RF signal is switched via the GaAs switch SWITCHA (ON) to the doubler. The output signal of the latter is passed via the DOUBLER MODULATOR to switchable bandpass filters and via the GaAs switch SWITCHC (ON) to the output amplifier.

### 7.1.2 Mixer with LO, RF and IF Filters

The RF signal supplied by the detector preceding the mixer is switched via the RF lowpass and an attenuator to the RF input of the mixer for level adjustment (level approx. -5 to -10 dBm). The signal of REF640 passes via a lowpass to the LO input of the mixer. The IF signal reaches the RF switch SWITCHB (ON) preceding the output amplifier via the IF amplifier and the IF lowpass (5 kHz  $\leq f_{\rm ZF} < 65$  MHz, level approx. 0 dBm).

### 7.1.3 Output Amplifier

The three-stage linear broadband amplifier amplifies the input signal by approx. 19 dB. The operating points of the stages RF AMPLIFIER 12 and RF AMPLIFIER 13 are controlled.

### 7.1.4 AM Signal Path a. Nominal Value of RF Level

The signal of the AMMOD line is passed to the D/A converter for setting of the modulation depth and is then applied to the D/A converter RFLEV for setting of the RF level.

### 7.1.5 RF Level Control

For instruments without option SMY-B40, the level detector at the output X226 FOPU is used with instrument frequencies  $f_{\rm RF} \geq 10$  MHz. The RF level at the diode is approx.+ 19 dBm. The linearization circuit allows for a dynamic range of approx. 30 dB with good linearity (important for low distortion).

For instruments with option SMY-B40, the detector on the option SMY-B40 is used for level control at instrument frequencies  $\geq$  10 MHz. Its output voltage is applied to the motherboard via the cable W125 and then fed into the input X2.A5 DETEXT of this module.

The level detector in the RF path preceding the mixer is used with instrument frequencies  $f_{RF} < 10$  MHz instead of the detector at the output X226 FOPU. The RF level at the diode is approx. +15 dBm.

The level is controlled via the PI regulator N335. The reference value is supplied by the D/A converter RFLEV and compared to the actual value of one of the three detectors (VDET, DETEXT or VDETMIX) according to the frequency range. The output voltage of the PI regulator adjusts the control element:

the AM MODULATOR operates in the range  $\rm f_{RF} \leq 1040~MHz;$  the DOUBLER MODULATOR operates in the range  $\rm f_{RF} > 1040~MHz;$  additionally, the control voltage of the AM MODULATOR is fixed to approx. 14 V by the control signal MODUFIX, in order to obtain minimum attenuation.

The 3-dB bandwidth of the control loop can be reduced by AMSLOW from approx. 300 kHz to approx. 50 kHz (see special function 13).

Activating of KLEMM-N by the processor sets the AM modulator to maximum attenuation, which is used, e.g., for frequency changes in order to avoid level spikes.

#### 7.1.6 Serial Interface

The incoming data are clocked into the shift registers and the D/A converters LEVEL PRESET, RFLEV and AM.

### 7.1.7 Circuit for Diagnostics Selection

One of eight dc voltages can be applied to the diagnostic line via the diagnostic multiplexer. The voltage can be displayed on the instrument.

Special function	· Nominal volt	age range	Remark
101	0.00 V to		RF level before passing Doubler
			Modulator
102	0.00 V to	6 V	Detector voltage output FOPU
103	0.00 V to	6 V	Detector voltage mixer
104	0.01 V to	3 V	RF level after passing the filter bank
105	-6.00 V to	0 V	Reference value of level control
106	-1.00 V to	10 V	Output voltage of control amplifier
107	-1.00 V to	10 V	Control voltage of the AM modulator
108	0.50 V to	13 V	Control voltage of the LEVEL PRESET
			element

### 7.2 Test Instrument and Utilities

- Spectrum analyzer (e.g., FSBS)
- Oscilloscope (e.g., BOL)
- DC voltmeter (multimeter, e.g., UDL33)
- Network analyzer (e.g., ZVR)
- RF power meter (e.g. NRVD with sensor NRV-Z51)
- 10-dB N-attenuator pad (e.g. DNF)

### 7.3 Troubleshooting

Prior to opening the instrument, it is useful to first start the calibration routine LEVEL PRESET and localize possible error sources using the diagnostic voltages.

### 7.3.1 Errors Occurring Only in the Range $f_{RF}$ < 10 MHz

incorrect level at X226 Either the detector in the mixed

range supplies an incorrect voltage or the PI regulator is not controlled

correctly.

Check voltage VDETMIX using special

function 103.

bad AM distortion Check the linearization circuit of

the detector.

### 7.3.2 Errors Occurring Only in the Range $f_{RF}$ < 65 MHz

Incorrect RF level at X226 Check input REF640, IF amplifier, RF

amplifier 4 and control of SBDON-P and SBDON-N of the changeover

switches.

Harmonics too high Check IF amplifier, IF lowpass and RF

switch SWITCHB.

Spurious signals too high The mixer is either faulty or its

input level is too high (nominal level at the mixer RF input < -5 dBm). Check IF amplifier, IF lowpass

and RF switch SWITCHB and

the RF lowpass.

### 7.3.3 Errors in the Range 5 kHz $\leq f_{RF} \leq 1040$ MHz

No RF level at X226 The control voltage of the AM

modulator must be > 12 V, otherwise, the level control does not work correctly or the reference value of RFLEV D/A converter is incorrect. Check level at the output of harmonic filters (special function 104). Check the RF signal path using a spectrum analyzer with RF probe providing dc isolation (the gain of the amplifier

stages is approx. 7 dB)

Harmonics too high Check harmonic filters and subsequent

RF amplifiers, check operating points

of the output amplifier.

Incidential phase

Check the control voltage of the AM modulation with AM too high modulator. Perform LEVEL PRESET calibration.

AM distortion too high

Test and adjust detector and linearization circuit, check AMSLOW control.

#### 7.3.4 Errors in the Range 1040 MHz $\leq f_{RF} \leq 2080$ MHz

No RF level at X226

The control voltage of the AM modulator must be > 12 V, otherwise, the level control does not work correctly or the reference value of RFLEV D/A converter is incorrect. Check level at the output of harmonic filters (special function 104) and level preceding the Doubler Modulator (special function 101). Check changeover switches SwitchA and SwitchC prior and subsequent to the bandpass filters. Check the RF signal path using a spectrum analyzer with RF probe providing dc isolation (the gain of the amplifier stages is approx. 7 dB)

Harmonics too high

Check harmonic filters and subsequent RF amplifiers, check switchable bandpass filters and the changeover switches SWITCHA and SWITCHC, check operating point of the DOUBLER MODULATOR and those of the output amplifier.

Subharmonics too high

Check switchable bandpass filters and the changeover switches SWITCHA and SWITCHC, check operating point of the DOUBLER MODULATOR, check LEVEL PRESET voltage, perform LEVEL PRESET calibration (special function 45).

Incidential phase modulation with AM too high

Check the control voltage of the AM modulator. Perform LEVEL PRESET calibration.

AM distortion too high

Test and adjust detector and linearization circuit, check AMSLOW control.

Spurious signals at approx. 1 ALC loop oscillates; check detector and linearization circuit. Perform LEVEL PRESET calibration.

### 7.4 Testing and Adjustment

Hints:

Ground via-holes have been fitted next to the coupling capacitors or resistors. A coaxial cable can be soldered in at such a location and a test instrument (e.g., a network or spectrum analyzer) can be connected via a coupling capacitor or an external dc isolation. Therefore, the coaxial cable is routed through the hole, the external conductor is soldered at the via-hole and the inner conductor at the desired location.

### 7.4.1 Testing Data Transmission

The test is performed with the instrument settings listed in the table.

• Test the voltages at D120: "1" = +5 V, "0" = 0 V

RF	frequency	്D120	14 D120/6	Remark South Comment		*	
RF	1MHz	0	1	DETMIXON	 		
RF	10MHz	. 1	0	DETON			- 1

## 7.4.2 Testing the Output Voltage of the Control Amplifier

The LEVEL PRESET calibration is required for optimum operation of the amplitude modulator. This optimum operating point depends on the RF-frequency range.

The following applies for the frequency range  $f_{RF} \leq 1040~MHz$ : the nominal output voltage of the control amplifier is 6.3 V for an output level of 13 dBm (19 dBm with option SMY-B40). When the level is reduced electronically to 7 dBm (13 dBm with option SMY-B40), this voltage shall drop to 3.9 V and remain constant at 3.9 V with further electronic reduction down to -6 dBm (0 dBm with option SMY-B40).

The following applies for the frequency range  $f_{RF} > 1040~MHz:$  the nominal output voltage of the control amplifier is 7.5 V for an output level of 13 dBm (19 dBm with option SMY-B40). When the level is reduced electronically to 7 dBm (13 dBm with option SMY-B40), this voltage shall drop to 5.4V and remain constant at 5.4 V with further electronic reduction down to -6 dBm (0 dBm with option SMY-B40).

- Terminate the instrument output RF  $50\Omega$  with  $50\Omega$ .
- Set LEVEL to 13 dBm (19 dBm with option SMY-B40) and
- switch on special function 1 (non-interrupting level setting))
- \_ The output voltage of the control amplifier can be measured using special function 106.

#### 7.4.3 Testing the LEVEL PRESET Control Voltage

- Terminate the instrument output RF  $50\Omega$  with  $50\Omega$ .
- Set LEVEL to 13 dBm (19 dBm with option SMY-B40).
- Switch on special function 1 (non-interrupting level setting)
- The LEVEL PRESET voltage can be measured using special function 108. The voltage depends on the RF frequency and the RF level. The controller transmits the calculated values to the LEVEL PRESET D/A converter.

Typical voltages are given in the table below:

grī Lighen.	SMY02 wi	thout opt	ion SMY-I	340	SMY02 wi	th option	SMY-B40	AND AND AND AND AND AND AND AND AND AND
RF-Frequenz	13 dBm	7 dBm	0 dBm	-6 dBm	19 dBm	13 đBm	6 dBm	0 dBm
25 MHz	1.4 V	1.4 V	1.0 V	0.8 V	1.4 V	1.4 V	1.0 V	0.8 V
100 MHz	1.6 V	1.6 V	1.2 V	0.8 V	1.6 V	1.6 V	1.2 V	0.8 V
300 MHz	1.4 V	1.4 V	1.0 V	0.8 V	1.4 V	1.4 V	1.0 V	0,8 V
500 MHz	1.3 V	1.3 V	1.0 V	0.8 V	1.3 V	1.3 V	1.0 V	0.8 V
750 MHz	2.0 V	2.0 V	1.4 V	1.0 V	2.0 V	2.0 V	1.4 V	1.0 V
800 MHz	1.6 V	1.6 V	1.2 V	1.0 V	1.6 V	1.6 V	1.2 V	1.0 V
1040 MHz	2.2 V	2.2 V	1.5 V	1.2 V	2.2 V	2.2 V	1.5 V	1.2 V
1041 MHz	1.0 V	1.0 V	0.9 V	v 8.0	1.0 V	1.0 V	0.9 V	0.8 V
1200 MHz	1.2 V	1.2 V	1.0 V	0.9 V	1.2 V	1.2 V	1.0 V	0.9 V
1400 MHz	1.3 V	1.3 V	1.1 V	1.0 V	1.3 V	1.3 V	1.1 V	1.0 V
1600 MHz	1.4 V	1.4 V	1.1 V	1.0 V	1.4 V	1.4 V	1.1 V	1.0 V
1800 MHz	1.8 V	1.8 V	1.5 V	1.4 V	1.8 V	1.8 V	1.5 V	1.4 V
2000 MHz	2.1 V	2.1 V	1.6 V	1.5 V	2.1 V	2.1 V	1.6 V	1.5 V
2080 MHz	2.4 V	2.4 V	1.8 V	1.6 V	2.4 V	2.4 V	1.8 V	1.6 V

### 7.4.4 Testing the Operating Points of Amplifier Stages

Test point	Nominal voltage	Remark
N360/3	5.50 ± 1.1 V	RF AMPLIFIER 2
N410/3	5.50 ± 1.1 V	RF AMPLIFIER 3
V602 Collector	8.90 ± 0.3 V	RF AMPLIFIER 4
V612 Collector	5.90 ± 0.3 V	IF AMPLIFIER
V671 Collector	5.50 ± 1.1 V	RF AMPLIFIER 7
V874 Collector	5.20 ± 1.1 V	RF AMPLIFIER 8
V769 Collector	5.20 ± 1.1 V	RF AMPLIFIER 9
V801 Collector	5.20 ± 1.1 V	RF AMPLIFIER 11
V817 Collector	15.9 ± 0.3 V	RF AMPLIFIER 12
V832 Collector	15.9 ± 0.3 V	RF AMPLIFIER 13

### 7.4.5 Testing the Harmonic Filter Control

\_ Testing LPSELECT-0 ... LPSELECT-3 and the lines TPO to TP8.

RF frequency	2	LECT- 1 /11 - D111	174 = AT 1 STC - 4T		Remark
1560.00 MHz	0	0	0	1	Lowpass 1, Doubler range
1040.01 MHz	0	0	1	0	Lowpass 1, Doubler range Lowpass 2, Doubler range
780.00 MHz	0	0	0	1	Lowpass 1
520.00 MHz	0	0	1	0	Lowpass 2
390.00 MHz	0	0	1	1	Lowpass 3
260.00 MHz	0	1	0	0	Lowpass 4
195.00 MHz	0	1	0	1	Lowpass 5
130.00 MHz		1	1	1	
97.50 MHz	"	1	•	1	Lowpass 6
65.00 MHz	1 1	J.	7	1	Lowpass 7
	1	0	2	0	Lowpass 8
64.00 MHz	0	0	1	0	Lowpass 2, Mixer range

For output frequencies 65 MHz  $\leq f_{RF} \leq$  1040 MHz on the instrument, the output frequency is supplied by the synthesis module.

For output frequencies  $\rm f_{RF}>1040~MHz$  on the instrument, the synthesis module provides the half output frequency (520 MHz <  $\rm f_{SYN} \le 1040~MHz)$ .

### 7.4.6 Testing the RF Level at the Harmonic Filter Output

- Terminate the instrument output RF  $50\Omega$  with  $50\Omega$ .
- Setting: RF LEVEL 13 dBm (19 dBm with option SMY-B40).
- \_ The rectified RF voltage can be measured using special function 104.

Typical voltages are given in the table below:

RF frequency	Diagnostic voltage	e de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la constitue de la consti	
10 MHz	0.8 V		
100 MHz	0.6 V		
200 MHz	0.9 V		
400 MHz	1.1 V		
600 MHz	1.2 V		
800 MHz	0.8 V		
1000 MHz	1.1 V		
1040 MHz	0.9 V		
1041 MHz	1.5 V		
1200 MHz	1.1 V		
1400 MHz	1.0 V		
1600 MHz	1.0 V		
1800 MHz	1.0 V		
2000 MHz	1.8 V		
2080 MHz	1.9 V		

### 7.4.7 Testing Control of the Bandpass Filter Switches

\_ Testing BP10N, BP20N and BP30N.

RF frequency D112/3	BP10 D112		N. BP30N /11	Remark
1040.00 MHz	0	0	0	Bandpass filters switched off
1040.01 MHz	1	0	0	Bandpass 1 on
1310.40 MHz	0	1	0	Bandpass 2 on
1651.10 MHz	0	0	1	Bandpass 3 on

### 7.4.8 IF Amplification Adjustment

- ullet Connect a spectrum analyzer to the instrument output RF  $50\Omega$ .
- Setting: RF 10 MHz LEVEL 13 dBm (19 dBm with option SMY-B40)
- Measure RF signal, note RF level
- Decrease RF frequency by 1 Hz
- Adjust the RF level to the same value using the potentiometer R645
- Subsequent to adjustment, call the calibration routine LEVEL PRESET.

### 7.4.9 IF Detector Linearity Adjustment

- Setting: RF 9.9 MHz
  LEVEL +5.1 dBm(ll.1 dBm with option SMY-B40)
- Measure and note the output level at the RF output (= ref level)
- Setting: Switch on special function 1 (non-interrupting level setting)

  LEVEL -14.9 dBm (-8.9 dBm with option SMY-B40)
- Adjust R619 that the measured level is 20 dB below the previously measured reference level. Repeat adjustment once, since the reference value slightly changes with use of R619; after the adjustment, the accuracy of the 20-dB reduction shall reach ± 0.1 dB.

### 7.4.10 Detector Linearity Adjustment at the Output FOPU

Note: This adjustment must be carried out if option SMY-B40 is not fitted!

- Setting: RF 100 MHz LEVEL 13 dBm
- Measure and note the output level at the RF output of the instrument (= reference level)

• Setting: Switch on special function 1 (non-interrupting level

setting))

LEVEL -7 dBm

• Adjust R851 that the measured level is 20 dB below the previously measured reference level. Repeat adjustment once, since the reference value changes with use of R851; the accuracy of the 20-dB reduction shall reach ± 0.1 dB.

### 7.4.11 AM Depth Adjustment

• Setting: PRESET

LEVEL 7 dBm (+13 dBm with option SMY-B40)

AM EXT DC 100%

Switch on special function 105 (reference value of level control)

• Apply a dc voltage V = -1.000 V to AM EXT.

• Adjust to 0 V using POT R280.

### 7.5 Disassembly and Assembly

Remove upper instrument cover. The module is fixed to the support at the left and right sides. Subsequent to undoing these screws and disconnecting the coaxial connections at X224, X225 and X226, it can be taken out of its slot.

#### 7.6

#### Final Test

### 7.6.1 Maximum Output Level Check

• Setting:

LEVEL

19 dBm (25 dBm with option SMY-B40)

• Connect a power meter to X226 FOPU.

To prevent the sensor from being overdriven, it might be necessary to insert before a suitable RF-attenuator pad.

Vary the RF frequency from 5kHz to 2080 MHz.
 The RF level must remain > 15 dBm (20 dBm with option SMY-B40).

Typical levels are given in the table below:

	SMY02 without option SMY-B40	SMY02 with option SMY-B40
RF-frequency	output level	output level
10 MHz	19 dBm	21 dBm
200 MHz	19 dBm	25 dBm
400 MHz	19 dBm	24 dBm
600 MHz	20 dBm	25 dBm
800 MHz	18 dBm	26 dBm
1000 MHz	17 dBm	25 dBm
1200 MHz	19 dBm	24 dBm
1400 MHz	18 dBm	24 dBm
1600 MHz	17 dBm_	24 dBm
1800 MHz	16 dBm	23 dBm
2000 MHz	16 dBm	24 dBm
2080 MHz	16 dBm	24 dBm

### 7.6.2 Harmonics Suppression Check

Instrument without option SMY-B40:

• Setting:

LEVEL

10 dBm

• Connect a spectrum analyzer to X226 FOPU.

The level of the harmonics must be < -30 dBc.

Instrument with option SMY-B40:

• Setting:

LEVEL 16 dBm

Special 21 (ALC off)

As the connection from FOPU to the power module is undone for the measurement, the level control must be switched to sample-and-hold operation. This connection must be reestablished before any of the instrument settings are changed.

- Set measurement frequency
- Connect spectrum analyzer to XD226 FOPU The level of the harmonics must be <-25 dBc.

Typical values are given in the table below:

	SMY02 without	ption SMY-B40	SMY02 with option SMY-B40			
RF-frequency	2*fRF	3*frf	2*fRP	3*fRF		
1 MHz	-45 dBc	-40 dBc	-45 dBc	-48 dBc		
10 MHz	-50 dBc	-45 dBc	-48 dBc	-48 dBc		
200 MHz	-50 dBc	-45 dBc	-40 dBc	-50 dBc		
400 MHz	-45 dBc	-40 dBc	-35 dBc	-45 dBc		
600 MHz	-35 dBc	-40 dBc	-35 dBc	-50 dBc		
800 MHz	-35 dBc	-40 dBc	-35 dBc	-50 dBc		
1000 MHz	-35 dBc	-50 dBc	-32 dBc	-50 dBc		
1200 MHz	-35 dBc	-50 dBc	-32 dBc	-50 dBc		
1400 MHz	-40 dBc	-45 dBc	-32 dBc	-50 dBc		
1600 MHz	-45 dBc	-45 dBc	-32 dBc	-50 dBc		
1800 MHz	-45 dBc	-45 dBc	-32 dBc	-50 dBc		
2000 MHz	-35 dBc	-50 dBc	-35 dBc	-50 dBc		
2080 MHz	-45 dBc	-50 dBc	-45 dBc	-50 dBc		

## 7.6.3 Nonharmonics Suppression Check

Instrument without option SMY-B40:

• Setting:

RF

63 MHz

LEVEL

13 dBm

- Connect a spectrum analyzer to X226 FOPU.
- Test spurious responses with the subsequent frequencies: 703 MHz, 640 MHz, 136 MHz, 73 MHz, 10 MHz
  The level of the spurious signals must be < -70 dBc (typ. < -100 dBc).

Instrument with option SMY-B40:

• Setting:

LEVEL 19 dBm

Special 21 (ALC off)

As the connection from FOPU to the power module is undone for the measurement, the level control must be switched to sample-and-hold operation. This connection must be reestablished before any of the instrument settings are changed.

- Test spurious signals for the following frequencies: 703 MHz, 640 MHz, 136 MHz, 73 MHz, 10 MHz
- Set RF-frequency
- $\bullet$  Connect spectrum analyzer to X226 FOPU The level of the spurious signals must be < -70 dBc (typ. < -100 dBc).

### 7.6.4 Subharmonics Suppression Check

Instrument without option SMY-B40: Setting: LEVEL 13 dBm

• Connect a spectrum analyzer to X226 FOPU.

• Set RF frequency on the SMY and measure the level of the subharmonics with  $\rm f_{SUB1}$  and  $\rm f_{SUB2}(see\ table\ below)$  . The level must be  $<-40\ dBc$  .

Instrument with option SMY-B40:

• Setting:

LEVEL 19 dBm

Special 21 (ALC off)

As the connection from FOPU to the power module is undone for the measurement, the level control must be switched to sample-and-hold operation. This connection must be reestablished before any of the instrument settings are changed.

- Set RF frequency
- Connect a spectrum analyzer to X226 FOPU.
- Measure the level of the subharmonics with  $f_{\rm SUB1}$  and  $f_{\rm SUB2}$  (see table below). The level must be < -40 dBc.

RF frequency	fsub1	fsub2	2.25	Haraman I		
1040.01 MHz	520.005 MHz	1560.015 MHz				
1310.39 MHz	655.195 MHz	1965.585 MHz				
1310.40 MHz	655.200 MHz	1965.600 MHz				
1559.99 MHz	779.995 MHz	2339.985 MHz				
1560.00 MHz	780,000 MHz	2340.000 MHz				
1651.09 MHz	825.545 MHz	2476.635 MHz	1			
1651.10 MHz	825.550 MHz	2476.650 MHz				
2080.00 MHz	1040.000 MHz	3120.000 MHz				

Pin	Name	Input/Output	Origin/Dest.	Specified range	Signal description
X2A.01	BLANK	Input	Rear panel	HCMOS level	RF-level blanking
X2A.05	DETEXT	Input	PHOD	0 to 10 V	Detector voltage
		į l			option SMY-B40
X2A.07	AMMOD	Input	CPU X3.34	-1 V to 1 V	AM signal
X2A.12	SERCLK	Input	CPU X3.2	HCMOS level	Clock
X2A.14	SERDAT	Input	CPU X3.4	HCMOS level	Serial data
X2A.15	AT1STB	Input	CPU X3.16	HCMOS level	Strobe 1
X2A.17	HFINT	Output	CPU X3.20	HCMOS level	Interrupt level control
X2A.19	DIAG-5V	Output	CPU X3.6	-5V to 5V	Diagnostics
X2A. 22	VA24-P	Input	Power X21.22	23.4V to 24.6V	Analog supply voltage
X2A.24	VA15-P	Input	Power X21.13	14.80V to 15.75V	Analog supply voltage
X2A.25		ĺ			
X2A.28	VA-5P	Input	Power X21.5	5.10V to 5.25V	Analog supply voltage
X2A.30	VA15-N	Input	Power X21.20	-15.75V to -14.85V	Analog supply voltage
X224	FSYN	Input	YSYN X124	6 - 12dBm	65 - 1040 MHz
X225	REF640	Input	YSYN X125	9 - 12 dBm	640 MHz
X226	FOPU	Output	Attenuator X2	-6 to 20 dBm	5 kHz - 2.08 GHz



Schaltteillisten
numerisch geordnet
Part lists
in numerical order
Listes des pièces détachées
par numéros de référence

İ (<del>)</del>-5 •

Kennz. Comp. No.		nnung nation		Stock No.	Hersteller Manufacturer	Bezeichnung Designation		thaitan in Intainad in
•	XX VARIANTENE							
	IDENTIFICATION   VAR O2 = GRUN						-	
	MOD 02 = BASI	C_MODEL						
	VAR 03 = SMY1	12+SMY-B40 ERUESTET AUS						
	VAR	_						
	MOD 03 = SMY1							
	MOD	ERTED O. O2	1					
	VAR 04 = SMY4	4/45						
	MOD 04 = SMY4 VAR 06 = SMY4							
	SMY-	B40					İ	
	UMGE VAR	RUESTET AUS						
	MOD 06 = SMY4	X WITH OPT.						
	SMY-	B40 ERTED 0.MODO4	.		1		ļ	
	CONV	ERIED O. MODO						
C12	CC 47NF+-10%5		cc ·	0007.5195.00	PHILIPS_CO	2238 581 15645	ļ	
C13	CERAMIC CHIP CC 1NF+-1% 50		lcc (	0007.7398.00	PHILIPS CO	2222 863 *8102		
	SMD CERAMIC C	APACITOR				000 0102		
C14	NICHT BESTUEC			0007.5237.00	ח פפו ודאק	2238 581 15649		
17	CERAMIC CHIP	CAPACITOR			_			
C20	CE 220UF+-20% ELECTROLYTIC	•	CE	0008.7927.00	PANASONIC	ECA-1AFG221I		
C2 1	CE 10UF+-20%3	5V RD5,5XH6	(	OBO3.0667.00	NAT_PANASO	ECE-A1VKS-100		
C22	ELECTROLYTIC (   CE 10UF+-20%3		İ		} _	ECE-A 1VKS-100		
_	ELECTROLYTIC (	CAPACITOR						
C132	CC 100NF+-10%		Icc (	0007.5237.00	PHILIPS_CO	2238 581 15649		
C133	CC 100NF+-10%		cc e	0007.5237.00	PHILIPS_CO	223B 581 15649		
C149	CERAMIC CHIP ( CC 100NF+-10%							
154	CERAMIC CHIP					2238 581 15649		
C156	CC 100NF+-10%	50V X7R 1206	CC (	0007.5237.00	PHILIPS_CO	2238 581 15649		
C157	CERAMIC CHIP ( CC 100NF+-10%		cc d	0007.5237.00	PHILIPS CO	2238 581 15649		
	CERAMIC CHIP	CAPACITOR						
C158 162	CC 100NF+-10%	17	CC (	0007.5237.00	PHILIPS_CO	2238 581 15649		
0170	CC 100NF+-10%	50V X7R 1206	CC C	0007.5237.00	PHILIPS_CO	2238 581 15649		
C207	CERAMIC CHIP ( CE 10UF +-10%		CF 4	0007.7246.00	SPRAGUE	2930 106 X9 025	net	
	TANTALUM SMD-0	CAPACITOR	1			2500 100 AB 025	021	
20B	CC 2,7PF+-0,25 CERAMIC CHIP (		Icc (	0007.8188.00	MURATA	GRM42-6COG 2R7 C	50PT	
	NUR VAR/ONLY N	MOO: 02 04						
C208	CC 2,7PF+-0,25 CERAMIC CHIP (		Icc o	0007.8188.00	MURATA	GRM42-6COG 2R7 C	50PT	
	NUR VAR/ONLY							
	NICHT BESTUECH			2000 2000 22	MUDATA	001140 0000 000		
209	CC 22PF+-1%50V CERAMIC CHIP (		lee (	0099.8396.00	MURATA	GRM42-6COG 22OF	5OPT	
C219	CC 22PF+-1%50V	/ NPO 1206	cc c	0099.8396.00	MURATA	GRM42-6CDG 220F	50PT	
	CERAMIC CHIP ( NUR VAR/ONLY N							
C2 19	CC 33PF+-1%50V	/ NPO 1206	cc c	0099.8780.00	MURATA	GRM42-6COG 330F	50PT	
	CERAMIC CHIP ( NUR VAR/ONLY N							
C220	CC 270PF+-1%50	OV NPO 1206	cc c	0099.8867.00	PHILIPS_CO	2222 863 18271		
C22 1	CERAMIC CHIP (	CAPACITOR	Į				FORT	
UEE !	CC B,2PF+-0,25 CERAMIC CHIP (	CAPACITOR	الالا	0007.B242.00	HURATA	GRM42-6COG 8R2 C	וייטפ	
	NICHT BESTUECK							
	NOT FITTED	/ NPO 1206	cc c	0099.8396.00	MURATA	GRM42-6COG 220F	5OPT	
2240	CC 22FFT-1/2000		ι ` `					
	CERAMIC CHIP (	CAPACITOR	۔ مما	1000 044	LAND AVA	00040 0000		
		CAPACITOR DV NPO 1206	Į	0099.8415.00		GRM42-6COG 101F	50PT	
C242	CERAMIC CHIP C CC 100PF+-1%50 CERAMIC CHIP C CC 100NF+-10%5	CAPACITOR DV NPO 1206 CAPACITOR SOV X7R 1206	Į			GRM42-6COG 101F : 2238 5B1 15649	50PT	
C242 C244	CERAMIC CHIP ( CC 100PF+-1%50 CERAMIC CHIP ( CC 100NF+-10%5 CERAMIC CHIP (	CAPACITOR DV NPO 1206 CAPACITOR SOV X7R 1206 CAPACITOR	cc c	0007.5237.00	PHILIPS_CO	2238 5B1 15649	50PT	
C242 C244	CERAMIC CHIP C CC 100PF+-1%50 CERAMIC CHIP C CC 100NF+-10%5	CAPACITOR DV NPO 1206 CAPACITOR 50V X7R 1206 CAPACITOR 50V X7R 1206	cc c	0007.5237.00	PHILIPS_CO		5OPT	
C242 C244	CERAMIC CHIP C CC 100PF+-1%5C CERAMIC CHIP C CC 100NF+-10%5 CERAMIC CHIP C CC 100NF+-10%5	CAPACITOR DV NPO 1206 CAPACITOR 50V X7R 1206 CAPACITOR 50V X7R 1206	cc c	0007.5237.00	PHILIPS_CO	2238 5B1 15649	50PT	
C242 C244	CERAMIC CHIP C CC 100PF+-1%5C CERAMIC CHIP C CC 100NF+-10%5 CERAMIC CHIP C CC 100NF+-10%5	CAPACITOR DV NPO 1206 CAPACITOR 50V X7R 1206 CAPACITOR 50V X7R 1206	cc c	0007.5237.00	PHILIPS_CO PHILIPS_CO	2238 5B1 15649 2238 581 15649 Sachnu	Immer	Biatt-Nr. Paga
C240 C242 C244 C245	CERAMIC CHIP ( CC 100PF+-1%50 CERAMIC CHIP ( CC 100NF+-10%5 CERAMIC CHIP ( CC 100NF+-10%5 CERAMIC CHIP (	CAPACITOR DV NPO 1206 CAPACITOR SOV X7R 1206 CAPACITOR SOV X7R 1206 CAPACITOR Datum	cc c	0007.5237.00 0007.5237.00 Schalttelli	PHILIPS_CO PHILIPS_CO	2238 5B1 15649 2238 581 15649 Sachnu	ummer k No.	Paga

Kennz. Comp. No.		Benenn Designe				Sachnun Stock		Harsteller Manufacturer		eichnus		<del>(************************************</del>		eiten in eined in
C250		NF+-10%5	SOV >	(7R 1206	СС	0007.5	237.00	PHILIPS_CO						
264 C275		C CHIP C PF+-0.25		CITOR /NPO1206				MURATA			OG 8R2	C5OPT		
C280	CERAMI	C CHIP C F+-1%50V	APA(	CITDR	1			MURATA			OG 220F			
	CERAMIC	C CHIP C	APA(	CITDR	l									
C300	CERAMIC	C CHIP C	APA(		ICC	0099.8	1480.00	MURATA	GRM4	12-6C	DG 100	C5OPT		
C3O2		F+-1%50V C CHIP C			CC	0099.8	821.00	MURATA	GRM4	2-6C	OG 820F	50PT		
C3O3	CC 82P	F+-1%50V C CHIP C	NPC	1206	cc	0099.8	821.00	MURATA	GRM4	2-6C	OG 820F	50PT		
C313	CC 1001	NF+-10%5	K VO	(7R 1206	СС	0007.5	237.00	PHILIPS_CO	2238	581	15649			
C3 15		C CHIP C +-1% 50V			СС	0007.7	398.00	PHILIPS_CO	2222	863	*8102			
C316		RAMIC CA +-1% 50V						PHILIPS_CO						
C318	SMD CER	RAMIC CA	PACI	TOR				PHILIPS_CO				-		
	CERAMIC	C CHIP C	APAC	ITOR										
C3 19	CERAMIC	NF+-10%5 C CHIP C	APAC	ITOR	CC	0007.5	237.00	PHILIPS_CO	2238	581	15649			
C325		PF+-1%50 C CHIP C			CC	0099.8	415.00	MURATA	GRM4	2-6C	OG 101F	50PT		
C327	CC 1NF1	H-1% 50V RAMIC CA	NPO	1206	СС	0007.7	398.00	PHILIPS_CO	2222	863	*8102			
C328	CC 1NF+	H-1% 50V	NPO	1206	СС	0007.7	398.00	PHILIPS_CO	2222	863	*8102			
C329	CC 100N	RAMIC CA NF+-10%5	ov x	7R 1206	СС	0007.5	237.00	PHILIPS_CO	2238	581	15649			
C330		CHIP C NF+-10%5						PHILIPS_CO						
C340	CERAMIC	CHIP C	APAÇ	ITOR				PHILIPS_CO						
_	CERAMIC	CHIP C	APAÇ	ITOR	1									
C356	CERAMIC	+-1%50V CHIP C	APAC	ITOR				MURATA			OG 820F	- 1		
C357	_	:+-1%50V : CHIP C		. —	cc	0099.8	821.00	MURATA	GRM4	2-6C0	OG 820F	50PT		
C359	CC 100N	F+-10%5 CHIP C	ov x	7R 1206	CC	0007.5	237.00	PHILIPS_CO	2238	581	15649			
	NICHT 8	BESTUECK		-101										
C360		F+-1%50			СÇ	0099.8	850.00	PHILIPS_CO	2238	863	18221			
C361		CHIP C					- 1	PHILIPS_CO						
C362	CERAMIC	CHIP C	APAC	ITOR			- 4	PHILIPS_CO						
	CERAMIC	CHIP C	APAC	ITOR				_						
C400	CERAMIC	#F+-10%50 CHIP C	APAC	ITDR				PHILIPS_CO						
C401	SMD CER	-1% 50V AMIC CAI	PACI	TOR			1	PHILIPS_CO						
C402	CC 1NF+	-1% 50V	NPO	1206	СС	0007.7	398.00	PHILIPS_CO	2222	863	*8102			
C404	CC 100N	F+-10%50	OV X	7R 1206	СС	0007.5	237.00	PHILIPS_CO	2238	581	15649			
C405	CC 100N	F+-10%50	OV X	7R 1206	СС	0007.5	237.00	PHILIPS_CO	2238	581	15649			
C410		CHIP C/ -1% 50V			СС	0007.7	398.00	PHILIPS_CO	2222	863	*8102			
C412		AMIC CAP					- 1	PHILIPS_CO						
C417	CERAMIC	CHIP C/	APAC	ITOR				PHILIPS_CO						
	CERAMIC	CHIP C	APAC	ITOR				_						Ì
C440 442	CERAMIC	F+-10%50   CHIP C/	APAC	1	CC	JUU7.52	231.00	PHILIPS_CO	2238	581	15649			
C445	XX ENTH INCLUDE	IALTEN IN D IN	N											
C500	IN LEIT	ERPLATTE		1206	CC ·	0007 7	ദേള ഹ	PHILIPS_CO	2222	863	*810°			
C501	SMD CER	AMIC CAR	PACI	TOR	ļ									
	CERAMIC	F+-10%50	APAC		CC	.52	237.00	PHILIPS_CO	∠∠3 <b></b> 0	30 I	15049			
C502	INCLUDE													
C504		ERPLATTE		1206 i	СС	0007.7	00.888	PHILIPS_CO	2222	863	<b>*</b> 8102			
-		AMIC CAP												
MENP5	413	3PUA	Äi	Datum Date			Schaltteliki Parts list					ummer k No.		Biatt-Nr. Page
								<del> , ,</del>		400			C A	
<b>BOHDI</b>	E&SCH\	<b>NARZ</b>	28	16.09.97	E	E AUSGA	ANGSTEI	L 2.08GHZ		ıUb	2.700	D.U	ЭA	2+
NURUE								OBGHZ	1					ı

	Kannz. Comp. No.	Benennung Designation	Stock No.	Hersteller Menufacturer	Bazeichnung Designation	enthalten in
	C505	CC 3,3PF+-0,25 50VNP01206	CC 0007.8194.00		RM42-6COG 3R3 C5OPT	contained in
	C506	CERAMIC CHIP CAPACITOR CC 2,7PF+-0,25 50VNP01206	CC 0007.8188.00	MURATA GR	RM42-6COG 2R7 C50PT	
	C507	CERAMIC CHIP CAPACITOR CC 2,7PF+-0,25 50VNP01206	CC 0007.8188.00	MURATA GR	RM42-6COG 2R7 C50PT	
	C509	CERAMIC CHIP CAPACITOR CC 1NF+-1% 50V NPO 1206	CC 0007.7398.00			
	C510	SMD CERAMIC CAPACITOR CC 3,9PF+-0,25 50VNP01206	CC 0007.8207.00			
	C511	CERAMIC CHIP CAPACITOR CC 3,3PF+-0,25 50VNP01206			M42-6COG 3R9 C5OPT	ļ
Ì		CERAMIC CHIP CAPACITOR	CC 0007.8194.00		M42-6COG 3R3 C5OPT	
ı	C512	CC 3,3PF+-0,25 50VNP01206 CERAMIC CHIP CAPACITOR	CC 0007.8194.00	MURATA GR	M42-6CDG 3R3 C5OPT	
ı	C513	XX ENTHALTEN IN INCLUDED IN	•			
ļ	C514	IN LEITERPLATTE CC 1NF+-1% 50V NPO 1206	CC 0007.7398.00 F	PHILIPS CO 22	22 863 *8102	
1	C515	SMD CERAMIC CAPACITOR CC 5.6PF+-0.25 50VNP01206	CC 0007.8220.00 N		M42~6COG 5R6 C50PT	
1	C516	CERAMIC CHIP CAPACITOR CC 4,7PF+-0,25 50VNP01206	CC 0007.8213.00 M			
ı	C517	CERAMIC CHIP CAPACITOR CC 4,7PF+-0,25 50VNP01206			M42-6CDG 4R7C 50PT	
	C517	CERAMIC CHIP CAPACITOR	CC 0007.8213.00 N		M42-6COG 4R7C 50PT	
		CC 1NF+-1% 50V NPO 1206 SMD CERAMIC CAPACITOR	CC 0007.7398.00 P			
	C5 19	CC 1.8PF+-0,25 50VNP01206 CERAMIC CHIP CAPACITOR	CC 0007.8165.00 M		M42-6COG 1R8 C50PT	
	C520	CC 1,5PF+-0,25 50VNP01206 CERAMIC CHIP CAPACITOR	CC 0007.8159.00 M	MURATA GRI	M42-6COG 1R5 C50PT	
	C521	CC 1,5PF+-0,25 50VNPO1206 CERAMIC CHIP CAPACITOR	CC 0007.8159.00 M	IURATA GRI	M42-6COG 1R5 C50PT	
İ	C522	XX ENTHALTEN IN INCLUDED IN				
	C523	IN LEITERPLATTE XX ENTHALTEN IN				
	0020	INCLUDEO IN IN LEITERPLATTE				
	C524	XX ENTHALTEN IN			1	
	0505	INCLUDED IN IN LEITERPLATTE				
ľ	C525	XX ENTHALTEN IN INCLUDED IN				
Į	C526	IN LEITERPLATTE CC 100NF+-10%50V X7R 1206	CC 0007.5237.00 P	HILIPS CO 223	88 581 15649	
1	C527	CERAMIC CHIP CAPACITOR CC 1NF+-1% 50V NPO 1206	CC 0007.7398.00 P		The state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the s	
ı	C530	SMD CERAMIC CAPACITOR CC 1NF+-1% 50V NPO 1206	CC 0007.7398.00 P			
İ	C531	SMD CERAMIC CAPACITOR CC 1NF+-1% 50V NPO 1206	CC 0007.7398.00 Pi			
	C532	SMD CERAMIC CAPACITOR CC 12PF+-1% 50V NPO 1206	CC 0099.8744.00 M			
	C533	CERAMIC CHIP CAPACITOR CC 10PF+-0,25 50VNPO 1206			142-6COG 120 F50PT	
	C534	CERAMIC CHIP CAPACITOR	CC 0099.8480.00 MI		142-6COG 100 C50PT	
		CC 10PF+-0,25 50VNPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8480.00 MI		142-6COG 100 C50PT	
	C536	CC 1NF+-1% 50V NPO 1206 SMD CERAMIC CAPACITOR	CC 0007.7398.00 PF		1	
	C537	CERAMIC CHIP CAPACITOR	CC 0099.8767.00 MI		142-6COG 180F 50PT	
	C538	CC 12PF+-1% 50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8744.00 MI		42-6COG 120 F50PT	
	C539	CC 12PF+-1% 50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8744.00 ML		42-6COG 120 F50PT	
	C540	CC 1NF+-1% 50V NPO 1206 SMD CERAMIC CAPACITOR	CC 0007.7398.00 PI	HILIPS_CO 222	2 863 *8102	
	C545		CC 0099.8409.00 ML	URATA GRM	42-6COG 270F 50PT	
	C546		CC 0099.8767.00 MI	URATA GRM	42-6COG 180F 50PT	
	C547		CC 0099.8767.00 ML	URATA GRM	42-6COG 180F 50PT	
	C553	CC 1NF+-1% 50V NPO 1206	CC 0007.7398.00 PH	HILIPS_CO 222	2 863 *8102	
		SMD CERAMIC CAPACITOR				
					E	
	MENP5	413 3PUA ÄI Datum	Schaltteilliste Parts list fo		Sachnummer Stock No.	Blett-Nr. Page
	/êr					
	ROHDE	88CHWARZ   28   16.09.97	EE AUSGANGSTEIL	2.08GHZ	1062.7005.01	SA   3+

Kennz. Comp. No.		Sanann Dasigna				Sachnu Stock		Hersteller Manufacturer	Sazeichnu Designati			ilten in iined in
C560	_	+-1%50V	NP		CC C		8780.00			OG 330F 50PT		
C562	CC 27PF	+-1%50V	/ NPI	D 1206	cc o	099.	8409.00	MURATA	GRM42-60	COG 270F 50PT		
C564	CC 22PF	+-1%50V	NP(	1206	cc o	099.	8396.00	MURATA	GRM42-60	OG 220F 50PT		
C568		CHIP C		CITUR VNPO1206	cc o	007.	8220.00	MURATA	GRM42-60	COG 5R6 C5OPT		
C569		CHIP C -1% 50V			cc a	007.	7398.00	PHILIPS_CO	2222 863	3 *8102		
C570		AMIC CA +-1% 5		ITOR NPO 1206	cc o	099.	8744.00	MURATA	GRM42-60	OG 120 F50PT		
C571		CHIP C		CITOR								
	INCLUDE IN LEIT	O IN ERPLATT	E							ļ		
C573		+-1% 5 CHIP C		NPO 1206 CITOR	cc o	099.1	8750.00	MURATA	GRM42-60	OG 150F 50PT		
C575	CC 15PF		OV I	NPO 1206	cc o	099.1	8750.00	MURATA	GRM42-60	OG 150F 50PT		
C580	CC 15PF		1 VO	NPO 1206	cc o	099.	8750.00	MURATA	GRM42-60	OG 150F 50PT		
C582	CC 12PF		1 VO	NPO 1206	сс о	099.1	8744.00	MURATA	GRM42-60	OG 120 F50PT		
C583	XX ENTH	ALTEN I		22 10 K								
C584	IN LEIT	ERPLATT	_	/NPO1206	CC A	007 1	3220.00	MURATA	GRM42-60	OG 5R6 C5OPT		
C585	CERAMIC	CHIP C	APA(					PHILIPS_CO				
C599	CERAMIC XX ENTH	CHIP C	APA(		00 0		2207.00		2200 00.	.55 .5		
3503	INCLUDE IN LEIT	O IN										
C600		+- 1% 5	1 VO	NPO 1206	сс о	099.8	3767.00	MURATA	GRM42-60	OG 180F 50PT		
C601	CC 27NF CERAMIC	+-10%50	VX7F	1206	cc o	099.8	3473.00	PHILIPS_CO	2238 581	16633		
C602	CC 100P CERAMIC	F+-1%50	V NE	0 1206	сс о	099.8	3415.00	MURATA	GRM42-60	OG 101F 50PT		
C603	CC 18PF CERAMIC	+-1% 5	OV N	IPO 1206	CC O	099.8	3767.00	MURATA	GRM42-60	OG 180F 50PT		
C604		+-0,25	50VN	IPO 1206	CC O	099.8	3480.00	MURATA	GRM42-60	OG 100 C50PT		
C605		F+-0,25	50\	/NP01206	cc o	007.8	3213.00	MURATA	GRM42-60	OG 4R7C 50PT		
C606		F+-0,25	50\	/NP01206	cc o	007.8	3207.00	MURATA	GRM42-60	OG 3R9 C5OPT		
C607		F+-0,25	50\	/NP01206	cc o	007.8	3207.00	MURATA	GRM42-60	OG 3R9 C5OPT		
C608	CC 220P CERAMIC	F+-1%50	V NE	0 1206	CC O	099.8	3850.00	PHILIPS_CO	2238 863	18221		
C609		F+-10%5	א עם	7R 1206	cc o	007.5	237.00	PHILIPS_CO	2238 581	15649		
C610		F+-10%5	X V0	7R 1206	CC O	007.5	5237.00	PHILIPS_CO	2238 581	15649		
C611		+-0,25	4V0	IPO 1206	CC O	099.8	3480.00	MURATA	GRM42-60	OG 100 C50PT		
C612		F+-10%50	X VO	7R 1206	cc o	007.5	237.00	PHILIPS_CO	2238 581	15649		
C613		F+-10%50	X VO	7R 1206	CC O	007.5	237.00	PHILIPS_CO	2238 581	15649		
C614		F+-10%50	X VO	7R 1206	CC O	007.5	237.00	PHILIPS_CO	2238 581	15649		
C615		F+~ 10%50	X VO	7R 1206	CC O	007.5	237.00	PHILIPS_CO	2238 581	15649		
C616		F+-0,25	50\	/NPO1206	CC O	007.8	3171.00	MURATA	GRM42-6C	OG 2R2 C5OPT		
C617	CC 4,7P	F+-0,25	50\	/NPO1206	CC O	007.8	3213.00	MURATA	GRM42-6C	OG 4R7C 50PT		
C618	-	F+-0,25	50V	/NPO1206	CC O	007.8	3242.00	MURATA	GRM42-60	OG 8R2 C50PT		
C619	CC 8,2P	F+-0,25	50\	/NPO1206	CC O	007.8	3242.00	MURATA	GRM42-6C	OG 8R2 C5OPT		
C620		F+-0,25	50V	/NPO1206	CC O	007.8	3213.00	MURATA	GRM42-60	OG 4R7C 50PT		
C621	_	F+-0,25	50\	/NP01206	cc o	007.8	3159.00	MURATA	GRM42-60	OG 1R5 C5OPT		
MENP5	413	3PUA	ÄI	Datum Date			Schaltteilli Parts lis		ļ	Sachnummer Stock No.		Siatt-Nr. Page
ROHDI	E&SCHV	VARZ	28	16.09.97			SANGSTE I	L 2.08GHZ	10	62.7005.01	SA	4+
L					UU	1701	UNIT 2.	COUNT				<u> </u>

	Kennz. Comp. No.	Benen Design	nung	7/-	Τ		haummer lock No.	Hersteller Manufacturer		Bezelchn Designat			thaiten in ntained in
	C623	CC 220PF+-1%5	0V I	NPO 1206	CC			PHILIPS_CC					maniou in
	C625	CERAMIC CHIP	50	VNPO 1206	cc	009	9.8480.00	MURATA	GRI	M42-6	COG 100 C50P	T	
	C627		50V	NPO 1206	cc	009	9.8767.00	MURATA	GR	442-6	COG 180F 50P	т.	
	C628	CERAMIC CHIP (			cc	000	7.5237.00	  PHILIPS_CO					
İ	C629	CERAMIC CHIP (						SPRAGUE			010 D2T	ĺ	
	C631	TANTALUM SMO-6	CAP	ACITOR	1			PHILIPS_CO	_				
	C632	CERAMIC CHIP ( CC 47PF+-1%50)	CAPA	CITOR	١							_	
		CERAMIC CHIP (	CAPA	CITOR	1		9.8496.00				COG 470F 50P	T	
	C633	CC 100NF+-10%5	CAPA	CITOR	1			PHILIPS_CO	223	88 58	1 15649		
	C634	CE 10UF +-10% TANTALUM SMO-0	APA	CITOR	1			SPRAGUE			3 X9 025 D2T		
ı	C635	CC 100NF+-10%			i			PHILIPS_CO	223	88 58	1 15649		
	C636	CE 10UF +-10% TANTALUM SMD-0			CE	0007	7.7246.00	SPRAGUE	293	106	X9 025 02T	1	
	C637	CE 10UF +-10% TANTALUM SMO-0	25V	7343	CE	0007	7.7246.00	SPRAGUE	293	100	X9 025 D2T		
	C638	CC 100NF+-10%5 CERAMIC CHIP C	VO	X7R 1206	cc	0007	7.5237.00	PHILIPS_CO	223	8 581	15649		
ı	C639	CC 100NF+-10%E	VO	X7R 1206	cc	0007	7.5237.00	PHILIPS_CO	223	8 581	15649		
	C640	CC 4,7PF+-0,25	50	VNP01206	СС	0007	7.8213.00	MURATA	GRM	42-60	OG 4R7C 50P	Ţ	
١		NICHT BESTUECK		CITOR									
	C641	NOT FITTED CC 47PF+-1%50V			СС	0099	.8496.00	MURATA	GRM	42-60	OG 470F 50P	r	
	C642	CERAMIC CHIP C CC 68PF+-1%50V	NP	0 1206	СС	0099	.8815.00	MURATA	GRM	42-60	OG 680F 50P	Г	
	C643	CERAMIC CHIP C	NP	0 1206	cc	0099	.8815.00	MURATA	GRM	42-60	OG 680F 50P	Г	
6	C644	CERAMIC CHIP C CC 4,7PF+-0,25	50	VNP01206	CC	0007	.8213.00	MURATA	GRM	42-6C	OG 4R7C 50P1	1	
	1	CERAMIC CHIP C NICHT BESTUECK		CITOR									
ź	C645	NOT FITTEO CC 47PF+-1%50V	CO	G 1206	cc	0099	.8496.00	MURATA	GRM	49-6C	OG 470F 50P1		
20	C646	CERAMIC CHIP C CC 8,2PF+-0,25	-				.8242.00				OG 8R2 C50P1		
	C647	CERAMIC CHIP C CC 12PF+-1% 5	APA	CITOR			.8744.00					1	
	C650	CERAMIC CHIP C CC 100NF+-10%5	APA	CITOR				PHILIPS_CO			OG 120 F50P1		
ı	C651	CERAMIC CHIP C CC 100NF+-10%5	APA	CITOR				PHILIPS_CO					
	C652	CERAMIC CHIP C	APA	CITOR				PHILIPS_CO					
١	C653	CERAMIC CHIP C	APA	CITOR									
ı	C654	CERAMIC CHIP C.	APA	CITOR				PHILIPS_CO					ļ
		CC 10NF+-10%50 CERAMIC CHIP C	APA	CITOR			.8521.00				7R103K 50PT		l
	C656	CC 1NF+-1% 50V SMD CERAMIC CA	PAC	ITOR				PHILIPS_CO					
l	C660 663	CC 100NF+-10%5	APA	CITOR				PHILIPS_CO					Ì
	C664	CERAMIC CHIP CA	APA	CITOR							OG 120 F50PT		
	C668	CC 10PF+-0,25 !		CITOR							DG 100 C50PT		
	C669	CC 100NF+-10%50 CERAMIC CHIP CA		K7R 1206   CITOR	СС	0007	.5237.00	PHILIPS_CO	2238	3 581	15649		
		NICHT BESTUECK	Γ										
ı	C670	CC 100NF+-10%50 CERAMIC CHIP CA			CC	0007	.5237.00	PHILIPS_CO	2238	3 581	15649		
	C671	CC 100NF+-10%50 CERAMIC CHIP CA	C VC	K7R 1206	СС	0007	.5237.00	PHILIPS_CO	2238	3 581	15649		
	C672	CC 220PF+-1%50V CERAMIC CHIP CA	/ N	PO 1206	CC	0099	.8850.00	PHILIPS_CO	2238	863	18221		
	C673	CC 220PF+-1%50V CERAMIC CHIP CA	/ NI	0 1206	СС	0099	.8850.00	PHILIPS_CO	2238	863	18221		İ
		CERAMIC CHIP CA	ar A (	JUIL									
+	MENDE	419 9544	ų.	Datum			Schattteitl	ste für			Sachnummer		Blatt-Nr.
-	MENP5	413 3PUA	Äl	Date			Parts lis				Stock No.		Page
	<b>®</b>		28	16.09.97	E	E AU	SGANGSTE I	L 2.08GHZ		106	2.7005.0	1 SA	5+
	KUMDE	&SCHWARZ			_	HEOLI	T JIMIT O	00013					

Kannz. Comp. No.	Senennung Designation	Sechnummer Stock No.	Hersteller Manufecturer	Bezeichnung Designetion	enthalten in contained in
C674	CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	PHILIPS_CO	2238 581 15649	
C675	CERAMIC CHIP CAPACITOR CC 220PF+-1%50V NPD 1206	CC 0099.8850.00	PHILIPS CO	2238 863 18221	
C676	CERAMIC CHIP CAPACITOR CC 220PF+-1%50V NPO 1206		_		
	CERAMIC CHIP CAPACITOR	CC 0099.8850.00	PHILIPS_CO	2238 863 18221	
C677	CC 100NF+-10%50V X7R 1206 CERAMIC CHIP CAPACITOR	CC 0007.5237.00	PHILIPS_CO	2238 581 15649	
C678	CC 220PF+-1%50V NPO 1206	CC 0099.8850.00	PHILIPS_CO	2238 863 18221	
C679	CERAMIC CHIP CAPACITOR CC 1PF+-0.25 50V NPO 1206	CC 0099.8667.00	PHILIPS CO	2238 863 15108	
C680	CERAMIC CHIP CAPACITOR CC 1NF+-1% 50V NPO 1206		_		
C080	SMD CERAMIC CAPACITOR	CC 0007.7398.00	PHILIPS_CO	2222 803 *8102	
C681	CC 1NF+-1% 50V NPO 1206 SMD CERAMIC CAPACITOR	CC 0007.7398.00	PHILIPS_CO	2222 863 *8102	
C682	CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	PHILIPS_CO	2238 581 15649	
C700	CERAMIC CHIP CAPACITOR CC 1PF+-0,25 50V NPO 1206	CC 0099.8667.00	PHILIPS CO	2238 863 15108	
C701	CERAMIC CHIP CAPACITOR				
	CC 1NF+-1% 50V NPO 1206 SMD CERAMIC CAPACITOR	CC 0007.7398.00			
C702	CC 1NF+-1% 50V NPO 1206 SMD CERAMIC CAPACITOR	CC 0007.7398.00	PHILIPS_CO	2222 863 *8102	
0705	CC 56PF+-1%50V NPD 1206	CC 0099.8809.00	MURATA	GRM42-6COG 560F 50PT	
0707	CERAMIC CHIP CAPACITOR CC 220PF+-1%50V NPO 1206	CC 0099.8850.00	PHILIPS CD	2238 863 18221	
C708	CERAMIC CHIP CAPACITOR CC 82PF+-1%50V NPO 1206	CC 0099.8821.00		GRM42-6COG 820F 50PT	
	CERAMIC CHIP CAPACITOR				
0709	CC 82PF+-1%50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8821.00	MURATA	GRM42-6COG 820F 50PT	
C <b>7</b> 10	CC 1NF+-1% 50V NPO 1206	CC 0007.7398.00	PHILIPS_CO	2222 863 *8102	
714	SMD CERAMIC CAPACITOR CC 3,9PF+-0,25 50VNP01206	CC 0007.8207.00	MURATA (	GRM42-6COG 3R9 C5OPT	
7 15	CERAMIC CHIP CAPACITOR CC 220PF+-1%50V NPO 1206	CC 0099.8850.00		2020 062 10001	
	CERAMIC CHIP CAPACITOR			1	
720	CC 1NF+-1% 50V NPO 1206 SMO CERAMIC CAPACITOR	CC 0007.7398.00	PHILIPS_CO	2222 863 *8102	
721	CC 82PF+-1%50V NPO 1206	CC 0099.8821.00	MURATA (	GRM42-6COG 820F 50PT	
723	CERAMIC CHIP CAPACITOR CC 82PF+-1%50V NPO 1206	CC 0099.8821.00	MURATA (	GRM42-6COG 820F 50PT	
724	CERAMIC CHIP CAPACITOR CC 220PF+-1%50V NPO 1206	CC 0099.8850.00	PHILIPS CO S	2228 863 18221	
	CERAMIC CHIP CAPACITOR				
.725 .727	CC 1NF+-1% 50V NPO 1206 SMD CERAMIC CAPACITOR	CC 0007.7398.00	PHILIPS_CO 2	2222 863 *8102	
728	CC 100PF++1%50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8415.00	MURATA (	GRM42-6COG 101F 50PT	
729	CC 100PF+-1%50V NPO 1206	CC 0099.8415.00	MURATA (	GRM42-6COG 101F 50PT	
732	CERAMIC CHIP CAPACITOR CC 220PF+-1%50V NPO 1206	CC 0099.8850.00	PHILIPS CO S	2238 863 18221	
	CERAMIC CHIP CAPACITOR				
734	CC 82PF+-1%50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8821.00	MURATA (	GRM42-6COG 820F 50PT	
735	CC 1NF+-1% 50V NPO 1206 SMD CERAMIC CAPACITOR	CC 0007.7398.00	PHILIPS_CO :	2222 863 *8102	
736	CC 82PF+-1%50V NPO 1206	CC 0099.8821.00	MURATA (	GRM42-6COG 820F 50PT	
738	CERAMIC CHIP CAPACITOR CC 47PF+-1%50V CDG 1206	CC 0099.8496:00	MURATA (	GRM42-6COG 470F 50PT	
	CERAMIC CHIP CAPACITOR				
740	CC 220PF+-1%50V NPD 1206 CERAMIC CHIP CAPACITOR	CC 0099.8850.00			
741	CC 100NF+-10%50V X7R 1206 CERAMIC CHIP CAPACITOR	CC 0007.5237.00	PHILIPS_CO :	2238 581 15649	
742	CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	PHILIPS_CO 2	2238 581 15649	
	CERAMIC CHIP CAPACITOR NICHT BESTUECKT			turtement	
.740	NOT FITTED	00 0000 0050 00	D	2000 200 10001	
743	CC 220PF+-1%50V NPD 1206 CERAMIC CHIP CAPACITOR	CC 0099.8850.00	_		
744	CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	PHILIPS_CD 2	2238 581 15649	
	CERAMIC CHIP CAPACITOR NICHT BESTUECKT				
745	NOT FITTED CC 100NF+-10%50V X7R 1206	CC 0007.5237.00	אווודפ כח י	2238 581 15649	
5	CERAMIC CHIP CAPACITOR	0007.5207.00		1200 501 15045	
MENP5	413 3PUA Ai Datum	Schaltteilli	ste für	Sachnummer	Biatt-N
	413 3PUA Ai Dete	Parts lis	t for	Stock No.	Page

EE AUSGANGSTEIL 2.08GHZ

OUTPUT UNIT 2.08GHZ

1062.7005.01 SA

28 16.09.97

Kennz. Comp. No.	Benennung Designation	Sachnummer Stock No.	Hersteller Bezeichnung Menufecturer Designetion	enthalten in contained in
C747	CC 100PF+-1%50V NPO 1206	CC 0099.8415.00	MURATA GRM42-6COG 101F 50PT	
C748	CERAMIC CHIP CAPACITOR CC 100PF+-1%50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8415.00	MURATA GRM42-6COG 101F 50PT	
C750	CC 1NF+-1% 50V NPO 1206	CC 0007.7398.00	PHILIPS_CO 2222 863 *8102	
C751	SMO CERAMIC CAPACITOR CC 1NF+-1% 50V NPO 1206	CC 0007.7398.00	PHILIPS_CD 2222 863 *8102	
C753	SMO CERAMIC CAPACITOR CC 100NF+-10%50V X7R 1206 CERAMIC CHIP CAPACITOR	CC 0007.5237.00	PHILIPS_CD 2238 581 15649	
C762	CC 1NF+-1% 50V NPO 1206	CC 0007.7398.00	PHILIPS_CD 2222 863 *8102	
C765	SMD CERAMIC CAPACITOR CC 220PF+-1%50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8850.00	PHILIPS_CO 2238 863 18221	
C766	CC 56PF+-1%5OV NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8809.00	MURATA GRM42-6COG 560F 50PT	
C767	CC 1NF+-1% 50V NPO 1206 SMO CERAMIC CAPACITOR	CC 0007.7398.00	PHILIPS_CO 2222 863 *8102	
C768	CC 1NF+-1% 50V NPO 1206 SMD CERAMIC CAPACITOR	CC 0007.7398.00	PHILIPS_CO 2222 863 *8102	
C769	CC 220PF+-1%50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8850.00	PHILIPS_CO 2238 863 18221	
C770 772	CC 100NF+-10%50V X7R 1206 CERAMIC CHIP CAPACITOR	CC 0007.5237.00	PHILIPS_CD 2238 581 15649	
C773	CC 220PF+-1%50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8850.00	PHILIPS_CD 2238 863 18221	
C774	CC 220PF+-1%50V NPD 1206 CERAMIC CHIP CAPACITOR	CC 0099.8850.00	PHILIPS_CD 2238 863 18221	
C775	CC 100NF+-10%50V X7R 1206 CERAMIC CHIP CAPACITOR	CC 0007.5237.00	PHILIPS_CD 2238 581 15649	
C776	CC 33PF+-1%50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8780.00	MURATA GRM42-6COG 330F 50PT	
C783	CC 100PF+-1%50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8415.00	MURATA GRM42-6COG 101F 50PT	
C795	CC 1,2PF+-0,25 50VNP01206 CERAMIC CHIP CAPACITOR	CC 0007.8142.00	MURATA GRM42-6COG 1R2 C5OPT	
C796	CC 1,5PF+-0,25 50VNPO1206 CERAMIC CHIP CAPACITOR	CC 0007.8159.00	MURATA GRM42-6COG 1R5 C5OPT	
C797	CC 1,2PF+-0,25 50VNPO1206 CERAMIC CHIP CAPACITOR	CC 0007.8142.00	MURATA GRM42-6COG 1R2 C5OPT	
C798	CC 220PF+-1%50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8850.00	PHILIPS_CO 2238 863 18221	
C799	CC 220PF+-1%50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8850.00	PHILIPS_CO 2238 863 18221	
C800	CE 1UF +-10% 25V EIA3528 TANTALUM SMD-CAPACITOR	CE 0007.7217.00	SPRAGUE 293D 105 X9 025 82T	
C801	CC 100PF+-1%50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8415.00	MURATA GRM42-6COG 101F 50PT	
C802	CC 100PF+-1%50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8415.00	MURATA GRM42-6COG 101F 50PT	
CB03	CC 1NF+-1% 50V NPO 1206 SMO CERAMIC CAPACITOR	CC 0007.7398.00	PHILIPS_CO 2222 863 *8102	
C804	CC 1NF+-1% 50V NPO 1206 SMD CERAMIC CAPACITOR	CC 0007.7398.00	PHILIPS_CO 2222 863 *8102	
C805	CE 1UF +-10% 25V EIA3528 TANTALUM SMD-CAPACITOR	CE 0007.7217.00		
C806	CC 100NF+-10%50V X7R 1206 CERAMIC CHIP CAPACITOR	CC 0007.5237.00	PHILIPS_CO 2238 581 15649	
C808	CE 1UF +-10% 25V EIA3528 TANTALUM SMD-CAPACITOR	CE 0007.7217.00		
C8 10	CC 1PF+-0,25 50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8667.00	PHILIPS_CO 2238 863 15108	
	NICHT BESTUECKT NDT FITTEO			
CB 12	CC 1PF+-0,25 50V NPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8667.00	PHILIPS_CD 2238 863 15108	
C0 16	NICHT BESTUECKT NOT FITTEO	00 0000 0400 00	HUDATA DOMAS COSS 400 OTCO	
C816 C817	CC 10PF+-0.25 50VNPO 1206 CERAMIC CHIP CAPACITOR	CC 0099.8480.00		
C8 18	CC 3,9PF+-0,25 50VNPO1206 CERAMIC CHIP CAPACITOR CC 3,3PF+-0,25 50VNPO1206	CC 0007.8207.00		
C8 19	CERAMIC CHIP CAPACITOR CC 100PF+-1%50V NPO 1206	CC 0007.8194.00 CC 0099.8415.00		
C820	CERAMIC CHIP CAPACITOR CE 1UF +-10% 25V EIA3528			
V020	TANTALUM SMO-CAPACITOR	CE 0007.7217.00	SPRAGUE 293D 105 X9 025 B2T	
MENP5	413 3PUA At Datum	Schalttellis Paris list		Blatt-Nr. Page
<u>~</u>				
<b>⋘</b> ROHDE	28 16.09.97	EE AUSGANGSTEI	L 2.08GHZ 1062.7005.01	<b>SA</b> 7+

Kennz, Comp. No.		Benen Design			Sachnummer Stock No.	Harsteller Manufacturer	Bezeichnung Designation		alten in eined in
	NICHT NOT FI	BESTUECH	KT						
C821	CE 100	UF+-20%	25V RD8X9,5		0803.0580.00	MATSUSHITA	ECE-A1ESS-101		
C828	CE 1UF	+-10% 2	CAPACITOR 25V EIA3528	CE	0007.7217.00	SPRAGUE	293D 105 X9 025 B2T		
Ċ830			CAPACITOR SOV NPO 1206	lcc	0099.8667.00	PHILIPS CO	2238 863 1510B		
	CERAMI		CAPACITOR				2200 000 10100		
Coas	NOT FI	TTED			0007 0104 00	AU IDATA	00840 0000 000 0000		
C831	CERAMI	C CHIP C	5 50VNPO1206 CAPACITOR		0007.8194.00		GRM42-6COG 3R3 C5OPT		
C832			OV NPO 1206 CAPACITOR	cc	0099.8415.00	MURATA	GRM42-6COG 101F 50PT		
C833	TANTAL		25V EIA352B CAPACITOR	CE	0007.7217.00	SPRAGUE	293D 105 X9 025 B2T		
C834	NDT FI	TTED			0903 0590 00	MATCHCHITA	ECE_41ECC. 101		
	ELECTRO	OLYTIC C	25V RDBX9,5 CAPACITOR				ECE-A1ESS-101		
C835			SOV NPO 0603 NPACITOR		0009.8304.00	AVX	0603 5A *** BATOOJ		
C836			01.4339 2X3MM 25V EIA3528		0007.7217.00	SPRAGUE	293D 105 X9 025 B2T		
CB39	TANTAL	UM SMD-C	APACITOR SV EIA3528		0007.7217.00		293D 105 X9 025 B2T		
CB40	TANTALI	UM SMD-C	APACITOR SOV X7R 1206						
843	CERAMIC	C CHIP C	APACITOR				2238 5B1 15649		
C844		PF+-1% RAMIC-CA	50VNPO 0603 PACITOR		0009.4680.00		GRM39COG***F50PT		
CB46			OV X7R 1206 APACITOR	CC	0007.5237.00	PHILIPS_CO	2238 581 15649		
C847	CC 47PF	-+-1%50V	COG 1206	СС	0099.8496.00	MURATA	GRM42-6COG 470F 50PT		
C848	CC 10PF	+-0,1 5	OV NPO 0603	СС	0009.4567.00	AVX	0603 5A *** 8ATOOJ		
C849	CC 1PF+		OV NPO 1206	СС	0099.8667.00	PHILIPS_CO	2238 863 15108		
		C CHIP C BESTUECK	APACITOR T						
C850	NOT FIT		OV X7R 1206	CC	0007 5237 00	מזוושם כח	2238 581 15649		
852 C853	CERAMIC	CHIP C	APACITOR	İ					
	SMO CER	RAMIC CA	PACITOR				2222 863 *8102		
C854			OV X7R 1206 APACITOR	i		_	2238 581 15649		
C855			OV X7R 1206 APACITOR	CC	0007.5237.00	PHILIPS_CO	2238 581 15649		
CB70	CC 100N	√F+-10%5		cc	0007.5237.00	PHILIPS_CO	2238 5B1 15649		
C871	CC 100N	lF+-10%5	OV X7R 1206	СС	0007.5237.00	PHILIPS_CO	2238 581 15649		
C880	CC 100N	(F+−10%5		СС	0007.5237.00	PHILIPS_CO	2238 581 15649		
C881	CE 1UF	+-10% 2		CE	0007.7217.00	SPRAGUE	293D 105 X9 025 B2T		
C882			APACITOR NPO 1206	СС	0007.7398.00		2222 863 *B102		
C883		AMIC CA	PACITOR NPO 1206		i	_	2222 863 *B102		
CBB4	SMD CER	RAMIC CA					ļ		
	SMD CER	RAMIC CA	PACITOR				2222 863 *B102		
CBB5 B90	CERAMIC	CHIP C	APACITOR			_	223B 5B1 15649		
C892			OV X7R 1206 APACITOR	CC	0007.5237.00	PHILIPS_CO	2238 581 15649		
C893	CC 1NF+	_	NPO 1206	СС	0007.7398.00	PHILIPS_CO	2222 863 *B102		1
C894	CC 100P	F+-1%50		СС	0099.B415.00	MURATA	GRM42-6COG 101F 50PT		
D10				BL	0007.6827.00	PHILIPS	(PC)74HCT4051(T)		
D100	BL PC74		4X2IN SCHM	BL	0007.6340.00	PHILIPS	(PC)74HCT132(D/T)		
D102				BL	OB04.09 <b>7</b> 7.00		(PC)74HC4094(D/T)		
MENDS	440	2014	v. Datum		Schaltteilli	ste für	Sachnummer		Biett-Nr.
MENP5	413	3PUA	At Date		Parts lis		Stock No.		Page
ROHDE	E&SCH\	WARZ	28 16.09.97		E AUSGANGSTEI		1062.7005.01	SA	8+
				0	UTPUT UNIT 2.	08GHZ			

D105 D110 D111 D112 D115 D120 D140 D141 D145 D150 D200 D210 D220 D430 D431 D432	QUAD 2INPUT AND BL PC74HC094T BUS REGISTER BL PC74HC08T QUAD 2INPUT AND BL PC74HC86T QUAD 2INPUT EXO BL PC74HC4094T BUS REGISTER BJ DACB143 12B SERIAL D/A-(BS DG413DY 2A2R QUAD ANALOG CMO: BJ DACB143 12B SERIAL D/A-(BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BL PC74HCT42T BDECODER BL PC74HCT04T GHEXINVERTER	8ST.BUSREG  4X2IN.ANDG GATE  4X2IN.ANDG GATE  4X2IN.EXOR OR GATE  8ST.BUSREG  1X12B-DAC CONVERTER ANALOGSCH 1X12B-DAC CONVERTER 1X12B-DAC CONVERTER 1X12B-DAC CONVERTER ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH	BL BL BL	0804.09 0007.34 0007.35 0804.09 1012.95 1004.70 1004.70	977.00 486.00 511.00 977.00 510.00 510.00 510.00 510.00	PHILIPS_SE PHILIPS_SE PHILIPS_SE PHILIPS_SE PHILIPS_SE PMI SILICDNIX PMI	(PC)74HCOB(D/T) (PC)74HC4094(D/T) (PC)74HC0B(D/T) (PC)74HC0B(D/T) (PC)74HC4094(D/T) (PC)74HC4094(D/T) DACB143FS DG413DY DACB143FS DACB143FS DG413DY DG413DY			
D111 D112 D115 D120 D140 D141 D145 D150 D200 D210 D220 D430 D431	BL PC74HC4094T BUS REGISTER BL PC74HC08T QUAD 2INPUT AND BL PC74HC08T QUAD 2INPUT AND BL PC74HC86T QUAD 2INPUT EXO BL PC74HC4094T BUS REGISTER BJ DACB143 12B SERIAL D/A-( BS DG413DY 2A2R QUAD ANALOG CMOS BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL	8ST.BUSREG  4X2IN.ANDG GATE  4X2IN.ANDG GATE  4X2IN.EXOR OR GATE  8ST.BUSREG  1X12B-DAC CONVERTER ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH BCD/D. DEC	BL BL	0007.34 0007.35 0007.35 0804.09 1012.95 1004.70 1012.95 1004.70	486.00 486.00 511.00 577.00 510.00 510.00 510.00 510.00 510.00 510.00 510.00	PHILIPS_SE PHILIPS_SE PHILIPS_SE PHILIPS_SE PMI SILICONIX PMI PMI SILICONIX	(PC)74HC08(D/T) (PC)74HC0B(D/T) (PC)74HC86(D/T) (PC)74HC4094(D/T) DACB143FS DG413DY DACB143FS DACB143FS DG413DY			
D112 D115 D120 D140 D141 D145 D150 D200 D210 D220 D430 D431	BL PC74HCO8T QUAD 2INPUT AND BL PC74HCO8T QUAD 2INPUT AND BL PC74HCB6T QUAD 2INPUT EXO BL PC74HC4094T BUS REGISTER BJ DACB143 12B SERIAL D/A-( BS DG413DY 2A2R QUAD ANALOG CMO: BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BL PC74HCT04T HEXINVERTER BL PC74HCT04T HEXINVERTER BM SW-239 GAAS S	GATE  4X2IN.ANDG GATE  4X2IN EXOR OR GATE  8ST.BUSREG  1X12B-DAC CONVERTER ANALOGSCH 1X12B-DAC CONVERTER 1X12B-DAC CONVERTER ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH S.SWITCH ANALOGSCH S.SWITCH BCD/D. DEC	BL BL	0007.34 0007.35 0B04.05 1012.95 1004.70 1012.95 1004.70 1004.70	386.00 511.00 577.00 510.00 558.00 558.00 558.00	PHILIPS_SE PHILIPS_SE PHILIPS_SE PMI SILICONIX PMI PMI SILICONIX	(PC)74HC0B(D/T) (PC)74HC86(D/T) (PC)74HC4094(D/T) DACB143FS DG413DY DACB143FS DACB143FS DG413DY	)		
D115 D120 D140 D141 D145 D150 D200 D210 D220 D430 D431	BL PC74HC08T QUAD 2INPUT AND BL PC74HCBGT QUAD 2INPUT EXO BL PC74HC4094T BUS REGISTER BJ DACB143 12B SERIAL D/A- BS DG413DY 2A2R QUAD ANALOG CMO: BJ DAC8143 12B SERIAL D/A- BJ DAC8143 12B SERIAL D/A- BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BL PC74HCT04T HEXINVERTER BL PC74HCT04T HEXINVERTER BM SW-239 GAAS S	4X2IN.ANDG GATE 4X2IN EXOR OR GATE 8ST.BUSREG  1X12B-DAC CONVERTER ANALOGSCH 1X12B-DAC CONVERTER 1X12B-DAC CONVERTER ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH S.SWITCH ANALOGSCH S.SWITCH BCD/D. DEC	BL	0007.35 0B04.05 1012.95 1004.70 1012.95 1004.70 1004.70	511.00 977.00 510.00 958.00 958.00 958.00	PHILIPS_SE PHILIPS_SE PMI SILICONIX PMI PMI SILICONIX	(PC)74HC86(D/T) (PC)74HC4094(D/T) DACB143FS DG413DY DAC8143FS DACB143FS DG413DY	)		
D120 D140 D141 D145 D150 D200 D210 D220 D430 D431	BL PC74HCB6T QUAD 2INPUT EXO BL PC74HC4O94T BUS REGISTER BJ DACB143 12B SERIAL D/A- BS DG413DY 2A2R QUAD ANALOG CMO: BJ DAC8143 12B SERIAL D/A- BJ DAC8143 12B SERIAL D/A- BJ DAC8143 12B SERIAL D/A- BJ DAC8143 12B SERIAL D/A- BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BL PC74HCT04T DECODER BL PC74HCT04T HEXINVERTER BL PC74HCT04T HEXINVERTER BM SW-239 GAAS S	4X2IN EXOR OR GATE 8ST.BUSREG 1X12B-DAC CONVERTER ANALOGSCH S.SWITCH 1X12B-DAC CONVERTER 1X12B-DAC CONVERTER ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH BCD/D. DEC	BL	0804.09 1012.95 1004.70 1012.95 1012.95 1004.70 1004.70	977.00 510.00 558.00 510.00 510.00 558.00	PHILIPS_SE PMI SILICDNIX PMI PMI SILICONIX	(PC)74HC4094(D/T DACB143FS DG413DY DACB143FS DACB143FS DG413DY	)		
D140 D141 D145 D150 D200 D210 D220 D430 D431	BL PC74HC4094T BUS REGISTER BJ DACB143 12B SERIAL D/A-0 BS DG413DY 2A2R QUAD ANALOG CMOS BJ DAC8143 12B SERIAL D/A-0 BJ DAC8143 12B SERIAL D/A-0 BS DG413DY 2A2R QUAD ANALOG CMOS BS DG413DY 2A2R QUAD ANALOG CMOS BS DG413DY 2A2R QUAD ANALOG CMOS BS DG413DY 2A2R QUAD ANALOG CMOS BS DG413DY 2A2R QUAD ANALOG CMOS BS DG413DY 2A2R QUAD ANALOG CMOS BL PC74HCT04T 6 HEXINVERTER BL PC74HCT04T 6 HEXINVERTER BM SW-239 GAAS S	8ST.BUSREG  1X12B-DAC CONVERTER ANALOGSCH S.SWITCH 1X12B-DAC CONVERTER 1X12B-DAC CDNVERTER ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH BCD/D. DEC		1012.95 1004.70 1012.95 1012.95 1004.70 1004.70	510.00 958.00 610.00 958.00 958.00	PMI SILICDNIX PMI PMI SILICONIX	DACB143FS DG413DY DAC8143FS DACB143FS DG413DY	)		
D141 D145 D150 D200 D210 D220 D430 D431	BJ DACB143 12B SERIAL D/A- BS DG413DY 2A2R QUAD ANALOG CMO: BJ DAC8143 12B SERIAL D/A- BS DG413DY 2A2R QUAD ANALOG CMD: BS DG413DY 2A2R QUAD ANALOG CMD: BS DG413DY 2A2R QUAD ANALOG CMD: BS DG413DY 2A2R QUAD ANALOG CMD: BS DG413DY 2A2R QUAD ANALOG CMD: BL PC74HCT04T E BL PC74HCT04T E HEXINVERTER BL PC74HCT04T E HEXINVERTER BM SW-239 GAAS S	CONVERTER ANALOGSCH S.SWITCH 1X12B-DAC CONVERTER 1X12B-DAC CDNVERTER ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH BCD/D. DEC	BL	1004.70 1012.95 1012.95 1004.70 1004.70	05B.00 610.00 610.00 058.00	SILICDNIX PMI PMI SILICONIX	DG413DY DAC8143FS DACB143FS DG413DY			
D145 D150 D200 D210 D220 D430 D431	BS DG413DY 2A2R QUAD ANALOG CMO: BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BS DG413DY 2A2R QUAD ANALOG CMO: BL PC74HCT42T E DECODER BL PC74HCT04T E HEXINVERTER BL PC74HCT04T E HEXINVERTER BM SW-239 GAAS S	ANALOGSCH S.SWITCH 1X12B-DAC CONVERTER 1X12B-DAC CDNVERTER ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH BCD/D. DEC	BL	1012.95 1012.95 1004.70 1004.70	510.00 510.00 558.00 558.00	PMI PMI SILICONIX	DAC8143FS DACB143FS DG413DY			
D150 D200 D210 D220 D430 D431	BJ DAC8143 12B SERIAL D/A-( BJ DAC8143 12B SERIAL D/A-( BS DG413DY 2A2R QUAD ANALOG CMOS BS DG413DY 2A2R QUAD ANALOG CMOS BS DG413DY 2A2R QUAD ANALOG CMOS BL PC74HCT42T E DECODER BL PC74HCT04T E HEXINVERTER BL PC74HCT04T E HEXINVERTER 8M SW-239 GAAS S	1X12B-DAC CONVERTER 1X12B-DAC CDNVERTER ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH BCD/D. DEC	BL	1012.95 1004.70 1004.70	510.00 958.00 958.00	PMI SILICONIX	DACB143FS DG413DY			
D200 D210 D220 D430 D431	BJ DAC8143 12B SERIAL D/A-( BS DG413DY 2A2R QUAD ANALOG CMDS BS DG413DY 2A2R QUAD ANALOG CMDS BS DG413DY 2A2R QUAD ANALOG CMDS BL PC74HCT42T E DECODER BL PC74HCT04T E HEXINVERTER BL PC74HCT04T E HEXINVERTER BM SW-239 GAAS S	1X12B-DAC CDNVERTER ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH BCD/D. DEC	BL	1004.70 1004.70	58.00 58.00	SILICONIX	DG413DY			
D210 D220 D430 D431	BS DG413DY 2A2R QUAD ANALOG CMDS BS DG413DY 2A2R QUAD ANALOG CMDS BS DG413DY 2A2R QUAD ANALOG CMDS BL PC74HCT42T E DECODER BL PC74HCT04T E HEXINVERTER BL PC74HCT04T E HEXINVERTER 8M SW-239 GAAS S	ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH BCD/D. DEC	BL	1004.70	58.00		•	ļ		
D220 D430 D431	BS DG413DY 2A2R QUAD ANALOG CMOS BS DG413DY 2A2R QUAD ANALOG CMOS BL PC74HCT42T E DECODER BL PC74HCT04T E HEXINVERTER BL PC74HCT04T E HEXINVERTER BM SW-239 GAAS S	ANALOGSCH S.SWITCH ANALOGSCH S.SWITCH BCD/D. DEC	BL	1004.70		SILICONIX	DG413DY			
D430 D431	QUAD ANALOG CMOS BS DG413DY 2A2R QUAD ANALOG CMOS BL PC74HCT42T E DECODER BL PC74HCT04T E HEXINVERTER BL PC74HCT04T E HEXINVERTER 8M SW-239 GAAS S	S.SWITCH ANALOGSCH S.SWITCH BCD/D. DEC	BL	1004.70						
D431	QUAD ANALOG CMDS BL PC74HCT42T E DECODER BL PC74HCT04T E HEXINVERTER BL PC74HCT04T E HEXINVERTER 8M SW-239 GAAS S	S.SWITCH BCD/D. DEC	BL			SILICONIX	DG413DY			
D431	DECODER BL PC74HCTO4T 6 HEXINVERTER BL PC74HCTO4T 6 HEXINVERTER 8M SW-239 GAAS S		1	-0007 . 69		PHILIPS	(PC)74HCT42(T)			
	HEXINVERTER BL PC74HCT04T 6 HEXINVERTER 8M SW-239 GAAS S		RI				(PC)74HCT04(D/T)			
U7U4	HEXINVERTER 8M SW-239 GAAS S	6XINVERT	1							
D759			"				(PC)74HCTO4(D/T)			
				OB53.55			SW239			
D760	BM SW-239 GAAS S GAAS RF-SWITCH		1	0853.55			SW239			
D800	BM SW-239 GAAS S GAAS RF-SWITCH	SPDTSWITCH		0853.55	79.00	ANZAC	SW239			
L20	LD 10 UH 10% 3R3	3 144 MA	LD	0026.41	84.00	DALE	IM2	13		
L21	CHOKE LD 470NH 10% C	D,15A 1210	LD	0007.99	26.00	SIEMENS	882422-A3471-K 100			
L22	SMD-INDUCTOR LD 470NH 10% C	D, 15A 1210	LD	0007.99	26.00	SIEMENS	882422-A3471-K100			
L300	SMD-INDUCTOR LD 220NH 10% C	),2BA 1210	LD	0520.79	11.00	SIEMENS	B82422-A3221-K100	,		
L301	SMD-INDUCTOR	0.60A 1210					882422-A3220-K 100			
L305	SMD-INDUCTOR LD 1,00UH10%1,00	DOHMO.39OA	LD	0067.28			IM2			
L325	CHOKE LD 1,00UH10%1,00			0067.28			IM2			
L340	CHOKE LD 1,00UH10%1,00			0067.28			IM2			
L350	CHOKE XX ENTHALTEN IN	,		0007.120		DALL	I In Z			
	INCLUDED IN IN LEITERPLATTE							1		
L351	LD 1,00UH10%1,00 CHOKE	DHMO,390A	LD	0067.286	33.00	DALE	IM2	İ		
	NICHT BESTUECKT									
L353	NDT FITTED LD 1,00UH10%1,00	OHMO,390A	LD	0067.286	3.00	DALE	IM2			
	CHDKE NICHT BESTUECKT									
L355	NDT FITTED LD 220NH 10% O	,28A 1210	LD	0520.79	11.00	SIEMENS	BB2422-A3221-K100	,		
L360	SMD-INDUCTDR LD 1,00UH10%1,00	ODHMO,390A	LD	0067.286	33.00	DALE	IM2			
L361	CHOKE LD 1,00UH10%1,00	DHMO,390A	LD	OO67.2B	3.00	DALE	IM2			
L380	CHOKE XX ENTHALTEN IN									
	INCLUDED IN IN LEITERPLATTE									
L400	LD 0,82UH10%0,B5 CHOKE	DHMO,420A	LD	0067.2B	57.00	DALE	IM2			
MENP5	413 3PUA ة	Datum		s	chaltta Hils		Sachnur	nmer	11	Blatt-Nr.
	. TO OTOK A	N Date			Parts list		Stock			Paga
ROHDI	&SCHWARZ	B 16.09.97		E AUSGA! UTPUT UI		L 2.OBGHZ	1062.7005	.01 S	A	9+

095.0028~0693

Kennz, Comp. No.	Benennung Designation		Sechnummer Stock No.	Hersteller Manufecturer		ezeichnung esignation		alten in ained in	
L410	LD 0,68UH10%0,600HM0,5	OOA LI	0067.2840.00		IM2	-			
L416	CHOKE LD 1,00UH10%1,00DHM0,3	BOA LI	0 0067.2863.00	DALE	IM2				
L417	CHOKE LD 1,00UH10%1,000HMO,3	BOA LI	0 0067.2863.00	DALE	IM2	-			
Ĺ431	CHOKE LD 1UH 10% 0,38A 1	210 LI	6006.0130.00	SIEMENS	B82	422-A1102-K100			
L432	SMD-INDUCTOR LD 1UH 10% 0,38A 1	210 LI	0 6006.0130.00	SIEMENS	B82	422-A1102-K100			
L500	SMD-INDUCTOR LD 1,20UH10%O,180HMO,6	2OA  LI	0 0067.2870.00	DALE	IM2				
L505	CHOKE LD 100NH 10% 0,080HM 1	.4A L	0 0067.2740.00	DALE	IM2				
L510	CHDKE LD 0,33UH10%0,22DHM0,B	BOA LE	0 0067.2805.00	DALE	IM2				
L517	CHOKE LD 0,15UH10%0,100HM1,2	BOA LE	0067.2763.00	DALE	IM2				
L520	CHOKE LD 0,B2UH10%0,850HM0,4	OA LE	0 0067.2857.00	DALE	IM2				
L530	CHOKE LD 3,30UH10%0,850HM0,2	SSA LE	0067.2928.00	DALE	IM2				
L532	CHOKE LD 22NH 10% 0,60A 1	10	1002.4897.00	SIEMENS	BB2	422-A3220-K100		1	
534 L536	SMD-INDUCTOR LD 3,30UH10%0,850HM0,2	5A LD	0067.292B.00	DALE	IM2				
L537	CHOKE   LD 22NH 10% 0,60A 1	10	1002.4897.00	SIEMENS	B82	422-A3220-K 100			
L538	SMD-INDUCTOR LD 47NH 10% 0,51A 1	10	0008.5976.00	SIEMENS	B82	422-A3470-K100			
L539	SMO-INOUCTOR LO 47NH 10% 0,51A 1 SMD-INDUCTOR	10	000B.5976.00	SIEMENS	B82	122-A3470~K100			
L540 542	LD 22NH 10% 0,60A 1 SMD-INOUCTOR	10	1002.4897.00	SIEMENS	882	122-A3220-K100			
L543	LD 3,30UH10%0,850HM0,2	5A LD	0067.2928.00	DALE	IM2				
L544	LO 22NH 10% 0,60A 1: SMO-INOUCTOR	10	1002.4897.00	SIEMENS	B824	122-A3220-K 100			
L545 547	LO 47NH 10% 0,51A 1: SMO-INOUCTOR	10	0008.5976.00	SIEMENS	8824	122-A3470-K100		ĺ	
L548	LD 22NH 10% 0,60A 18	10	1002.4897.00	SIEMENS	8824	122-A3220-K100			
L549 551	LO 22NH 10% O,60A 1: SMO-INOUCTOR	10	1002.4897.00	SIEMENS	B824	322-A3220-K100			
L553	LD 3,30UH10%0,850HMO,20	5A LO	0067.2928.00	DALE	IM2				
L559	LD 22NH 10% 0,60A 1: SMD-INOUCTOR	10	1002.4897.00	SIEMENS	B824	22-A3220-K100		1	
L560	LD 47NH 10% 0,51A 1: SMO-INDUCTOR	10	0008.5976.00	SIEMENS	B824	22-A3470-K100			
L561	LD 22NH 10% 0,60A 1: SMD-INDUCTOR	10	1002.4897.00	SIEMENS	B824	22-A3220-K100			
L562	LD 100NH 10% 0,44A 12 SMD-INDUCTDR	10 LD	0007.9249.00	SIEMENS	8824	22-A3101-K100			
L563	LD 47NH 10% 0,51A 12 SMD-INDUCTDR	10	0008.5976.00	SIEMENS	BB24	22-A3470-K100			
L564	LD 100NH 10% 0,44A 12 SMD-INDUCTOR		0007.9249.00	SIEMENS	B824	22-A3101-K100			
L565	LD 47NH 10% 0,51A 12 SMD-INDUCTOR		0008.5976.00			22-A3470-K100		ļ	
L566	LD 47NH 10% 0,51A 12 SMD-INDUCTOR		0008.5976.00		B824	22-A3470-K100			
L568	LD 3,30UH10%0,85DHM0,2E CHOKE		0067.2928.00		IM2				
L570 572	LD 22NH 10% 0,60A 12 SMD-INDUCTOR		1002.4B97.00			22-A3220-K100			
L5B0	LD 22NH 10% 0,60A 12 SMD-INDUCTOR		1002.4B97.00			22-A3220-K100			
L5B3	LD 22NH 10% 0,60A 12 SMD-INDUCTOR		1002.4897.00			22-A3220-K100			
L584	LD 22NH 10% 0,60A 12 SMD-INDUCTDR	1	1002.4B97.00			22-A3220-K 100			
L585	LD 1UH 10% 0,38A 12 SMD-INDUCTOR		6006.0130.00			22-A1102-K100			
L600 602	LD 1,00UH10%1,000HM0,38 CHDKE		0067.2863.00		IM2				
L604	LD 1UH 10% 0,3BA 12 SMD-INDUCTOR	IO  LD	6006.0130.00	SIEMENS	B824	22-A1102-K100			
MENP5	413 3PUA ÄI Datu		Schallteilli Parts list			Sachnummer Stock No.		Blatt-Nr. Page	
ROHDI	2B 16.09	.97	EE AUSGANGSTEI	L 2.OBGHZ		1062.7005.01	SA	10+	
OUTPUT UNIT 2.08GHZ									

	Kennz. Comp. No.	Benen Design				Sachnummer Stock No.	Hersteller Manufacturer		lezeichnung Designation		alten in ained in
	L608	LD 12NH 10%		70A 1210		1002.4900.00			2422-A3120-K100		
Í	L610	SMD-INDUCTOR LD 12NH 10%	0	70A 1210		1002.4900.00	SIEMENS	B82	2422-A3120-K100		
l	L612	SMD-INDUCTOR LD 1UH 10%	0,	38A 1210	LD	6006.0130.00	SIEMENS	B83	2422-A 1 102-K 100		;
	L613	SMD-INDUCTOR LD 1UH 10%	0,	38A 1210	LD	6006.0130.00	SIEMENS	882	2422-A1102-K100		
	L630	SMD-INDUCTOR LD 47NH 10%	0,	51A 1210		0008.5976.00	SIEMENS	882	2422-A3470-K100		
	L632	SMD-INDUCTOR LD 22NH 10%	٥.	60A 1210		1002.4897.00			2422-A3220-K100		
١	L633	SMD-INDUCTOR LD 22NH 10%	•	60A 1210	ĺ	1002.4897.00			2422-A3220-K100		
	L642	SMD-INDUCTOR LD 1,00UH10%1,	-		   	0067.2863.00		IM2			
	L643	CHDKE LD 0,27UH10%0,			ĺ	0067.2792.00		IM2			
	L645	CHOKE				0067.2763.00					
١		LD 0,15UH10%0, CHOKE						IM2			
	L647	LD O,18UH10%O, CHOKE		•	l	0067.2770.00		IM2			Ì
	L649	LD O,15UH10%O, CHOKE		•	ILD	0067.2763.00		IM2			
ı	L6SO	LD 22NH 10% SMD-INDUCTOR		60A 1210		1002.4897.00		882	422-A3220-K100		
	L651	LD 22NH 10% SMD-INDUCTOR		60A 1210		1002.4897.00		882	422-A3220-K 100		
	L660 663	LD 1UH 10% SMD-INDUCTOR	0,	38A 1210	LD	6006.0130.00	SIEMENS	882	422-A1102-K100		
	L668	LD 1UH 10% SMD-INDUCTDR	Ο,	38A 1210	LD	6006.0130.00	SIEMENS	882	422-A1102-K100		
ı	L669	LO 1,000H10%1, CHOKE	000	HMO,390A	LD	0067.2863.00	DALE	IM2	·		
ı	L670	LO 1UH 10% SMD-INDUCTOR	٥,	38A 1210	LD	6006.0130.00	SIEMENS	882	422-A1102-K100		
ı	L671	LO 1UH 10% SMO-INDUCTOR	٥,	38A 1210	LD	6006.0130.00	SIEMENS	882	422-A1102-K100		
1	L672	LO 1,00UH10%1, CHOKE	000	HMO,390A	LD	0067.2863.00	OALE	IM2			
ı		NICHT BESTUECK NOT FITTEO	Т			1			1 1		
ı	L673	LD 1,00UH10%1, CHOKE	000	HMO,390A	LO	0067.2863.00	DALE	IM2			
1		NICHT BESTUECK	Т								
Ì	L674	LO 0,82UH10%0, CHOKE	850	HMO,420A	LD	0067.2857.00	OALE	IM2			Ì
I	L67S	LD 1,00UH10%1,	000	HMO,390A	LO	0067.2863.00	OALE	IM2			
ı	L705	LO 220NH 10% SMD-INOUCTOR	0,	28A 1210	LO	0S20.7911.00	SIEMENS	882	422-A3221-K100		
	L706	LO 220NH 10%	٥,	28A 1210	LD	OS20.7911.00	SIEMENS	882	422-A3221-K100		
	L709	SMD-INDUCTOR LD 4,7UH 10% SMD-INDUCTOR	٥,	1SA 1210	LD	0008.1687.00	SIEMENS	B82	422-A1472-K100		
Ì	L714	LD 100NH 10%	0,	44A 1210	LD	0007.9249.00	SIEMENS	882	422-A3101-K100		1
	L720	SMD-INDUCTOR LD 4,7UH 10%	٥,	15A 1210	LD	0008.1687.00	SIEMENS	B82	422-A 1472-K 100		
	L727	SMD-INDUCTOR LD 1UH 10%	0,	38A 1210	LD	6006.0130.00	SIEMENS	882	422-A 1 102-K 100		
	L730	SMD-INDUCTOR LD 100NH 10%	0,4	44A 1210	LĐ	0007.9249.00	SIEMENS	B82	422-A3101-K100		ł
	L732	SMD-INDUCTOR LD 4,7UH 10%	٥,	1SA 1210	LD	0008.1687.00	SIEMENS	B82	422-A1472-K100		
	L738	SMD-INDUCTOR LD 100NH 10%	0,	44A 1210	LD	0007.9249.00	SIEMENS	B82	422-A3101-K100		
	L739	SMD-INDUCTOR LD 100NH 10%	0,4	44A 1210	LD	0007.9249.00	SIEMENS	882	422-A3101-K100		
	L740	SMD-INDUCTOR LD 0,82UH10%0,8	3 <b>5</b> DI	HMO,420A	LĐ	0067.2857.00	DALE	IM2			
		CHOKE NICHT BESTUECK	r								
l	L742	NOT FITTED LD 1,00UH10%1,0	DODI	-MO,390A	LĐ	0067.2863.00	DALE	IM2			
		CHDKE NICHT BESTUECK	г			}					
				Ì							
F	145115-	440 05	T	Detum		Schaltteillis	ite für		Sachnummer		Blatt-Nr.
F	MENP5	413 3PUA	Äl	Date		Parts list			Stock No.		Page
	<b>*</b>		28	16.09.97	E	E AUSGANGSTEI	L 2.08GHZ		1062.7005.01	SA	11+
	KUMDE	E&SCHWARZ			D	UTPUT UNIT 2.	08GHZ				

Kennz. Comp. No.		Benennu Designat			Sechnummer Stock No.	Hersteller Manufecturer		zeichnung ssignetion		alten in eined in
L748	NDT FITTED XX ENTHALT	EN IN	1							
1354	INCLUDED I	LATTE			0000 0100					
L754 756	SMD-INDUCT	DR	0,38A 1210	ļ	6006.0130.00		B82	422-A 1 102-K 100		
L765 768	LD 1,00UH1 CHDKE	0%1,0	AOPE, OMHOO	LD	0067.2863.00	DALE	IM2			
L770	LD 1,00UH1 CHOKE		OODHMO,390A	LD	0067.2863.00	DALE	IM2			
L771	CHDKE	0%1,0	OODHMO,390A	LD	0067.2863.00	DALE	IM2	'n		
L800	NICHT BEST				0067 0057 00	DALE.	****			
L801	CHDKE		5DHMO,420A ODHMO,390A		0067.2857.00 0067.2863.00		IM2			
L816	CHDKE	•	-				IM2	100 10100 1110		
	LD 12NH 10	DR	0,70A 1210		1002.4900.00			422-A3120-K100		
L8 17	LD 3,9MH O INTERFERENCE IN LEITERPH	CE CH	DKE		1020.5256.00	SIEMENS	B82	500-C-A2		
L8 1B	LD SMD-DR.			1	1085.1661.00	PHILIPS	WBS	2.5-5/4.8/10-4B1		
L8 19	LD 2,2UH 10 SMD-INDUCTO		0,27A 1210	LD	0520.7B70.00	SIEMENS	B824	122-A 1222-K 100		
L829	LD SMD-DR.		OHM 100MH		1085.1661.00	PHILIPS	WBS2	2.5-5/4.8/10-4B1		
L830	LD 2,2UH 10		0,27A 1210	LD	0520.7870.00	SIEMENS	B824	122-A1222-K100		
L831	SMD-INDUCTO LD 3,9MH O INTERFERENCE	,2A 20 CE CH			1020.5256.00	SIEMENS	8825	500-C-A2		
L840		<b>)%</b> (	0,38A 1210	LD	6006.0130.00	SIEMENS	B824	122-A 1 102-K 100		
L841		<b>)%</b> (	0,38A 1210	LD	6006.0130.00	SIEMENS	8824	22-A1102-K100		
L845	LD 100UH 10	0%	0,06A 1210	LD	0007.9261.00	SIEMENS	8824	22-A1104-K100		
L880	LD 1,20UH10		80HMO,620A	LD	0067.2870.00	DALE	IM2			
L885	CHOKE LD 1UH 10 SMD-INDUCTO		O,38A 1210	LD	6006.0130.00	SIEMENS	8824	22-A1102-K100		
N20	BD TLO74ACE		XFET OPAMP		0007.7B23.00	TEXAS	TL07	4A(CD)		
N130	OPERATIONAL BD NE5532D	:	2XLN OPAMP		0007.7798.00	SIGNETICS	NE55			
N131	DPERATIONAL BD NE5532D	:	2XLN OPAMP		0007.7798.00	SIGNETICS	NE55	32D		
N223	DPERATIONAL BO TLO72ACD		LIFIER KFET OPAMP		0803.1057.00	TEXAS	TL 0	72 ACDR		
N22B	DPERATIONAL BD TL072ACD		LIFIER KFET DPAMP	Ì	0803.1057.00			72 ACDR		
N235	OPERATIONAL BD NE5534D	. AMPL	IFIER OPAMP		OB15.7555.00			34(D)		
N275	DPERATIONAL BD TLO72ACD				OBO3.1057.00			72 ACDR		
N276	OPERATIONAL BD TLO72ACD	. AMPL			OBO3.1057.00			72 ACDR		
N300	OPERATIONAL BM MSAO486	AMPL	LIFIER		0846.4293.00		MSA-			
	BRDADBAND A NICHT BESTU	MPLIF	· · · · · · · · · · · · · · · · · · ·		23 10.7230.00	STORIEN	mon"	U-100		
N360	NDT FITTED BM MSA1105		-1.3G MMIC		1051.4051.00	AVANTEK	MSA-	1 105-TR1		
N600	IC MICROWAV BO TLO74ACD	4)	KFET OPAMP		0007.7823.00	TEXAS	TL07	4A(CD)		
N610	DPERATIONAL BO AD744KR		IFIER FET OPAMP		0854.1754.00	ANALDG_DEV	(AD)	744KR		
N740	BIFET DPAMP BM MSAO4B6 BROADBAND A NICHT BESTU NDT FITTED	DC-3.			OB46.4293.00	AVANTEK	MSA-	04B6		
						- ··				
MENP5	413 3PU	Α .	Äl Datum Date	ļ. <u>.</u>	Scheltteilli Perts lis			Sechnummer Stock No.		Blatt-Nr. Pege
ROHDE	&SCHWAR		16.09.97		E AUSGANGSTEI			1062.7005.01	SA	12+

Kennz. Comp. No.	Benen Design				Sachnummer Stock No.	Hersteller Manufacturer	Bezeichnung Designation		naltan in tainad in
N776	BO NE5532D		XLN OPAMP	,	0007.7798.00		NE5532D	2011	, amau #1
778 N840	OPERATIONAL A		IFIER FET OPAMP	,	0007.7823.00		TLO74A(CD)		
N845	OPERATIONAL AND BO AD744KR BIFET OPAMP		IFIER EET OPAMP	' <b> </b>	0854.1754.00				
P300	VL EINPRESSST	IFT	L=6,8	VΙ	0010.7250.00	AMP	1-928776-5		
P305	VL EINPRESS5TI	IFT	L=6,8	VL	0010.7250.00	AMP	1-928776-5		
P352	VL EINPRESSST	IFT	L=6,8	VL	0010.7250.00	AMP	1-928776-5		
P353	PIN   VL EINPRESSSTI   PIN	[FT	L=6,8	V∟	. 0010.7250.00	AMP	1-928776-5		
P375	VL EINPRE555TI	[FT	L=6,8	VL	. 0010.7250.00	AMP	1-928776-5		
P380	VL EINPRESS5TI	FT	L=6,8	VL	. 0010.7250.00	AMP	1-928776-5		
P385	VL EINPRESSSTI	FT	L=6,8	VL	. 0010.7250.00	AMP	1-928776-5		
P600	VL EINPRESSSTI	FT	L=6.8	VL	. 0010.7250.00	AMP	1-928776-5		
P601	PIN VL EINPRESSSTI	FT	L=6,8	VL	0010.7250.00	AMP	1-928776-5		
P620	PIN   VL EINPRESS5TI   PIN	FT	L=6,8	VL	. 0010.7250.00	AMP	1-928776-5		
P621	VL EINPRE5SSTI PIN	FT	L=6,8	VL	0010.7250.00	AMP	1-928776-5		
P628	VL EINPRESS5TI PIN	FT	L=6,8	VL	0010.7250.00	AMP	1-928776-5		
P848	VL EINPRESSSTI PIN	FT	L=6,8	VL	0010.7250.00	AMP	1-928776-5		
P866	VL EINPRESSSTI PIN	FT	L=6,8	VL	0010.7250.00	AMP	1-928776-5		
R1	RG 100 OHM+-1% CHIP RESISTOR	TK1	00 1206	RG	0006.8884.00	ROEDERSTEI	OC2 1000HM 1%TK100		
R9	RG 10,0KOHM+-1		100 1206	RG	0007.0793.00	ROEOERSTEI	OC2 10,0KOHM 1%TK100		
R10	RG 10,0KOHM+-1 RG CHIP RESIST	%TK	100 1206	RG	0007.0793.00	ROEDERSTEI	OC2 10,0KOHM 1%TK100		
R11	RG 182 KOHM+-1		100 1206	RG	0007.5989.00	ROEDERSTEI	DC2 182KOHM 1%TK100		
R12	RG 121, OKOH+-19 CHIP RESISTOR	%TK	100 1206	RG	0007.1960.00	RESISTA	OC2 121KOHM 1% TK100		
R13	RG 121, OKOH+-19 CHIP RESISTOR	%TK	100 1206	RG	0007.1960.00	RESISTA	DC2 121KOHM 1% TK100		
R14	RG 56,2KOHM+-19 CHIP RESISTOR	%TK	100 1206	RG	0007.1883.00	ROEOERSTEI	DC2 56,2KOHM 1%TK100		
R15	RG 27,4KOHM+-19 RESISTOR CHIP	%TK	100 1206	RG	0007.5895.00	ROEDERSTEI	OC2 27,4KOHM 1%TK100		
R16	RG 1,OMOHM+-1% CHIP RESISTOR	TK 10	00 1206	RG	0815.7532.00	DRALORIC	CRC 1206		
R17	RG 100 OHM+-1% CHIP RESISTOR	TK 10	00 1206	RG	0006.8884.00	ROEDERSTEI I	DC2 1000HM 1%TK100		
R20	RG 47,5 OHM+-19 RE515TOR CHIP	KTK1	100 1206	RG	0007.5566.00	ROEDERSTEI	DC2 47,50HM 1%TK100		
R21	RG 100 OHM+-1% CHIP RESISTOR	TK 10	00 1206	RG	0006.8884.00	ROEDERSTEI I	DC2 1000HM 1%TK100		
R22 25	RG 47,5 OHM+-1; RE5ISTOR CHIP	%TK 1	100 1206	RG	0007.5566.00	ROEDER5TEI I	DC2 47,50HM 1%TK100		
R26	RG 10,0KOHM+-19 RG CHIP RE5IST		100 1206	RG	0007.0793.00	ROEDERSTEI (	DC2 10,0KOHM 1%TK100		
R27	RG 47,5 OHM+-19 RESISTOR CHIP		100 1206	RG	0007.5566.00	ROEDERSTEI (	DC2 47,50HM 1%TK100		
R33	RG 100 OHM+-1%1 CHIP RESISTOR	TK 1C	00 1206	RG	0006.8884.00	ROEDER5TEI (	DC2 1000HM 1%TK100		
R34	RG 100 OHM+-1%1 CHIP RESISTOR	TK 1C	00 1206	RG	0006.8884.00	ROEDER5TEI (	DC2 1000HM 1%TK100		
R35	RG 2,0 KOHM+-19 RESISTOR CHIP	/TK 1	100 1206	RG	0007.5737.00	ROEDER5TEI I	DC2 2,0KOHM 1%TK100		
R36	RG 1,OMOHM+-1%1 CHIP RESISTOR	TK 10	00 1206	RG	0815.7532.00	DRALORIC (	CRC 1206		
R38	RG 10,0KOHM+-1% RG CHIP RESISTO		100 1206	1			DC2 10,0KOHM 1%TK100		
R41 48	RG 10,0KOHM+-17 RG CHIP RE515TO	<b>6TK 1</b>	100 1206	RG	0007.0793.00	ROEDERSTEI [	DC2 10,0K0HM 1%TK100		
MENP5	413 3PUA	Äŀ	Datum Date		Schalttellis Parts list		Sachnummer Stock No.		Blatt-Nr. Page
(R)		00	16 00 0=	_				C A	
ROHDE&SCHWARZ 28 16.09.9			16.09.97		E AUSGANGSTEI		1062.7005.01	SA	13+
		i 1		ı Ü	OUTPUT UNIT 2.4	USGHIZ	1		

Kennz. Comp. No.	Benenr Design				Sechnummer Stock No.	Hersteller Manufacturer		zeichnung esignation		naiten in tained in
R49	RG 20,0KOHM+-		·····	RG				20,0KOHM 1%TK10		centou III
56 R116	RESISTOR CHIP RG 10,0KOHM+-1		(100 1206	1				10,0KOHM 1%TK10	Ī	
R117	RG CHIP RESIST	I%T}	(100 1206	RG	0007.0793.00	ROEDERSTEI	DC2	10,0KOHM 1%TK10	0	
Ř119	RG CHIP RESIST		100 1206	1		l .		8250HM 1%TK100		
R120	CHIP RESISTOR   RG 100,0KOH+-1	1 <b>%</b> Tk	(100 1206	RG	0007.1948.00	ROEDERSTEI	DC2	100KOHM 1%TK100		
122 R123	CHIP RESISTOR RG 10,0KOHM+-1	%T#	(100 1206	l				10,0KOHM 1%TK10	}	
R124	RG CHIP RESIST RG 10,0KOHM+-1	OR		ł					İ	
R130	RG CHIP RESIST RG 10,0KOHM+-1	OR		ļ				10, DKOHM 1%TK10	ĺ	
132 R133	RG CHIP RESIST RG O-OHM WIDER	OR			0007.5108.00	Ī		1206		
R134	RESISTOR CHIP RG 10,0KOHM+-1	0-0	HM	ĺ				10,0KOHM 1%TK100		
R149	RG CHIP RESIST RG 10.0KOHM+-1	OR				1			}	
R160	RG CHIP RESIST	OR	1.0			1		1D, OKOHM 1%TK 1D0	1	
R161	CHIP RESISTOR RG 100,0KOH+-1	-						100K0HM 1%TK 100	1	
R162	CHIP RESISTOR							100K0HM 1%TK100	1	
	RG 1,0 KO +-1% CHIP RESISTOR							1,0KOHM 1%TK100		
R163	RG 1,0 KO +-1% CHIP RESISTOR							1,0KOHM 1%TK100		
R165	RG 100,0K0H+-19							100K0HM 1%TK100		
R166	RG 100,0K0H+-19							100K0HM 1%TK100	}	
R167	RG 1,0 KO +-1% CHIP RESISTOR							1,0K0HM 1%TK100		
R168	RG 1,0 KO +-1% CHIP RESISTOR		1					1,0K0HM 1%TK100		
R170	RG 100,0KOH+-11 CHIP RESISTOR		1					100KOHM 1%TK100		
R171	RG 100,0K0H+-19 CHIP RESISTOR	%TK	100 1206	RG	0007.1948.00	ROEOERSTEI	DC2	100K0HM 1%TK100		
R172	RG 1,0 KO +-1% CHIP RESISTOR	TK 1	00 1206	RG	0006.7271.00	ROEOERSTEI	OC2	1,0K0HM 1%TK100		
R173	RG 1,0 KO +-1%T CHIP RESISTOR	TK 1	00 1206	RG	0006.7271.00	ROEOERSTEI	0C2	1,0KOHM 1%TK100		
R206	RG O-OHM WIDERS RESISTOR CHIP O NICHT BESTUECK NOT FITTED	0-C	ND-CHIP HM	RG	0007.5108.00	DRALORIC	CR 1	206		
R207	RG 10,0K0HM+-17		100 1206	RG	0007.0793.00	ROEDERSTEI	DC2	1D,0KOHM 1%TK100		
R208	RG CHIP RESISTOR RG 10,0KOHM+-1%	4TK	100 1206	RG	0007.0793.00	ROEDERSTEI	OC2	10,0KOHM 1%TK100		
R209	RG CHIP RESISTO RG 10,0KOHM+-17 RG CHIP RESISTO NICHT BESTUECKI	TK OR	100 1206	RG	0007.0793.00	ROEDERSTEI	DC2	10,0КОНМ 1%ТК100	+	
R211	NOT FITTED RG 3,01KOHM+-17 RESISTOR CHIP	(TK		RG	0007.5772.00	ROEDERSTEI	DC2	3,01KOHM 1%TK100		
R211	NUR VAR/ONLY MO RG 2,21KOHM+-17 RESISTOR CHIP	(TK	100 1206	RG	0007.5743.00	ROEDERSTEI	DC2	2,21KOHM 1%TK100		
R212	NUR VAR/ONLY MC RG 10,0KOHM+-1%	(TK		RG	0007.0793.00	ROEDERSTEI	DC2	10,0K0HM 1%TK100		
R213	RG CHIP RESISTO	(TK	100 1206	RG	0007.0793.00	ROEDERSTEI	DC2	10,0KOHM 1%TK100		
R214	RG CHIP RESISTOR 3,32KOHM+-1%		100 1206	RG	0007.5789.00	ROEDERSTEI	DC2	3,32KOHM 1%TK100		
R215	RESISTOR CHIP RG 20,DKOHM+-1%	ίτκ	100 1206	RG	0007.5866.00	ROEDERSTEI	DC2	20,DKOHM 1%TK100		
R216	RESISTOR CHIP RG 20,0K0HM+-1% RESISTOR CHIP NICHT BESTUECKT		100 1206	RG	0007.5866.00	ROEDERSTEI	DC2	20,0KOHM 1%TK100		
R218	NOT FITTED RG 1,0 KO +-1%T CHIP RESISTOR		00 1206	RG	0006.7271.00	ROEDERSTEI i	DC2	1,0KOHM 1%TK100		
MENP5	413 3PUA	Äl	Datum Date		Schalttellis Perts list			Sachnummer Stock No.		Blatt-Nr. Page
4002 70							1 6 4			
ROHDE&SCHWARZ 28 16.09			16.09.97		E AUSGANGSTEI			1062.7005.0	ı əa	14+
				0	UTPUT UNIT 2.0	D8GHZ				

Kennz. Comp. No.	Benennung Dasignation	Sachnummer Stock No.	Hersteller Bezeichnung Manufacturer Designation	enthalten in contained in
R220	RG 100 0HM+-1%TK100 1206	<del> </del>	ROEDERSTEI DC2 1000HM 1%TK100	
R221	CHIP RESISTOR RG 182 KOHM+-1%TK100 1206 RESISTOR CHIP NICHT BESTUECKT	RG 0007.5989.00	ROEDERSTEI DC2 182KOHM 1%TK100	
R240	NOT FITTED RG 10,0K0HM+-1%TK100 1206	RG 0007.0793.00	ROEDERSTEI DC2 10,0KOHM 1%TK100	
R241	RG CHIP RESISTOR RG 20,0KOHM+-1%TK100 1206	RG 0007.5866.00	ROEDERSTEI DC2 20,0KOHM 1%TK 100	
R259	RESISTOR CHIP RG 221 KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.6004.00	ROEDERSTEI DC2 221KOHM 1%TK100	
R259	NUR VAR/ONLY MOD: 02 04 RG 56,2KOHM+-1%TK100 1206 CHIP RESISTOR	RG 0007.1883.00	ROEDERSTEI DC2 56,2KOHM 1%TK100	
R271	NUR VAR/ONLY MOD: 03 06 RG 10,0K0HM+-1%TK100 1206	RG 0007.0793.00	ROEDERSTEI DC2 10,0KOHM 1%TK 100	
R272	RG CHIP RESISTOR RG 10,0KOHM+-1%TK100 1206	RG 0007.0793.00	ROEDERSTEI DC2 10,0KOHM 1%TK100	
R275	RG CHIP RESISTOR   RG 1,0 KO +-1%TK100 1206	RG 0006.7271.00	ROEDERSTEI DC2 1,0KOHM 1%TK100	
R276	CHIP RESISTOR RG 10,0K0HM+-1%TK100 1206 RG CHIP RESISTOR	RG 0007.0793.00	ROEDERSTEI DC2 10,0KOHM 1%TK100	
R278	RG 47,5KOHM+-1%TK100 1206 RESISTOR CHIP NUR VAR/ONLY MOD: 02	RG 0007.5950.00	ROEDERSTEI DC2 47,5KOHM 1%TK100	
R278	RG 30, 1KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5908.00	ROEDERSTEI DC2 30,1KOHM 1%TK100	
R280	NUR VAR/ONLY MOD: 03 04 06 RS 0,25W 5KOHM +-20% SMD	RS 0007.9632.00	SIEMENS S4G-5KOHM	
R283	POTENTIOMETER RG 20,0KOHM+-1%TK100 1206	RG 0007.5866.00	ROEDERSTEI DC2 20,0KOHM 1%TK100	
285 R286	RESISTOR CHIP RG 10,0KOHM+-1%TK100 1206 RG CHIP RESISTOR	RG 0007.0793.00	ROEOERSTEI DC2 10,0KOHM 1%TK100	
R299	RG 33,2KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5914.00	ROEDERSTEI DC2 33,2KOHM 1%TK100	
R299	NUR VAR/ONLY MOD: 02 04 RG 15,0K0HM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5843.00	ROEOERSTEI DC2 15,0KOHM 1%TK100	
R300	NUR VAR/ONLY MOD: 03 06 RG 0.05W 22R +-1% 0805	RG 0007.8920.00	HONEST JAP MR 08 M 22R 1% 0805	
R301 308	RESISTOR RK SMD-HEISSL.220R 0805 SMD-NTC-RESISTOR	1039.1310.00	SIEMENS 857620-C221-K62	
R310		RG 0006.8849.00	ROEDERSTEI DC2 68,10HM 1%TK100	
R312		RG 0006.8661.00	ROEDERSTEI DC2 12,10HM 1%TK100	
R313	RG 56,2 OHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.8826.00	ROEDERSTEI DC2 56,20HM 1%TK100	
R314	RG 511 OHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.9051.00	ROEDERSTEI DC2 5110HM 1%TK100	
R315	RL 0,60W 1,33KOHM+-1%TK50 RESISTOR	RL 0083.0684.00		
R3 16	RG 39,2 OHM+-1%TK100 1206 RESISTOR CHIP		ROEDERSTEI DC2 39,20HM 1%TK100	
R317	RL 0,60W 1,33KOHM+-1%TK50 RESISTOR	RL 0083.0684.00		
R3 18	RL 0,60W 1,33KOHM+-1%TK50 RESISTOR	RL 0083.0684.00		
R319	RG 562 OHM+-1%TK100 1206 CHIP RESISTOR		ROEDERSTEI DC2 5620HM 1%TK100	
R320 R321	RG 15,0 0HM+~1%TK100 1206 RESISTOR CHIP		ROEDERSTEI DC2 15,00HM 1%TK100	
R325	RG 15,0 OHM+-1%TK100 1206 RESISTOR CHIP RG 2,0 KOHM+-1%TK100 1206		ROEDERSTEI DC2 15,00HM 1%TK100 ROEDERSTEI DC2 2,0K0HM 1%TK100	
R325	RESISTOR CHIP RG 562 OHM+-1%TK100 1206	1	ROEDERSTEI DC2 2,0KUHM 1%1K100	ļ
R328	CHIP RESISTOR RG 56,2 OHM+-1%TK100 1206		ROEDERSTEI DC2 56,20HM 1%TK100	
R329	CHIP RESISTOR RL 0,60W 1,33KOHM+-1%TK50	RL 0083.0684.00		
R330	RESISTOR RG 15,0 OHM+-1%TK100 12D6 RESISTOR CHIP		ROEDERSTEI DC2 15,00HM 1%TK100	
		D_1 -444 ****	A. 61.	1
MENP5	413 3PUA ĀI Datum Date	SchaftteHlis Parts tist		Blatt-Nr. Page
<b>POUD</b>	28 16.09.97	EE AUSGANGSTEI	1062.7005.01	<b>SA</b> 15+

Kannz. Comp. No.	Banannung Designation	Sachnummar Stock No.	Herstaller Manufacturer	Bazeichnung Dasignation	anthaltan in containad in
R332	RL 0,60W 1,33K0HM+-1%TK50	RL 0083.0684.00	RESISTA MK	.2	
R333	RESISTOR RG 15,0 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5450.00	ROEOERSTEI OO	2 15,00HM 1%TK100	
R340	RG 511 OHM+-1%TK100 1206	RG 0006.9051.00	ROEDERSTEI OC	2 5110HM 1%TK100	
R341	CHIP RESISTOR RL 0,60W 1,33KOHM+-1%TK50	RL 0083.0684.00	RESISTA MK	2	
R342	RESISTOR RG 39,2 DHM+-1%TK100 1206	RG 0007.5543.00	ROEDERSTEI OC	2 39,20HM 1%TK100	
R355	RESISTOR CHIP RG O-OHM WIDERSTAND-CHIP	RG 0007.5108.00	ORALORIC CR	1206	
R356	RESISTOR CHIP D-OHM RL 0,60W 100 OHM+-1%TK50	RL 0082.6543.00	RESISTA MK	2	
	RESISTOR NICHT BESTUECKT				
R357	NOT FITTED RL 0,60W 100 OHM+-1%TK50	RL 0082.6543.00	RESISTA MK	2	
	RESISTOR NICHT BESTUECKT				
R360	NOT FITTED RL 0,60W 100 0HM+-1%TK50	RL 0082.6543.00	RESISTA MK	2	
R361	RESISTOR				
	RL 0,60W 100 OHM+-1%TK50 RESISTOR	RL 0082.6543.00			
R400	RG 511 OHM+-1%TK100 1206 CHIP RESISTOR	_		2 5110HM 1%TK100	
R401	RL 0,60W 1,33K0HM+-1%TK50 RESISTOR	RL 0083.0684.00			
R402	RG 39,2 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5543.00	ROEDERSTEI OC	2 39,20HM 1%TK100	
R404	RG 56,2 OHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.8826.00	ROEDERSTEI OC	2 56,20HM 1%TK100	
R405	RG 562 DHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.9068.00	ROEDERSTEI OC	2 5620HM 1%TK100	
R406	RG 15,0 0HM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5450.00	ROEDERSTEI OC	2 15,00HM 1%TK100	
R407	RG 15,0 0HM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5450.00	ROEDERSTEI OC	2 15,00HM 1%TK100	
R408	RL 0,60W 1,33K0HM+-1%TK50	RL 0083.0684.00	RESISTA MK	2	
R409	RESISTOR RL 0,60W 1,33KOHM+-1%TK50	RL 0083.0684.00	RESISTA MK	2	j
R410	RESISTOR RG 39,2KOHM+-1%TK100 1206	RG 0007.5937.00	ROEOERSTEI OC	2 39,2KOHM 1%TK100	
R411	RESISTOR CHIP RG 1,5 KOHM+-1%TK100 1206	RG 0007.5714.00	ROEDERSTEI OC	2 1,5KOHM 1%TK100	:
R412	RESISTOR CHIP RG 1,0 KO +-1%TK100 1206	RG 0006.7271.00	ROEDERSTEI OC	2 1,0KOHM 1%TK100	
R416	CHIP RESISTOR RL 0,60W 100 OHM+-1%TK50	RL 0082.6543.00	RESISTA MK	2	
R417	RESISTOR RL 0,60W 100 OHM+-1%TK50	RL 0082.6543.00	RESISTA MK	2	
R431	RESISTOR RG 10,0KOHM+-1%TK100 1206	RG 0007.0793.00	ROEDERSTEI DC	2 10,0KDHM 1%TK100	
438 R440	RG CHIP RESISTOR			2 10,0KOHM 1%TK100	
R442	RG CHIP RESISTOR RG 10,0KOHM+-1%TK100 1206			2 10,0K0HM 1%TK100	
R443	RG CHIP RESISTOR			2 10,0KOHM 1%TK100	
R450	RG CHIP RESISTOR	RG 0006.8884.00			
	CHIP RESISTOR	ĺ			
R451	RESISTOR CHIP	RG 0007.5589.00			- 1
R452	RESISTOR CHIP	RG 0007.5595.00			
R453	RESISTOR CHIP	RG 0007.5589.00			
R454	CHIP RESISTOR	RG 0006.8884.00			
R455	CHIP RESISTOR			2 56,20HM 1%TK100	
R500 5D2		RG 0007.5737.00	ROEDERSTEI OC	2 2,0K0HM 1%TK100	
R503		RG 0007.5672.00	ROEDERSTEI DC:	2 3920HM 1%TK100	1
R520 522	RG 1,21K0HM+-1%TK100 1206 CHIP RESISTOR	RG 0006.9968.00	ROEDERSTEI OC	2 1,21KDHM 1%TK100	
	J. Z. KEGZOTOK				
MENP5	413 3PUA AI Datum	Schalttallii		Sachnummer	Biatt-Nr.
	Data	Parts lis	. 10/	Stock No.	Page
🍪   ROHDI	E&SCHWARZ 28 16.09.97	EE AUSGANGSTEI	L 2.D8GHZ	1062.7005.01	SA 16+
		OUTPUT UNIT 2.	O8GHZ		

Kennz. Comp. No.	Benennung Designation	Sachnummer Stock No.		ezeichnung esignetion		elten in eined in
R530	RG 392 OHM+-1%TK100 1206	RG 0007.5672.00	ROEDERSTEI DC	2 3920HM 1%TK100		
R600	RESISTOR CHIP RG 221 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5614.00	ROEDERSTEI DC	2 2210HM 1%TK100		
R601	RL 0,60W 274 OHM+-1%TK50	RL 0083.0178.00	RESISTA MK2	2		
R602	RESISTOR RG 27,4 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5508.00	ROEDERSTEI DC2	2 27,40HM 1%TK100		
R603	RG 33,2 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5520.00	ROEDERSTEI DC2	2 33,20HM 1%TK100		
R604	RG 68,1 OHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.8849.00	ROEDERSTEI DC2	2 68,10HM 1%TK100		
R605	RG 15,0 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5450.00	ROEDERSTEI DC2	2 15,00HM 1%TK100		
R607	RG 825 KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.6133.00	ROEDERSTEI DC2	825KOHM 1%TK100		
R608	RG 100 OHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.8884.00	ROEDERSTEI DC2	! 1000HM 1%TK100		
R609	RG 1,5 KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5714.00	ROEDERSTEI DC2	1,5KOHM 1%TK100		
R611	RG 392 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5672.00	ROEDERSTEI DC2	3920HM 1%TK100		
R612	RG 475 OHM+-1%TK 100 1206 RESISTOR CHIP	RG 0007.5695.00	ROEDERSTEI DC2	4750HM 1%TK100		
R613	RG 3,57KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5795.00	ROEDERSTEI DC2	3,57KOHM 1%TK100		
R614	RG 2,74K0HM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5766.00	ROEDERSTEI DC2	2,74KOHM 1%TK100		
R615	RG 1,2MOHM+-5%TK200 1206 CHIP RESISTOR	0007.9949.00	ROEDERSTEI D 2	5		
	NICHT BESTUECKT NOT FITTED					
R616	RG 3,57KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5795.00	ROEDERSTEI DC2	3,57KOHM 1%TK10D		
R618	RG 100,0K0H+-1%TK100 1206 CHIP RESISTOR	RG 0007.1948.00	ROEDERSTEI DC2	100K0HM 1%TK100		
R619	RS 0,25W 5KOHM +-20% SMD POTENTIOMETER	RS 0007.9632.00	SIEMENS S4G	-5KOHM		
R620	RG 100,0K0H+-1%TK100 1206 CHIP RESISTOR	RG 0007.1948.00	ROEDERSTEI DC2	100K0HM 1%TK100		
R621	RG 475 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5695.00	ROEDERSTEI DC2	4750HM 1%TK100		
R622	RG 100 0HM+-1%TK100 1206 CHIP RESISTOR	RG 0006.8884.00	ROEDERSTEI DC2	1000HM 1%TK 100		
R623	RK SMD-HEISSL.220R 0805 SMD-NTC-RESISTOR	1039.1310.00	SIEMENS 857	620-C221-K62		
	NICHT BESTUECKT NOT FITTED					
R624	RK SMD-HEISSL.220R 0805 SMD-NTC-RESISTOR	1039.1310.00		620-C221-K62		
R625				27,40HM 1%TK100		
R626	RG 100 OHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.8884.00				
R627	RG 56,2 OHM+-1%TK100 1206 CHIP RESISTOR	ŀ		56,20HM 1%TK100		
R628	RG 100 OHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.8884.00				
R629	RG 100 OHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.8884.00				
R630	RG 825 OHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.7259.00	ROEDERSTEI DC2	8250HM 1%TK 100		
R631	RG 825 OHM+-1%TK100 1206 CHIP RESISTOR	RG 0006.7259.00	ROEDERSTEI DC2	8250HM 1%TK100		
R632	RG O-OHM WIDERSTAND-CHIP RESISTOR CHIP O-OHM	RG 0007.5108.00	DRALORIC CR	1206		
R633	RG 2,74KOHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5766.00	ROEDERSTEI DC2	2,74KOHM 1%TK100		
R634	RG 5,620HM+-1%TK100 1206 CHIP-RESISTOR	RG 0007.8442.00		4,00		
R635	RG 22,1KOHM+-1%TK100 1206 RESISTOR CHIP	282		22,1KOHM 1%TK100		į
R636	RG 1D,OKOHM+-1%TK1DD 12D6 RG CHIP RESISTOR			10,DKOHM 1%TK100		
R637	RG 1,5 KOHM+-1%TK100 1206 RESISTOR CHIP			1,5KOHM 1%TK100		
R638	RG 392 OHM+-1%TK100 1206 RESISTOR CHIP	RG 0007.5672.00	ROEDERSTEI DC2	3920HM 1%TK100		
	A10 ODUA . Datum	F-L-444-9914	rte tils			Dio44-At-
MENP5	413 3PUA ÄI Daten	Schatttellit Perts lis		Sachnummer Stock No.		Biett-Nr. Pege
Ø UP	28 16.09.97	EE AUSGANGSTEI	L 2.D8GHZ	1062.7005.01	SA	17+

Kennz. Comp. No.		Benen Desigr				Sachnumme: Stock No.	Hersteller Menufecturer	Bezeichnung Designetion		elten in eined in
R639				K100 1206	RG			DC2 10,0KOHM 1%TK100		
R640	RG 0-0		RST/	AND-CHIP	RG	0007.5108.00	DRALORIC	CR 1206		
R641		OR CHIP		OHM AND-CHIP	RG	0007.5108.00	DRALORIC	CR 1206		-
R642		DR CHIP 1 OHM+-		DHM (100 1206	RG	0006.8810.00	RESISTA	DC2 51,10HM 1%TK100		
R644		ESISTOR OHM+-1		100 1206	RG	0007.5695.00	ROEDERSTEI	DC2 4750HM 1%TK 100		
R645		OR CHIP	HM+-	-20% SMD	l	0007.9590.00		S4G-200 OHM		
R646	POTENT	IOMETER		-1%TK50		0083.0010.00		MK2		
R647	RESIST	OR		- 1%TK50	1	0082.9859.00		MK2		
R648	RESIST		_					DC2 1000HM 1%TK100		
R649	CHIP R	ESISTOR 40HM+-1								
R650	CHIP-R	ESISTOR			1	0007.8365.00		RC 02		
	RESIST	OR		1+-1%TK50		0083.0684.00		MK2		
R651	CHIP R	ESISTOR		00 1206		0815.7532.00		CRC 1206		
R652	CHIP R	ESISTOR		100 1206				DC2 68,10HM 1%TK100		
R653	CHIP R	ESISTOR		100 1206				DC2 56,20HM 1%TK100		
R654		2 OHM+-1 ESISTOR	1%TK	100 1206	RG	0006.8826.00	ROEDERSTEI	DC2 56,20HM 1%TK100		
R655		10HM+-1% ESISTOR	4TK 1	00 1206	RG	0007.8342.00	PHILIPS	RC 02		
R656	RL 0,60 RESIST		KOHM			0083.0684.00		MK2		
R657		OKOHM+-1 PRESIST		100 1206	RG	0007.0793.00	ROEOERSTEI	DC2 10,0KOHM 1%TK100		
R658	RG 10,0		I%TK	100 1206	RG	0007.0793.00	ROEDERSTEI	DC2 10,0K0HM 1%TK100		
R659		OHM+- 1%		00 1206	RG	0006.9051.00	ROEDERSTEI	DC2 5110HM 1%TK100		
R660		KOHM+-1	I%TK	100 1206	RG	0007.6110.00	ROEOERSTEI	DC2 681KOHM 1%TK100		
R661	RG 0-0H	HM WIOER			RG	0007.5108.00	DRALORIC	CR 1206		
R662	RG 0-01	M WIOER	RSTA	ND-CHIP	RG	0007.5108.00	DRALORIC	CR 1206		
R663	RG 0-01	M WIOER OR CHIP	RSTA	NO-CHIP	RG	0007.5108.00	DRALORIC	CR 1206		
		BESTUECK								
R670		W 100 0	HM+	-1%TK50	RL	0082.6543.00	RESISTA	MK2		
ļ		BESTUECK	T							
R671		W 100 0	HM+	-1%TK50	RL	0082.6543.00	RESISTA	MK2		
		BESTUECK	T							
R672	RL 0,60	W 100 D	HM+	-1%TK50	RL	0082.6543.00	RESISTA	MK2		
R673		W 100 0	HM+	-1%TK50	RL	0082.6543.00	RESISTA	MK2		l
R674		OHM+-1%	TK 10	00 1206	RG	0006.7259.00	ROEDERSTEI	DC2 8250HM 1%TK 100		
R675	_	OHM+-1%	TK 10	00 1206	RG	0006.7259.00	ROEDERSTEI	DC2 8250HM 1%TK 100		
R676		OHM+-1%	TK 16	00 1206	RG	0007.8442.00	PHILIPS	RC 02		
R677		OHM+-1%	TK 16	00 1206	RG	0006.7259.00	ROEDERSTEI	DC2 8250HM 1%TK 100		
R678		OHM+-1%	TK 16	00 1206	RG	0006.7259.00	ROEDERSTEI	DC2 8250HM 1%TK100		
R679		DHM+-1%	TK 16	00 1206	RG	0007.8442.00	PHILIPS	RC 02		
R680		W 100 0	HM+	-1%TK50	RL	0082.6543.00	RESISTA	MK2		
R681		W 100 0	HM+	-1%TK50	RL	0082.6543.00	RESISTA	MK2		
	RESISTO	IR								
HENDE	440	2014	Τ	Datum		Schaltteillis	sta für	Sechnummer		Blatt-Nr.
MENP5	413	3PUA	Äl	Dete		Parts list		Stock No.		Page
<b>®</b>	:peair	WA PAT	28	16.09.97	E	E AUSGANGSTEI	L 2.08GHZ	1062.7005.01	SA	18+
RUMUE	i&SCH\	MAKZ			0	UTPUT UNIT 2.0	08GHZ			
			_							

Kennz. Comp. No.	Benann Designa				Sachnummer Stock No.	Hersteller Manufacturer	Sezeichnung Designation		naiten in tained in
R682	RG 82,5 DHM+-1		00 1206	RG			DC2 82,50HM 1%TK10		
R683	CHIP RESISTOR RG 1,0 KO +-1%	KK 10	0 1206	RG	0006.7271.00	ROEDERSTEI	DC2 1,0KDHM 1%TK10	00	
R684	CHIP RESISTOR RG 475 KOHM+-1	%TK 1	00 1206	RG	0007.6079.00	ROEDERSTEI	DC2 475KOHM 1%TK10	00	
R685	RESISTOR CHIP RG 1,0 KO +-1%	TK 10	0 1206	RG	0006.7271.00	ROEDERSTEI	DC2 1,0KDHM 1%TK10	00	
R686	CHIP RESISTOR RG 1,OMOHM+-1%	TK 10	0 1206	RG	0815.7532.00	DRALORIC	CRC 1206		
R687	CHIP RESISTOR RG 511 OHM+-1%	TK 10	0 1206	RG	0006.9051.00	RDEDERSTEI	DC2 5110HM 1%TK100		
R688	CHIP RESISTOR RL 0,60W 1,33K	DHM+	-1%TK50	RL	0083.0684.00	RESISTA	MK2		
R689	RESISTDR RG 39,2 DHM+-1	%TK 10	00 1206	RG	0007.5543.00	ROEDERSTEI	DC2 39,20HM 1%TK10	00	
R690	RESISTOR CHIP RL 0,60W 1,33K	онм+-	-1%TK50	RL	0083.0684.00	RESISTA	MK2		
R691	RESISTOR RL 0,60W 1,33K	онм+-	-1%TK50	RL	0083.0684.00	RESISTA	MK2		
R692	RESISTOR RG 56,2 OHM+-1	%TK 16	00 1206	RG	0006.8826.00	ROEOERSTEI	DC2 56,20HM 1%TK10	00	
R693	CHIP RESISTOR RG 56,2 OHM+-1	%TK 10	00 1206	RG	0006.8826.00	ROEDERSTEI	DC2 56,20HM 1%TK10	00	
R694	CHIP RESISTOR RG 15,0 OHM+-1	%TK 10	00 1206	1			DC2 15,00HM 1%TK10		
697 R698	RESISTDR CHIP RG 562 OHM+-1%	TK 100	1206			111	DC2 5620HM 1%TK100		
R699	CHIP RESISTOR RG 56,2 DHM+-1	%TK 10	00 1206	l		7.50	DC2 56,2DHM 1%TK10	ļ	
R700	CHIP RESISTOR RG 82,5 OHM+-1	%TK 10	00 1206	ľ			DC2 82,5DHM 1%TK10		
R701	CHIP RESISTOR RG 1,0 KO +-1%	TK 100	1206	ļ			DC2 1,0KOHM 1%TK10	- 1	,
R702	CHIP RESISTOR RG 475 KOHM+-1	%TK 10	00 1206				OC2 475KOHM 1%TK10	Ì	
R703	RESISTOR CHIP RG 10,0KOHM+-1	% <u>T</u> K 10	00 1206		ì		DC2 10,0KOHM 1%TK1		
R704	RG CHIP RESIST		1206	ļ			OC2 1, OKOHM 1%TK10		
R705	CHIP RESISTOR RG 1,0MOHM+-1%	TK 100	1206		0815.7532.00		CRC 1206		
R706	CHIP RESISTOR RG 1,21KOHM+-1	%TK 10	00 1206				DC2 1,21KOHM 1%TK1	00	
R707	CHIP RESISTOR RG 1,21KOHM+-1	%TK 10	00 1206				OC2 1,21KOHM 1%TK1		
R708	CHIP RESISTOR RG O-OHM WIDERS			ļ	0007.5108.00		CR 1206		
R709	RESISTOR CHIP (			RG	0006.8884.00	ROEDERSTEI	0C2 1000HM 1%TK100		
R710	CHIP RESISTOR RG 121 OHM+-1%	TK 100	1206				DC2 1210HM 1%TK100		
R720	CHIP RESISTOR RG 100 OHM+-1%	ΓK 100					DC2 1000HM 1%TK100		
R721	CHIP RESISTOR RG 121 OHM+-1%	ΓK 100	1206	RG	0006.8903.00	ROEDERSTEI	DC2 1210HM 1%TK100		
R723	CHIP RESISTOR RG 1,21KOHM+-1;	6TK 10	0 1206	RG	0006.9968.00	ROEDERSTEI	DC2 1,21KOHM 1%TK1	00	İ
R724	CHIP RESISTOR RG 1,21KDHM+-13	<b>(ΤΚ 1</b> C	0 1206				DC2 1,21KDHM 1%TK1	1	
R725	CHIP RESISTOR RG 475 DHM+-1%1	FK 100	1206				DC2 4750HM 1%TK100		
R726	RESISTDR CHIP RG 475 OHM+-1%1	r <b>K</b> 100	1206	RG	0007.5695.00	ROEDERSTEI	DC2 4750HM 1%TK100		İ
R727	RESISTDR CHIP RG 332 OHM+-1%1	TK 100	1206	RG	0007.5650.00	ROEDERSTEI	DC2 332DHM 1%TK100		
R728	RESISTDR CHIP RG 332 OHM+-1%1	r <b>K</b> 100	1206	RG	0007.5650.00	ROEDERSTEI	DC2 3320HM 1%TK100		
R730	RESISTDR CHIP RG 332 OHM+-1%1	r <b>K 10</b> 0	1206	RG	0007.5650.00	ROEDERSTEI	DC2 3320HM 1%TK100		
R731	RESISTDR CHIP RG 1,21KOHM+-1%	6TK 10	0 1206	RG	0006.9968.00	ROEDERSTEI	DC2 1,21KOHM 1%TK1	00	
R732	CHIP RESISTOR RG 1,21KDHM+-1%	€TK 10	0 1206	RG	0006.9968.00	RDEDERSTEI	DC2 1,21KDHM 1%TK1	00	
R733	CHIP RESISTOR RG 39,2 OHM+-1%	(TK 10	0 1206	RG	0007.5543.00	ROEDERSTEI	DC2 39,20HM 1%TK10	0	
R734	RESISTOR CHIP RG 121 OHM+-1%1	r <b>K 10</b> 0	1206	RG	0006.8903.00	RDEDERSTEI	DC2 121DHM 1%TK100		
	CHIP RESISTOR								
HENDE	440 0004	,	Datum		Schaltteill	ste für	Sachnumn	ner .	Blatt-Nr.
MENP5	413 3PUA	ΪΙ	Date		Parts list		Stock N		Page
<b></b>		28 1	6.09.97	E	E AUSGANGSTEI	L 2.08GHZ	1062.7005.	01 SA	19+
KOMDE	&SCHWARZ			D	UTPUT UNIT 2.	O8GHZ			

Kennz. Comp. No.	Benenn Designe			Sachnummer Stock No.	Hersteller Menufecturer	Bezeichnung Designation		alten in eined in
R735	RG 100 OHM+-1% CHIP RESISTOR	TK 100 1206	RG	0006.8884.00	ROEDERSTEI	DC2 100DHM 1%TK100		
R736	RG 8,25KOHM+-1	%TK100 1206	RG	0007.0770.00	ROEDERSTEI	DC2 8,25KOHM 1%TK100		
R737	CHIP RESISTOR RG 8,25KOHM+-1	%TK 100 1206	RG	0007.0770.00	ROEDERSTEI	DC2 8,25KOHM 1%TK100		
R738	CHIP RESISTOR RG 2,0 KOHM+-1	%TK100 1206	RG	0007.5737.00	ROEDERSTEI	DC2 2,0KOHM 1%TK100		
R739	RESISTOR CHIP RL 0,60W 1,33K	DHM+-1%TK50	RL	0083.0684.00	RESISTA	MK2		
R740	RESISTOR RG O-OHM WIDER		RG	0007.5108.00	DRALORI C	CR 1206		
R741	RESISTOR CHIP (RG 68,1 OHM+-1)		RG	0006.8849.00	ROEDERSTEI	DC2 68,10HM 1%TK100		
	CHIP RESISTOR NICHT BESTUECK	т						
R742	NOT FITTED RG 68,1 OHM+-1	%TK 100 1206	RG	0006.8849.00	ROEDERSTEI	DC2 68,10HM 1%TK100		
	CHIP RESISTOR NICHT SESTUECK	Т						
R743	NDT FITTED RG 68,1 OHM+-1	%TK 100 1206	RG	0006.8849.00	RDEDERSTEI	DC2 68,1DHM 1%TK100		
i	CHIP RESISTOR NICHT BESTUECK	Т	ĺ					l li
R745	NDT FITTED RG 10,0KOHM+-19	_	RG	0007.0793.00	ROEDERSTEI	DC2 10,0KOHM 1%TK100		
R747	RG CHIP RESISTOR		RG	0007.0770.00	ROEDERSTEI	DC2 8,25KDHM 1%TK100		
R748	CHIP RESISTOR RG 8,25KDHM+-1; CHIP RESISTOR	%TK 100 1206	RG	0007.0770.00	ROEDERSTEI	DC2 8,25KOHM 1%TK100		
R750	RG 332 DHM+-1% RESISTOR CHIP	TK100 1206	RG	0007.5650.00	ROEDERSTEI	DC2 3320HM 1%TK100		
R751	RG 332 OHM+-1%	TK 100 1206	RG	0007.5650.00	ROEDERSTEI	DC2 332DHM 1%TK100		
R753	RG 475 OHM+-1%	TK 100 1206	RG	0007.5695.00	ROEDERSTEI	DC2 4750HM 1%TK100		
R754	RG 475 OHM+-1%	TK 100 1206	RG	0007.5695.00	ROEOERSTEI	DC2 4750HM 1%TK100		
R755	RG 1,0 KO +-1%1 CHIP RESISTOR	TK 100 1206	RG	0006.7271.00	ROEOERSTEI	DC2 1,0K0HM 1%TK100		
R760	RG 10,0KOHM+-1% RG CHIP RESIST		RG	0007.0793.00	ROEOERSTEI	DC2 10,0K0HM 1%TK100		
R761	RG O-OHM WIDERS RESISTOR CHIP O	STAND-CHIP	RG	0007.5108.00	ORALORIC	CR 1206		
R762	RG 47,5 OHM+-19 RESISTOR CHIP		RG	0007.5566.00	ROEDERSTEI	OC2 47,50HM 1%TK100		
R765	RG 3,92KOHM+-19 RESISTOR CHIP	%TK100 1206	RG	0007.5808.00	RESISTA	DC2 3,92KOHM 1%TK100		1
R766	RG 562 OHM+-1%1 CHIP RESISTOR	TK 100 1206	RG	0006.9068.00	ROEOERSTEI	DC2 5620HM 1%TK100		
R767	RG 15,0 OHM+-17 RESISTOR CHIP	%TK 100 1206	RG	0007.5450.00	ROEOERSTEI	DC2 15,0DHM 1%TK100		
R768	RL 0,60W 1,33KE RESISTOR	OHM+-1%TK50		0083.0684.00		MK2		
R769	RG 56,2 OHM+-19 CHIP RESISTOR		-	0006.8826.00	ROEDERSTEI	DC2 56,20HM 1%TK100		
R770	RL 0,60W 1,33KC			0083.0684.00		MK2		
R771	RG 15,0 OHM+-1% RESISTDR CHIP		- 1			DC2 15,0DHM 1%TK100		
R772	RG 511 OHM+-1%T CHIP RESISTOR					DC2 5110HM 1%TK100		1
R773	RG 39,2 OHM+-1% RESISTOR CHIP		-	(1)		DC2 39,20HM 1%TK100		
R774	RL 0,60W 1,33KD		1	0083.0684.00		MK2		
R776	RL 0,60W 100 OF RESISTOR		ł	0082.6543.00		MK2		
R777	RL 0,60W 100 DF RESISTOR			0082.6543.00		MK2		
R779	RG 332 OHM+-1%T RESISTDR CHIP					DC2 332DHM 1%TK100		
R780	RG 332 OHM+-1%T RESISTOR CHIP					DC2 3320HM 1%TK100		
R781 R782	RG 150 OHM+-1%T RESISTDR CHIP		1			DC2 1500HM 1%TK100		Ì
K/02	RG 150 OHM+-1%T RESISTOR CHIP	TK100 1206	KG	OO. 88cc. 1 OO	KVEDEKSIEI	DC2 150DHM 1%TK100		
MENP5	413 3PUA	Āl Datum Date		Schallteilli Parts lis		Sachnummar Stock No.		Biatt-Nr. Page
<b>♦</b>		28 16.09.9	7 .	EE AUSGANGSTEI	L 2.08GH7	1062.7005.01	SA	20+
ROHDE	&SCHWARZ			OUTPUT UNIT 2.			~-·	
L								1

Kennz. Comp. No.	Benennung Designation	Sachaummer Stock No.	Hersteller Menufacturer	Sezeichnung Designation		halten in tained in
R783	RG 47,5 OHM+-1%TK100 1206		<del></del>	C2 47,50HM 1%TK100	con	remen tu
R784	RESISTOR CHIP RG 47,5 OHM+-1%TK100 1206	RG 0007.5566.00	ROEDERSTEI DO	C2 47,50HM 1%TK100		
R785	RESISTOR CHIP RG 1,0 KO +-1%TK100 1206	1		C2 1,0KOHM 1%TK100		
790 R791	CHIP RESISTOR RL 0,60W 100 OHM+-1%TK50	RL 0082.6543.00				
1	RESISTOR NICHT BESTUECKT	NE 0002:0348:00	ACSISTA MIN	\ <del>\</del>		
,	NOT FITTED					
R792	RL 0,60W 100 OHM+-1%TK50 RESISTOR	RL 0082.6543.00	RESISTA MK	(2		
	NICHT BESTUECKT	J				
R793	RG 82,5KOHM+-1%TK100 1206 CHIP RESISTOR	RG 0007.1925.00	ROEDERSTEI DO	2 82,5KOHM 1%TK100		
R794	RG 12,1KOHM+-1%TK100 1206 CHIP RESISTOR	RG 0007.0841.00	ROEDERSTEI DC	2 12,1KOHM 1%TK100		
R800	RG 10,0KOHM+-1%TK100 1206 RG CHIP RESISTOR	RG 0007.0793.00	ROEDERSTEI DC	2 10,0KOHM 1%TK100		
R801	RG 10,0K0HM+-1%TK100 1206	RG 0007.0793.00	ROEDERSTEI DC	2 10,0KOHM 1%TK100		
R802	RG CHIP RESISTOR RG 8,25KOHM+-1%TK100 1206	RG 0007.0770.00	ROEDERSTEI DC	2 8,25KOHM 1%TK100		
R803	CHIP RESISTOR RG 8,25KOHM+-1%TK100 1206		ł	2 8,25KOHM 1%TK100		
R804	CHIP RESISTOR RG 332 OHM+-1%TK100 1206		į	2 3320HM 1%TK100		
R805	RESISTOR CHIP RG 332 OHM+-1%TK100 1206			2 3320HM 1%TK100		
R806	RESISTOR CHIP RG 475 OHM+-1%TK100 1206	•		2 4750HM 1%TK100		
R807	RESISTOR CHIP RG 475 OHM+-1%TK100 1206		1	2 4750HM 1%TK100		
R808	RESISTOR CHIP RG 121 OHM+-1%TK100 1206					
R809	CHIP RESISTOR			2 1210HM 1%TK100		
1009	RG 150 OHM+-1%TK100 1206 RESISTOR CHIP	KG 0007.5589.00	RUEDERSTEI DC:	2 1500HM 1%TK100		
	NICHT BESTUECKT NOT FITTED					
R810 812	RG 68,1 OHM+-1%TK100 1206 CHIP RESISTOR			2 68,10HM 1%TK100		
R813	RG O-OHM WIDERSTAND-CHIP RESISTOR CHIP O-OHM	RG 0007.5108.00	DRALORIC CR	1206		
R815	RG O-OHM WIDERSTANO-CHIP RESISTOR CHIP O-OHM	RG 0007.5108.00	DRALORIC CR	1206		
R816		RG 0007.5520.00	ROEDERSTEI OCA	2 33,20HM 1%TK100		
R817		RG 0007.5589.00	ROEDERSTEI OC	2 1500HM 1%TK100		
	NICHT BESTUECKT NOT FITTEO					
R818	RG 22,1 OHM+-1%TK100 1206	RG 0007.5489.00	ROEDERSTEI DC2	2 22,10HM 1%TK100		
R819	RG 1,0 KO +-1%TK100 1206			2 1,0KOHM 1%TK100		
R820	RG 10.0 OHM+-1%TK100 1206	RG 0006.8649.00		(8) 1206		Ì
R821	CHIP -RESISTOR RG 10,0KOHM+-1%TK100 1206	RG 0007.0793.00		2 10,0KOHM 1%TK100		
R822	RG CHIP RESISTOR RG 3,16KOHM+-1%TK100 1206	0007.0670.00				:
R823	CHIP RESISTOR			2 1210HM 1%TK100		
R824	CHIP RESISTOR			2 2,21KOHM 1%TK100		
R825	RESISTOR CHIP			1		
1	RESISTOR CHIP			2 2210HM 1%TK100		
R826	RESISTOR CHIP	İ		2 18,20HM 1%TK100		
R827	RESISTOR CHIP			2 47,5KOHM 1%TK100		
R828	RESISTOR CHIP O-OHM	RG 0007.5108.00		1206		
R829	CHIP RESISTOR			2 5620HM 1%TK100		
R830	RG 1,0 KO +-1%TK100 1206 CHIP RESISTOR	RG 0006.7271.00	ROEDERSTEI DC2	1,0K0HM 1%TK100		
MENP5	413 3PUA At Datum	Schaltteilli		Sechnummer		Blatt-Nr.
	TID OF DE Date	Parts list	l for	Stock No.		Pegs
POUDI	28 16.09.97	EE AUSGANGSTEI	L 2.08GHZ	1062.7005.01	SA	21+
ועמטא	EQSUTWARE	OUTPUT UNIT 2.	O8GHZ			

Kennz. Comp. No.	Benennung Designation		Sachnummer Stock No.	Hersteller Manufacturer	Bezelchnung Designation		iten in Ined in
R831	RG 10,0 0HM+-1%TK100 120	S R	G 0006.8649.00	ORALORIC	CR(8) 1206		
R832	CHIP -RESISTOR RG 10,OKOHM+-1%TK100 120	5 R	G 0007.0793.00	ROEOERSTEI	OC2 10,0KOHM 1%TK100		
R834	RG CHIP RESISTOR RG 3,16KOHM+-1%TK100 120	3	0007.0670.00	RESISTA	OC 2		
R835	CHIP RESISTOR RG 47,5KOHM+-1%TK100 120	s R	G 0007.5950.00	ROEDERSTEI	DC2 47,5KOHM 1%TK100		
R836	RESISTOR CHIP RG 2,21KOHM+-1%TK100 120	s R	G 0007.5743.00	ROEOERSTEI	OC2 2,21KOHM 1%TK100		
R837	RESISTOR CHIP RG 18,2 OHM+-1%TK100 120	R	G 0007.5466.00	ROEOERSTEI	OC2 18,20HM 1%TK100		
R838	RESISTOR CHIP RG 18,2 OHM+-1%TK100 120	R	0007.5466.00	ROEOERSTEI	OC2 18,20HM 1%TK100		
R839	RESISTOR CHIP RL 0,40W 820 OHM2% UNGEW	RI	0092.6069.00	RESISTA	MK1 8200HM 2% UNG.		
R841	RESISTOR RG 0,05W 100R +-1% 080	R	9007.9003.00	HONEST JAP	MR 08 M 100R 1% 0805		
R841	RESISTOR NUR VAR/ONLY MOO: O2 O4 RG O-OHM WIDERSTAND-CHIP RESISTOR CHIP O-OHM	RO	G 0007.5108.00	DRALORIC	CR 1206		
R842	NUR VAR/ONLY MOD: 03 06 RG 0,05W 100R +-1% 080 RESISTOR	RO	0007.9003.00	HONEST JAP	MR 08 M 100R 1% 0805		-111
R842	NUR VAR/ONLY MOO: 02 04 RG 0,05W 100R +-1% 080 RESISTOR NUR VAR/ONLY MOO: 03 06	R	9007.9003.00	HONEST JAP	MR 08 M 100R 1% 0805		
R843	NICHT BESTUECKT/NOT FITT RG 10K +-1% TK200 060		G 0009.5357.00	ORALORIC	CR 0603 1DK 1% TK200		14.
R844	SMD-RESISTOR EIAO603 RG 3,92KOHM+-1%TK100 120		0007.5808.00		OC2 3,92KOHM 1%TK100		
R845	RESISTOR CHIP RG 3,92KOHM+-1%TK100 120	R	0007.5808.00	RESISTA	DC2 3,92KOHM 1%TK100		
R846	RESISTOR CHIP RG 100 OHM+-1%TK100 120	R	0006.8884.00	ROEOERSTEI	OC2 1000HM 1%TK100		
R847	CHIP RESISTOR RG 121 OHM+-1%TK100 120	R	0006.8903.00	ROEOERSTEI	OC2 1210HM 1%TK100		
R848	CHIP RESISTOR RG 1,21KOHM+-1%TK100 120	R	0006.9968.00	ROEDERSTEI	DC2 1,21KOHM 1%TK100		
R849	CHIP RESISTOR RG 47,5 OHM+-1%TK100 120	R	0007.5566.00	ROEDERSTEI	OC2 47,50HM 1%TK100		
	RESISTOR CHIP NICHT BESTUECKT NOT FITTEO						11
R850	RG 100,0K0H+-1%TK100 120 CHIP RESISTOR	-					
R851	RS 0,25W 2KOHM +-20% SMD POTENTIOMETER	RS	0007.9626.00	SIEMENS	S4G-2KOHM		
R852	RG 100,0K0H+-1%TK100 120 CHIP RESISTOR				OC2 100KOHM 1%TK100		
R853	RG 39,2 OHM+-1%TK100 120 RESISTOR CHIP	-			OC2 39,20HM 1%TK100		
R854	RG 1,0M0HM+-1%TK100 120 CHIP RESISTOR NICHT BESTUECKT	RO	6 0815.7532.00	ORALORIC	CRC 1206		
R855	NOT FITTEO RG 4,32KOHM+-1%TK100 120 RESISTOR CHIP	RG	0007.5814.00	RESISTA	OC2 4,32KOHM 1%TK100		
R856	RG 3,32KOHM+-1%TK100 120 RESISTOR CHIP				OC2 3,32KOHM 1%TK100		
R857	RG 4,32KOHM+-1%TK100 120 RESISTOR CHIP		6 0007.5814.00		OC2 4,32KOHM 1%TK100		
R858	RG 56,2 OHM+-1%TK100 120 CHIP RESISTOR	1			DC2 56,20HM 1%TK100		
R859	RG 56,2 OHM+-1%TK100 120 CHIP RESISTOR				OC2 56,20HM 1%TK100		Ì
R860	RG O-OHM WIDERSTAND-CHIP RESISTOR CHIP O-OHM		0007.5108.00		CR 1206		
R861	RG 475 OHM+-1%TK100 120 RESISTOR CHIP				OC2 4750HM 1%TK100		
R862	RG 3,32KOHM+-1%TK100 120 RESISTOR CHIP	- 1			DC2 3,32KOHM 1%TK100		
R863	RG 392 OHM+-1%TK10D 120 RESISTOR CHIP				0C2 3920HM 1%TK100		
R866	RG 1,0M0HM+-1%TK100 120 CHIP RESISTOR	i IRG	6 0815.7532.00	ORALORIC	CRC 1206		
MENP5	413 3PUA Äl Datum Date		Schaltteill Parts lis		Sachnummer Stock No.		Blatt-Nr. Page
ROHDI	28 16.09.	7	EE AUSGANGSTE	IL 2.08GHZ	1062.7005.01	SA	22+

Kennz. Comp. No.	Banen Design				Sachnummer Stock No.		Hersteller Manufacturer		ezeichnung lesignation			naiten in tained in
R867	RG 3,92KOHM+-		1206	RG	0007.5B08	3.00			3,92KDHM	1%TK 100	22	
R868	RESISTOR CHIP RG 681 KOHM+- RESISTOR CHIP	1%TK 100	1206	RG	0007.6110	.00	ROEDERSTEI		2 681KOHM 1			
R869	RG 825 KOHM+-	1%TK 100	1206	RG	0007.6133	.00	ROEDERSTEI	DC2	825KOHM 1	%TK 100		
R870	RESISTOR CHIP RG 22,1KOHM+- RESISTOR CHIP		1206	RG	0007.5872	.00	ROEDERSTEI	DC2	2 22,1KOHM	1%TK 100		
RB71	RG 10,0KOHM+-		1206	RG	0007.0793	.00	ROEDERSTEI	DC2	10,0KOHM	1%TK100		
874 RB75	RG CHIP RESIST		1206	RG	0007.5714	.00	ROEDERSTEI	DC2	1,5KOHM 1	%TK 100		
RB76	RESISTOR CHIP RG 392 DHM+~1%	%TK 100	1206	RG	0007.5672	.00	ROEDERSTEI	DC2	3920HM 1%1	TK 100		
R880	RESISTOR CHIP RL 0,40W 470 [	OHM2% UN	NGEW.	RL	0092.6030	.00	RESISTA	MK 1	470DHM 2%	UNGEW.		
RBB2	RESISTOR RG 1B,2 OHM+-1	1%TK 100	1206	RG	0007.5466	.00	ROEDERSTEI	DC2	18,20HM 1%	6TK 100		
R887	RESISTOR CHIP RG 221 OHM+-1% RESISTOR CHIP	6TK 100	1206	RG	0007.5614	.00	ROEDERSTEI	DC2	2210HM 1%T	ΓK 100		
R889	RG 47,5 OHM+-1 RESISTOR CHIP NICHT BESTUECK		1206	RG	0007.5566	.00	ROEDERSTEI	DC2	47,5DHM 1%	₹К 100		
R898	NOT FITTED RG 100R +-1% T		0603	RG	0009.5334	.00	DRALORIC	CR	0603 100R 1	%TK200		
R899	SMD-RESISTOR E RG 1,0MOHM+-1%		1206	RG	0815.7532		DRALORIC	CRC	1206			
	CHIP RESISTOR NICHT BESTUECK NOT FITTED	ΙT										
U600	BM LRMS-2 HYBRID MIXER	MIXER	1GHZ		1062.6273	.00	MINI-CIRCU	LRM	S-2	f		
U666	BM AK3000-1 FREQUENCY DOPP	DOPP PLER	LER		1039.1256	.00	MINI-CIRCU	AK-	3000-1			
V11	AO 8AS32 OIODE	<b>7</b> 5V	UDI	ΑO	0006.7288	.00	PHILIPS	BAS	32 (L)			
V12		<b>7</b> 5V	UDI	ΑO	0006.7288.	.00	PHILIPS	8AS	32 (L)	1		
V13		45V 20	OMA .	AK	0007.3105.	.00	VALVO	всх	<b>7</b> 0 H			
V14		<b>7</b> 5V	UOI .	AO	0006.7288.	.00	PHILIPS	BAS	32 (L)			
V15	NICHT BESTUECK AO BAS32 DIOOE	75∨	UDI	AD I	0006.7288.	00	PHILIP\$	8AS3	32 (L)			
V25		75V		AD :	0006.7288.	.00	PHILIPS	BASS	32 (L)			
V26	OIOOE AD BAS32 DIODE	75V	UOI	AD (	0006.7288.	00	PHILIPS	BASS	32 (L)	1		
V35	AE BZV55/C5V1 ZENER DIDDE	0.5W	ZDI	AE :	0006.9839.	00	PHILIPS_SE	BZV5	55B5V1 (GEG	)		
V110		6,2V REF	FDI /	AE (	0418.0029.	00	COMPENSATE	1NB2	27(A)			
V130		70V DUO	UDI	AD (	0911.0092.	00	VALVO	BAV9	9			
V134		70V DUO	UDI	AD (	0911.0092.	00 1	/ALVD	BAV9	9	}		
V200	AK BCX70H N TRANSISTOR	45V 200	AMC	AK (	0007.3105.	00 \	VALVO	всх	<b>7</b> 0 H			
V310	AE BAR61 3X(PI) PIN DIODE ARRAY		PIN NU.)	•	4001.5082.	00 5	SIEMENS	BAR6	1(Q62702A12	20)		
V315	AE BAR61 3X(PI) PIN DIDDE ARRAY	) 100V	PIN	•	4001.50B2.	00 5	SIEMENS	BAR6	1(Q62702A12	20)		
V31B		70V DUD		AD (	0911.0092.	00 \	VALVD	BAV9	9			
V319		70V DUD	UDI /	AD (	0911.0092.	00 \	VALVD	BAV9	9			
V330	AD BAV99 7	70V DUD	UDI /	AD (	0911.0092.	00 \	/ALVO	BAV9	9			
V333		70V DUO			0911.0092.	ŀ		BAV9	9	مي		
V335 337		70V DUO	UDI A	AD (	0911.0092.	00 \	/ALVO	BAV9	9			
V400	AE BAR61 3X(PI) PIN DIODE ARRAY	) 100V / (ATTEN	PIN NU.)	4	400 <b>1.5</b> 0B2.	00 \$	SIEMENS	BAR6	1(Q62702A12	20)		
,										1		
MENPS	413 3PHA		tum			taillis			Saci	hnummer		Blatt-Nr.
MENP5	413 3PUA		tum ate			ttaillis Is list				hnummer ock No.		Blatt-Nr. Page

Kennz. Comp. No.	Benenn Designe				Sechnummer Stock No.	Kersteller Manufacturér		ezeichnung esignetion		iten in ined in
V404	AD BAV99	-	DUO UDI	ΑD	0911.0092.00		BAV	<del></del>		
V405		70V	IDU OUDI	AD	0911.0092.00	VALVO	BAV	99		
V410	DIODE BM MSA1105 O	5-1	.3G MMIC		1051.4051.00	AVANTEK	MSA	-1105-TR1		
V411	IC MICROWAVE M AD BAS32	DNO 75V		AD	0006.728B.00	PHILIPS	BAS	32 (L)		
V431	DIODE AK BCX70H N		V 200MA	l	0007.3105.00			70 H		
438 V500	TRANSISTOR AE BAR64-04 CA				1039.1327.00			6404 (Q62702-A101		
V511	DUAL PIN DIODE AE BAR64-04 CA				1039.1327.00			6404 (Q62702-A101		
	DUAL PIN DIODE					ļ		A		
V512	DUAL PIN DIODE				1039.1327.00			6404 (Q62702-A101		
V514 516	AE BAR64-04 CA DUAL PIN DIODE				1039.1327.00			6404 (Q62702-A101		
V520	AE BAR64-04 CA DUAL PIN DIDDE				1039.1327.00			6404 (Q62702-A101		
V523	AE BAR64-04 CA DUAL PIN DIODE	DO	PPEL PIN		1039.1327.00	SIEMENS		6404 (Q62702-A101		
V530	AE BAR64-04 CA DUAL PIN DIODE	DO	PPEL PIN		1039.1327.00	SIEMENS	BAR	6404 (Q62702-A101		
V532	AE BAR64-04 CA DUAL PIN DIODE	וסם	PPEL PIN		1039.1327.00	SIEMENS	BAR	6404 (Q62702-A101		
V535	AE BAR64-04 CA DUAL PIN DIODE	DO	PPEL PIN		1039.1327.00	SIEMENS	BAR	6404 (Q62702-A101		
V536	AE BAR64-04 CA DUAL PIN DIODE	DO	PPEL PIN		1039.1327.00	SIEMENS	BAR	6404 (Q62702-A101		
V539	AE BAR64-04 CA	DOF	PPEL PIN		1039.1327.00	SIEMENS	BAR	6404 (Q62702-A101		
V540	DUAL PIN DIODE AE BAR64-04 CA	DO	PPEL PIN		1039.1327.00	SIEMENS	BAR	6404 (Q62702-A101		
V543	DUAL PIN DIDDE AE BAR64-04 CA	DOF	PPEL PIN		1039.1327.00	SIEMENS	8AR	6404 (Q62702-A101		
V544	DUAL PIN DIODE AE BAR64-04 CA	DOF	PPEL PIN		1039.1327.00	SIEMENS	BAR	6404 (Q62702-A101		
V54B	DUAL PIN DIODE AE BAR64-04 CA	DOF	PPEL PIN		1039.1327.00	SIEMENS	BAR	6404 (Q62702-A101		
V600	DUAL PIN DIODE AE 8ZX55/B6V2	0,	,5W ZDI	ΑE	0012.2161.00	PHILIPS	8ZX	7986V2		
V602	ZENER DIODE AK 8FQ34T N		/ 150MA		0801.8283.00		8FQ:	1		
V604	TRANSISTOR		SCHOTTKY		1010.6214.00		_			
V606	SCHOTTKY DIODE	PA:			1010.6214.00	_		1		
V608	SCHOTTKY DIODE		IR	Δħ	0006.7288.00			32 (L)		
V610	DIODE AE 8ZV55/C5V1		.5W ZDI		0006.9839.00					
V610	ZENER DIODE AK BFQ34T N		/ 150MA	~-	0801.8283.00		8FQ:			
V635	TRANSISTOR	75V		ΛD	0006.72BB.00		-	32 (L)		
V635 V636	DIDDE			:						
	REFERENCE DIDDE	•	/ REFDI		0418.0029.00					
V656	DIODE	75V		ΑIJ	0006.72BB.00			32 (L)		
V670	BM MSAO4B6 DC-3 BROADBAND AMPLI NICHT BESTUECKI	FIE			OB46.4293.00	AVANIEK	MSA	-0486		
V671			3G MMIC		1051.4051.00	AVANTEK	MSA	-1105-TR1		
V680				AD	0911.0092.00	VALVO	BAV	99		
6B3 V700	DIODE AE HSMS2825 14				1010.6214.00	HEWLETT_PA	HSM:	S2825 L31		
V705	SCHOTTKY DIODE AE BAR64-04 CA	PA1	IR .		1039.1327.00			6404 (Q62702-A101		
V707	DUAL PIN DIODE AE BAR64-04 CA				1039.1327.00			6404 (Q62702-A101		
V715	DUAL PIN DIDDE	75V		AD	0006.7288.00			32 (L)		
V716	DIODE AD BAS32	75V			0006.7288.00			32 (L)		
	DIDDE									
MENP5	413 3PUA	ÄΙ	Detum Date		Schaftleilli Parts lis			Sachnummer Stock No.		Blatt-Nr. Page
				-					0.5	
ROHDI	E&SCHWARZ	2B	16.09.97	E	EE AUSGANGSTEI	L 2.08GHZ		1062.7005.01	<b>5</b> A	24+
				1	OUTPUT UNIT 2.	O8GHZ				1

Für claso Unterlago bahalton wir uns alle Rechto vor.

Kannz. Comp. No.	Senen Design				Sechnummer Stock No.	Hersteller Manufacturer		ezelchnung esignation		reiten in tained in
V717	AE BZV55/C6V2	1	O,5W ZDI	AE	0006.9851.00	PHILIPS	BZV	55B6V2	·	
V718	ZENER DIODE AE BZV55/C6V2 ZENER DIODE	1	O,5W ZDI	AE	0006.9851.00	PHILIPS	BZV	55B6V2		
V720	AE BAR64-04 CA		OPPEL PIN		1039.1327.00	SIEMENS	BAR	6404 (Q62702-A101		
V725	DUAL PIN DIODE AE BAR64-04 CA DUAL PIN DIODE	A De	OPPEL PIN		1039.1327.00	SIEMENS	BAR	6404 (Q62702-A101		
V730	AE BAR64-04 CA	A DI	OPPEL PIN		1039.1327.00	SIEMENS	BAR	6404 (Q62702-A101		
V735	AE BAR64-04 CA	) DE	OPPEL PIN		1039.1327.00	SIEMENS	BAR	6404 (Q62702-A101		
V745	AE BZV55/C6V2 ZENER DIODE		),5W ZDI	AE	0006.9851.00	PHILIPS	BZV	55B6V2		
V746	AE BZV55/C6V2 ZENER DIODE	(	0,5W ZDI	AE	0006.9851.00	PHILIPS	BZV	55B6V2		
V747	AD BAS32 DIODE	75\	/ UDI	AD	0006.7288.00	PHILIPS	BAS	32 (L)		
V748	AD BAS32 DIODE	75\	/ UDI	AD	0006.7288.00	PHILIPS	BAS	32 (L)		
V750 753	AD BAS32 DIODE	75∖	/ UDI	AD	0006.7288.00	PHILIPS	BAS	32 (L)		
V765	AD BAV99 DIODE	70\	DUD UDI	AD	0911.0092.00	VALVO	BAV	99		
V766		70V	DUO UDI	AD	0911.0092.00	VALV0	BAV	99		
V76B	AE BAR61 3X(PI PIN DIOOE ARRA		100V PIN ATTENU.)		4001.5082.00	SIEMENS	BAR	61(Q62702A120)		
V769	BM MSAO486 DC- BROADBAND AMPL	3.2	G MMIC		0846.4293.00	AVANTEK	MSA-	-0486		
V770 775	AE BAR64-04 CA DUAL PIN DIODE				1039.1327.00		BAR	6404 (Q62702-A101		
V780	8M MSAO486 DC- 8ROAOBANO AMPL NICHT BESTUECK	IFI			0846.4293.00	AVANTEK	MSA-	-0486		
V782	NOT FITTEO AE BAR64-04 CA		PPEL PIN		1039.1327.00	SIEMENS	BARE	6404 (Q62702-A101		
787 V801	BM MSA0486 OC-	3.2	- 1		0846.4293.00	AVANTEK	MSA-	0486		
V802	8ROAO8AND AMPL AE BZV55/C6V2		ER ,5W ZDI	ΑE	0006.9851.00	PHILIPS	8ZV5	55B6V2		
V803	ZENER OIODE AE BZV55/C6V2	0	,5W ZDI	ΑE	0006.9851.00	PHILIPS	BZVS	5586V2		
V804		75V	UDI	ΑO	0006.7288.00	PHILIPS	8AS3	2 (L)		
V805	DIOOE AO 8AS32 DIOOE	75V	UDI	ΑD	0006.7288.00	PHILIPS	8AS3	2 (L)		
V814		75V	UDI	AD	0006.7288.00	PHILIPS	BASS	2 (L)		
V815		75V	UDI	ΑD	0006.7288.00	PHILIPS	BAS3	2 (L)		
V816	AK BCX71J P TRANSISTOR	45	V 200MA	ΑK	0007.2096.00	VALVO	8CX7	1J GEGURTET		
V817		ΓRΑ	NSISTOR		1039.1404.00	AVANTEK	AT~6	4020		
V827		75V	UDI	AD	0006.7288.00	PHILIPS	BAS3	2 (L)		
VB2B	AK BCP6B-16 N TRANSISTOR BCP6		V TRANS		0008.2019.00	PHILIPS	вср6	8-25		
V829			V 200MA	AK	0007.2096.00	VALVO	всх7	1J GEGURTET		
V830		75V	UDI	AD	0006.7288.00	PHILIPS	BAS3	2 (L)		
V831	AK BCX71J P TRANSISTOR	45	V 200MA	AK	0007.2096.00	VALVO	всх7	1J GEGURTET		İ
V832		ΓRΑΙ	NSISTOR		1039.1404.00		AT-6	4020		
VB33	AK BCX71J P TRANSISTOR	451	/ 200MA	AK	0007.2096.00	VALVO	BCX7	1J GEGURTET		
V834	AK BCP68-16 N TRANSISTOR BCP6		V TRANS		0008.2019.00	PHILIPS	BCP6	8-25		
VB44	AE BAT62 1+1 40 DIODE PAIR	OV :			1051.4045.00			2 (62)		
V850	AE HSMS2825 14 SCHOTTKY DIODE	PA:			1010.6214.00					
VB53	AD BAS32 7 DIODE	75V	UDI	ΑD	0006.7288.00	PHILIPS	BAS3	2 (L)		
MENP5	413 3PUA	ÄI	Detum Date		Scheittellis Perts list		1	Sechnummer Stock No.		Blett-Nr. Page
\$\hat{\sigma}		28	16.09.97	F	E AUSGANGSTEI	2 08047		1062.7005.01	ςΛ	051
	&SCHWARZ		.0.03.37		OUTPUT UNIT 2.0			.002.7005.01	JA	25+

NB   NB   NB   NB   NB   NB   NB   NB	Kennz. mp. No.	i F	Benennung Designation			Sachnummer Stock No.	Harsteller Manufacturer	Bezeichnung Designation		alten in alted in
NSTO   AD 8AS32   75V   UDI   AD 0006.7288.00   PHILIPS   BAS32 (L)	/857	AD 8AS32	<del></del>	UDI	AD				Con	
V871   AE IN927	/870	DIODE AD 8AS32	75V	-						
V874   8M MSAO486 DC-3-26   MMIC BROADBAND AMPLIFIER	/871	AE 1N827		V REFDI	ΑE	0418.0029.00	COMPENSATE	1N827(A)		
V875	/874	8M MSA0486	DC-3.2			0846.4293.00	AVANTEK	MSA-0486		
V876   AE BAR61 3X(PI) 100V PIN PIN DIODE ARRAY (ATTENU.)	/875	AE HSMS282	5 1+1	SCHOTTKY		1010.6214.00	HEWLETT_PA	HSMS2825 L31		
V877	/876	AE BAR61 3	X(PI)	100V PIN		4001.5082.00	SIEMENS	BAR61(Q62702A120)		
X2	/877 .	AE BAR61 3	X(PI)	100V PIN		4001.5082.00	SIEMENS	8AR61(Q62702A120)		
CDNNECTOR 32P. FP STIFTLEISTE 4P.R2,54 PF 0009.6147.00 PIN CONNECTOR FJ EINBAUWINKELST. SMC ANGLE CONNECTOR FJ EINBAUWINKELST. SMC ANGLE CONNECTOR FJ O249.9684.00 ROSENBERGE 39S-205-400-D3	/1	DW KABEL W	1			1062.7086.00				
PIN CONNECTOR   FJ EINBAUWINKELST. SMC   ANGLE CONNECTOR							SIEMENS	V42254-B1200-8611		
ANGLE CONNECTOR   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Consideration   Considerat										
SMD-FILTER   LD SMD PI-FILTER 10GHZ   SURFACE-MOUNT-FILTER   LD SMD-T-FILTER 3,3NF   SMD-FILTER 3,3NF   SMD-FILTER 3,3NF   SMD-FILTER 3,3NF   SMD-FILTER 3,3NF   SMD-FILTER 10OPF   SMD-T-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF   SMD-FILTER 10OPF				. SMC	FJ	0249.9684.00	ROSENBERGE	39S-205-400-D3		
LD SMD PI-FILTER 10GHZ SURFACE-MOUNT-FILTER   LD SMD-T-FILTER 3,3NF SMD-FILTER   LO SMD-T-FILTER 3,3NF SMD-FILTER   LO SMD-T-FILTER 3,3NF SMD-FILTER   LO SMD-T-FILTER 100PF   SMD-FILTER   LO SMD-T-FILTER 3,3NF SMD-FILTER   LO SMD-T-FILTER 3,3NF SMD-FILTER   LO SMD-T-FILTER 3,3NF SMD-FILTER   LO SMD-T-FILTER 3,3NF SMD-FILTER   LO SMD-T-FILTER 100PF   1039.1356.00   MURATA   NFM61R00T1D1T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NFM61R20T332T1   NF				,3NF		1039.1362.00	MURATA	NFM61R2OT332T1		
LD SMD-T-FILTER 3,3NF   1039.1362.00   MURATA   NFM61R20T332T1	.2	LD SMD PI-	FILTER		LD	0008.5901.00	OXLEY	SLT/P/22000/SM3		
LO SMD-T-FILTER 3,3NF   1039.1362.00   MURATA   NFM61R20T332T1	3 1	LD SMD-T-F	ILTER 3			1039.1362.00	MURATA	NFM61R20T332T1		
LD SMD-T-FILTER 100PF   1039.1356.00   MURATA   NFM61R00T1D1T1	4   1	LO SMD-T-F	ILTER 3	,3NF		1039.1362.00	MURATA	NFM61R2OT332T1		
Z10 LO SMD-T-FILTER 3,3NF SMD-FILTER 100PF SMD-FILTER 100PF SMD-FILTER 100PF SMD-FILTER 100PF SMD-FILTER 100PF SMD-FILTER 100PF SMD-FILTER 100PF SMD-FILTER 100PF SWFACE-MOUNT-FILTER 2700 XX ENTHALTEN IN INCLUDEO IN IN LEITERPLATTE XX ENTHALTEN IN INCLUDEO IN IN LEITERPLATTE XX ENTHALTEN IN INCLUDEO IN IN LEITERPLATTE XX ENTHALTEN IN INCLUDEO IN IN LEITERPLATTE XX ENTHALTEN IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDIO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDIO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDEO IN INCLUDIO IN INCLUDIO IN INCLUDIO IN INCLUDIO IN INCLUDIO IN INCLUDIO IN INCLUDIO IN INCLUDIO IN INCLUDIO IN INCLUDIO IN INCLUDIO IN INCLUDIO IN INCLUDIO IN INCLUDIO IN INCLUDIO IN	5   ι	LD SMD-T-F	ILTER 10	DOPF		1039.1356.00	MURATA	NFM61ROOT1D1T1		
Z11 LD SMD-T-FILTER 100PF SMD-FILTER LD SMD-FILTER LD SMO PI-FILTER 10GHZ SURFACE-MOUNT-FILTER XX ENTHALTEN IN INCLUDEO IN IN LEITERPLATTE XX ENTHALTEN IN INCLUDEO IN IN LEITERPLATTE XX ENTHALTEN IN INCLUDEO IN IN LEITERPLATTE XX ENTHALTEN IN INCLUDEO IN IN LEITERPLATTE XX ENTHALTEN IN INCLUDEO IN IN LEITERPLATTE XX ENTHALTEN IN INCLUDEO IN	10	LO SMD-T-F		, 3NF		1039.1362.00	MURATA	NFM61R20T332T1		
Z20 LD SMO PI-FILTER 10GHZ SURFACE-MOUNT-FILTER  Z700 XX ENTHALTEN IN INCLUDEO IN IN LEITERPLATTE  Z710 XX ENTHALTEN IN INCLUDEO IN IN LEITERPLATTE  Z720 XX ENTHALTEN IN INCLUDEO IN IN LEITERPLATTE  Z720 XX ENTHALTEN IN INCLUDEO IN	11 [	LD SMD-T-F		DOPF .		1039.1356.00	MURATA	NFM61R00T101T1		
Z700 XX ENTHALTEN IN INCLUDEO IN IN LEITERPLATTE Z710 XX ENTHALTEN IN INCLUDEO IN IN LEITERPLATTE Z720 XX ENTHALTEN IN INCLUDEO IN INCLUDEO IN	20   L	LD SMO PI-	FILTER		LD	0008.5901.00	OXLEY	SLT/P/22000/SM3		
IN LEITERPLATTE  Z710	700	XX ENTHALTE	EN IN						1	
IN LEITERPLATTE  Z720	710	IN LEITERPL XX ENTHALTE	LATTE EN IN							
	720	IN LEITERPL XX ENTHALTE INCLUOEO IM	LATTE EN IN							
MENP5 413 3PUA ÄI Datum Schalttgilliste für Sachnummer Stock No.  28 16.09.97 EE AUSGANGSTEIL 2.08GHZ 1062.7005.01 SA	MENP5	413 3PU		Date		Parts lis	t for	Stock No.		Blatt-Ni Page



# **XY-Liste**

# **XY List**

#### Erklärung der Spaltenbezeichnungen:

Part: Bauelement-Kennzeichen.

Side: \_\_ Leiterplatten-Seite, auf der sich das Bauelement befindet.

XY: Koordinaten (Millimeter) des Bauelementes auf der Leiterplatte

bezogen auf den Nullpunkt.

SQR, PG: Planquadrat und Seite des Schaltbildes für das jeweilige Bauelement.

### Explanation of column designations:

Part: Identification of instrument part.

Side: Side of the PC board on which instrument part is positioned.

XY: Coordinates (millimeter) of the component on the PC board in reference

to zero point.

SQR, PG: Square and page of the diagram for the respective instrument part.



 Part		t-Se  e X			 r Pg	Part		 le ¥		 sar		+ Part	 د بۍ		· <b>-</b>		
												<del>-</del>	51Q		·	Sqr 	
303 309	В	1B		3 9				114			2	C327	В				•
310	B B	30 22		1 10 1 11		]		225 232			10 10	C328	В				
413	В	50	6					210			10	C329	A A				
414	В	40	7	-				177			10	C340	B				
506	В	81	В	_		C151		168			10	C356	В				į
507	В	92	10	2 3	0 6	C152		_			10	C357	В				
509	В	92	8	3 4	D 6	C153	В	128	54		10	C359	A				
514	В	96	9	5 5	0 6	C154	A	135	53	6A	10	C360	В	31			
515	В	111	9	5 51	) 6	C156		200	43	4A	10	C361	В	23	83	120	4
516	8		8		•	C157	A	158	53	5A	10	C362	A	48	86	11E	4
518		123	В			C15B		257		6A	10	C400	A	48	84	2C	
519		125	8	_		C159		241			10	C401	В	42		30	5
520		135	9.			C160		135	42	6E	10	C402	В	30		40	5
522 52B		137	7.			C161	A		44		10	C404	A	34	88	3C	5
52B 529	B B	148 148	8; 9;			C162	A		22	10E	10	C405	A	35	91	4C	
542	В	46	9: 9:			C170	A B	188 90	43 18	4A 100		C410	A	42	76	5E	5
543	В	20	11:			C207	В	82	46	8C	3	C412 C417	B A	37 70	72 70	50 7E	5
544	В	23	110		_	C209	A		44	6C	3	C417		126	123	7E 9B	5
545	В	37	11:			C219	В	82	43	8 <b>C</b>	3	C440		133	_	9B	5
548	В	76	132		3 6	C220	A		39	9E	3	C442		114	109	108	5
550	8	145	13	7 88	3 6	C221	8	64	21	9D	3	C445	В	63	86	1C	6
600	8	178	70	21	E 7	C240	8	57	12	10E	3	<b>C</b> 500	В	64	77	2E	6
602	8	63	178	81	11	C242	8	66	16	11F	3	C501	A	83	83	2F	6
607	В	215	83	3 4[	7	C244	A	78	40	4 A	3	C502	В	70	88	2D	6
608		208	86			C245	A	72	49	4A	3	C504	8	78	86	30	6
612		218	62			C250	A	58	62	2A	3	C505	8	79	94	3E	6
650		122				C251	A	64	62	2A	3	C506	В	91	97	3E	6
651 660	В	91	151 62			C252	A	55	5 <b>7</b>	2A	3	C507	8	91	88	4E	6
661		218 218	62			C253	A A	59 63	51 51	2A	3	C509	A	97	86	4F	6
705		150				C255	A	55	47	3A 3A	3	C510 C511	B 8	97 112	90 99	5E 5E	6
706		154			12	C256		164	39	5A	3	C511		110	85	5E	6
707		161			12	C257	A	57	1B	6A	3	C512		104	74	5E	6
708		232			12	C258	A	53	15	5A	3	C514		117	83	6F	6
740	8	192	129			C259		163	34	5A	3	C515		121	85	6E	6
766	В	171	147	50	12	C260		111	44	6A	3	C516		122	99	6E	6
777		226				C261	A	59	30	3A	3	C517		133	90	7E	6
77B		231				C262	A	64	31	3A	3	C518		135	87	7F	6
840		277	53			C263	A	55	25	4A	3	C519		146	77	8E	6
847		280	83			C264		115	44	6A	3	C520		146	86	BE	6
851 B53		288		110		C275	В	163	41	10	3	C521		146	94	8E	6
B53 B57		279 279	79 57			C280		135	37	3C	3	C522		140	77	8E	6
C12		279 208	33			C300	B B	39 24	20 27	30 4D	4 4	C523		140	B6	8E	6
C12		208 113	29			C302	B	34	27	4D 40	4	C524 C525		141 147	94	BE 9E	6
C14		227	44			C313	В	45	29	5C	4	C525		140		9E	6
C15		235	45			C315	В	18	24	50	4	C527		150		9r 11E	6
C16		227	21			C316	В	22	34	60	4	C530	A	59	93	2C	6
C17		239	14			C31B	A	12	37	5C	4	C531	В	72	96	2C	6
C20	В	107	16	20	2	C319	A	15	41	6 <b>C</b>	4	C532	В	52	97	2B	6
C21	В	126	32	3E	2	C325	В	30	3B	60	4	C533	В		104	2в	6
ROHOE	-	 I	- 1	Oatu Oate		* <b></b>			 List list	e fa		Sach-l Stock		er		B1 Pa	
& CHWARZ	+- <b>-</b> ·		03	17.0		EE AUS	GANC		_			1062.	<b>-</b>				 1+



+						+						+				
Part	Side	∍ X 	Y	Sqr 	Pg	Part	Side	∋ X 	Y	Sqr	Pg 	Part +- <del>-</del>	Side X	Y	Sqr	Pg
C534	В	43	104	4 3B	6	C634	В	254	87	8D	7	C726	A 241	135	10E	8
C536	A		109		6	C635		236	95	10D	7	C727	A 169		5E	8
C537	В		115		6	C636		238	98	100	7	C728	A 220		10D	8
C538	B		118		6 6	C637		245	83 85	9E 3A	7 7	C729	A 220 B 184	135 99	10D 6D	8 8
C540	A		120		6	C639		223 219	77	3B	7	C734	B 184 B 177		7C	8
C545	В		132		6	C640		220	92	10E	7	C735	A 180		6C	8
C546	В		131		6	C641		223	. 95	10D	7	C736	A 177	93	7C	8
C547	В		137		6	C642	В	207	95	10D	7	C738	B 191	103	7D	8
C553	A		131		6	C643	В		110	11D	7	C740		113	8D	8
C560	В	113 128			6 6	C644	В	213	113	11E	7	C741		186	3A	
C562	B B	116			6	C645 C646	B B	219	113 109	11D 11D	7 7	C742	A 204 B 210		9E 9D	8 8
C568	В		112		6	C647			114	11E	7	C744	A 272			12
C569	A		114		6	C650		183	69	7A	7	C745	B 148			12
C570	В	102	110	10B	6	C651	A	187	64	7A	7	C747	A 225	131	11D	8
C571	В	102			6	C652		215	67	6A	7	C748	A 228			8
C573	В	111			6	C653		218	67	6A	7	C750	A 211		11E	8
C575	B			) 11B	6 6	C654 C656		242 209	97 67	9D 2B	7 7	C751	A 198 A 203	124 135	11E	8 8
C582				11D	6	C660		157	91	4F	7	C754	A 154		2B	12
C583				120	6	C661		171	86	4F	7	C755	A 157		2B	12
C584	В	144	113	12D	6	C662		157	80	4E	7	C756	A 149		2B	
C585		103	71		6	C663	A	178	75	4E	7	C757	A 146		2B	12
C599					6	C664		210	95	10D	7	C762	A 183		7E	8
C600			86		7	C668		153	72	5 F	7	C765		175	2D	12
C601 C602		175 180	79 69		7 7	C669 C670		121 269	164 109	3E 7F	11	C766 C767	B 103 B 100		2E	12
C603		167	73		7	C671		264	97	7F	7	C768	B 100		2D 2D	12 12
C604		194	74		7	C672	В	129		2D	11	C769	B 109		3D	12
C605	В	217	67	4E	7	C673	В		151	3D	11	C770	A 104		2D	12
C606		220	76		7	C674	A		162	4E	11	C771	A 114	171		12
C607		218	86	_	7	C675	В		151		11	C772	B 119		3D	12
C608 C609		229 181	83 86		7 7	C676	B A		172 177	6D	11	C773		183	11E	12
C610		202	77		7	C677 C678	В		181	7E 7D		C774 C775	B 142 A 131		5D 4E	
C611		168	64		7	C679	В		181	8D		C776	A 187		6C	
C612		128			11	C680	A		190	8E		C777	A 184		6C	
C613		133			11	C681	A		190	8E	11	C778	A 172	166	6C	12
C614		105			11	C682	В		185	9C		C779	A 234		6B	
C615		105			11	C700		151		2D	8	C780	A 207		6B	1
C616	В	264	147 27		11 7	C701 C702		148 148		2D	8 8	C781	A 209 B 194		6A	
C617		256	30		7	C702		166		2E 3C	8	C783 C784	B 194		6E 7D	1
C619		264	37		7	C707		170		4C		C785	B 166		7C	1
C620		255	40		7	C708		166		4C	8	C786	B 205		8C	
C621	В	58	147	4D	11	C709	A	166	120	4C	8	C787	B 203	179	8D	12
C623		116			11	C710		168		4C	8	C788	B 232		8E	
C625		250	69		7	C714		169		4C	8	C789	B 222		7E	
C627 C628		260 269	74 76		7 7	C715 C720		170 180	98 137	5C 4D	8	C790 C791	B 197 B 174		7D 7D	
C629		265	82		7	C720		177		4D	8	C791	B 174		79 79	
C631		183	76		7	C723		184		4D	8	C793	B 210		7D	
C632	В	189	79		7	C724		184		4E	8	C794			7E	
C633	В	260	88	9D	7	C725	A	238	121	10E					9D	12
+	•		:			+ !						1				
ROHDE	-	-I		Datur Date					·List ·list				Nummer			att
& ROHDE	+		 +	nare		 			-TTE		·	Stock	 		Pa   - +	ge
SCHWAR	z		j			EE AUS									i	
			03	17.06	5.96	OUT	PUT_	UNI	2.0	8GHZ	3	1062.	7005.01	XY		2+
+	-+		+			+									+	

ĺ

Part	Side X		Part Side X	Y Sqr Pg	Part Side X Y	Sqr P
C796	B 243	L87 9D 12	C890 A 96		D210-C	
C797		LB7 10D 12		187 11C 11		
C798		185 10D 12	C893 B B6	171 11C 11	D210-E	
C799		l64 11D 12		185 10D 11	D220-A B 57 23	10C
CB00		140 2D 9	D10-A B 230	18 7E 2	D220-B	7D :
C801	A 272		D10-B	6A 2	D220-C	7D :
C802	A 265 1		D100-A B 208	39 8C 2	D220-D	10C :
C803	A 269		D100-B D100-C D100-D D100-E	9C 2	D220-E	3A :
C804	A 262		D100-C	10C 2	D430-A A 120 111	9D !
C805	B 275 1		D100-D	6D 10	D430-B	8B
CB06	A 279 1		D100-E	3A 10	D431-A A 109 111	10B
C808	B 284 1		D102-A B 175	39 2E 10	D431-B D431-C D431-D D431-E D431-F	10E
C810	B 279		1		D431-C	10E
C812	8 280		D105-A B 187	39 3C 10	D431-D	10D
C816	B 274 1	.16 6C 9			D431-E	10D
C817	B 281 1	17 6D 9		8C 10	D431-F	10D
C818	B 284 1	.07 7b 9	1	7A 10	D431-G	10B
C819	B 277 1	.07 7E 9		3A 10		
C820	A 293 1		D110-A B 161			10C
C821	B 286 1		1	2A 10	· ·	100 ·
C828	B 284		D111-A A 14B		The state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the s	11B !
C830		51 10D 9	D111-B		D432-E	
C831		72 9D 9	D111-C		D432-F	
C832	B 280		D111-D	60 10 60 10		
C833	A 260 1				D432-G	
C834			0111-E		0759 B 217 128	
		16 10E 9	D112-A A 148		0760 B 235 130	
C836		44 10D 9	0112-8	68 10	0800 B 270 156	20 9
C839		57 10E 9	D112-C	68 10	L20 B 124 15	20 2
C840	A 154 1		0112-D	7A 10	L21 A 103 16	20 2
C841		08 38 9	D112-E	5A 10	L22 8 98 29	3D 2
C842	A 153 1		0115-A 8 197	39 4C 10	L300 8 27 23	40 4
C843	A 154 1		D115-8 0115-C	- 7C 10	L301 B 45 23	3D 4
C844		21 110 9	0115-C	3E 10	L305 B 39 32	50 4
C846	B 2B3	30 7C 9	l p115-p	7¤ 10	L325 8 17 39	6D 4
C847	B 282	39 8C 9	D115-E	4A 10	L340 B 39 44	8D 4
C848	B 284	22 8C 9	0120-A 8 86	53 7E 10	L350 B 23 67	10D 4
CB49	B 2B2	50 10b 9	D120-B	2A 10	•	10D 4
C850	A 286	91 6A 9	D140-A B 142		ſ	10E 4
C851	A 296	81 7A 9	D140-B	2B 3	_	9D 4
C852	A 278	82 6B 9	D141-A B 146			11D 4
C853		75 6C 9	D141-B	1C 3	l .	11E 4
C854		34 8A 9	D141-C			11D 4
C855		3B 8A 9	D141-D		L400 B 30 83	
C870		36 11B 9	D141-E	4D 3	}	
C871		74 11C 9	D141-E D145-A B 95			4D 5
C880	A 253 1		D145-R B 95		L416 B 72 73	6D 5
C881		92 8E 9	1	5B 3	L417 B 62 70	6E 5
C8B2			D150-A B 74		L431 A 97 89	
		31 10C 11	D150-B	9E 3		11E 5
C883	B 77 11		D200-A B 57		L500 B 81 77	2E 6
C884		72 10C 11	D200-B	4E 3	L505 B 94 89	4F 6
C885	A 152 1		D200-C	4E 3	L510 B 114 86	6F 6
C886	A 155 1		D200-D	4E 3	L517 B 137 91	7F 6
C887	A 72 18		D200-E	1A 3	L520 B 147 119	9E 6
CBBB			D210-A B 57		L530 B 56 93	2C 6
C889	A B5 18	31 10C 11	D210-B	7E 3	L532 B 55 98	2B 6
	-I	Datum			Sach-Nummer	-+  Blat
ROHDE	1	Date	XY-:		Stock-Nr	Page
& SCHWARZ		<del>-+-</del>	EE AUSGANGSTEI	. 2 08000		-+
		17 06 96	Uliabilia tixitu	2 00000	1062.7005.01 XY	3+
	. 0.		. OULFUL UNIT	a contract i	LUDZ ZUUS III XX	

Part S	Side X	Y	 Sqr	Pg	Part	Side X	Y	Sqr	Pg	Part S	 id	 e X	. У	Sqr	Pg
L533	B 20	10	 1 2B	6	L662	A 157	В3	 3F	7	N130-A	 B	142	52	10D	10
L534		10			L663	A 175				N130-B			02	10c	
L536	B 8:	1 10		6	L668	A 157	75	5F	7	N130-C				6A	10
L537	B 57				L669	B 49		7D		N131-A		244	168		
L538		5 110 2 123			L670	A 267		7F		N131-B				10C	
L540		. 12. 5 118			L671 L672	A 264 B 102	93 161	7F	7 11	N131-C N223-A		88	38		10 3
L541		119			L673		164		11	N223-B		00	50	7B	3
L542		123		6	L674		163		11	N223-C				7A	
L543		119		6	L675	B 106	164	4E	11	N228-A	В	60	12	10E	3
L544		134			L676		175		11	N228-B				11E	3
L545		129			L677		175			N228-C				5A	3
L546 L547		129 134		6 6	L678		175 182	90 10D	11	N235-A N235-B	B	76	46	8C 4A	3 3
L548		129		6	L705		134	3C	8	N275-A	В	167	34	2D	3
L549		130		6	L706		135	3C	8	N275-B	_	,	٠.	2D	3
L550	B 26	129	9 6B	6	L709	B 166	121	4C	8	N275-C				5A	3
L551		137		6	L714	B 169	101	5C	8	N276-A	В	111	41	3C	3
L553		135		6	L720	B 1B1		4D	8	N276-B				4B	3
L559		135		6	L727	A 170		5E	В	N276-C	_			6A	3
L560 L561		138 136		6 6	L730	B 183 B 181	112 97	5D	8	N300	В	17	55	9D	4
L562		136		6	L732		100	7C 7D	8 8	N360 N600-A	В	17	72 70	11D 2C	4 7
L563		133		6	L739		110	8D	8	N600-R		210	70	2B	7
L564	B 121			6	L740		138	9D	8	N600-C				3B	7
L565	B 102	128	9B	6	L742	B 211		9E	8	N600-D				3A	7
L566	B 141			6	L748	B 205		9D	8	N600-E				6A	7
L568			10C	6	L754	A 234		11Đ	8	N610-A	A	193	70	3C	7
L570			10B	6	L755	A 157		2B	12	N610-B				5A	7
L571 L572	B 108		7 11B 9 11B	6 6	L756 L765	A 145	150 185		12	N740		194		8D	8
L580			) 11C	6	L766		175		12 12	N776-A N776-B	A	146	108	6C 6B	12 12
L583		117		6	L767	B 137	185		12	N776-C				4A	
L584	B 141	110	11D	6	L768	B 141			12	N777-A	A	146	156	6C	
L585	A 99	74	2A	6	L770	B 259	189			N777-B				6B	12
L600	B 174			7	L771	B 276		11E	12	N777-C				3A	12
L601	B 180			7	L800	B 294		5E	9	N778-A	A	146	179		
L602	B 171			7	L801	B 276		5F	9	N778-B				6B	
L604 L608	A 171 B 218			7 7	L816 L817	B 284 B 293		6D 38	9	N778-C		200	01	3A	
L610	B 220			7	L818	B 295	73	8E	9	N840-A N840-B	А	200	81	6B 10B	9
L612	A 129			11	L819	B 291	86	8E	9	N840-B				10B	9
L613	A 106			11	L829	B 299	34	10E	9	N840-D				11C	9
L630	B 257			7	L830	B 297	47	10E	9	N840-E				6A	9
L632	B 266			7	L831	B 242		10E	9	N845-A	A	283	33	7B	9
L633	B 243			7	L840	A 158		3B	9	N845-B			_	7A	9
L642 L643	B 268			7	L841	A 157		3A	9	P300	В	86	36	6C	3
L645	B 239		9E	7 7	L845 L880	B 277 B 257	17	9B 6F	9	P305 P352	В	67 59		10C	3
L647	B 204			7	L885	B 257 A 156		3B	9	P352 P353	B B	59 62		11D 12E	3 3
L649	B 218			7	N20-A	B 225	41	9B		P355		155	34	2D	3
L650	B 224			7	N20-B		_	10B		P380		119	41	4C	3
L651	B 233	108	12D	7	N20-C			7D	2	P385		109	50	5C	3
L660	A 157			7	N20-D			7C	2	P600		186	62	3C	7
L661	A 171	83	4F	7	N20-E			5A	2	P601	В	187	85	3C	7
+ 	+   +	+ 1	Datum		+ 1									+ 	
ROHDE	<del>-</del> I		Datum Date	•			-List -list			Sach-Nu		er			att
& -	! +	 +			 		112		,,	Stock-N	·			Pa	ge
SCHWARZ	1	į			EE AUSG	ANGSTE	L 2.	08GH	ız İ					i	
		03	17.06			UT_UNIT				1062.70	05	.01	XY		4+
+	+	÷			+										

Part	Si	de X	Y		r Pg	Part	Sid	e X	Y	Sqr 	Pg	Part	Side	∋ X	Y	Sqr	Pg
P620		B 222		2 4		R123		197	45		10	R308	В				
P621		B 223		D 4.		R124		194	45		10	R310	В				
P628		B 177		4 4		R130		128		1DD		R312	В				
P848		B 277		2 70		R131		225	37		10	R313	A				
P866		B 297		3 8		R132		232	36		10	R314	В	41			
R1 R9		A 119 A 226		7 21		R133		236	47		10	R315	В	46			
		n 226 B 219				R134		250				R316	В	45			
R10 R11						R149		200	36		10	R317	В	12			
5		A 229				R160		125	44		1D	R318	В	15			4
R12 R13		B 222 B 212				R161 R162		139	47		10	R319	A				4
R14		B 212						125	47		10	R320	A	15			4
R14		B 212				R163		146	53		10	R321	A	20			4
i		A 210				R165	В		56		10	R325	В	34			4
R16		н 210 В 110		0 110		R166		1D4	56		10	R327	A	21			4
R20		B 143				R167		102 106	56		10	R328	A	23			4
R21		3 143 3 142				R170	B		41		10	R329	В	46			4
R21		3 142 3 181				R170	В		23 23		10 10	R330	A	21			4
R23		3 188 3 188				R171	В	85	30		10	R332 R333	В	46			4
R24		3 193				R172	В	86	19		10 1D	R340	A	26			4
R25		3 199				R206	В		41	1D	3	R340	B B	41 43			4
R26		3 209				R207	В	82	53	5D	3	R341	В	43			4 4
R27		3 164				R208	В	72	53	5E	3	R355	В	17	56		4
R28		3 176				R209	В	54	30	8D	3	R356	В	38			
R29		3 156				R211	В	70	53	5E	3	R357	В	36		10E	4 4
R30		166				R212	В	82	51	7C		R360					
R31		3 172				R212	В	68	47	8D	3 3	R361	8	42		11E	4
R32		3 172 3 178				R213	В	74	31	8E	3	R4D0	B B	55 45		11E	4
R33		3 150				R214	A	60	37	9E	3	R401			81	2D	5
R34		156				R216	В	60	37	8E	3	R401	8	55	84		5
R35		241	2:			R218	В	71		10D	3	R402	В	48	79	2C	5
R36		181	1			R220	В	64		11B	3	R404 R405	A	37 28	84	4D	5 5
R38		218	4:			R221	В	67		9D	3	ŧ .	A		82	4D	
R41		234				R240	В	55		11E	3	R406	A	33	81	4C	5
R42		231	2			R241		66		11E	3	R407 R408	A	29	91	4C	5
R43		229	2			R259		79	48	8C	3	R408	В	42 32	86 91	3 C	5
R44		236				R271		168	37		3	R410	B A				5
R45		229				R272		161	36	3D	3	R410		44			5 5
R46		236				R275		156	41		3	R412		37			5
R47		231	1			R276		173	33		3	R412		85			5
R48		234	14			R278		171	36		3	R417		75		6E	5
R49		221	30			R280		129	42	3C	3	R417	A		101		5 5
R50		239	32			R283		119	43	4B	3	R431			113		5 5
R51		221	28			R284		121	50	4C	3	R432			102		5
R52		221	2			R285		115	50	4C	3	R433			102		5
R53		221	15			R286		91	44	7B	3	R435			112		5
R54		221	23			R299	A		39		3	R436			122		5
R55		221	18			R300	В	42	17	2D	4	R437			135		5
R56		221	20			R3D1	В	39	17	2 D	4	R438			119		5
R116		197	49		10	R302	В	37	17	2 D	4	R440			130		5
R117		157	63		10	R303	В	34	17	2D	4	R442			108		5
R119		238	47		10	R304	В	32	17	2 D	4	R443			113		5
R120		180			10	R305	В		17	2D		R450			95		5
R121		168			10	R3D6	В		17			R451				11D	
R122		82				1	В			3D						11D	
	<u>-</u> +-					<del></del>				<del>-</del>							
	- 1	-I		Datu				XY-	List	e fª	r	Sach-	Numm	er			att
ROHDE				Date				XY-	list	fo	r	Stock	-Nr			Pa	.ge
& SCHWAR							CANO	 :STP		 08cu	1					<b>+</b>	
	-		03	17. D	6.96	EE AUS	DIIT	בבבב. יידאט	 2.n	8CH4		1062	7005	.01	γv		5+
j	ı		77	_,.,		1 301	- ~ 1_			J-114	'	1002.	1000	• 0 1	ΥI	i	⊤د

-3

†					+						+					
Part	Side X	Y 	Sqr 	Pg 	Part	Side	: X	Y	Sqr	Pg	Part	Side	> X	¥	Sqr	Pg
R453	A 95	119	11D	5	R648	A	241	88	9E	7	R709	A	166	114	3C	 8
R454	A 95		11C	5	R649		247	98	9D	7	R710			120		
R455	A 81	114	11C	5	R650	В	89	190	10C	11	R720	A	183	139	3 D	8
R500	A 80	83	2F	6	R651	A	187	81	2C	7	R721	A	178	130	4D	8
R501	A 77			6	R652		184	78	2C	7	R723			130	4E	8
R502	A 75	83		6	R653		206	82	1C	7	R724			123	4E	8
R503	B 75	83	3E	6	R654		202	79	1B	7	R725			126	10E	8
R520 R521			9F 9F	6	R655			101	9D	7	R726			138	10E	8
R521	A 143 A 148		9F	6 6	R656 R657	В	221	190 80	11C 3B	11 7	R727			124	10E	8
R530	B 69	93	2C	6	R658		223	75	3B	7	R728 R730			135 112	10E 5C	8 8
R600	B 164	79	2D	7	R659	В	95	184	11C	11	R731			102	6D	8
R601	B 178	82	2E	7	R660		190	77	2C	7	R732		183	93	7D	8
R602	A 184	79	2E	7	R661	8		161		11	R733			190	11C	11
R603	A 181	75	2E	7	R662	В		157	5D	11	R734		177	97	6C	8
R604	8 189	72	2D	7	R663	В	19	152	5D	11	R735		182	105	6C	8
R605	B 164		2D	7	R670	В	115	161	3D	11	R736		222	120	10D	8
R607	A 193	83	3D	7	R671	В		164	3E	11	R737	A	223	135	10D	8
R608	B 192	74	2D	7	R672	В		164	4D		R738	A				11
R609	B 187	82	2D	7	R673	В		164		11	R739	В		188		11
R611	A 180	64	4C	7	R674	В		150	4D		R740			134	8D	8
R612 R613	A 178 A 197	67 66	3C 3C	7 7	R675 R676	В		147	5C		R741		194		9D	8
R614	A 194	77	3C	7	R675	B B		151 155	5D		R742		191		9D	8
R615	A 197	77	3C	7	R678	8		164	60 60		R743 R745		191 210		9E 9C	8
R616	A 202	69	2B	7	R679	8		158	6D		R747				11D	8 8
R618	A 194	86	2C	7	R680	В		171		11	R748		216		11D	8
R619	B 198	79	2C	7	R681	В		174		11	R750		208		11E	8
R620	A 196	81	28	7	R682	8		185		11	R751		201		11E	8
R621	B 231	80	5E	7	R683	8	63	187		11	R753		201		11E	8
R622	8 186	69	3E	7	R684	8	65	187	8D	11	R754	A	196	120		8
R623	8 231	77	6E	7	R685	A	48	190	8E		R755	A	203	126	11E	8
R624	8 231	74	6E	7	R686	A		187	8E	1	R760			121	11C	8
R625	B 231	72	6E	7	R687	8		182		11	R761				11C	8
R626	8 228 B 230	69	6D	7	R688	В		190	8C		R762		182		7E	8
R627 R628	B 230 B 230	66 64	6D 6D	7 7	R689	A		190	9C		R765		100		2E	
R629	B 186	67	3E	7	R690 R691	B B		189	9C 10C		R766		100		2D	
R630	B 264	24	5C	7	R692	A		177	9C	,	R767 R768		113 119		2C	
R631	B 264	15	5B	7	R693	A			10C		R769		104		2D 2D	
R632	B 241	64	6D	7	R694	A		182	9C		R770		119		3D	1
R633	A 212	63	2C	7	R695	A			10C		R771		111		3C	
R634	B 264	21	5C	7	R696	A			10C		R772		109		3D	
R635	A 206	72	2A	7	R697	A	91	183	11C	11	R773		118		3C	
R636	A 206	74	2B	7	R698	A			10C		R774		121		3C	
R637	A 213	85	38	7	R699	A			11C		R776		124		4E	1
R638	A 213	83	3A	7	R700		154		2D	8	R777		135		4E	
R639	A 217	83	3A	7	R701		154		2D	8	R779		187		6C	
R640 R641	B 258 B 269	46 69	6C	7	R702		153		3D	8	R780		232		6B	
R641	B 243	67	8D 7D	7 7	R703 R704		225 150	138		8	R781		191		6C	
R644	B 264	88	8D	7	R704 R705		142		2D 3E	8	R782 R783		207 172		6B	1
R645	B 252	80	9D	7	R706		169		4C	8	R784		205		6C 6B	1
R646	B 249	79	9D	7	R707		169		4C	8	R785		203 197		6E	•
R647	в 241	81	9E	7	R708			138		8	R786		197		6D	
	+	+-		+						+					-+	+
	-I	ם	atum	[			XY-	List	e f¤	r	Sach-1	Numme	er		Bl	att
ROHDE		D	ate				XY-	list	fo	r	Stock-	-Nr				ge
& 	+	+-		+				<b></b>							-+	<del>:</del>
SCHWARZ	i	٦,	7.06.		EE AUSC						1000					ا رم
	   <del> </del>	+-	. , , , , , , , , , , , , , , , , , , ,	70	OUT	eur_u	NT.T.		oghz 	<u> </u>	1062.7	/005	.01	XY	 	6+
	·			+						+					-+	+

ļ

Part	Side	∍ X	¥	Sqr	Рg	Part	Side	x	Y	Sqr	Pg	Part	Sid	ie X	Y	Sqr	Рg
+   R787	 В	168	170	7C	 12	R850	 A 2	288	110	 5B	 9	V404		23	77	4C	 5
R788		2D3				R851	В 2		93	5B		V405		22			5
R789		206				R852	A 2		89	5 B		V410		54			5
R790		234				R853	В 2		75	8D		V411		40			5
R791	В	276	182	2 11E	12	R854	A 2		72	5B		V431		102		11E	5
R792				11E	12	R855	A 2	287	70	6B	9	V432		124		11E	5
R793		140			12	R856	A 2		26	7B	9	V433	P	132	96	11D	5
R794		142				R857	A 2		41	7B		V434				11D	5
R800		271			9	R858			112		9	V435				11D	5
R801		263			9	R859			107		9	V436				11C	5
R802 R803		275 262			9	R860 R861	B 2 A 2		75		9	V437			134		5
R804		276			9	R862	A 2		43 79		9	V438 V500		75	115 84		5
R805		265			9	R863	A 2		46			V511		99			6 6
R806		271			9	R866	A 2		47			V512		103			6
R807		261			9	R867	B 2		32	7C		V514		109			6
R808		286			9	R868	A 2		35	7C		V515		123			6
R809		294		5D	9	R869	A 2		41	BC		V516		131		7E	6
R810		297			9	R870	A 2		87	9В		V520			101	9E	6
R811		290			9	R871	A 2			10B		V523	В		1D7	9D	6
R812		282			9	R872	A 3			11B		V530	В			1C	6
R813		288			9	R873	A 2			11B		V532	В			1B	6
R815		291			9	R874	A 2			11¢		V535	В		105	3B	6
R816 R817		274 294			9	R875	A 3			10C	9	V536	В		113	3B	6
R818		284			9	R880	A 2 B 2		92	10B	9	V539 V540	В		121	5B	6
R819		282			9	R882			160	7E 7F	9	V543	B B		124 125	5B 7B	6 6
R820		278			9	R887			136		9	V544	B		123	7B	6
R821		297			9	R889	B 2		83	8D	9	V548	В		123		6
R822		295			9	R898	B 2		24		9	V600		175		2E	7
R823	A	281	164	7 <b>F</b>	9	R899	A 2	во	27	7B	9	V602		170		2D	7
R824		278			9	U600	В 2		56	6D	7	V604-				2D	7
R825		281			9	U666			154	5D		V604-				2D	7
R826		29D				V11				7C		V606-		203	64	3C	
R827		278			9	V12	B 2		53	8C	2	V606-				2B	7
R828 R829		288 285	72		9	V13	A 2			10C	2	V608		199		3C	7
R830		281	66		9	V14 V15	B 1 B 1		30 34	3F 3F	2 2	V610 V612		260 242		8D	7
R831		278	72		9	V25	B 2		29	3C	2	V612		213	95 80	9D 3A	7
R832		266		9E	9	V26	B 2		29	3C	2	V636		202	85	3A	7
R834		262		9E	9	V35	A 2		11	6A	2	V656		206	64	2B	7
R835		267		9F	9	V110	B 2		51	8B		V670		117			11
R836		268		9F	9	V130	B 1			10C		V671	В	79	151	3D	
R837	A	255	129	9F	9	V134	B 2			10B		V680	A		187	9B	
R838		252		9 <b>F</b>	9	V200		68	24	10D	3	V681	A			10B	
R839		286	65	9D	9	V310		21	3D	5D	4	V682	A			1DB	
R841		291		11D	9	V315		21	44	7 D	4	V683	A			11B	11
R842		289		11D	9	V318		17	23	5C	4	V7DD-		157	117	2D	8
R843		295		11D	9	V319		26	32	6C	4	V700-				2D	8
R844		281	20	9C	9	V330		17	51	7C	4	V705		169		4C	8
R845		281 280	23	8B	9	V333		20	44	7C	4	V707		169		5C	8
R846 R847		280 267	30 126	8C 9F	9	V335 V336		80 70	39 35	8C	3	V715			124		8
R848		267 286	36	9F	9	V336		79 76	35 37	8C 9C	3 3	V716 V717			135		8
R849		276		1DD	9	V4D0		33	8D	4D	5	V717			120 139		8
	+	 I	+: [1	 Datum		+ 	<b></b>	 XY-	 List	 e f¤	 r	Sach-	 Num	ner		+   <sub>R</sub> 1	¦ att
RDHDE			- 1	Date						fo		Stock			•	Pa	
& SCHWARZ			+			EE AUS						+ <b></b> - 				-+ 	+ 
	1		03 :	17.06.	96	OUT	PUT_U	NIT	2.D	8GHZ		1D62.	700	5.01	XY		7+

Part	Sid	e X	Y	Sqr	Pg	Part S	id	e X	Y	Sqr	Pg	Part	Sid	e X	Y	Sqr	Pç
V720	В	182	136	4D	8	V787	В	222	186	as	12	V875-	- <b></b> -			 8E	11
V725			116		8	V801	В	284	157	4D	9	V876	В	84	175	11D	11
V730	В	181	109	6D	8	V802	A	277	149	2E	9	V877	В	75	175	9D	11
V735	В	190	96	7D	8	V803	A	262	156	3E	9	VC1	В	126	36	4E	2
V745	A	215	134	11D	8	V804	A	275	159	3E	9	VC2	В	116	35	4E	2
V746	A	213	120	12D	8	VB05	A	265	156	3E	9	W1A	В	210	135	10B	I
V747	A	210	12B	11E	8	V814	A	284	160	7 <b>F</b>	9	W1B	В	210	135	1D	1:
V748	A	207	123	11E	8	V815	A	298	169	7E	9	X2A	В	189	11	2C	2
V750	A	193	124	11E	8	VB16	A	2B9	174	7E	9	X2B	В	189	11		
V751	A	196	126	11E	8	V817	В	284	101	7 D	9	X205	В	70	40	10B	3
V752	A	200	130	11E	8	V827	A	261	126	9F	9	X224	В	17	15	1D	4
V753	A	191	124	11E	8	V828	A	287	167	BF	9	X225	В	258	15	5B	-
V765	A	113	184	2C	12	V829	A	285	169	7F	9	X226	В	283	15	12D	9
V766	A	119	173	3C	12	V830	A	264	116	9E	9	<b>Z1</b>	8	118	20	2E	2
V76B	В	103	173	2D	12	VB31	A	256	116	9E	9	<b>Z</b> 2	В	131	17	2E	2
V769	В	123	175	4D	12	V832	В	283	65	9D	9	23	В	100	20	2D	2
<b>V770</b>		183		6E	12	V833	A	259	135	9F	9	24	В	141	20	2D	2
V771	В	183	157	6D	12	V834	A	257	13B	10F	9	25	В	187	20	2D	2
V772	В	172	163	6D	12	VB44-A	В	2B6	26	8c	9	26	В	194	20	2C	2
V773	В	237	177	8E	12	V844-B				7C	9	27	В	169	20	2C	2
V774	В	214	179	8D	12	V850-A	A	285	45	7B	9	Z8	В	164	20	28	2
V775	В	214	186	BD	12	V850-B				6B	9	<b>Z</b> 9	В	174	20	28	2
V7B0	В	265	183	11D	12	VB53	A	291	77	6C	9	Z10	В	146	20	2B	2
V782	8	174	148	6E	12	V857	A	288	30	7B	9	211	8	113	20	2F	2
V7B3	В	175	150	6D	12	V870	A	277	92	10B	9	Z20	8	126	17	2E	2
V784	В	172	151	6D	12	V871	В	271	112	10B	9	Z700		222	149	7E	12
V785	В	224	183	8E	12	V874	В	35	1B1	60	11	2710		197		70	_
V786	8	222	184	80	12	V875-A	В	58	186	8D	11	2720		174		70	

(

Ĺ


		÷	·	<b>.</b>	
ROHDE	-I	Datum Date	XY-Liste fªr XY-list for	Sach-Nummer Stock-Nr	Blatt Page
SCHWARZ	03	17.06.96	EE AUSGANGSTEIL_2.0BGHZ OUTPUT_UNIT_2.08GHZ	1062.7005.01 XY	8-


Y




Stromläufe
Bestückungspläne
Circuit diagrams
Components plans
Schémas de circuit
Plans des composants









BINDENDE ANGABEN UEBER VARIANTEN. TRIMMUERTE, BAUTERLWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA. FOR BINDING INFORMATION ON MODELS, TRIMMING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.




ACHTUNG: EGB! ELEKTROSTATISCH GEFAEHROETE BAUELEHENTE ERFORDERN EINE BESONDERE HANDHABUNG. ATTENTION ESD!

ELECTROSTATIC SENSITIVE DEVICE REQUIRE A SPECIAL HANDLING

5

6





NICHT BESTUECKTE BAUTEILE S FOR BINDING INFORMATION ON


TRIMMING AND COMPONENTS VAL NONFITTED COMPONENTS SEE PA

6

3







AEND

IND.

8

RENDERUNGS-

HITTELLUNG


9

DATUM


NAME


ZU GERBET


ROHDE&SCHWA





-15081
























BINDENDE ANGABEN UEBER VARIANTEN, TRIMMUERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA. FOR BINDING INFORMATION ON MODELS, TRIMING AND COMPONENTS VALUES AND MONFITTED COMPONENTS SEE PARTS LIST.

04/02		03.03.97	ΕI	MENP	TAG	NAME	BENENHUNG
				BEARB.		Ei	2 20017
				GEPR.			AUSGANGSTEIL 2.08GHZ
				NORH			OUTPUT UNIT 2.08GHZ
				PLOTT	03.03.97		
				(8)			ZEICHNNR.
04/01		15.12.96	ΕI	1 X ½			
REND.	AENDERUNGS-	DATUN	NAME	RUF	DE&SU	HUARZ	1 to the second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second
IND.	METTELLUNG	001011	anne	ZU SERAE	t SMY		816.1.6 1002.2002
	Ω				1	0.000	11 12 12




N.F. ~ NOT FITTED / NICHT BESTUECKT

BINDENDE ANGABEN UEBER VARIANTEN. TRIMMUERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA. FOR BINDING INFORMATION ON MODELS.
TRIMMING AND COMPONENTS VALUES AND
NONFITTED COMPONENTS SEE PARTS L15



IND.	MITTEILUNG			ZU GERAE	r SMY	~	REG.I.V.
AENO.	AENOERUNGS-	DATUM	NAME	RUF	DE&SC	HAHKY	
09/01		16.12.95	ΕI	1 7 7			
				(Ps)			ZEICHNN
				PEOII	03.03.97		
				NORM			וטס
				GEPR.			คบ
				BEARÐ.		ΕI	
04/02		D3.03.97	Εl	MENP	TAG	NAME	BENENNUNG



N.F. - NOT FITTED / NICHT BESTUECKT

BINDENDE RNGABEN UEBER VARIA Trimhwerte, bauteilwerte und Nicht Bestueckte Bauteile Si




	03.03
	16.12
RENDERUNGS- HITTEILUNG	DATE

6

7


R


C




N.F. - NOT FITTED / NICHT BEST









ROHDE&SCHUARZ

SMY

10

1062.7005.015

ERSTE Z.

1062.5502

12

1062.55D2

11

REG.1.9.

04/01

AEND.

AENDERUNGS-


HITTEILUNG


9

DATUM

NAME

ZU GERAET






BINDENDE ANGABEN UEBER VARIANTEN, TRIMMUERTE, BAUTEILWERTE UNO NICHT BESTUECKTE BADTEILE SIEHE SA. FOR BINDING INFORMATION TRIMMING AND COMPONEN NONFITTED COMPONENTS

## N.F. - NOT FITTED / NICHT BESTUECKT



04/02		03.03.97	٤١	MENP	TAG	NAME
				BEARB.		13
				GEPR.		
				NORM		
				PLOTI	03.03.97	
				R		
04/01		16.12.96	ΕI	\\\ 5/		
AEND.	AENDERUNGS-	DATUM	NAME	RUH	DE&SCI	1WHKZ
IND.	MITTELLUNG	VILLON	поис	ZU GERAE	r SMY	
	9				10	)





N.F. - NOT FITTED / NICHT BESTUECKT





ACHTUNG: EGB!
ELEKTROSTATISCH GEFAEHRDETE
BAUELEHENTE ERFORDERN EINE
BESONDERE HANDHABUNG.


ATTENTION ESD!
ELECTROSTATIC SENSITIVE DEVIC
















NAME 03.03.97 EI TAS BINDENDE ANGABEN UEBER VARIANTEN. 04/02 MENP NICHT BESTUECKT TPINNUERTE, BAUTEILVERTE UND BEARB. Εŀ NICHT BESTUECKTE BRUTEILE SIENE SA. SEPR. NORM ITUNG: EGB! FOR BINDING INFORMATION ON MODELS, PLOTT 03.03.97 NOSTATISCH GEFAEHRDETE EHENTE ERFORDERN EINE SONDERE HANDHABUNG. TRIBBING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST. 15.12.98 E1 ENTION ESD! 04/81 ROHDE&SCHWARZ STATIC SENSITIVE DEVICES RE A SPECIAL HANDLING AENDERUNGS-AEND DRIUM NRME IND. MITTELLUNG SMY 9 10 8 7













N.F. - NOT FITTED / NICHT BESTUECKY


- PRINTED ON PCB TH ∗PCB


4


5

6

NONFIT






















N.F. - NOT FITTED / NICHT BESTUECKT


BINDENDE ANGABEN UEBER VARIANTEN, TRINHUERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA. FOR BINDING INFORMATION TRIMMING AND COMPONENTS SE


04/02		03.03.97	٤١	MENP	TAG	NAME
		-		BEARB.		Εl
				GEPR.		
				NORM		
				PLOTT	03.03.97	
				R		
04/01		16.12.96	ΕI	1 8 %		
REND.	AENDERUNGS-	DATUM	NAME	ROH	DE&SC	HUHRZ
IND.	MITTELLUNG	V ( U )	# U # L	ZU SERAE	ı SMY	


8


A

9










NICHT BESTUECKTE BAUTEILE SIEHE SA.

NONFITTEO COMPONENTS SEE PARTS LIST.

IND	. MITTEIŁUNG			ZU SERAE	1 SMY 4	Ω	1062.5502   ERSIE Z. 1062.5502
HENC	1	3 11121111	NAME	KUH		HUARZ	4063 5503
04/0	1	16.12.96	ΕI		105466		1062.7005.015
				(§)\(\)	· · · · · · · · · · · · · · · · · · ·	<del> </del>	ZEICHNNR. BLATT-NR
				PLOTT	03.03.97		
				NORM			OUTPUT UNIT 2.08GHZ
				GEPR.			AUSGANGSTEIL 2.08GHZ
				BEARB.		ΕI	
04/0	2	03.03.97	ΕI	MENP	186	Nane	BENENNUNG



N.F. - NOT FITTED / NICHT BESTUECKT

BINDENDE ANGABEN DEBER VARIANTEN, TRIMMURTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA. FOR BINDING INFORMATION ON MODELS, TRIMMING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST



04/02	<del></del>	03.03.97	ΕI	MENP	TAG	NAME	BENENNUNG
				BEARB.		ΕI	•
				GEPR.			AUSGA
				изои			OUTPUT U
				PLOTE	03.03.97		
				(PS)			ZEICHNNR.
04/01		16.12.96	E I	1 37		1	
REND.	RENDERUNGS-	DATUM	NAME	ROHDE&SCHWARZ			4062
120	HITTETENHAG	DATUM	NAME		- 687		DCC 1 1 108

. -NR. 1062 REG. S. V.


IND.

8

HITTEILUNG

9

SMY 10








04/02 03


04/01 16


REND. RENDERUNGSIND. MITTELLUNG





















































OUTPUT UNIT 2.08GHZ

1062,5502

11

1062.7005.015

ERSTE Z.

ZEICHN.-NR.

REG. 1. V.

NORH

PLOTT

(R) (S)

16.12.96 E I

NAME

NUTAD

04/0

AEND

INĐ.

AENDERUNGS-

HITTEILUNG

9

03.03.97

ROHDE&SCHUARZ

SMY


10

A

BLATT-NR.

1062:5502

11+



N.F. - NOT FITTED / NICHT BESTUECKT


BINDENDE ANGABEN UEBER VARIANTEN, TRIMMUERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA.


9

FOR BINDING INFORMATION ON MODELS.
TRIMMING AND COMPONENTS VALUES AND
NONFITTED COMPONENTS SEE PARTS LIST



OY/OY  REND AENOERUNGS- IND HITTEILUNG	15.12.96 08fun	E I	⟨°§⟩   ROHDE&SCHWARZ_			10
				03.03.31		ZEICHNNR.
	<del> </del>		PLOTI	03.03.97		
			NORH			OUTPUT UN
			SEPR.			AUSGAN
			BEARB.		ΕI	
04/02	03.03.97	E١	MENP	186	NAHE	BENENNUNG








N.F. - NOT FITTED / NICHT BEST



ACHTUNG: EGB!
ELEXTROSTATISCH BEFREHRO
BRUELERENTE ERFORDERN E
BESONDERE HANDHABUNG
ATTENTION ESD!
ELECTROSTATIC SENSITIVE D
REQUIRE A SPECIAL HANDL








N.F. - NOT FITTED / NICHT BESTUECKT


BINDENDE ANGABEN UEBER VARIANTEN, TRIMMERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA.


NG


FOR BINDING INFORMATION ON MODELS.
TRIMMING AND COMPONENTS VALUES AND
NONFITTED COMPONENTS SEE PARTS LIST.


OY/O1 AEND. IND.	AENDERUNGS- MITTEILUNG	16.12.95 DATUM	NAME	ROH	HDE&SCHUARZ		1062.7005.015 v. 1062.5502 ERSIE Z. 1062.5502			
D. (04		46 42 46		RS			ALIENRNK.			
				PLOTT	03.03.97					
				NORM			OUTPUT UNIT 2.08GHZ			
				GEPR.			AUSGANGSTEIL 2.08GHZ			
				BEARB.		ΕI				
)4/92		03.03.97	1.3	MENP	TAG	NAME	BERENHUNG			















Signal-Name	Page-No.: Zones
+15VB1	02: 4F 5B 7C 03: 1B 4B 10D 06: 1A 10: 6A 10D
+15VB2	05: 11C 11D 06: 2F 3A 9F
+15VB3	02: 4F 04: 5D 6C 6D 7D 10E 11E 05: 3C 4C 6E
+15VB4	02: 4E 07: 3F 08: 2E 09: 2B 11: 1B 12: 1B
+15VE	07: 2F 3B 4F 5A 6A
+15VF	07: 7F 9F
+15VH	09: 3B
+15VHI	07: 6F 08: 9E 09: 3B 4F 6A 7A 10C
+15VK	11: 3B 3E 4E 7E 9C 10C 11C 12: 1D 3D 4F
+15VL	10: 6A 10C 12: 2A 3B 5D 11F
+24VH	02: 4E 09: 5F
+5VB	02: 3C 4D 6A 8C 03: 1B 05: 8C 10: 1B 2F 3F 4F 5E 6F 7C 7F 8E 9E 9F 10F
+9V-I	07: 1C 2C 4A
-15VB1	02: 4E 5A 7A 03: 1A 4A 10: 6A 8B
-15VB3	02: 4E 04: 4C 8C 05: 2C 4E
-15VB4	02: 4E
Druck 18.06.96 Abt.1GPK	Name DR   Dat.18.06.96   Ae.Mi.   Aei. 04
ROHDE & SCHWARZ	nung AUSGANGSTEIL_2.08GHZ OUTPUT_UNIT_2.08GHZ 13+
Typ. SMY Reg in Ve	rz. 1062.5502 V Sachnummer 1062.7005 S

Signal-Name =========	=======	Page	=:	201 ====	1es =====				
-15VB4		07:	_						
		08:							
		09:							
		11:							
		12: 							
-15VE		07:	4F 6A	7A					
-15VHI		09:	3A 6A	8A					
-15VK		11:	3A 8B	8D	12B				
		12:	3C	<b>-</b> -					
-15VL		08:	11C						
		10:							
		12:	2A 3B						
-9V-I		07:	1B 3B	3D	4B				
ALCOFF		03:							
		10:	7E						
AM		02:	4D						
		03:	1D						
AMINVERS		03:	1B						
		10:							
AMSLOW		03:	1 tr						
		10:							
BLANK		02:	4C						
		10:							
BLANKENABLE		10:	3E						
BLANKINVERS		10:	3E						
BP10N		10:	7B						
		12:							
BP20N		10:	<b>-</b>						
		12:							
BP30N		10:	<b>-</b>						
		12:	_						
CLK1		02:	 4B						
		10:							
DETFILT		02:	 6D						
		08:							
DETMIXON		03:	1E						
ruck 18.06.96				18.0	6.96	Ae.Mi.	Ae	i. 04	
ROHDE & SCHWA	Bener	nung A	USGANO			+ .08GHZ )8GHZ	<del>+</del>		<b>-</b> .4+
	++						+		
Cyp. SMY	Reg in Ve	erz. 1062	.5502	v	Sac	chnummer	1062.7	005	S

Signal-Name ====================================	Page-No.: Zones 
DETMIXON	10: 7E
DETON	03: 1E 10: 7E
DIAG-0	02: 7E 10: 3E
DIAG-1	02: 7E 10: 3E
DIAG-2	02: 7E 10: 3E
DIAG-3	02: 7E 10: 3E
DIAGON	10: 3E
DOUBLEROUT	09: 2C 12: 12D
HF-INT-ENABLE	02: 11C 10: 3E
KLEMM-N	03: 1F 10: 8C
LPSELECT-0	05: 8D 10: 7C
LPSELECT-1	05: 8D 10: 7C
LPSELECT-2	05: 8D 10: 78
LPSELECT-3	05: 8D 10: 7B
MODUFIX	03: 10C 10: 7E
RFBOUT	08: 12D 09: 1D
RFLEVENABLE	10: 7E
RFLOLEV	04: 12D 05: 1D
SACON	10: 7E
SACON-N	08: 9E
ruck 18.06.96 Abt.	GPK Name DR   Dat.18.06.96   Ae.Mi.   Aei. 04
ROHDE & SCHWARZ	Benennung AUSGANGSTEIL_2.08GHZ OUTPUT_UNIT_2.08GHZ 15+
Typ. SMY Reg i	n Verz. 1062.5502 V Sachnummer 1062.7005 S


Signal-Name ====================================	Page-No.: Zones
SACON-N	09: 2F 10: 11B
sacon-p	08: 9E 09: 2F 10: 11C
SBDON	10: 5E
SBDON-N	0B: 2E 10: 11C
SBDON-P	08: 2E 10: 11D
SEROUT	02: 4C 10: 1E
SIG-11-12	11: 12D   12: 1D
SIG10	05: 7D   06: 1E
SIG80-1	06: 11E   08: 1C
SIG80-2	07: 1D   08: 5B
SIG80-3	07: 12D 08: 11B
TP1	05: 12E 06: 4F
TP2	05: 12E 06: 6F
TP3	05: 12D 06: 7F
TP4	05: 12D 06: 2C
TP5	05: 12D 06: 3C
TP6	05: 12D 06: 5C
TP7	05: 12C 06: 7C
•	-+
• :	ennung AUSGANGSTEIL_2.08GHZ OUTPUT_UNIT_2.08GHZ 16+
Typ. SMY Reg in	Verz. 1062.5502 V   Sachnummer 1062.7005 S


Signal-Name	Page-No.: Zones
TP8	05: 12C 06: 10C
UDOUBLER	02: 11E 11: 8E
ULPRE	02: 11E 03: 12E 05: 4E
UMODULATOR	02: 11E 03: 12C 04: 6E
UREF6	03: 9F 10: 118
UREF6N	03: 4C 10: 11B
UREF9	09: 5C 6C 12B
UREF9N	09: 5A 6B 8B 12C
UREGELVERST	02: 6C 03: 11B
URF-SOLL	02: 11E   03: 7C
VDAM	03: 118 11: 10E 12: 2F
VDET	02: 11E 03: 1E 09: 8B
VDETMIX	02: 11E 03: 1F 07: 5F
VDETMIXE	07: 4C 5F
VDEXT	02: 4F 03: 1E
VDEXTON	03: 1E 10: 7E
WR1	02: 4B 10: 1E
Druck 18.06.96 Abt.1GPK	Name DR   Dat.18.06.96   Ae.Mi.   Aei. 04
ROHDE & SCHWARZ	nung AUSGANGSTEIL_2.08GHZ OUTPUT_UNIT_2.08GHZ 17-
Typ. SMY Reg in Ve	rz. 1062.5502 V Sachnummer 1062.7005 S




1062.7005.01


DRIES















TRIMMING AND COMPONENTS VALUES AND HOMFITTED COMPONENTS SEE PARTS LIST





SERVICEUNTERLAGEN Eichleitung 1 GHz 0826.5065.01

# Inhaltsverzeichnis

′	Pru	fen und Instandsetzen der Baugruppe	5
	7.1	Funktionsbeschreibung	5
		7.1.1 Eichleitung mit integriertem Überspannungsschutz	5
		7.1.2 Ansteuerung der Eichleitung	
	7.2	Meßgeräte und Hilfsmittel	6
	7.3	Fehlersuche	6
		7.3.1 Ansteuercode	6
		7.3.2 Ansteuerpuls der Dämpfungsglieder	
	7.4	Prüfen und Abgleich	7
		7.4.1 Prüfen der Dämpfungsglieder und der Ansteuerdruckschaltung	7
		7.4.2 Prüfen des Überspannungsschutzes	7
		7.4.2.1 Statische Prüfung	7
		7.4.2.2 Prüfung und Abgleich bei Gleichspannung (nur VAR04)	8
		7.4.2.3 Prüfung bei Wechselspannung (nur VAR04)	8
		7.4.2.4 Prüfung und Abgleich bei Wechselspannung (nur	
		VAR02)	8 8
	•	7.4.3 Schnittstellen	

Schaltteilliste Koordinatenliste Stromlauf Bestückungsplan

#### 7

# Prüfen und Instandsetzen der Baugruppe

#### ACHTUNG!!!

Die Baugruppe darf nicht geöffnet werden, da sonst der Garantieanspruch erlischt und ein Neuabgleich durchgeführt werden muß.

Für SMY ohne Option SMY-B40 ist für diese Baugruppe die Variante 02 erforderlich.

Für SMY mit Option SMY-B40 ist für diese Baugruppe die Variante 04 erforderlich.

# 7.1 Funktionsbeschreibung

(Siehe hierzu Stromlauf und Blockschaltbild 0826.5065.01S)

# 7.1.1 Eichleitung mit integriertem Überspannungsschutz

Die Eichleitung ist zwischen das Ausgangsteil (bzw. der Baugruppe Powermodul bei Geräten mit Option SMY-B40) und den Geräteausgang geschaltet. Mit ihr kann das Signal um 130dB in 10dB-Stufen abgesenkt werden. Kleinere Pegelsprünge werden mit Hilfe der elektronischen Pegelregelung eingestellt. Die Eichleitung des SMY01 enthält fünf Dämpfungsglieder mit den Werten 10, 2\*20 und 2\*40dB, ein Überspannungsschutzsubstrat und ein 50 Ohm Abschlußwiderstand. Die Dämpfungsglieder können durch jeweils eine Kontaktgruppe, die aus drei Einzelkontakten besteht, eingeschaltet oder überbrückt werden. Jede dieser Kontaktgruppen wird von einer Wippe betätigt, die von einer Magnetspule angetrieben und durch einen Permanentmagneten in der Endlage gehalten wird.

Hinter den Dämpfungsgliedern sitzt auf der Eichleitungsgrundplatte in Richtung Geräteausgang das Überspannungsschutzsubstrat und anschließend der RF-OFF-Schalter. Das Überspannungsschutzsubstrat erkennt hohe DC-Spannungen und HF-Pegel, welche an die Ausgangsbuchse Xl angelegt werden und betätigt den RF-OFF-Schalter. Der RF-OFF-Schalter kann aber auch vom Rechner über die Software bedient werden.

# 7.1.2 Ansteuerung der Eichleitung

Die Dämpfungseinstellung erfolgt durch serielle Datenübertragung (siehe 7.3.1). Die Ansteuerbits werden über die Datenleitungen (X77.B1 SERDAT) mit dem Clock (X77.B2 SERCLK) in das Schieberegister (D5) auf der Eichleitungsansteuerdruckschaltung geschoben. Mit dem Strobe (X77.B3 ELSTB) werden die Ausgänge des Schieberegisters gesetzt und die gewünschte Dämpfung eingestellt. Die Ansteuerung der Magnetspulen der Kontaktgruppen erfolgt über die Leistungsgatter D1 bis D4.

Beim SMY01 wird eine zu hohe HF-Spannung an der Ausgangsbuchse durch eine Spitzenwertgleichrichtdiode erkannt. Eine zu hohe DC-Spannung wird durch einen Widerstand detektiert. Im Überspannungsfall sprechen die Komperatoren N10 a,b an und setzen das Flip-Flop D6, welches über eine Verstärkerstufe V30 und das Gatter D4 direkt den RF-Schalter betätigt.

Dem Rechner wird der Überlastfall über die Interruptleitung (X77.B4) mitgeteilt. Dieser Interrupt wird dann rückgesetzt, wenn der RF-OFF-Schalter zusätzlich vom Rechner über Software betätigt wird. Der RF-OFF-Schalter kann von Hand über die Tastenfolge 'LEVEL ON' wieder geschlossen werden.

## 7.2 Meßgeräte und Hilfsmittel

- 1. Ohmmeter (Meßbereich bis 2MOhm)
- 2. Leistungsmeßsender (z.B. SMGL)
- 3. Gleichspannungsnetzgerät für ±15V
- 4. Speicheroszilloskop

#### 7.3 Fehlersuche

## 7.3.1 Ansteuercode

Läßt sich am Gerät ein gewünschter Ausgangspegel nicht einstellen, so muß am Schieberegisterausgang D5 der ordnungsgemäße Ansteuercode der einzelnen Dämpfungsglieder überprüft werden (siehe Tabelle 7.3.1).

Tabelle 7.3.1 für ATT01 im SMY01 (CW-Betrieb):

Ansteuercode am Schieberegister D5 (74HC 4094)

Pege	lein	stellu	ng	Pin5	6	4-	725	14	11,9
mit		ohne		Q2	Q3	Q1	Q4	Q5	Q8, Q9
Opt	ion	SMY-B4	0 - 4 -	40dB	20dB	10dB	20dB	40dB	RF-OFF
19	dBm	13	dBm	1	1	1	1	1	0
6	dBm	0	dBm	1	1	0	1	1	0
-4	dBm	-10	đBm	1	1	1	0	1	0
-24	dBm	-30	dBm	1	1	1	1	0	0
-64	dBm	-70	dBm	0	1	1	1	1	0
-84	dBm	-90	dBm	0	1	1	0	0	0
-104	dBm	-110	dBm	0	0	1	0	0	0
-114	dBm	-120	dBm	0	0	0	0	0	0

<sup>&#</sup>x27;1' = 5V, '0' = 0V

#### 7.3.2 Ansteuerpuls der Dämpfungsglieder

Entspricht der Puls an den Magnetspulen D1 bis D4 nicht der in Bild 7.3.2 gezeichneten Form, so liegt ein auftretender Dämpfungsfehler an der Ansteuerdruckschaltung und nicht an den Dämpfungsgliedern mit den zugehörigen Kontaktgruppen vor.




Bild 7.3.2

## 7.4 Prüfen und Abgleich

# 7.4.1 Prüfen der Dämpfungsglieder und der Ansteuerdruckschaltung

Hierzu ist zu verfahren wie in Kapitel 5.2.6 der Wartungsunterlage im Betriebshandbuch beschrieben ist.

# 7.4.2 Prüfen des Überspannungsschutzes

#### 7.4.2.1 Statische Prüfung

- Stecker X41 von der Eichleitungsansteuerdruckschaltung abziehen.
- Einen Ausgangspegel von -117dBm einstellen.

Mit einem Ohmmeter kann nun die Diode des Überspannungsschutzes in Sperr- und Durchlaßrichtung gemessen werden.

• Die Messung erfolgt zwischen Masse und dem Durchführungsfilter Z11.

Mit einem Ohmmeter kann auch der DC-Spannungsmeßwiderstand gemessen werden.

 Die Messung erfolgt zwischen dem RF-Ausgang und dem Durchführungsfilter Z12. Der Sollwert beträgt 6 ±1kOhm.

## 7.4.2.2 Prüfung und Abgleich bei Gleichspannung (nur VAR04)

- Mit Pot R14 die Spannung an N10/2 auf 1.4 V  $\pm$  10 mV einstellen.
- An die RF-Ausgangsbuchse X1 des Geräts eine DC-Spannung aus einer Gleichspannungsquelle anlegen.

Ein Rücksetzen des RF-OFF-Schalters erfolgt mit der Tastenkombination 'LEVEL ON'.

# 7.4.2.3 Prüfung bei Wechselspannung (nur VAR04)

- Einen Ausgangspegel von -117 dBm einstellen.
- Einen Leistungsmeßsender mit dem RF-Ausgang des SMY verbinden und eine RF von 100 MHz einstellen.
- \_ Der RF-OFF-Schalter muß bei 30 ... 33 dBm ansprechen.

Ein Rücksetzen des RF-OFF-Schalters erfolgt mit der Tastenkombination 'LEVEL ON'.

# 7.4.2.4 Prüfung und Abgleich bei Wechselspannung (nur VAR02)

- · Einen Ausgangspegel von -117 dBm einstellen.
- · Einen Leistungsmeßsender mit dem RF-Ausgang des SMY verbinden und eine RF von 1000 MHz einstellen.
- Der RF-OFF-Schalter muß bei 0.3 ... 0.7 W ansprechen, ein Abgleich kann mit dem Potentiometer R14 erfolgen.

Ein Rücksetzen des RF-OFF-Schalters erfolgt mit der Tastenkombination 'LEVEL ON'.

#### 7.4.2.5 Prüfung bei Gleichspannung (nur VAR02)

- · An die RF-Ausgangsbuchse X1 des Geräts eine DC-Spannung aus einer Gleichspannungsquelle anlegen.
- \_ Der RF-OFF-Schalter muß bei Spannungen ±(5 ... 7 V) ansprechen.

Ein Rücksetzen des RF-OFF-Schalters erfolgt mit der Tastenkombination 'LEVEL ON'.

# 7.4.3 Schnittstellen

Pin	Name 1-1	Ein/Ausgang	Herkunft	/Ziel	Wertebereich	Signalbeschreibung
X77.A1	GND					
X77.B1	SERDAT	Eingang	Rechner	X3.4	TTL-HCT	Serielle Daten
X77.A2	GND					
X77.B2	SERCLK	Eingang	Rechner	X3.2	TTL-HCT	Clocksignal
X77.A3	GND					
Х77.ВЗ	ELSTB	Eingang	Rechner	X3.19	TTL-HCT	Strobesignal
X77.A4	GND					
X77.B4	HFOVERLOAD	Ausgang	Rechner	X3.22	TTL-HCT	Overload Interrupt
X77.A5	GND					
X77.B5	frei	}				
X77.A6	VA5-P	Eingang	Netzteil	X21.5	+4.5 +5.3V	Versorgung +5.1V
					42 ±8mA	
X77.B6	"	-	h			•
X77.A7	VA15-P	9	•	X21.13	+14.9 . +15.6V	Versorgung +15V
					20 ±4mA	
X77.B7	lo l		*		64	μ.
X77.A8	VA15-N		*	X21.19	-15.514.4V	Versorgung -15V
					3 ±.5V	
X77.B8	w w	-	n		**	-
		i				
X1		Eingang	Ausgangst	eil		
X2	!	Ausgang	RF-Buchse	:		



SERVICE INSTRUCTIONS
Attenuator 1GHz
0826.5065.01

#### Contents

7	Tes	ting a	d Repair of the Module	. 5
	7.1	Funct	on Description	. 5
		7.1.1	Attenuator with Overvoltage Protection	. 5
		7.1.2	Control of the Attenuator	. 5
	7.2	Test	nstruments and Utilities	. 6
	7.3	Troub	eshooting	. 6
		7.3.1	Control Code	. 6
		7.3.2	Control Pulse of the Attenuator Pads	. 7
	7.4	Testi	g and Adjustment	. 7
		7.4.1	Testing the Attenuator Pads and the Control P.C.B	. 7
		7.4.2	Testing the Overvoltage Protection	. 7
			7.4.2.1 Static Test	. 7
			7.4.2.2 Testing with DC Power Supply (VAR04 only)	
			7.4.2.3 Testing with AC Supply (VAR04 only)	
			7.4.2.4 Testing and Adjustment with AC (VAR02 only)	. 8
			7.4.2.5 Testing with DC Voltage Supply (VAR02 only)	. 8
		7.4.3	Interfaces	9

Parts list List of coordinates Circuit diagram Components layout diagram

#### 7 Testing and Repair of the Module

#### CAUTION!!!

Do not open the module, since otherwise the warranty expires and re-adjustment is required.

For instruments without option SMY-B40, this module with VAR02 is necessary.

For instruments with option SMY-B40, this module with VAR04 is necessary.

## 7.1 Function Description

(Cf. circuit diagram and block diagram 0826.5065.01S)

## 7.1.1 Attenuator with Overvoltage Protection

The attenuator is connected between the output module (the power module for instruments with option SMY-B40, respectively) and the instrument output. It is used to attenuate the signal by 130 dB in steps of 10 dB. Smaller level jumps are set via the electronic level control. The attenuator of the SMY01 consists of five attenuator pads of 10, 2\*20 and 2\*40 dB, an overvoltage-protection substrate and a 50-Ohm terminator. The attenuator pads can be switched on or bypassed by means of one contact group each, which consists of three individual contacts. Each of these contact groups is actuated by a rocker, which is driven by a magnetic coil and kept in end position by a permanent magnet.

The overvoltage-protection substrate and the RF-OFF switch are accommodated on the attenuator motherboard subsequent to the attenuator pads. The overvoltage-protection substrate detects high dc voltages and RF levels which are applied to the output socket X1 and actuates the RF-OFF switch. The RF-OFF switch may also be software-controlled via the controller.

#### 7.1.2 Control of the Attenuator

The attenuation is set via serial data transmission (cf. 7.3.1). The control bits are clocked into the shift register (D5) on the attenuator control p.c.b. via the data lines (X77.B1 SERDAT) using the clock X77.B2 SERCLK. The strobe (X77.B3 ELSTB) sets the outputs of the shift registers and the desired attenuation. The magnetic coils of the contact groups are controlled via the power gates D1 to D4.

A peak-responding rectifier diode fitted to the SMY01 detects an unpermissibly high RF voltage at the output socket. An unpermissibly high dc voltage is detected by a resistor. In case of overvoltage, the comparators N10 a,b respond and set the flip-flop D6, which directly actuates the RF switch via an amplifier stage V30 and the gate D4. The information on overload is passed to the controller via the interrupt line (X77.B4). This interrupt is reset if the RF-OFF switch is additionally software-controlled. The RF-OFF switch can be reset manually via the key sequence 'LEVEL ON'.

#### 7.2 Test Instruments and Utilities

- 1. Ohmmeter (Measuring range up to 2 MOhms)
- 2. Power generator (e.g., SMGL)
- 3. DC power supply for ±15V
- 4. Storage oscilloscope

#### 7.3 Troubleshooting

#### 7.3.1 Control Code

If a desired output level can not be set on the instrument, check at the shift register D5 whether the control code of the individual attenuator pads is correct (see table 7.3.1).

Table 7.3.1 for ATT01 in SMY01 (CW mode):

Control code at shift register D5 (74HC 4094)

		setting			6 1/2-500	4	<b>17</b> jälkettelelele	14	11,9
wit	h	with	out	Q2	Q3 (4) ****	Q1	Q4	·Q5	Q8,Q9
opt	ion	SMY-B4	0	40 dB	20 dB	10 dB	20 dB	40 dB	RF-OFF
19	dBm	13	dBm	1	1	1	1	1	0
6	dBm	0	dBm	1	1	0	1	1	0
-4	dBm	-10	₫Bm	1	1	1	0	1	0
-24	dBm	-30	dBm	1	1	1	1	0	0
-64	dBm	-70	₫Bm	0	1	1	1	1	0
-84	₫Bm	-90	₫Bm	0	1	1	0	0	0
-104	dBm	-110	dBm	0	0	1	0	0	0
-114	dBm	-120	dBm	0	0	0	0	0	0

<sup>&#</sup>x27;1' = 5V, '0' = 0V

#### 7.3.2 Control Pulse of the Attenuator Pads

If the pulse at the magnetic coils D1 to D4 does not correspond to the form illustrated in fig. 7.3.2, an error occurred on the control p.c.b., the attenuator pads with the associate contact groups are, however, o.k.




Fig. 7.3.2

#### 7.4 Testing and Adjustment

# 7.4.1 Testing the Attenuator Pads and the Control P.C.B.

Proceed as described in Section 5.2.6 of the maintenance instructions given in the operating manual.

## 7.4.2 Testing the Overvoltage Protection

#### 7.4.2.1 Static Test

- Withdraw connector X41 from the attenuator p.c.b.
- Set output level to -117dBm.

The overvoltage-protection diode can be measured in forward and reverse direction using an ohmmeter.

• The measurement can be performed between ground and the lead-through filter Z11.

The shunt of the dc voltage can also be measured using an ohmmeter.

 $\bullet$  The measurement is performed between the RF output and the lead-through filter Z12. The rated value is 6  $\pm 1 \text{kOhm}$ .

## 7.4.2.2 Testing with DC Power Supply (VAR04 only)

- Use pot R14 to set the voltage at N10/2 to 1.4 V  $\pm$  10 mV.
- Apply a dc voltage from a dc power supply to the RF output socket X1 of the instrument.
- \_ The RF-OFF switch must respond for voltages between  $\pm$  (7.5 V to 8.5 V) at the RF-socket.

The RF-OFF switch is reset using the key combination 'LEVEL ON'.

# 7.4.2.3 Testing with AC Supply (VAR04 only)

- Set output level to -117 dBm.
- Connect a signal generator to the RF output of the SMY and set an RF of 100 MHz.
- \_ The RF-OFF switch must respond for 30 ... 33 dBm.

The RF-OFF switch is reset using the key combination 'LEVEL ON'.

# 7.4.2.4 Testing and Adjustment with AC (VAR02 only)

- Set output level to -117 dBm.
- Connect a signal generator to the RF output of the SMY and set an RF of 1000 MHz.
- Supplying with 0.3 ... 0.7 W, the RF-OFF switch must respond. It can be adjusted using the potentiometer R14.

The RF-OFF switch is reset using the key combination 'LEVEL ON'.

# 7.4.2.5 Testing with DC Voltage Supply (VAR02 only)

- · Apply a dc voltage from a dc power supply to the RF output socket X1 of the instrument.
- \_ The RF-OFF switch must respond with voltages  $\pm (5 \dots 7 \text{ V})$ .

The RF-OFF switch is reset using the key combination 'LEVEL ON'.

#### 7.4.3 Interfaces


GND		Origin/Dest.	Specified range	Signal description
ULID		-		
SERDAT	Input	Controller X3.4	TTL-HCT	Serial data
GND				
SERCLK	Input	Controller X3.2	TTL-HCT	Clock signal
GND				
ELSTB	Input	Controller X3.19	TTL-HCT	Strobe signal
GND				
HFOVERLOAD	Output	Controller X3.22	TTL-HCT	Overload interrupt
GND		İ		
not used				
VA5-P	Input	P. supply X21.5	+4.5 to +5.3V	+5.1V supply
			42 ±8mA	
•	-	-	*	n
VA15-P	*	• x21.13	+14.9 to +15.6V	+15V supply
İ			20 ±4mA	
•	-	a	•	%
VA15-N	-	• X21.19	-15.5 to -14.4V	-15V supply
	i		3 ±.5V	
•	π	7	10	я
			ļ	
	Input	Output module		
	Output	RF socket		
	GND SERCLK GND ELSTB GND HFOVERLOAD GND not used VA5-P  VA15-P	GND SERCLK Input GND ELSTB Input GND HFOVERLOAD Output GND not used VA5-P Input  VA15-P *  Input  Input  Input	GND SERCLK Input Controller X3.2 GND ELSTB Input GND HFOVERLOAD Output Controller X3.19 GND not used VA5-P Input P. supply X21.5  VA15-P X21.13 Input Output module	GND SERCLK Input Controller X3.2  TTL-HCT  GND ELSTB Input Controller X3.19 TTL-HCT  GND HFOVERLOAD Output Controller X3.22 TTL-HCT  GND not used VA5-P Input P. supply X21.5 +4.5 to +5.3V 42 ±8mA  VA15-P X21.13 +14.9 to +15.6V 20 ±4mA VA15-N Input Output module




Schaltteillisten
Stromläufe
Bestückungspläne
Part lists
Circuit diagrams
Components plans
Listes des pièces détachées
Schémas de Circuit
Plans des composants

	Kennz. Comp. No.	Banennung Designation					Sachnummer Stock No.	Hersteller Manufacturer		Bazaichnung Dasignation		anthaltan in contained in	
	•	IDENTIF VAR 02 MDD 02 ERSETZI VAR 00/ VAR 04	= 8ASIC REPLAC	OF AUS MO E /41	MODELS FUEHRUNG DEL +840						700		
	A71	ATTENAU NUR VAF		ITRO IOD :	L		0826.5071.02						
	A71	ED ANST NUR VAR	TEUERUNG R/ONLY M STROML./	OD:	04		0826.5071.04						
	сз		JF+-20%3		RM5	CE	0008.7904.00	PANASONIC	ECA-	1VFG2218Q	0826.5	5071.01	
	c8	CE 1000	DLYTIC C JF+-20%3	5V	RM5		0008.7510.00	PHILIPS_CO	2222	116 90042	0826.5	5071.01	
	C10	CK 100N			2,5H7MKT	СК	0099.2930.00	RDEDERSTEI	MKT	1826-410-06-4W	0826.5	071.01	
	C11		iF+-5%63	VRD:	2,5H7MKT	СК	0099.2930.00	ROEDERSTEI	MKT	1826-410-06-4W	0826.5	071.01	
Sonalton 9 Vor.	C13		F+-20%2			CE	0087.9334.00	KEMET	T340	A155M025 AS	0826.5	071.01	
	C14	CC 10NF	LYTIC C -20+50%			СÇ	0087.7525.00	VALVO	2222	640 51103	0826.5	071.01	
	C16		-20+50%	7X8	R40 <b>0</b> 0	СС	0087.7525.00	VALVO	2222	640 51103	0826.5	071.01	
	C18	CAPACIT CC 10NF	OR -20+50%	7X8	R4000	СС	0087.7525.00	VALVO	2222	640 51103	0826.5	071.01	
	сзо	CAPACIT CE 47UF	'OR '+-20%63'	٧	RM5		0008.7440.00	PHILIPS_CO	2222	116 90112	0826.5	071.01	
	C31		LYTIC C: +-20%63		CITOR RM5		0008.7440.00	PHILIPS_CO	2222	116 90112	0826.5	071.01	
	C32		LYTIC C. +-20%63		CITOR RM5		0008.7440.00	PHILIPS_CO	2222	116 90112	0826.5	071.01	
wir uns alle Rochte vor.	C100				CITOR BK1200LR		0092.0919.00			2 T 154 K5X5CR			
n ese n	02				_/MOS-LC	8J	0294.8490.00	NSC	0S75	361N	0826.5	071.01	
, F	D3	8J SN75		XTTI	_/MOS-LC	8J	0294.8490.00	NSC	DS75	361N	0826.5	071.01	
	04	8J SN75		XTTI	_/MOS-LC	8J	0294.8490.00	NSC	DS75	361N	0826.5	071.01	
	05	BL PC74		851	r.SH.REG		0099.9711.00	PHILIPS_SE	(PC)	74HC4094N(P)	0826.5	071.01	
	D6	8ST.SHI BL CD40 FLIPFLO	138E :		REGIST. - FLIPFL		0086.7021.00	RCA	CD40	138E	0826.5	071.01	
	K1 6	LD ELEK ELECTRD		ET (	(EICHL.)		0294.8425.00				0294.8	877.00	
	N10	BO LF412CN 2XFET OPAMP OPERATIONAL AMPLIFIER				0356.0521.00	NSC	LF41:	2CN	0826.5	071.01		
	R6	RESISTO	R		1%TK50		0083.1097.00		MK2			071.01	
	R7	RL 0,60 RESISTO	W 121KDI R	HM+-	-1%TK50	l	0083.2070.00		MK2		0826.5	071.01	
	R8	RL 0,60 RESISTO	W 1KDHM <sup>.</sup> R	+- 1%	6TK50	RL	0082.2160.00	RESISTA	MK2		0826.5	071.01	
	R9		W 1KDHM	+-1%	4TK50	RL	0082.2160.00	RESISTA	MK2		0826.5	071.01	
	R10	RL 0,60W 1KDHM+-1%TK50 RESISTOR RL 0,60W 8,25KOHM+-1%TK50 RESISTOR RS 0,5W1KDHM+-10%10X10X5 CERMET PDTENTIDMETER T			RL	0082.2160.00	RESISTA	MK2		0826.5	071.01		
	R 12				RL	0083.1239.00	RESISTA	MK2		0826.5	071.01		
	R14				RS	0087.7560.00	BDURNS	3386	-1-102	0826.5	071.01		
	R18	RL 0,60 RESISTO		OHM:	1%TK50	RL	0083.1297.00	RESISTA	MK2		0826.5	071.01	
	MENP5	413	3PUA	ΙÄ	Datum Date		Schaltteill Parts lis			Sachnummer Stock No.		Blatt-Nr. Page	
095.0026-0693	ROHDI	E&SCH\	WARZ	21	16.09.97	Z	ZE EICHLEITUNG (SMX)			0826.5065.01 SA <sub>1+</sub>			

Kennz. Comp. No.	Beneni Design	nung etion			Sachnummar Stock No.	Hersteller Menufacturer	Bezeichnung Designation		alten in eined in
R21	RL 0,60W 10,0W	OHI	N+-1%TK50	RL	0083.1297.00	RESISTA	MK2	0826.	5071.01
R22	RESISTOR RL 0,60W 4,75M	(OHI	/+-1%TK50	RL	0083.1097.00	RESISTA	MK2	0826.	5071.01
R30	RESISTDR RL 0,60W 12,1K	OH	#+-1%TK50	RL	0083.1351.00	RESISTA	MK2	0826.5	5071.01
Ř31	RESISTOR RL 0,60W 4,75W RESISTOR	OHN	M+-1%TK50	RL	0083.1097.00	RESISTA	MK2	0826.5	5071.01
V1	AE BZX55/810 ZENER DIODE	(	,5W ZDI	AE	0289.4302.00	VALVO	8ZX79810	0826.5	5071.01
V2	AE 8ZX55/810 ZENER DIODE	C	,5W ZDI	AE	0289.4302.00	VALVO	BZX79810	0826.5	5071.01
V3	AE 8ZX79/85V6 ZENER DIODE NUR VAR/ONLY N		,5W ZDI	AE	0012.5254.00	VALVO	8ZX7985V6	0826.5	5071.01
V3	AE BZX79/86V8 ZENER DIODE	C	,5W ZDI	AE	0586.9906.00	PHILIPS	8ZX7986V8	0826.5	5071.01
V4	NUR VAR/ONLY M AD 1N4448 DIODE	75V		AD	0012.0700.00	PHILIPS_SE	1N4448 "	0826.5	5071.01
V5	AE 8ZX79/85V6 ZENER DIODE		,5W ZDI	AE	0012.5254.00	VALVO	8ZX7985V6	0826.5	071.01
V5	NUR VAR/ONLY M AE 8ZX79/86V8 ZENER DIODE	O	,5W ZDI	AE	0586.9906.00	PHILIPS	8ZX79B6V8	0826.5	071.01
V6		OD: 75V		AD	0012.0700.00	PHILIPS_SE	1N4448 "	0826.5	071.01
V8		75V	UDI	AD	0012.0700.00	PHILIPS_SE	1N4448 "	0826.5	071.01
v9		45	V 200MA	AK	0010.3777.00	VALVO	8CY79IX	0826.5	071.01
V20		75V	UOI	AD	0012.0700.00	PHILIPS_SE	1N4448 "	0826.5	071.01
V21		75V	UOI	AD	0012.0700.00	PHILIPS_SE	1N4448 "	0826.5	071.01
V30	OIOOE AK 8CY59IX N TRANSISTOR	45	V 200MA	AK	0010.5163.00	VALVO	8CY59IX	0826.5	071.01
W41	OX KASEL W41 CASLE W41				0826.8370.00				
X1	FJ EINBAUBUCHS	E S	YST.SMA	FJ	0294.8154.00	SUHNER	22SMA-50-0-26/111NH	0294.8	983.00
X2	SOCKET FJ EINBAUBUCHS	E S	YST.SMA	FJ	0294.8154.00	SUHNER	22SMA-50-0-26/111NH	0294.8	983.00
X41	SOCKET FP STIFTL.WIN : ANGLE PIN CONNI	ECT		FP	0087.9105.00	8INOER	742-5-11-0191-00-36	0826.5	071.01
X100	3-POLIG/3 PINS FP BUCHSE VERT SOCKET		L P.V.1P	FP	0278.5577.00	OUPONT CON	75377-001GEGURTET	0826.5	071.01
X77A	FP STIFTLEISTE PIN CONNECTOR		P.R2,54	FΡ	0242.3600.00	8INDER	742-11-0179-00-36	0826.5	071.01
X778	8-POLIG/8 PINS FP STIFTLEISTE PIN CONNECTOR 8-POLIG/8 PINS	36	P.R2,54	FP	0242.3600.00	8INDER	742-11-0179-00-36	0826.5	071.01
Z1	DT DAEMPFUNGSGI				0912.5269.00			0294.8	983.00
Z2	DT DAEMPFUNGSGI	LIE	D20D8/50		0912.5252.00			0294.8	983.00
z3	ATTENUATOR 2008 DT DAEMPFUNGSG	_IEI	D10D8/50		0912.5246.00			0294.8	983.00
Z4	ATTENUATOR 1008	İE	D20D8/50		0912.5252.00			0294.8	983.00
Z5	ATTENUATOR 20DE	ĹΙΕΙ	D40D8/50		0912.5269.00			0294.8	983.00
z6	ATTENUATOR 40D8 DT ANSCHLUSSLE	TUI			0915.0800.00			0294.8	983.00
Z7	CONNECTION LINE 8D UESERSPANNUM	VGS:			0915.4205.00			0294.8	983.00
Z11	OVERVOLTAGE-PRO	)   E	CITON		1008.5850.00			0294.8	983.00
Z12	FILTER LD PI-FILTER FILTER				1008.5850.00			0294.8	983.00
		ĺ	Datum		Schalttelli	eta tür	Sachnumme		Blatt-Nr.
MENP5	413 3P0A	ΙÄ	Date		Perts lis		Stock No.		Page
ROHDE	&SCHWARZ	21	16.09.97	Z	E EICHLEITUNG	(SMX)	0826.5065.0	1 SA	2-



Ansicht und Leitungsführung Lötseite View of tracks on solder side





ACHTUNG: EGB!
Elektrostatisch gefahrdete
Bauelemente erfordern eine
besondere Handhabung.
ATTENTION ESD!
Electrostatic sensitive
devices require a special


	В		10.85	HOF	Maí Tolera	le ohne inzangabe		Maßstab 1	; 1	-1111	
ı								Halbzeug, W	erkstoff		
					1KSA	Tag	Name	Benennung			
					Bearb.	10.85	HOF				
					Gepr			Anst	euerung/Eichleitung		Z
JOI					Norm				3		
7					(R)			Zeichn -Nr		81	att-Nr
F					ROH	IDE&SC	HWARZ		826.5071.01		2
	And Zust.	Anderungs- Mitteilung	Tag	Name	zu Gera	t SMX		reg ı V	erste Z	V	

PE 095 2506.0781

Für diese Unterlage behaiten wir uns alle Rechte vor.

C. in Carolin Marchine

Markey



ROHDE&SCHWARZ

zu Geraat SMX

Aend. Zust.


Aenderung


Datum


826.5065 S


leg.L.V. 826.4517


4.4















Bindende Angaben über Varianten, Trimmwerte, Bauteilwerte und nicht bestückte Bauteile siehe SA

For binding Information on models, trimming and components values and nonfitted components see parts list.


	IND.	HITTEILUNG			ZU SEPRET	รถม		PES. 1. V.	826. 4517 Epste 2.	
- 1	REND.	AENDERUNGS-	NUTRO	NAME	KOH	DE&SC	HUARZ		020,3003.013	1. 2n
- [	/				I Y?				826.5065.015	1+
ı								ZEICHNNR.	•	BLATT-MR.
					PLOTI					
					NORM			ATTE	หน่คาดก	
				·	GEPP.	03.97	El	ZEEIC	CHLEITUNG	
	09		03 .97	EL	BERRB.		ни	]	·	
	08/	48746	11.04.95	нп	MENP	าสร	NRME	BENENKUNG		





A				Jernet			_	
IND.	HITTEILUNG	1 "" 1	wunt.	ZU SEPRET	SIIX		PEG. 1.V.	826
HEND	RENDERUKSS-	DATUM	ияле	ROH	DE&SC!	HUARZ		
1	-							
				6			ZEICHN	MR.
				PLOTT				
				NORT			AT.	TENUI
		<u> </u>		SEPR.	03.97	EI	ZEEI	CH
09		03.97	EI	BEARB.		нп	1	
180	48746	11.84.95	нп	MENP	TAG	NAUE	BENENNUN	E






	ACHTUNG: EGB! ELEKTROSTATISCH GEFREHRDETE BAUELERATE ERFORGERN EINE BESONGERE HANDHRBUNG.
123	ATTENTION ESD! ELECTROSTATIC SENSITIVE DEVICES REQUIRE & SPECIAL HANDLING
	and the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of t

7			
RENO. IND.	RENDERUNGS-	DATUM	NAME
/	*		<u> </u>
		<u> </u>	
	·		
	4.		
09		03.97	EI
08/	48746	11.04.95	

E

ATTENUATORS





ACHTUNG: EGB!
ELEKTROSTERTISCH GEFREHRDE:
BRUELEREHTE ERFORDERN EIN
BESCHOEPE HANDHRBUHG.

ATTENTION ESD!
ELECTROSTATIC SENSITIVE DEV
PEQUIPE A SPECIAL HANDLIN



SERVICEUNTERLAGEN
Eichleitung 2 GHz
0801.1108.01

## Inhaltsverzeichnis

7	Prü:	fen und Instandsetzen der Baugruppe	5
	7.1	Funktionsbeschreibung	5
		7.1.1 Eichleitung mit integriertem Überspannungsschutz	5
		7.1.2 Ansteuerung der Eichleitung	5
	7.2	Meßgeräte und Hilfsmittel	6
	7.3	Fehlersuche	6
		7.3.1 Ansteuercode	6
		7.3.2 Ansteuerpuls der Dämpfungsglieder	7
	7.4	Prüfen und Abgleich	7
		7.4.1 Prüfen der Dämpfungsglieder und der Ansteuerdruckschaltung	7
		7.4.2 Prüfen des Überspannungsschutzes	7
		7.4.2.1 Statische Prüfung	7
		7.4.2.2 Prüfung bei Wechselspannung (nur VAR04) 8	
		7.4.2.3 Prüfung bei Gleichspannung (nur VARO4) 8	3
		7.4.2.4 Prüfung und Abgleich bei Wechselspannung (nur VAR02)	8
		7.4.2.5 Prüfung bei Gleichspannung (nur VARO2) 8	
		7.4.3 Schnittstellen	2

Schaltteilliste Koordinatenliste Stromlauf Bestückungsplan

#### 7

#### Prüfen und Instandsetzen der Baugruppe

#### ACHTUNG!!!

Die Baugruppe darf nicht geöffnet werden, da sonst der Garantieanspruch erlischt und ein Neuabgleich durchgeführt werden muß.

Für SMY ohne Option SMY-B40 ist für diese Baugruppe die Variante 02 erforderlich.

Für SMY mit Option SMY-B40 ist für diese Baugruppe die Variante 04 erforderlich.

## 7.1 Funktionsbeschreibung

(Siehe hierzu Stromlauf und Blockschaltbild 0801.1108.01S)

## 7.1.1 Eichleitung mit integriertem Überspannungsschutz

Die Eichleitung ist zwischen das Ausgangsteil (bzw. der Baugruppe Powermodul bei Geräten mit Option SMY-B40) und den Geräteausgang geschaltet. Mit ihr kann das Signal um 135dB in 5dB-Stufen abgesenkt werden. Kleinere Pegelsprünge werden mit Hilfe der elektronischen Pegelregelung eingestellt. Die Eichleitung enthält sechs Dämpfungsglieder mit den Werten 5, 10, 2\*20 und 2\*40dB, ein Überspannungsschutzsubstrat und ein 50 Ohm Abschlußwiderstand. Die Dämpfungsglieder können durch jeweils eine Kontaktgruppe, die aus drei Einzelkontakten besteht, eingeschaltet oder überbrückt werden. Jede dieser Kontaktgruppen wird von einer Wippe betätigt, die von einer Magnetspule angetrieben und durch einen Permanentmagneten in der Endlage gehalten wird.

Hinter den Dämpfungsgliedern sitzt auf der Eichleitungsgrundplatte in Richtung Geräteausgang das Überspannungsschutzsubstrat und anschließend der RF-OFF-Schalter. Das Überspannungsschutzsubstrat erkennt hohe DC-Spannungen und HF-Pegel, welche an die Ausgangsbuchse X1 angelegt werden und betätigt den RF-OFF-Schalter. Der RF-OFF-Schalter kann aber auch vom Rechner über die Software bedient werden.

## 7.1.2 Ansteuerung der Eichleitung

Die Dämpfungseinstellung erfolgt durch serielle Datenübertragung (siehe 7.3.1). Die Ansteuerbits werden über die Datenleitungen (X77.B1 SERDAT) mit dem Clock (X77.B2 SERCLK) in das Schieberegister (D5) auf der Eichleitungsansteuerdruckschaltung geschoben. Mit dem Strobe (X77.B3 ELSTB) werden die Ausgänge des Schieberegisters gesetzt und die gewünschte Dämpfung eingestellt. Die Ansteuerung der Magnetspulen der Kontaktgruppen erfolgt über die Leistungsgatter D1 bis D4.

Hohe HF- und DC-Spannungen an der Ausgangsbuchse werden durch Spitzenwertgleichrichtdioden erkannt. Wird eine Überspannung erkannt, sprechen die Komperatoren N10 a,b an und setzen das Flip-Flop D6, das über V8 und D4 direkt den RF-OFF-Schalter betätigt.

Während der Ansprechzeit des RF-OFF-Schalters schließen die Pindioden auf dem Überspannungsschutzsubstrat die Überspannung kurz. Durch die beiden Monoflops V33 und V34 wird den Pindioden im Überlastfall ein hoher DC-Strom eingeprägt, wodurch diese niederohmig werden. Dem Rechner wird der Überlastfall über die Interruptleitung (X77.B4) mitgeteilt. Dieser Interrupt wird dann rückgesetzt, wenn der RF-OFF-Schalter zusätzlich vom Rechner über Software betätigt wird. Der RF-OFF-Schalter kann von Hand über die Tastenfolge 'LEVEL ON' wieder geschlossen werden.

#### 7.2 Meßgeräte und Hilfsmittel

- 1. Ohmmeter (Meßbereich bis 2MOhm)
- 2. Leistungsmeßsender (z.B. SMGL)
- 3. Gleichspannungsnetzgerät für ±15V
- 4. Speicheroszilloskop

#### 7.3 Fehlersuche

## 7.3.1 Ansteuercode

Läßt sich am Gerät ein gewünschter Ausgangspegel nicht einstellen, so kann am Schieberegisterausgang D5 der ordnungsgemäße Ansteuercode der einzelnen Dämpfungsglieder überprüft werden (siehe Tabelle 7.3.1).

Tabelle 7.3.1 für 02 im CW-Betrieb

Ansteuercode am Schieberegister D5 (74HC 4094)

1	1	1	=	5V.	101	=	0.07

Pege	leir	stellu	ng	Pin4	5	6×0 ×	7 (04) 1947	14 0	13	11,9
mit	u i velika. ≉	ohn	e ``	. <b>Q</b> 0	Q1	Q2	Q3	Q4	:Q5	Q7,Q8
Opt	ion	SMY-B4	0	40 dB	20 dB	5 dB	10 dB	20 dB	40 dB	RF-
			4.5	(4:1	- 1 a					OFF
19	dBm	13	dBm	1	1	1	1	1	1	0
14	dBm	8	dBm	1	1	0	1	1	1	0
9	dBm	3	dBm	1	1	1	1	0	1	0
-1	dBm	-7	dBm	1	1	1	0	1	1	0
-21	dBm	-27	dBm	1	1	1	1	1	0	0
-61	dBm	-67	dBm	0	1	1	1	1	0	0
-101	dBm	-107	dBm	0	0	1	0	1	0	0
-114	dBm	-122	dBm	0	0	0	0	0	0	0

<sup>&#</sup>x27;1' = 5V, '0' = 0V

## 7.3.2 Ansteuerpuls der Dämpfungsglieder

Entspricht der Puls an den Magnetspulen D1 bis D4 nicht der in Bild 7.3.2 gezeichneten Form, so liegt ein auftretender Dämpfungsfehler an der Ansteuerdruckschaltung und nicht an den Dämpfungsgliedern mit den zugehörigen Kontaktgruppen vor.




Bild 7.3.2

## 7.4 Prüfen und Abgleich

# 7.4.1 Prüfen der Dämpfungsglieder und der Ansteuerdruckschaltung

Hierzu ist zu verfahren wie in Kapitel 5.2.6 der Wartungsunterlage im Betriebshandbuch beschrieben ist.

## 7.4.2 Prüfen des Überspannungsschutzes

## 7.4.2.1 Statische Prüfung

- Stecker X41 von der Eichleitungsansteuerdruckschaltung abziehen.
- Einen Ausgangspegel von -122 dBm einstellen.

Mit einem Ohmmeter können nun die Dioden des Überspannungsschutzes in Sperr- und Durchlaßrichtung gemessen werden. In Sperrichtung muß der Widerstand sehr groß sein.

• Die Messung erfolgt zwischen der Ausgangsbuchse X1 und dem Durchführungsfilter Z9 für die erste Diode, am Durchführungsfilter Z10 für die zweite.

#### 7.4.2.2 Prüfung bei Wechselspannung (nur VAR04)

- Einen Ausgangspegel von -122 dBm einstellen.
- Einen Leistungsmeßsender mit dem RF-Ausgang des SMY verbinden und eine RF von 25 MHz einstellen.
- \_ Der RF-OFF-Schalter muß bei 30 ... 33 dBm ansprechen

#### 7.4.2.3 Prüfung bei Gleichspannung (nur VAR04)

- An die RF-Ausgangsbuchse X1 des Geräts eine DC-Spannung aus einer Gleichspannungsquelle anlegen.
- \_ Der RF-OFF-Schalter muß bei Spannungen an der N-Buchse von ±(7.5 V ... 8.5 V)ansprechen.

Ein Rücksetzen des RF-OFF-Schalters erfolgt mit der Tastenkombination 'LEVEL ON'.

# 7.4.2.4 Prüfung und Abgleich bei Wechselspannung (nur VAR02)

- Einen Ausgangspegel von -122 dBm einstellen.
- Einen Leistungsmeßsender mit dem RF-Ausgang des SMY verbinden und eine RF von 25 MHz einstellen.
- Der RF-OFF-Schalter muß bei 27.5 dBm ±1.5 dB ansprechen, ein Abgleich kann mit dem Potentiometer R30 erfolgen.

#### 7.4.2.5 Prüfung bei Gleichspannung (nur VAR02)

- An die RF-Ausgangsbuchse X1 des Geräts eine DC-Spannung aus einer Gleichspannungsquelle anlegen.
- Der RF-OFF-Schalter muß bei Spannungen von  $\pm (5 \dots 7 \ V)$  ansprechen.

Ein Rücksetzen des RF-OFF-Schalters erfolgt mit der Tastenkombination 'LEVEL ON'.



SERVICE INSTRUCTIONS
Attenuator 2 GHz
801.1108.01

#### Contents

7	Test	ting a	nd Repai	r of the Module	5
	7.1	Funct	ion Desc	ription	5
		7.1.1	Attenua	tor with Overvoltage Protection	5
		7.1.2	Control	of the Attenuator	5
	7.2	Test	Instrume	nts and Utilities	6
	7.3	Troub	leshooti	ng	6
		7.3.1	Control	Code	6
		7.3.2	Control	Pulse of the Attenuator Pads	6
	7.4	Testi	ng and A	djustment	7
		7.4.1	Testing	the Attenuator Pads and the Control P.C.B	7
		7.4.2	Testina	the Overvoltage Protection	7
			_	Static Test	
				Testing with AC Supply (VAR04 only)	
				Testing with DC Voltage Supply (VAR04 only)	
					0
			1.4.2.4	Testing and Adjustment with AC Supply (VAR02 only)	8
			7.4.2.5	Testing with DC Voltage Supply (VAR02 only)	
		7 4 3	Interfac	700	Q

Parts list List of coordinates Circuit diagram Components layout diagram

#### 7

#### Testing and Repair of the Module

#### CAUTION!!!

Do not open the module, since otherwise the warranty expires and re-adjustment is required.

For instruments without option SMY-B40, this module with VAR02 is necessary.

For instruments with option SMY-B40, this module with VAR04 is necessary.

#### 7.1 Function Description

(Cf. circuit diagram and block diagram 0801.1108.01S)

## 7.1.1 Attenuator with Overvoltage Protection

The attenuator is connected between the output module (the power module for instruments with option SMY-B40, respectively) and the instrument output. It is used to attenuate the signal by 135 dB in steps of 5 dB. Smaller level jumps are set via the electronic level control. The attenuator consists of six attenuator pads of 5, 10, 2\*20 and 2\*40 dB, an overvoltage-protection substrate and a 50-Ohm terminator. The attenuator pads can be switched on or bypassed by means of one contact group each, which consists of three individual contacts. Each of these contact groups is actuated by a rocker, which is driven by a magnetic coil and kept in end position by a permanent magnet.

The overvoltage-protection substrate and the RF-OFF switch are accommodated on the attenuator motherboard subsequent to the attenuator pads. The overvoltage-protection substrate detects high dc voltages and RF levels which are applied to the output socket Xl and actuates the RF-OFF switch. The RF-OFF switch may also be software-controlled via the controller.

#### 7.1.2 Control of the Attenuator

The attenuation is set via serial data transmission (cf. 7.3.1). The control bits are clocked into the shift register (D5) on the attenuator control pcb via the data lines (X77.B1 SERDAT) using the clock X77.B2 SERCLK. The strobe (X77.B3 ELSTB) sets the outputs of the shift registers and the desired attenuation. The magnetic coils of the contact groups are controlled via the power gates D1 to D4.

Peak-responding rectifier diodes detect high RF and dc voltages at the output socket. If an overvoltage has been detected, the comparators N10 a,b respond and set the flip-flop D6, which directly actuates the RF-OFF switch via V8 and D4. During the response time of the RF-OFF switch, the pin diodes on the overvoltage-protection substrate short-circuit the overvoltage. In case of overvoltage, the pin diodes are impressed by a high dc current by means of the two monoflops V33 and V34, the pin diodes thus becoming low-impedance. The information on overload is passed to the controller via the interrupt line (X77.B4). This interrupt is reset if the RF-OFF switch is additionally software-controlled. The RF-OFF switch can be reset manually via the key sequence 'LEVEL ON'.

#### 7.2 Test Instruments and Utilities

- 1. Ohmmeter (Measuring range up to 2 MOhms)
- 2. Power generator (e.g., SMGL)
- 3. DC power supply for ±15 V
- 4. Storage oscilloscope

#### 7.3 Troubleshooting

#### 7.3.1 Control Code

If a desired output level can not be set on the instrument, check at the shift register D5 whether the control code of the individual attenuator pads is correct (see table 7.3.1).

Table 7.3.1 for SMY02 (CW mode):

Control code at shift register D5 (74HC 4094)

Le	re1	setting		Pin4	5	6	27年實際經濟	14	13	11,9
wit		with	out	Q0	Q1	Q2 48 45 5	Q3	Q4	Q5	Q7, Q8
opt	ion	SMY-B4	0	40 dB	20 dB	5 dB	10°dB	20-đB	40 dB	RF- OFF
19	dBm	13	dBm	1	1	1	1	1	1	0
14	dBm	8	dBm	1	1	0	1	1	1	0
9	dBm	3	dBm	1	1	1	1	0	1	0
-1	dBm	-7	dBm	1	1	1	0	1	1	0
-21	dBm	-27	dBm	1	1	1	1	1	0	0
-61	dBm	-67	dBm	0	1	1	1	1	0	0
-101	dBm	-107	dBm	0	0	1	0	1	0	0
-114	dBm	-122	dBm	0	0	0	0	0	0	0

<sup>&#</sup>x27;1' = 5V, '0' = 0V

#### 7.3.2 Control Pulse of the Attenuator Pads

If the pulse at the magnetic coils D1 to D4 does not correspond to the form illustrated in fig. 7.3.2, an error occurred on the control p.c.b., the attenuator pads with the associate contact groups are, however, o.k.




Fig. 7.3.2

## 7.4 Testing and Adjustment

## 7.4.1 Testing the Attenuator Pads and the Control P.C.B.

Proceed as described in Section 5.2.6 of the maintenance instructions given in the operating manual.

# 7.4.2 Testing the Overvoltage Protection

## 7.4.2.1 Static Test

- Withdraw connector X41 from the attenuator p.c.b.
- Set output level to -122dBm.

The overvoltage-protection diodes can be measured in forward and reverse direction using an ohmmeter. The impedance must be very high when the diodes are reverse-biased.

• The measurement is performed between the output socket Xl and the lead-through filter Z9 for the first diode, lead-through filter Z10 for the second diode.

# 7.4.2.2 Testing with AC Supply (VAR04 only)

- Set output level to -122 dBm.
- Connect a signal generator to the RF output of the SMY and set an RF of 25 MHz.
- \_ The RF-OFF switch must respond with 30 ... 33 dBm.

#### 7.4.2.3 Testing with DC Voltage Supply (VAR04 only)

- Apply a dc voltage from a dc power supply to the RF output socket X1 of the instrument.
- The RF-OFF switch must respond for voltages between ± (7.5 to 8.5 V) at the N socket.

The RF-OFF switch is reset using the key combination 'LEVEL ON'.

### 7.4.2.4 Testing and Adjustment with AC Supply (VAR02 only)

- Set output level to -122 dBm.
- Connect a signal generator to the RF output of the SMY and set an RF of 25 MHz.
- \_ The RF-OFF switch must respond with 27.5 dBm ±1.5dB, it can be adjusted using the potentiometer R30.

#### 7.4.2.5 Testing with DC Voltage Supply (VAR02 only)

• Apply a dc voltage from a dc power supply to the RF output socket X1 of the instrument.

\_ The RF-OFF switch must respond with voltages  $\pm$  (5 ... 7 V). The RF-OFF switch is reset using the key combination 'LEVEL ON'.

#### 7.4.3 Interfaces

Pin	Name	Input/Output	Origin/Dest.	Specified range	Signal description
X77.A1	GND				
X77.B1	SERDAT	Input	Controller X3.4	TTL-HCT	Serial data
X77.A2	GND				
X77.B2	SERCLK	Input	Controller X3.2	TTL-HCT	Clock signal
X77.A3	GND				
X77.B3	ELSTB	Input	Controller X3.19	TTL-HCT	Strobe signal
X77.A4	GND				
X77.B4	HFOVERLOAD	Output	Controller X3.22	TTL-HCT	Overload interrupt
X77.A5	GND				
X77.B5	not used				
X77.A6	VAS-P	Input	Power supply X21	5+4.5 to +5.3 V	+5.1 V supply
				42 ±8mA	
X77.B6	-	-	=	•	<b>*</b>
X77.A7	VA15-P	•	• X21.13	+14.9 to +15.6V	+15 V supply
				20 ±4mA	
X77.B7	•	•	•	•	•
X77.A8	VA15-N	•	- X21.19	-15.5 to -14.4 V	-15 V supply
				3 ±.5 V	
X77.B8	*	•	•	-	•
<b>x</b> 1		Input	Output module		
X2		Output	RF socket		



Schaltteillisten
Stromläufe
Bestückungspläne
Part lists
Circuit diagrams
Components plans
Listes des pièces détachées
Schémas de Circuit
Plans des composants


Für diese Unterlage behalten Wir uns alle Rachta vor.

Kennz. Comp. No.	Banan: Design				Sachnummer Stock No.	Hersteller Manufacturer		ezeichnung esignetion		sitan in sinad in
٠	XX VARIANTENEF IDENTIFICATION VAR O2 = GRUND MOD O2 = BASIC ERSETZT/REPLAC VAR OO/MOD OO VAR O4 = SMY12 MOD O4 = SMY12	DF AUS MO	MDDELS FUEHRUNG DEL /4S+B40							
<b>A9</b> 0	ED ANSTEUERUNG ATTENUATOR CON NUR VAR/ONLY M ZUGEH.STRDML./	EI TRO	CHLEITG. L O2		0801.1120.02					
A90	801.1108 S ED ANSTEUERUNG NUR VAR/DNLY M ZUGEH.STROML./ 801.110BS GS UNGEPRUEFT.	OD: CIR	O4 C.DIAGR.		0801.1120.04					
C1	CE 220UF+-20%3	5V	RM5	CE	0008.7904.00	PANASONIC	FC4	-1VFG221B0	0801 1	120.01
7 C8	ELECTROLYTIC C CE 100UF+-20%3	APA		-	0008.7510.00					120.01
	ELECTROLYTIC C	APA	CITOR			1				
C9	CE 47UF+-20%63 ELECTROLYTIC C	APA			0008.7440.00					120.01
C10	CK 100NF+-5%63 CAPACITOR		-	ŀ			MKT	1826-410-06-4W	0801.1	120.01
C11	CE 1,5UF+-20%2 ELECTROLYTIC C			CE	0087.9334.00	KEMET	T34	O A1SSMO25 AS	0801.1	120.01
C1S	CC 10NF-20+SO% CAPACITOR	7X8I	R4000	CC	0087.7525.00	VALVO	222	2 640 51103	OB01.1	120.01
C17	CC 10NF-20+SO% CAPACITOR	7XBI	R4000	cc	0087.7525.00	VALVD	222	2 640 S1103	0801.1	120.01
C18	CK 100NF+-5%63	VRD:	2,5H7MKT	СК	0099.2930.00	ROEOERSTEI	MKT	1826-410-06-4W	0801.1	120.01
C19	CAPACITOR CC 3,3NF+-10%6	X7R	2000	СС	0087.7083.00	PHILIPS_CO	222	2 630 S(1)1332	0801.1	120.01
C20	CAPACITOR CK_33NF+-S%63V	RD:	2,5H7MXT	СК	0099.2900.00	ROEDERSTEI	MKT	1826-333/014	0801.1	120.01
C20	CAPACITOR NUR VAR/ONLY MO CK 3,3NF +-1% POLYPROPYLENE	63\ CAP	V RM5 KP ACITOR	ск	0007.7623.00	ROEOERSTEI	KP1	830-233 06 1 3 W	0801.1	120.01
сзо	NUR VAR/ONLY MO CE 47UF+-20%63		O4 RMS		0008.7440.00	PHILIPS_CO	222	2 116 90112	0801.1	120.01
C31	ELECTROLYTIC C. CE 47UF+-20%63		CITOR RMS	1	0008.7440.00				0801.1	120.01
cas	ELECTRDLYTIC C		CITOR		00B2.77BS.00				0801.1	
C36	CAPACITOR CC 680NF+-10% : CAPACITOR				0082.77BS.00	_			0801.1	
D1	BJ SN75361AP 2	(TTI	_/MOS-LC	BJ	0294.8490.00	NSC	057	5361N	0801.1	120.01
D2	LEVEL CONVERTED BJ SN7S361AP 23		_/MOS-LC	ВJ	0294.8490.00	NSC	DS 7	S361N	0801.1	120.01
4 D5	LEVEL CONVERTED BL PC74HC4094P	₹						)74HC4094N(P)	0801.1	
D6	8ST.SHIFT A.STI	DRE	REGIST.		0086.7021.00	_		0138E	0801.1	
	FLIPFLOP	_,,,,,	1 4441 1		5555.7521.00	.von	CD4	O I GUL	0001.1	120.01
K1	LD ELEKTROMAGNI	ET (	(EICHL.)		0294.8425.00				0294.89	92S.00
6 K9	ELECTROMAGNET LD ELEKTROMAGNE ELECTROMAGNET	ET (	(EICHL.)		0294.8425.00				0294.89	925.00
N10			T OPAMP		0356.0521.00	NSC	LF4	12CN	OBO1.1	120.01
N20	OPERATIONAL AMPLIFIER BS TL604CP 2X ANALDGSCH ANALOG SWITCH			ВJ	0300.6199.00	TEXAS	TL6	04CP	0801.1	
R5	RL O,60W 1KDHM	1%	1TK50	RL	0082.2160.00	RESISTA	MK2		0801.1	120.01
R6	RESISTDR RL 0,60W 1KOHM+-1%TK50			RL	0082.2160.00	RESISTA	MK2		0801.1	120.01
R7	RESISTOR RL 0,40W 1,00K0 RESISTOR				0092.1444.00		MK 1	1K00 1% TK50	0801.1	
MENP5	413 3PUA	Äl	Datum Data		Schaltteilli Parte lie			Sachnummer Stank No		Blatt-Nr.
			Data		Parts lis	. 101		Stock No.		Page
<b>®</b> ROHDI	&SCHWARZ	13	16.09.97		ZE EICHLEITUNG	G (SMG/SMH)		0801.1108.0	1 SA	1+

Kennz. Comp. No.	Benennu Designet			Sachnummer Stock No.	Hersteller Manufecturer	Bezeichaung Designation	*		naiten in tained in
R8	RL 0,60W 12,1KC	DHM+-1%TK50	RL	. 0083.1351.00	RESISTA	MK2	-	0801.	1120.01
R9	RL 0,60W 4,75KC	)HM+-1%TK50	RL	0083.1097.00	RESISTA	MK2		0801.	1120.01
R10	RESISTOR RL 0,60W 10,0KC	)HM+-1%TK50	RL	0083.1297.00	RESISTA	MK2		0801.	1120.01
Ř11	RESISTOR RL 0,60W 24,3KC RESISTOR		RL	0083.1574.00	RESISTA	MK2		0801.	1120.01
R11	NUR VAR/ONLY MO RL 0,60W 66,5KO RESISTOR NUR VAR/ONLY MO	)HM+-1%TK50	RL	0083.1874.00	RESISTA	MK2		0801.	1120.01
R12	RL 0,60W 4,75K0		RL	0083.1097.00	RESISTA	MK2		0801.	1120.01
R13	RESISTOR RL O,60W 11,5KO	HM+-1%TK50	RL	0083.1339.00	RESISTA	MK2		0801.	1120.01
R14	RESISTOR RL O,60W 100KOH	M+-1%TK50	RL	0082.1764.00	RESISTA	MK2		0801.	1120.01
R16	RESISTOR RL 0,60W 6,81KO RESISTOR	HM+-1%TK50	RL	0082.2560.00	RESISTA	MK2		0801.	1120.01
R16	NUR VAR/ONLY MO RL 0,60W 20,0KD RESISTOR		RL	0083.1522.00	RESISTA	MK2		0801.	1120.01
R17	NUR VAR/ONLY MO RL 0,60W 24,3KO RESISTOR		RL	0083.1574.00	RESISTA	MK2		0801.	1120.01
R17	NUR VAR/ONLY MO RL O,60W 66,5KO RESISTOR	HM+-1%TK50	RL	. 0083.1874.00	RESISTA	MK2		0801.	120.01
R18	NUR VAR/ONLY MO		RL	0083.1339.00	RESISTA	MK2		0801.	120.01
R19	RESISTOR RL 0,60W 100KOH	M+-1%TK50	RL	0082.1764.00	RESISTA	MK2		0801.1	120.01
R20	RESISTOR RL 0,60W 681 KON	HM+-1%TK50	RL	0083.2735.00	RESISTA	MK2		0801.1	120.01
R21	RESISTOR RL 0,60W 332 KO	HM+-1%TK50	RL	0083.2441.00	RESISTA	MK2		0801.1	120.01
R22	RESISTOR RL 0,40W 10,0KD	HM+-1%TK50	RL	0092.1567.00	RESISTA	MK1 10K0 1%	TK50	0801.1	120.01
R25	RESISTOR RL 0,40W 10,0KO	HM+-1%TK50	RL	0092.1567.00	RESISTA	MK1 10K0 1%	TK50	0801.1	120.01
R26	RESISTOR RL 0,60W 1KOHM+- RESISTOR	-1%TK50	RL	0082.2160.00	RESISTA	MK2		0801.1	120.01
R26	NUR VAR/ONLY MOU RL O-OHM-WIDERST O-OHM RESISTOR	Γ. 0204	RL	0069.0000.00	ORALORIC	OMA 0204		0801.1	120.01
R30	NUR VAR/ONLY MOC RS 0,5W1OKOHM+-1 CERMET POTENTION NUR VAR/ONLY MOC	10%10X10X5 KETER T	RS	0247.7903.00	SPECTROL	63 M TO	10	0801.1	120.01
R30	RS 0,5W1KOHM+-1C CERMET POTENTION NUR VAR/ONLY MOD	0%10X10X5 METER T	RS	0087.7560.00	80URNS	3386F-1-102		0801.1	120.01
R31	RL 0,60W 332 OHN RESISTOR		RL	0083.0255.00	RESISTA	MK2		0801.1	120.01
R32	RL 0,60W 332 OHN RESISTOR	4+-1%TK50	RL	0083.0255.00	RESISTA	MK2		0801.1	120.01
R33	RL 0,60W 82,5KDF RESISTOR	M+−1%TK50	RL	0082.2302.00	RESISTA	MK2		0801.1	120.01
R34	RL 0,60W 82,5KOH RESISTOR	łM+− 1%TK50	RL	0082.2302.00	RESISTA	MK2		0801.1	120.01
R35	RL 0,40W 20,0KOH RESISTOR	łM+~1%TK50		0092.0402.00	RESISTA	MK 1		0801.1	120.01
R36	RL 0,60W 22,1KDH RESISTOR	M+~1%TK50	RL	0083.1545.00	RESISTA	MK 2		0801.1	120.01
V6	AD 1N4448 75 DIODE	IDU VOI	AD	0012.0700.00	PHILIPS_SE	1N4448 "		0801.1	120.01
V7	AK BCY79IX P 4	15V 200MA	AK	0010.3777.00	VALVO	8CY79IX		0801.1	120.01
V8	TRANSISTOR AK BC173C N 2 TRANSISTOR	25V 100MA		0010.4444.00	ITT-SEMICO	BC549C		0801.1	120.01
V10	AD 1N4448 75 DIODE	IDU V	AD	0012.0700.00	PHILIPS_SE	1N4448 "		0801.1	120.01
V12	AD 1N4448 75 DIODE	SV UDI	AD	0012.0700.00	PHILIPS_SE	1N4448 "		0801.1	120.01
MENP5	A12 2014	. Detum		Scheltteilli	ste für		Sechnummer		Blatt-Nr.
mENTO	413 3PUA 2	Al Date		Parts list			Stock No.		Page
ROHDE	E&SCHWARZ 1	3 16.09.97	Z	E EICHLEITUNG	(SMG/SMH)	0801.1	108.01	I SA	2+

Kennz. Comp. No.	Benenn Designe			T	Sachnummer Stock No.	Hersteller Menufecturer	Bezeichnung Designation			ilten in Sined in
V20	AE 8ZX55/88V2		,5W ZDI	AE	0012.2178.00		8ZX7988V2		<del>.                                       </del>	120.01
V2 1	ZENER DIDDE	<b>7</b> 5V	UDI		0012.0700.00			11		120.01
V22	DIODE AD 1N4448	75V	UDI		0012.0700.00			tt	0801.1	120.01
V23	DIODE AE 8ZX85/C8V2	1	,3W ZDI	1	0092.8526.00	_	BZX85C8V2		0801.1	120.01
V24	ZENER DIODE		COAMPDI		0252.5386.00		8AV45			120.01
V25	LDW LEAKAGE DI AE 8ZX55/88V2		,5W ZDI		0012.2178.00		BZX7988V2			120.01
V26	ZENER DIODE AE 8ZX85/C8V2		,3W ZDI	f	0092.8526.00		BZX85C8V2			120.01
V27	ZENER DIODE	75V	UDI		0012.0700.00			11		120.01
V28	DIODE	75V	UDI	1	0012.0700.00	_		tt		120.01
	DIODE NUR VAR/ONLY M	OD:	02			_				
V30	AD 1N4448 DIODE	<b>7</b> 5V	UDI	AD	0012.0700.00	PHILIPS_SE	1N4448	11	0801.1	120.01
V31	NUR VAR/ONLY M AD 1N4448 DIODE	OD: 75V	O4 UDI	AD	0012,0700.00	PHILIPS_SE	1N4448	tt	0801.1	120.01
V32	AD 1N4448	75V	UDI	AD	0012.0700.00	PHILIPS_SE	1N4448	11	0801.1	120.01
V33	DIODE AK 8C337-40 N	45\	/ 800MA		0303.9524.00	ITT	8C337-40		0801.1	120.01
V34	TRANSISTDR AK BC327-40 P TRANSISTOR	45\	AMOO8 \		0303.9518.00	PHILIPS_SE	8C327-40		0801.1	120.01
W12	DX KABEL W12 CA8LE W12				0801.7629.00					
X1	FJ EINBAUBUCHS	E SY	/ST.SMA	FJ	0294.8154.00	SUHNER	22SMA-50-0	)-26/111NH	0294.8	725,00
X2	SOCKET FJ EINBAUBUCHSI	E SY	/ST.SMA	FJ	0294.8154.00	SUHNER	22SMA-50-0	7-26/111NH	0294.8	725.00
X41	SOCKET FP STIFTL.WIN			FP	0243.3578.00	81NDER	742-5-11-0	187-00-36	0801.1	120.01
X77A	ANGLE PIN CONNI 3-POLIG/3 PINS FP STIFTLEISTE			FP	0242.3600.00	BINDER	742-11 <b>-</b> 017	9-00-36	0801.1	120.01
X778	PIN CONNECTOR 8-POLIG/8 PINS FP STIFTLEISTE	36F	.R2,54	FP	0242.3600.00	8INDER	742-11-017	9-00-36	0801.1	120.01
	PIN CONNECTOR 8-POLIG/8 PINS									
Z1	DT DAEMPFUNGSGL				0912.5269.00				0294.83	725.00
Z2	DT DAEMPFUNGSGI	_IEC	20D8/50		0912.5252.00	:			0294.87	725.00
Z3	DT DAEMPFUNGSGI ATTENUATION 5DE	_IEC	5D8/50		0912.5281.00				0294.87	725.00
Z4	DT DAEMPFUNGSGLATTENUATOR 2008	LIEC	20D8/50		0912.5252.00				0294.87	725.00
Z5	DT DAEMPFUNGSGI ATTENUATOR 1008	LIED	10DB/50		0912.5246.00				0294.87	725.00
<b>Z</b> 6	DT DAEMPFUNGSGL ATTENUATOR 40DE	.IED	40DB/50		0912.5269.00	- Agranda			0294.87	725.00
<b>Z</b> 7	DT ANSCHLUSSLET	TUN			0915.0800.00				0294.87	725.00
Z8	8D UE8ER5PANNUN	NGS5			0800.9570.00	And the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of the state of t			0294.87	725.00
<b>Z</b> 9	OVERVOLTAGE PRO	JIEC	, I I UN		1008.5850.00				D294.87	725.00
Z 10	FILTER LD PI-FILTER FILTER				1008.5850.00				0294.87	725.00
	FILIER									
						- Andrews				:
AICHINE	440 0004		Datum		Schalttell	liste für		Sachnummer		Blatt-Nr.
MENP5	413 3PUA	Äl	Date		Parts II			Stock No.		Page
ROHDI	E&SCHWARZ	13	16.09.97	2	ZE EICHLEITUN	G (5MG/5MH)	080	1.1108.01	I SA	3-

Ansicht und Leitungsfuehrung Loetseite View of tracks on solder side




Bindende Angaben über Varianten, Trimmwerte, Bauteilwerte und nicht bestückte Bauteile siehe SA

For binding Information on models, trimming and components values and nonfitted components see parts list.

K 14	41828	5.89 03.97	H0 EI		le ohne inzangabe		Maßstab Halbzeug, W	1 1 /erkstoff			
				MENP	Tag	Name	Benennung		·····		
				Весгь.	05.89	НО					_
				Gepr.	03.97	ΕI					
				Norm			ED Ar	nsteuerun	g Eichleit	ung .	
				<b>(\$)</b>		2	Zeichn,-Nr.	0044	120.01	1 _	Blatt-Nr 2 =
Х., .1	Ändosungs	-			ideasc	HWARZ		801.1	120.01		v. B
Änd. Zust.	Änderungs- Mitteilung	Tag	Name	zu Geri	± SMG		гед. i, V.	801.0001 V	erste Z.		

# Ansicht und Leitungsfuehrung Loetseite View of tracks on solder side



Inierzu HVC 250)


ACHTUNG: EGB! Elektrostatisch getährdete Bauelemente erfordern eine besondere Handhabung.

ATTENTION ESD! Electrostatic sensitive devices require a special handling.

K 14	41828	5.89 03 <b>.</b> 97	HO EI		Ne ohne Inzangabe	×	
				MENP	Tag	Name	t
		1		Bearb.	05.89	НО	
				Gepr.	03.97	EL	
				Norm			-
Änd.	Änderungs			1	IDE&SC	HWARZ	
Zust.	Änderungs- Mitteilung	Tag	Name	zu Gerö	it SMG		

ht und Leitungsfuehrung Bauteilseite of tracks on component side


Ansicht und View of tra



(Nierzu HVC 250)

ACHTUNG: EGB!
Elektrostatisch gefährdete
Bauelemente erfordern eine
besondere Handhabung.
ATTENTION ESD!
Electiostatic sensitive
devices require a special
handling.

Änd. Änder Zust. Mitte



Für diese Unterlage behalten wir uns alle Rechte vor.

D


В

**\_**---





ACHTUNG: EGB!
Elektrostatisch gefährdete
Bauelemente erfordern eine
besondere Handhabung.
ATTENTION ESD!
Electrostatic sensitive
devices require a special
handling.




Bindende Angaben über Varianten, Trimmwerte, Bauteilwerte und nicht bestückte Bauteile siehe SA E

For binding Information on models, trimming and components values and nonfitted components see parts list.

ı	05/	46470	11.84.95	ни	MENP	1RG	KANE	BEKENNUN	G	
	06		03 .97	<u>BI</u>	BERP8.	03.97	ÊΙ			- 1
					GEPP.			ZE E I	ICHLEITUNG	1
				-	NORM			AT.	TENUATORS	
					PLOTT					
- 1					(%)			ZETCHN	NP. DLA1	I - RP
- 1					1 1 2				DOA AADO DAC	+
	AE XD.	AENDEPUNGS-	DRIUN	368%	ROH	DE&SC	HUARZ		801.1108.015	BL
┙	IND.	UITTEILUNG	J, O	.,,,,,,	ZU SEPACI	Sng		PES, 1 V	801.0001 (1951) 2	
	<u> </u>			C				~		

E \$







$\triangle$	ACHTUNG: EGB!
	ELEKTROSTATISEN GEFAENPDETE
	BAUELENENTE EPFOPOEPH EIKE
	BESONDEPE HANDHRBUNG.
APA	ATTENTION ESD!
	LEFECTADETATIC SENSITIVE DEVICES
. 4000000000000000000000000000000000000	PERVIPE A SPECIAL HANGLING

	<b>A</b>			C				7
	INO.	MITTELLUNG	VITTUIL	n n II [	ZU SEPAC	r SMG		9[6.1 V
	REND.	RENDEPUNGS-	DAIUN	NRME	ROF	IDE&SC	HUARZ	
	1				1 \ 7			
ı								ZEICHW
					PLOTT			
1					KOPN			AT1
1					GEPP.			ZE EI
1	06		97, 03	61	BERP8.	03.97	El	]
ļ	05/	46470	11.04.95		MENP	TAG	мапе	BENENNUNI


#### ATTENUATORS





	)
05/	46470
06	
	*-
/	
REND.	RENDEPUNGS-
END.	MILITITUME

#### ATTENUATORS






ACHTUNG: EGB! ELEFTPOSTATISCH GEFRENPOETE BAUELENEHTE EPFOPDEPH EINE BESONDERE HANDHABUNG. ATTENTION ESD! CLECTROSTATIC SENSITIVE DEVICES
PEDVIRE A SPECIAL HANDLING

05/	46470
06	<u> </u>
1	-
. OKI	RENDEPUNGS MITTEILUNG

Ļ





ACHTUNG: EGB!

ELCTIPOSTATISCH GEFRENPOETE
BAVELERENT EPFOPPEPH EINE
BESONDEPE HANDHABUNG.
ATTENTION ESD!
ELCCTPOSTATIC SENSITIVE DEVICES
PEOUIPE A SPECIAL MANOLING

1

E

100 TERROR TO AND HILL FERTHER 100 A

C


В


2


\_\_\_


Lt.


\_\_\_\_\_
















SERVICEUNTERLAGEN
NETZTEIL
1062.5690.02

## Inhaltsverzeichnis

7	Prü	fen und Instandsetzen der Baugruppe	5
	7.1	Funktionsbeschreibung	5
	7.2	Meßgeräte und Hilfsmittel	5
	7.3	Fehlersuche	5
	7.4	Allgemeine Daten	5
		7.4.1 Oberspannung unbelastet	6
		7.4.2 Oberspannung belastet	6
		7.4.3 Brummspannung	6
	7.5	Prüfen und Abgleich	6
		7.5.1 Prüfen des Regelverhaltens und der Störspannung	6
		7.5.2 Kurzschlußverhalten	7
	7.6	Zerlegung und Zusammenbau	7
	7 7	Fytorne Cahnittatelle	-

Schaltteilliste Koordinatenliste Stromlauf Bestückungsplan

## 7.1 Funktionsbeschreibung

Das Netzteil versorgt die Baugruppen des Gerätes mit fünf geregelten Gleichspannungen von -15V, +24V, +15V, +7.5V sowie +5.1V. Zusetzlich wird der Lüfter des Gerätes aus der Oberspannung des +7.5V Regelteils versorgt.

Der Netztrafo wird primärseitig über ein Netzfilter und einen Spannungswähler gespeist.

Es stehen vier Primärspannungen zur Auswahl: 100V, 120V, 220V und 230V.

Der Netztrafo ist primärseitig durch eine Schmelzsicherung gegen Kurzschluß sowie über eine in die Trafoeinheit vergossene Thermosicherung gegen thermische Überlastung geschützt.

Auf der Sekundärseite weist der Netztrafo vier Wicklungen auf, die die Brückengleichrichterschaltungen speisen.

Die an den vier Ladekondensatoren der Gleichrichterschaltungen anstehenden Oberspannungen werden vier integrierten Spannungsreglerschaltungen zugeführt. Der +5.1V Spannungsregler wird von der Ausgangsspannung des +7.5V Reglers gespeist.

Die Ausgangsspannungen der Spannungsregler sind entweder intern oder durch äußere Beschaltung festgelegt.

## 7.2 Meßgeräte und Hilfsmittel

- Digitalmultimeter (z.B. R&S UDS5)
- Stelltrafo 90V...265V, 50Hz
- Oszilloskop
- Elektronische Last

#### 7.3 Fehlersuche

Ausfall aller Spannungen

Spannungswähler auf korrekte Einstellung, Netzsicherung und ggf. Thermoschalter überprüfen.

Ausfall einer Spannung

Das Netzteil entlasten und entsprechenden Reglerbaustein überprüfen (ggf. ist auch die Last zu überprüfen).

#### 7.4 Allgemeine Daten

Die angeführten Werte der Oberspannungen und Brummspannungen der Gleichrichterschaltungen sollen als zusätzliche Angaben die Fehlersuche erleichtern. Sie sind nicht Bestandteil der Baugruppenprüfung. Die Werte gelten bei einer Netzspannung von 230V ±1V und 50Hz Netzfrequenz.

# 7.4.1 Oberspannung unbelastet

Spannungen an Ladeelko gemessen						
+5.1V	+7.5V	+15.0V	+24.0V	-15.0V		
+7.5 ±0.3V	+13.2V ±1.0V	+24.8V ±1.0V	+38.8V ±1.0V	-24.9V ±1.0V		

## 7.4.2 Oberspannung belastet

	Spann	ungen an Ladeelko g	enessen - To	
+5.1V (1.0A)	+7.5V (0.95A)	+15.0V (1.5A)	+24.0V (0.3A)	-15.0V (0.5A)
+7.5 ±0.3V	+10.9V ±1.0V	+20.7V ±1.0V	+32.2V ±1.0V	-21.3V ±1.0V

## 7.4.3 Brummspannung

Spannungen an Ladeelko gemeesen							
+7.5V	+15.0V	+24.0V	-15.0V				
max. 500mVss	max.400mVss	max. 50mVss	max. 300mVss				

# 7.5 Prüfen und Abgleich

Alle Meßwerte ohne Toleranzangaben sind als Richtwerte zu verstehen. Spannungen ohne weitere Bezeichnungen bedeuten DC-Spannungen.

# 7.5.1 Prüfen des Regelverhaltens und der Störspannung

- Spannungswähler auf 230V einstellen
- \_ Die Netzspannung von 230V auf 207V ändern und max. Änderung und Störspannung nach der Tabelle überprüfen.

Hefpunkt	Bezugspunkt	Spannung	Toleranz	Max. Anderung	Störsp. Veff
X22.1	GND	+5.1V	±4%	20mV	<3mV
X22.4	GND	+7.5V	±4%	50mV	<3mV
X22.2	GND	+15.0V	±4%	50mV	<3mV
X22.22	GND	+24.0V	±4%	70mV	<3mV
X22.6	GND	-15.0V	±4%	50mV	<3mV

## 7.5.2 Kurzschlußverhalten

- Netzteil unbelastet (Kabel zum Motherboard und Option ROSC abziehen)
- Upr. =  $230V \pm 1V$
- Frequenz 50Hz
- \_ Ausgangsspannungen nacheinander kurzschließen und Kurzschlußstrom bestimmen.
- \_ Funktion der Regler durch Messung der Ausgangsspannungen (siehe 7.4.1) prüfen.

in the tall (v)	Pin (x3)	Bezug	Kurzschlußstrom
+5.1V	X21.5\6\7	GND	<4.5A
+7.5V	X21.8	GND	<4.5A
+15.0V	X21.13\14\15\16	GND	<4.0A
+24.0V	X21 . 22	GND	<2.5A
-15.0V	X21.19\20	GND	<2.5A

GND

X21.1\2\3

X21.9\10\11\12

X21.17\18

X21.21

## 7.6 Zerlegung und Zusammenbau

Nach dem Öffnen des Gerätes und der gekennzeichneten Schrauben auf der Rückwanne sowie dem Lösen des Kabels W21, kann die Baugruppe aus dem Rahmen herausgenommen werden.

Der Einbau der Baugruppe und Zusammenbau des Gerätes erfolgt entsprechend in umgekehrter Reihenfolge.

7.7 Externe Schnittstelle

Pin	Name	Ein/Ausgang	Herkunft	/Ziel	Wertebereich	Signalbeschreibung
X4.1	LÜFTPLU	Ausgang	Lüfter		9v13v	Plusspannung
X4.2	LÜFTMIN	Ausgang	Lüfter			Masse
X4.3	CODE					
X4.4	TEMPREG	Ausgang	Lüfter		100kΩ NTC	Temperaturregelung
X21.4	USVC	Ausgang	A3 MBRD	X21.4	+7.2V+7.8V	+5V Überspannung für Reset
X21.5	VA5-P	Ausgang	A3 MBRD	21.5	+4.9V+5.3V	+5.1V Versorgungsspannung
X21.6	VA5-P	Ausgang	A3 MBRD	X21.6	+4.9V+5.3V	+5.1V Versorgungsspannung
X21.7	VA5-P	Ausgang	A3 MBRD	X21.7	+4.9V+5.3V	+5.1V Versorgungsspannung
X21.8	VA7.5-P	Ausgang	A3 MBRD	X21.8	+7.2V+7.8V	+7.5V Versorgungsspannung
X21.13	VA15-P	Ausgang	A3 MBRD	X21.13	+14.4V+15.6V	+15V Versorgungsspannung
X21.14	VA15-P	Ausgang	A3 MBRD	X21.14	+14.4V+15.6V	+15V Versorgungsspannung
X21.15	VA15-P	Ausgang	A3 MBRD	X21.15	+14.4V+15.6V	+15V Versorgungsspannung
X21.16	VA15-P	Ausgang	A3 MBRD	X21.16	+14.4V+15.6V	+15V Versorgungsspannung
X21.19	VA15-N	Ausgang	A3 MBRD	X21.19	-15.6V14.4V	-15V Versorgungsspannung
X21.20	VA15-N	Ausgang	A3 MBRD	X21.20	-15.6V14.4V	-15V Versorgungsspannung
X21.22	VA24-P	Ausgang	A3 MBRD	X21.22	+23.0V+25.0V	+24V Versorgungsspannung
X21.23	OVENCOLD	Ausgang	A3 MBRD	X21.23	HCMOS-Pegel	Ofen kalt (Opt Ref. Oszill.)
X21.24	OPTTUNE	Eingang	A3 MBRD	X21.24	0V10V	Abstimmspannung (Opt Ref Osz)
X21.25	REFOFF	Eingang	A3 MBRD	X21.25	HCMOS-Pegel	ON/OFF (Option Ref. Oszill.)

Pin	Name	Ein/Ausgang	Herkunft	/Ziel	Wertebereich	Signalbeschreibung
X21.26	OPTERKREF	Ausgang	A3 MBRD	X21,26	HCMOS-Pege1	Optionerkennung Ref. Oszillator
X22.1	VA5-P	Ausgang	A8 ROSC	X22.1	+4.9V+5.3V	+5V Versorgungsspannung
X22.2	VA15-N	Ausgang	A8 ROSC	X22.2	-15.6V14.4V	-15V Versorgungsspannung
X22.3	frei					
X22.4	REFOFF	Ausgang	A8 ROSC	X22.4	HCMOS-Pegel	Ref. Oszillator ON/OFF (Option)
X22.5	OPTERKREF	Eingang	A7 POWS	X21.26	HCMOS-Pege1	Optionerkennung
X22.6	VA15-N	Ausgang	A8 ROSC	X22.6	-15.6V14.4V	-15V Versorgungsspannung
X22.7	frei					
X22.9	frei					
X22.11	frei					
X22.12	frei					
X22.13	OVENCOLD	Eingang	A7 POWS	X21.23	HCMOS-Pegel	Ofen kalt (Option)
X22.16	OPTTUNE	Ausgang	A8 ROSC	X22.16	0V10V	Abstimmspannung (Option)

GND X21.1\2\3\9\10\11\12\17\18\21 X22.8\10\14\15



SERVICE INSTRUCTIONS

**Power Supply** 

1062.5690.02

## Contents

7	Testing and Repair of the Module	5
7.1	Function Description	5
7.2	Test Instruments and Utilities	5
7.3	Troubleshooting	5
7.4	General Data	5
	7.4.1 High-end Voltage without Load	6
	7.4.2 High-end Voltage under Load	6
	7.4.3 Hum Voltage	6
7.5	Testing and Adjustment	6
	7.5.1 Testing Regulating Performance and Noise Voltage	6
	7.5.2 Short-Circuit Test	7
7.6	Disassembly and Assembly	7
7 7	Euternal Interface	-7

Parts list List of coordinates Circuit diagram Component layout diagram

## 7.1 Function Description

The power supply provides five regulated dc voltages of -15V, +24V, +15V, +7.5V and +5.1V. The voltage for the blower is derived from the high-end voltage of the +7.5 regulator. The power transformer is primary fed via an ac filter and a

voltage selector.

Four primary voltages can be selected: 100V, 120V, 220V and 230V. The power transformer is provided with a fuse to protect it against short-circuits. A thermal release encapsulated in the transformer section protects it against thermal overload. On the secondary side, the transformer provides four windings which feed the bridge rectifier circuits.

The high-end voltages available at the four charging capacitors of the rectifier ciruits are applied to four integrated voltage-regulating ciruits. The voltage for the +5.1V voltage regulator is derived form the output voltage of the +7.5V regulator. The output voltages of the voltage regulators are either fixed internally or by external circuitry.

## 7.2 Test Instruments and Utilities

- Digital multimeter (e.g., R&S UDS5)
- Variable-ratio transformer 90V to 265V, 50Hz
- Oscilloscope
- Electronic load

# 7.3 Troubleshooting

Failure of all voltages Check, whether voltage selector

has been set correctly, check fuse

and thermal protection, if

necessary.

Failure of a single voltage

Disconnect the power supply from the load and check the regulating component of interest (check load, if required).

#### 7.4 General Data

The data of the high-end and hum voltages of the rectifier circuits are given in addition to make troubleshooting easier. They are not tested with the board test. The values given apply for an ac voltage of 230V  $\pm 1V$  and an ac supply frequency of  $50 \, \mathrm{Hz}$ .

### 7.4.1 High-end Voltage without Load

Voltages measured at charging capacitor						
+5.1V	+7.5V	+15.0V	+24.0V	-15.0V		
+7.5 ±0.3♥	+13.2V ±1.0V	+24.8V ±1.0V	+38.8V ±1.0V	-24.9V ±1.0V		

## 7.4.2 High-end Voltage under Load

. v . v . = . e g.v4	Voltages	measured at charging	capacitor	建建建建筑建筑工作,由于中央
+5.1V (1.0A)	+7.5V (0.95A)	+15.0V (1.5A)	+24.0V (0.3A)	-15.0V (0.5A)
+7.5 ±0.3V	+10.9V ±1.0V	+20.7V ±1.0V	+32.2V ±1.0V	-21.3V ±1.0V

## 7.4.3 Hum Voltage

Voltages measured at charging capacitor						
+7.5V	+15.0V	+24.0V	~15.0V			
max. 500mVpp	max.400mVpp	max. 50mVpp	max. 300mVpp			

## 7.5 Testing and Adjustment

All measured values indicated without tolerances are recommended values. Voltages given without any further detail are dc voltages.

## 7.5.1 Testing Regulating Performance and Noise Voltage

- Set voltage selector to 230 V.
- \_ Vary the ac supply voltage from 230 V to 207 V and check max. deviation and noise voltage according to the table below.

Test point	Ref. point	Voltage	Tolerance	Max.deviation	Noisa voltaga Vrms
X22.1	GND	+5.1V	±4%	20mV	<3mV
X22.4	GND	+7.5V	±4%	50mV	<3mV
X22.2	GND	+15.0V	±4%	50mV	<3mV
X22.22	GND	+24.0V	±4%	70mV	<3mV
X22.6	GND	-15.0V	±4%	50mV	<3mV

E-2

### 7.5.2 Short-Circuit Test

- Power supply without load (withdraw cables to motherboard and ROSC option)
- $Vpr. = 230V \pm 1V$
- Frequency 50Hz
- \_ Successively short-circuit output voltages and determine the short-circuit current.
- \_ Check, if the regulators work correctly by measuring the output voltages (cf. 7.4.1).

TOWNS VAY(V) CONTE	Pin (x3)	Reference	Short-circuit current
+5.1V	X21.5\6\7	GND	<4.5A
+7.5V	X21.8	GND	<4.5A
+15.0V	X21.13\14\15\16	GND	<4.0A
+24.0V	X21.22	GND	<2.5A
-15.0V	X21.19\20	GND	<2.5A

GND

X21.1\2\3

X21.9\10\11\12

X21.17\18

X21.21

## 7.6 Disassembly and Assembly

Subsequent to opening the instrument, undoing the screws marked on the backpanel and disconnecting the cable W21, the module can be removed from the frame.

Installation of the module and reassembly of the instrument are carried out in the reverse order.

7.7 External Interface

Pin	Name	Input/Output	Origin/De	est.	Specified range	Signal description
X4.1	LÜFTPLU	Output	Blower		9V to 13V	Positive voltage
X4.2	LÜFTMIN	Output	Blower			Ground
X4.3	CODE	}				
X4.4	TEMPREG	Output	Blower		100kΩ NTC	Temperature control
x21.4	U5VC	Output	A3 MBRD	X21.4	+7.2V to +7.8V	+5V Overvoltage for reset
X21.5	VA5-P	Output	A3 MBRD	21.5	+4.9V to +5.3V	+5.1V jSupply Voltage
X21.6	VA5-P	Output	A3 MBRD	X21.6	+4.9V to +5.3V	+5.1V Supply Voltage
X21.7	VA5-P	Output	A3 MBRD	X21.7	+4.9V to +5.3V	+5.1V Supply Voltage
X21.8	VA7.5~P	Output	A3 MBRD	X21.8	+7.2V to +7.8V	+7.5V Supply Voltage
X21.13	VA15-P	Output	A3 MBRD	X21.13	+14.4V to +15.6V	+15V Supply Voltage
X21.14	VA15-P	Output	A3 MBRD	X21.14	+14.4V to +15.6V	+15V Supply Voltage
X21.15	VA15-P	Output	A3 MBRD	X21.15	+14.4V to +15.6V	+15V Supply Voltage
X21.16	VA15-P	Output	A3 MBRD	X21.16	+14.4V to +15.6V	+15V Supply Voltage
X21.19	VA15-N	Output	A3 MBRD	X21.19	-15.6V to -14.4V	-15V Supply Voltage
X21.20	VA15-N	Output	A3 MBRD	X21.20	-15.6V to -14.4V	-15V Supply Voltage
X21.22	VA24-P	Output	A3 MBRD	X21.22	+23.0V to +25.0V	+24V Supply Voltage
X21.23	OVENCOLD	Output	A3 MBRD	X21.23	HCMOS level	Oven cold (ref oscoption)
X21.24	OPTTUNE	Input	A3 MBRD	X21.24	<b>0V</b> to <b>10</b> V	Tuning volt. (ref osc option)
X21.25	REFOFF	Input	A3 MBRD	X21.25	HCMOS 1evel	ON/OFF (ref osc option)

Pin	Name	Input/Output	Origin/D	est.	Specified range	Signal description
X21.26	OPTERKREF	Output	A3 MBRD	X21.26	HCMOS level	Identification of ref.
X22.1	VA5-P	Output	A8 ROSC	X22.1	+4.9V to +5.3V	+5V Supply Voltage
X22.2	VA15-N	Output	A8 ROSC	X22.2	-15.6V to -14.4V	-15V Supply Voltage
X22.3	not used					
X22.4	REFOFF	Output	A8 ROSC	X22.4	HCMOS level	Ref. osc. option ON/OFF
X22.5	OPTERKREF	Input	A7 POWS	X21.26	HCMOS level	Identification of option
X22.6	VA15-N	Output	A8 ROSC	X22.6	-15.6V to -14.4V	-15V Supply Voltage
X22.7	not used					
X22.9	not used					
X22.11	not used					
X22.12	not used					
X22.13	OVENCOLD	Input	A7 POWS	X21.23	HCMOS level	Oven cold (option)
X22.16	OPTTUNE	Output	A8 ROSC	X22.16	0V to 10V	Tuning voltage (option)

GND X21.1\2\3\9\10\11\12\17\18\21 X22.8\10\14\15



Schaltteillisten numerisch geordnet Part lists in numerical order Listes des pièces détachées par numéros de référence Ausdruck vom: Donnerstag, 14. Oktober 2004 15:52:45

1	5 C.	ı	, 12.
ST	rs.	ST	ST
		1	
:127-2W	:127-2/3	7127-2W	
SS SCHMELZS.T4 JEC127-2N	SS SCHMEL, T3, 15/EC127-2/3	SS SCHMELZS,T1 IEC127-2N	SS SCHMELZS, 2.5AT
0020.7600.00	0009.0584.00	0009.5434.00	1062.5702.00
イン	カメ	F 5	97

Sicherungen im 5My Netzteil Für diese Unterlage behalten wir uns alle Rechte vor.

C2 CE 10UF +-10X 10V 6032 CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 108 K 010 AS 1082. CE 0007.7281.00 KEMET T491 C 1082. CE 1082. CE 0007.7281.00 KEMET T491 C 1082. CE 1082. CE 0007.7280.00 KEMET T491 C 1082. CE 0007.7280.00 KEMET T491 C 1082. CE 0007.7280.00 KEMET T491 C 1082. CE 0007.7280.00 KEMET T491 C 1082. CE 0007.7280.00 KEMET T491 C 1082. CE 0007.7280.00 KEMET T491 C 1082. CE 0007.7280.00 KEMET T491 C 1082. CE 0007.7280.00 KEMET T491 C 1082. CE 0007.7280.00 KEMET T491 C 1082. CE 0007.7280.00 KEMET T491 C 1082. CE 0007.7280.00 KEMET T491 C 1082. CE 0007.7280.00 KEMET T491 C 1082. CE 0007.7280.00 KEMET T491 C 1082. CE 0007.7280.00 KEMET T491 C 1082. CE 0007.7280.00 KEMET T491 C 1082. CE 0007.7280.0	thaitan in ntainad in
POWER SUPPLY HIERZU STROM 1062.5890S SEE CIRC. OJAGR. 1062.5890S SEE CIRC. OJAGR. 1062.5890S SEE CIRC. OJAGR. 1062.5890S SEE CIRC. OJAGR. 1062.5890S SEE CIRC. OJAGR. 1062.5890S SEE CIRC. OJAGR. 1062.5890S SEE CIRC. OJAGR. 1062.5890S C2 CE COUP + 1075 (107 602) C3 CATATALUM SMD-CAPACITOR C4 CE CIOUP + 1075 (107 602) C4 CE CECUPH-20X10V RN2.5 ELECTROLYTIC CAPACITOR C5 CE 220UP+-20X10V RN2.5 C6 CE 220UP+-20X10V RN2.5 C7 CETABLY CAPACITOR C6 CE 220UP+-20X10V RN2.5 C7 CETABLY CHIP CAPACITOR C7 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C8 CE 100UP+-10X50V XTR 1206 C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C8 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CETABLY CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9 CHIP CAPACITOR C9	
ELECTROLYTIC CAPACITOR C2 C1 OUP +10X 10V 10V 10V 10V 10V 10V 10V 10V 10V 10V	
C2 CE 10UF +-10¼ 10V 6032 CE 0007.7281.00 KEMET T491 C 106 K 010 AS 1082. TATALLM SMD-CAPACITOR CE 10UF +-10½ 10V 6032 CE 0007.7281.00 KEMET T491 C 106 K 010 AS 1082. TATALLM SMD-CAPACITOR CE 1007-7201 V 100 CE 0008.7927.00 PANASONIC ECA-1AFG2211 1062. ELECTROLYTIC CAPACITOR CE 0007.7281.00 KEMET T491 C 106 K 010 AS 1062. TATALLM SMD-CAPACITOR CE 0007.7287.00 PANASONIC ECA-1AFG2211 1062. ELECTROLYTIC CAPACITOR CE 0007.7287.00 PANASONIC ECA-1AFG2211 1062. ELECTROLYTIC CAPACITOR CE 100F+-10½ 55½ 7343 CE 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. ELECTROLYTIC CAPACITOR CE 100F+-10½ 55½ 7343 CE 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. ELECTROLYTIC CAPACITOR CE 100F+-10½ 50½ X781 1206 CE 0008.7891.00 PANASONIC ECA-1AFG2211 1062. ELECTROLYTIC CAPACITOR CE 100F+-10½ 50½ X781 1206 CE 0008.7891.00 PANASONIC ECA-1AFG2101 1062. ELECTROLYTIC CAPACITOR CE 100F+-10½ 50½ X781 1206 CE 0008.7891.00 PANASONIC ECA 1 JFG 101 BQ 1062. CERMIC CHIP CAPACITOR CE 100F+-20½ 50½ 7345 CE 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. ELECTROLYTIC CAPACITOR CE 100F+-10½ 50½ 7345 CE 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. ELECTROLYTIC CAPACITOR CE 100F+-10½ 50½ 7345 CE 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. ELECTROLYTIC CAPACITOR CE 100F+-10½ 50½ 7345 CE 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. ELECTROLYTIC CAPACITOR CE 100F+-10½ 50½ 7345 CE 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. ELECTROLYTIC CAPACITOR CE 100F+-10½ 50½ 7345 CE 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. ELECTROLYTIC CAPACITOR CE 100F+-10½ 50½ 7345 CE 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. ELECTROLYTIC CAPACITOR CE 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. ELECTROLYTIC CAPACITOR CE 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. ELECTROLYTIC CAPACITOR CE 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. ELECTROLYTIC CAPACITOR CE 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. ELECTROLYTIC CAPACITOR CE 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. ELECTROLYTIC CAPACITOR CE 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. ELECT	5902.0
C3	5902.0°
C4	5902.0
C5	5902.01
CS CC 100NF+-10X5GV X7R 1206 CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 100F+-10X 25V 179343 CC 0007.7246.00 SPRAGUE 2301 106 X9 025 027 1062. CC 100VF+-10X5GV X7R 1206 CC 0007.7246.00 SPRAGUE 2930 106 X9 025 027 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CC 0007.5237.00 PHILIPS_CO 2238 581 15649	5902.01
C20	5902.01
C21 CE 10UF +-10X_2EV 7348 TANTALUM SMO-CAPACITOR CE 100UF+-20X2EV RMZ.5 CE 0009.7891.00 PANASONIC ECA-TEFG1011 1062.   C22 CE CONF+-10X50V X78 1206 CE 2.2MF+-20X50V R030X25 CE 1.00UF+-20X50V R030X25 CE 1.00UF+-20X50V R030X25 CE 1.00UF+-20X50V R030X25 CE 1.00UF+-10X50V X78 1206 CE 2.2MF+-20X50V R030X25 CE 1.00UF+-10X50V X78 1206 CERAMIC CHIP CAPACITOR CE CE 1.00UF+-20X25V R036X30 CE 1.00UF+-10X50V X78 1206 CERAMIC CHIP CAPACITOR CE CE 1.00UF+-20X25V R036X30 CELECTROLYTIC CAPACITOR CE 1.00UF+-20X25V R036X30 CELECTROLYTIC CAPACITOR CE 1.00UF+-20X25V R036X30 CELECTROLYTIC CAPACITOR CE 1.00UF+-20X25V R036X30 CELECTROLYTIC CAPACITOR CE 1.00UF+-20X25V R036X30 CELECTROLYTIC CAPACITOR CE 1.00UF+-20X25V R036X30 CERAMIC CHIP CAPACITOR CE 0009.7924.00 PANASONIC ECA-1EFG1011 CO22.   C49 CE 1.00UF+-20X25V R036X30 CE 0009.7931.00 PANASONIC ECA-1EFG1011 CO22.   C40 CE 1.00UF+-20X25V R036X30 CE 0009.7931.00 PANASONIC ECA-1EFG1011 CO22.   C40 CE 1.00UF+-20X25V R036X30 CE 0009.7931.00 PANASONIC ECA-1EFG1011 CO22.   C40 CE 1.00UF+-20X25V R036X30 CE 0009.7891.00 PANASONIC ECA 1.0FG 101 BQ 1062.   C40 CE 1.00UF+-20X25V R036X30 CE 0009.7891.00 PANASONIC ECA 1.0FG 101 BQ 1062.   C40 CE 1.00UF+-20X25V R036X30 CE 0009.7891.00 PANASONIC ECA 1.0FG 101 BQ 1062.   C40 CE 1.00UF+-20X25V R036X30 CE 0009.7891.00 PANASONIC ECA 1.0FG 101 BQ 1062.   C40 CE 1.00UF+-20X25V R036X30 CE 0009.7891.00 PANASONIC ECA 1.0FG 101 BQ 1062.   C40 CE 1.00UF+20X25V R036X30 CE 0009.7891.00 PANASONIC ECA 1.0FG 101 BQ 1062.   C40 CE 1.00UF+20X25V R036X30 CE 0009.7891.00 PANASONIC ECA 1.0FG 101 BQ 1062.   C40 CE 1.00UF+20X25V R036X30 CE 0009.7891.00 PANASONIC ECA 1.0FG 101 BQ 1062.   C40 CE 1.00UF+20X25V R036X30 CE 0009.7891.00 PANASONIC ECA 1.0FG 101 BQ 1062.   C40 CE 1.00UF+20X25V R036X30 CE 0009.7891.00 PANASONIC ECA 1.0FG 101 BQ 1062.   C40 CE 1.00UF+20X25V R036X30 CE 0009.7891.00 PANASONIC ECA 1.0FG 101 BQ 1062.   C40 CE 1.00UF+20X25V R036X30 CE 0009.7891.00 PANASONIC ECA 1.0FG 101 BQ 1062.   C40 CE 1.00UF+20X25V R036X30 CE 0009.7891.00 PANASONIC ECA 1.0FG 10	5902.01
C22   CE 100UFF-20X25V RMZ.5   CE 0008.7891.00   PANASONIC   ECA-1EFG1011   1062.   C28   CC 100NF+-10X50V X7R 1206   CE 2.2MF+20X50V R030X25   CE 2.2MF+20X50V R030X25   CE 100UF+20X63V RMS   CE 100UF+20X63V X7R 1206   CE 100UF+20X63V X7R 1206   CE 100UF+20X63V X7R 1206   CE 100UF+20X50V RMS   CE 100UF+20X50V RMS   CE 100UF+20X50V RMS   CE 100UF+20X50V RMS   CE 100UF+20X50V RMS   CE 10UF+20X50V RMS   CE 10UF+20X50V RMS   CE 10UF+20X50V RMS   CE 10UF+20X50V RMS   CE 10UF+20X50V RMS   CE 10UF+20X50V RMS   CE 10UF+20X50V RMS   CE 10UF+20X50V RMS   CE 10UF+20X50V RMS   CE 10UF+20X50V RMS   CE 10UF+20X50V RMS   CE 10UF+20X50V RMS   CE 10UF+20X50V RMS   CE 10UF+20X50V RMS   CE 10UF+20X50V RMS   CE 10UF+20X50V RMS   CE 0008.7891.00   PANASONIC   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG1011   1062.   CEA-1EFG	5902.01
C28	5902.01
C30	5902.01
C31	5902.01
C38 CC 100NF+-10X50V X7R 1206 CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. CEAMIC CHIP CAPACITOR CE 15MF+-20X25V R035X30 CE 16CTNCVITIC CAPACITOR CE 10UF+-10X25V R03.5 CE 10UF+-10X25V R03.5 CE 10UF+-10X25V R03.5 CE 10UF+-10X25V R03.5 CE 10UF+-10X25V R03.5 CE 10UF+-10X50V X7R 1206 CE 0007.7246.00 SPRAGUE 2930 106 X9 025 D2T 1062.1 TANTALUM SMO-CAPACITOR CC 100NF+-10X50V X7R 1206 CERAMIC CHIP CAPACITOR CC 100NF+-10X50V X7R 1206 CERAMIC CHIP CAPACITOR CC 100NF+-10X50V X7R 1206 CERAMIC CHIP CAPACITOR CC 1000NF+-10X50V X7R 1206 CERAMIC CHIP CAPACITOR CC 1000NF+-10X50V X7R 1206 CERAMIC CHIP CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.1 1062.	5902.01
C40 CE 15MF+-20%25V R035X30 CO C C C C C C C C C C C C C C C C C C	5902.01
C42 CE 100UF+~20X25V RM2.5 CE 0008.7891.00 PANASONIC ECA-1EFG101I 1062. CE 0UF +~10X 25V 7349 TANTALUM SMO-CAPACITOR CE 10UF +~10X 25V 7349 TANTALUM SMO-CAPACITOR CC 10ONF+~10X50V X7R 1206 CE 0007.7246.00 SPRAGUE 2930 106 X9 025 D2T 1062. TANTALUM SMO-CAPACITOR CC 10ONF+~10X50V X7R 1206 CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2338 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2338 581 15649 1062. TANTALUM SMO-CAPACITOR CC 0007.5237.00 PHILIPS_CO 2338 581 15649 1062. TANTA	5902.01
C48 CC 100MF+-10X50V X7R 1206 CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062.1 CC 100MF+-10X50V X7R 1206 CERAMIC CHIP CAPACITOR 1062.6715.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5237.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 15649 1062.1 CC 0007.5207.00 PHILIPS_CO 2238 581 1564 PHILIPS_CO 2238 581 1564 PHILIPS_CO 2238 581 1564 PHILIPS_CO 2238 581 1564 PHILIPS_CO 2238 581 1564 PHILIPS_CO 2238 581 1564 PHILIPS_CO 2238 581 1564 PHILIPS_CO 2238 581 1564 PHILIPS_CO 2238 581 1564 PHILIPS_CO 2238 581 1564 PHILIPS_CO 2238 581 1564 PHILIPS_CO 2	5902.01
CC 100NF+-10/50V X7R 1206 CERAMIC CHIP CAPACITOR  E1	5902.01
FAN UNIT  SS SCHMELZ.T2,5HIEC127-2V FUSE F2 SS SCHMELZ.T2,5HIEC127-2V FUSE F3 FUER/FOR 100/120V F4 220/230V F5 SS SCHMELZS.T4 IEC127-2/V FUSE F6 F7 ST TEMP.SICH. 150GR0 2,5A TEMPERATURFUSE 150GR0 N1 80 LT1085CT +ADJ REGL IC VOLTAGE REGULATOR N20 B0 LT1085CT +ADJ REGL IC VOLTAGE REGULATOR N30 B0 LT1085CT +ADJ REGL IC VOLTAGE REGULATOR N30 B0 LM3197T +A0J1A5 VREGL VOLTAGE REGULATOR N40 B0 LM317T +A0J1A5 VREGL VOLTAGE REGULATOR N50 B0 LM317T +A0J1A5 VREGL VOLTAGE REGULATOR R1 RL 0,35W190 OHM+-0,1%TK25 R2 RL 0,35W190 OHM+-0,1%TK25 R2 RL 0,35W190 OHM+-0,1%TK25 R2 RL 0,35W190 OHM+-0,1%TK25 R2 RL 0,35W190 OHM+-0,1%TK25 R2 RL 0,35W190 OHM+-0,1%TK25 R2 RL 0,35W374 OHM+-0,1%TK25 R2 RL 0,35W374 OHM+-0,1%TK25 R2 RL 0,35W374 OHM+-0,1%TK25 RL 0083.7389.00 RESISTOR R1 RL 0,35W374 OHM+-0,1%TK25 RL 0083.7389.00 RESISTOR R2 RL 0,35W374 OHM+-0,1%TK25 RL 0083.7389.00 RESISTA MK2  MENP5 413 3PUA Ät Datum Date Parts liet for Schaltheilliste für Sachnummar Stock No.	5902.01
F2 SS SCHMELZ.T2,5HIEC127-2V FUSE FURF/FOR 100/120V FUSE FUSE FUSE SS SCHMELZS.T4 IEC127-2/V FUSE FUSE SS SCHMELZS.T4 IEC127-2/V FUSE ST TEMP.SICH. 150GR0 2,5A TEMPERATURFUSE 150GR0  N1 80 LT1085CT +ADJ REGL IC VOLTAGE REGULATOR N2 BO LT1085CT +ADJ REGL IC VOLTAGE REGULATOR N2 BO LT1085CT +ADJ REGL IC VOLTAGE REGULATOR N30 BO UA7824UC+24V1A0 VREGL VOLTAGE REGULATOR N40 BO LM317T +ADJ1A5 VREGL VOLTAGE REGULATOR N40 BO LM317T +ADJ1A5 VREGL VOLTAGE REGULATOR N40 BO LM317T +ADJ1A5 VREGL VOLTAGE REGULATOR N50 CLM7824UC+24V1A0 VREGL VOLTAGE REGULATOR N50 CLM7824UC +24V1A0 VREGL VOLTAGE REGULATOR N50 CLM7824UC +24V1A0 VREGL VOLTAGE REGULATOR N50 CLM7824UC +24V1A0 VREGL VOLTAGE REGULATOR N50 CLM7824CT 1062.5 N5C LM7824CT 1062.5 N5C LM7824CT 1062.5 N5C LM7824CT 1062.5 N5C LM7824CT 1062.5 N5C LM7824CT 1062.5 N5C LM7824CT 1062.5 N5C RESISTOR R1 RL 0,35W100 0HM+-0,1%TK25 RESISTOR R2 RL 0,35W199 0HM+-0,1%TK25 RESISTOR R4 RL 0,35W374 0HM+-0,1%TK25 RL 0083.7329.00 RESISTA MK2 1062.5 RESISTOR R4 RL 0,35W374 0HM+-0,1%TK25 RL 0083.7389.00 RESISTA MK2 1062.5 RESISTOR R5 RL 0,35W374 0HM+-0,1%TK25 RL 0083.8327.00 RESISTA MK2 1062.5 RESISTOR R4 RL 0,35W374 0HM+-0,1%TK25 RL 0083.8327.00 RESISTA MK2 1062.5 RESISTOR R5 RL 0,35W374 0HM+-0,1%TK25 RL 0083.8327.00 RESISTA MK2 1062.5 RESISTOR R5 RESISTOR R1 0,35W374 0HM+-0,1%TK25 RL 0083.8327.00 RESISTA MK2 1062.5 RESISTOR R1 0,35W374 0HM+-0,1%TK25 RL 0083.8327.00 RESISTA MK2 1062.5 RESISTOR R1 0,35W374 0HM+-0,1%TK25 RL 0083.8327.00 RESISTA MK2 1062.5 RESISTOR R1 0,35W374 0HM+-0,1%TK25 R1 0083.8327.00 RESISTA MK2 1062.5 RESISTOR R1 0,35W374 0HM+-0,1%TK25 R1 0083.8327.00 RESISTA MK2 1062.5 R1 0083.8327.00 R1 1062.5 R1 0083.8327.00 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062.5 R1 1062	
F2	
F. 6 F7 FUSE ST TEMP.SICH. 150GR0 2,5A TEMPERATURFUSE 150GR0  N1 80 LT1085CT +ADJ REGL IC VOLTAGE REGULATOR N2 B0 LT1085CT +ADJ REGL IC VOLTAGE REGULATOR N2 B0 LT1085CT +ADJ REGL IC VOLTAGE REGULATOR N2 B0 LT1085CT +ADJ REGL IC VOLTAGE REGULATOR N20 B0 LT1085CT +ADJ REGL IC VOLTAGE REGULATOR N30 B0 UA7824UC+24V1AO VREGL VOLTAGE REGULATOR N40 B0 UA7824UC+24V1AO VREGL VOLTAGE REGULATOR N40 B0 LM317T +ADJ1A5 VREGL VOLTAGE REGULATOR R1 R1 RL 0,35W100 OHM+-0,1%TK25 RESISTOR R2 R2 R4 R 0,35W120 OHM+-0,1%TK25 R5 R5 R1 R1 R1 R1 R1 R1 R1 R1 R1 R1 R2 R3 R4 R1 R1 R3 R5 R1 R1 R1 R1 R3 R5 R1 R1 R1 R1 R1 R1 R1 R1 R1 R1 R2 R1 R3 R5 R5 R5 R5 R5 R1 R1 R1 R1 R1 R1 R1 R1 R1 R2 R1 R2 R3 R5 R5 R5 R5 R5 R5 R1 R1 R1 R1 R1 R1 R1 R1 R2 R1 R2 R2 R5 R5 R5 R5 R5 R5 R5 R5 R5 R5 R5 R1 R1 R1 R1 R1 R1 R1 R2 R1 R2 R2 R2 R3 R3 R4 R1 R2 R3 R4 R1 R3 R4 R1 R4 R1 R3 R5 R5 R5 R5 R5 R5 R5 R5 R5 R5 R5 R5 R5	
ST TEMP.SICH. 150GRO 2,5A   TEMPERATURFUSE 150GRO	5902.01
N2   BO LT1085CT +AOJ   REGL   2031.7680.00   LINEAR_TEC LT1085CT   1062.5     N2   BO LT1085CT +AOJ   REGL   2031.7680.00   LINEAR_TEC LT1085CT   1062.5     N3   BO LT1085CT +AOJ   REGL   2031.7680.00   LINEAR_TEC LT1085CT   1062.5     N3   BO UA7824UC+24V1AO   VREGL   VOLTAGE REGULATOR   BO UA7824UC+24V1AO   VREGL   VOLTAGE REGULATOR   BO LM317T   +AOJ1A5   VREGL   BO 0336.4621.00   NSC   LM7824CT   1062.5     N4   RL 0,35W100   OHM+-0,1%TK25   RL 0083.7220.00   ORALORIC   SMA0207   1062.5     R2   RL 0,35W499   OHM+-0,1%TK25   RL 0083.7220.00   RESISTA   MK2   1062.5     R4   RL 0,35W499   OHM+-0,1%TK25   RL 0083.8562.00   RESISTA   MK2   1062.5     R5   RL 0,35W374   OHM+-0,1%TK25   RL 0083.7389.00   RESISTA   MK2   1062.5     R5   RL 0,35W374   OHM+-0,1%TK25   RL 0083.8327.00   RESISTA   MK2   1062.5     MENP5   413   3PUA   At   Datum   Date   Date   Parts list for   Sachnummar   Stock No.      MENP5   413   3PUA   At   Datum   Date   Parts list for   Sachnummar   Stock No.     N5   N6   N6   N6   N6   N6   N6   N6	5977.00
N2   B0 LT1085CT +A0J   REGL   2031.7680.00   LINEAR_TEC LT1085CT   1062.55     N20   B0 LT1085CT +A0J   REGL   2031.7680.00   LINEAR_TEC LT1085CT   1062.55     N20   B0 LT1085CT +A0J   REGL   2031.7680.00   LINEAR_TEC LT1085CT   1062.55     N30   B0 UA7824UC+24V1A0 VREGL   80 0336.4621.00   NSC   LM7824CT   1062.55     N40   B0 LM317T +A0J1A5 VREGL   80 0339.4080.00   NSC   LM-317T   1062.55     N40   B0 LM317T +A0J1A5 VREGL   80 0339.4080.00   NSC   LM-317T   1062.55     R1	902.01
N20   B0 LT1085CT +A0J   REGL   CV0LTAGE REGULATOR   B0 UA7824UC+24V1A0 VREGL   D0 0336.4621.00   NSC   LM7824CT   1062.5	5902.01
N30   B0 UA7824UC+24V1A0 VREGL   B0 0336.4621.00   NSC   LM7824CT   1062.5     N40   B0 LM317T	902.01
N40   B0 LM317T +A0J1A5 VREGL   80 0339.4080.00   NSC   LM-317T   1062.5     R1	902.01
RESISTOR RL 0,35W499 0HM+-0,1%TK25 RESISTOR RL 0,35W121 0HM+-0,1%TK25 RESISTOR RS RL 0,35W374 0HM+-0,1%TK25 RESISTOR RL 0,35W374 0HM+-0,1%TK25 RESISTOR  MENP5 413 3PUA A Datum Date  Datum Date  SchallteHiliste für Parts list for  Sachnummar Stock No.  2 NETZTEIL EINHEIT  1062.5	902.01
R2 RL 0,35W499 0HM+-0,1%TK25 RL 0083.8562.00 RESISTA MK2  R4 RL 0,35W121 0HM+-0,1%TK25 RL 0083.7389.00 RESISTA MK2  R5 RL 0,35W374 0HM+-0,1%TK25 RL 0083.8327.00 RESISTA MK2  MENP5 413 3PUA A Datum Date Parts list for Sachnummar Stock No.  PARTS Sachnummar Stock No.  2 NETZTEIL EINHEIT 1062.5690.01 SA	902.01
R4 RL 0,35W121 0HM+-0,1%TK25 RL 0083.7389.00 RESISTA MK2 1062.5 RESISTOR RL 0,35W374 0HM+-0,1%TK25 RL 0083.8327.00 RESISTA MK2 1062.5 MENP5 413 3PUA Aι Datum Date Schalttelliiste für Parts list for Stock No.	902.01
R5 RL 0,35W374 0HM+-0,1%TK25 RL 0083.8327.00 RESISTA MK2 1062.5  MENP5 413 3PUA A: Datum Date Schatttelliste für Parts list for Stock No.  O1 16.09.97 ZE NETZTEIL EINHEIT 1062.5690.01 SA	902.01
Parts list for Stock No.    O1 16.09.97   ZE NETZTELL EINHEIT   1062.5690.01 SA	902.01
© 01 16.09.97 ZE NETZTEIL EINHEIT 1062.5690.01 SA	Biatt-Nr. Page
ROHDE&SCHWARZ POWER SUPPLY	1+

	Kennz. Comp. No.		genen Design					ummar k No.	Harsteller Manufecturer	Sezeichnung Designation		halten in teined in
	R <b>8</b>		O OHM+- RESISTO		00 1206	RG			DRALORIC	CR(B) 1206		5902.01
	R20		5W100 0		, 1%TK25	RL	0083	.7220.00	DRALORIC	SMA0207	1062.	5902.01
	R2 1	_	5W1, 10K0	DHM+-(	O, 1%T25	RL	0083	.9223.00	DRALORIC	SMA0207	1062.	5902.01
	R2B	RG 10,	O OHM+- RESISTO		00 1206	RG	0006	.8649.00	DRALORIC	CR(B) 1206	1062.	5902.01
	R38	RG 10,	O OHM+-	1%TK10	00 1206	RG	0006	.8649.00	DRALORIC	CR(B) 1206	1062.	5902.01
ı	R40		5W 100 OH		1%TK25	RL	0083.	7220.00	DRALORIC	SMA0207	1062.	5902.01
	R41		5W1,10K0	DHM+-C	), 1%T25	RL	0083.	9223.00	DRALORIC	SMA0207	1062.	5902.01
	R4B		O OHM+-		00 1206	RG	0006.	8649.00	DRALORIC	CR(B) 1206	1062.	5902.01
ı	R90	RK HEI THERMI	SSL. 100F STOR	KOHM1C	0,5W		0520.	5983.00	SIEMENS	B57164-K104-K	1062.	5902.01
	S1	SB NET	ZSCHALTE SWITCH	R 2XU	O.KN.	SB	0007.	5143.00	ITT-SEL	NE18 2U E E		
	T1	LT RIN	GKERNTRA ORMER	NFO SM	ΙΥ		1062.	5977.00				1
	V1		C5000/33	300	BRGL	AG	0084.	5109.00	TELEFUNKEN	880C5000/330OSI	1062.5	5902.01
	V20	RECTIF	05000/33	800	BRGL	AG	0084.	5109.00	TELEFUNKEN	B80C5000/3300SI	1062.5	5902.01
I	V30	AG B250	OC 1500		BRGL	AG	0208.	2340.00	GEN_INSTRU	B380C1500	1062.5	902.01
1	V40	1.12 - 1 - 1	05000/33	00	BRGL	AG	0084.	5109.00	TELEFUNKEN	BB0C5000/3300SI	1062.5	902.01
	V41	AG 1N40 RECTIF	007 G	L1000	V 1A0	AG	0013.	0310.00	ITT-SEMICO	1N4007	1062.5	902.01
	X2		CKERLEIS	TE 5P	.GER	FΡ	1026.	3132.00	J_S_T_DEUT	B5P-VH-B	1062.5	902.01
	хз	FP STEC	CKERLEIS	TE 4P	.GER	FP	1026.	3055.00	J_S_T_DEUT	B4P-VH-B	1062.5	902.01
	X4	FP STIF	TLEISTE	36P.	R2,54	FP	0242.	3600.00	BINDER	742-11-0179-00-36	1062.5	902.01
	X21		KERLEIS	TE 26	P.GER	FP	0820.	8610.00	SIEMENS	V23535-A2200-A262	1062.5	902.01
	X22		TOR 26P. CKERLEIS TOR	TE 16	P.GER	FP	4007.	2304.00	SIEMENS	V23535-A2200-A162	1062.5	902.01
	Z1		ST.M.N W.VOLTA			FN	0006.	0919.00	CORCOM	F-7364D		
	MENP5	413 E&SCHV	3PUA	Ät 01 16	Datum Date 3.09.97	Z	E NETZ	Schalttellii Paris iis ZTEIL , EI	t for	Sachnumme Stock No. 1062.5690.0		Biett-Nr. Page
L						P	OWER S	SUPPLY				



# **XY-Liste**

# XY List

## Erklärung der Spaltenbezeichnungen:

Part: Bauelement-Kennzeichen.

Side: Leiterplatten-Seite, auf der sich das Bauelement befindet.

XY: Koordinaten (Millimeter) des Bauelementes auf der Leiterplatte

bezogen auf den Nullpunkt.

SQR, PG: Planquadrat und Seite des Schaltbildes für das jeweilige Bauelement.

## Explanation of column designations:

Part: Identification of instrument part.

Side: Side of the PC board on which instrument part is positioned.

XY: Coordinates (millimeter) of the component on the PC board in reference

to zero point.

SQR, PG: Square and page of the diagram for the respective instrument part.

		Se	rvi	ce-I	}e1	evai	nte Bau	itei.	1e /	Serv	vice.	-Rel	evant (	Comp	ohent	S		
Part	Side	X	Y	Sc	įr :	Pg	Part	Sid	e X	Y	Sqr	Pg	Part	Side	e X	Y	Sqr	Pg
F3	В	22	3:	2 2	2F	2	F6	В	37	50	2C	2	X4	В	10	67	2B	2
F4	В	22	: 18	3 2	E	2	X2	В	13	37	2F	2	X21	В	132	5	7E	2
F5 	B	22	. 58	3 2	2D	2	X3	В	35 	70	2C	2	X22	В	99	5	6 B	2
l	Vicht	Se	rvio	e-R	ele	 evar	nte Bau	tei.	le /	Non-	Serv	ice	-Releva	ant (	Compo	nen	ts	
Part	Side	X	Y	Sq	r l	Pg	Part	Side	e X	Y	Sqr	Pg	Part	Side	× X	Y	Sqr	Pε
C1	В	95	26	3	E	2	C43	A	139	58	4B	2	R8	A	72	4	2F	2
C2	Α	161	. 58	3 4	E	2	C48	Α	6	46	2C	2	R20	В	125	60	4E	2
C3	Α	150	58	5	E	2	GND1	В	132	21	6E	2	R21	В	117	60	4D	2
C4	В	161	. 86	4	F	2	GND2	В	139	39	6D	2	R28	Α	27	4	2E	2
C5	В	153	86	5	F	2	GND3	В	127	7	6C	2	R38	Α	43	65	2D	2
C8	Α	65	4	. 2	F	2	GND4	В	152	22	6C	2	R40	В	143	60	4C	2
C20	В	95	70	3	D	2	N1	В	162	94	3F	2	R41	В	135	60	4C	2
C21	Α	121	. 58	4	D	2	N2	В	150	94	4F	2	R48	Α	6	39	2C	2
C22	В	121	86	4	D	2	N20	В	116	94	3E	2	R90	В	114	58	2B	2
C28	Α	21	4	2	D	2	N30	В	128	94	3D	2	V1	В	81	8	2F	2
C30	В	59	85	3	С	2	N40	В	139	94	3C	2	V20	В	36	8	2E	2
C31	В	135		4	C	2	R1	В	164	60	4 P	2	V30	В	. 44	73	2D	2
238	Α	46			С	2	R2	В	158	60	4E	2	V40	В	3	30	2C	2
C40	В	54	33	3	C	2	R4	В	154	60	5F	2	V41	В	148	40	5C	2
342	В	142	86	4	С	2	R.5	В	147	60	5E	2	VCC1	В	155	26	6B	2

ROHDE	ÄI	Datum  Date	XY-Liste für XY-list for	Sach-Nummer   Stock-Nr	Blatt  Page
SCHWARZ			ED NETZTEILEINHEIT	 	
oonwake j		03 23.08.94	1	   1062.5902.01 XY	1




.

I



Stromläufe
Bestückungspläne
Circuit diagrams
Components plans
Schémas de circuit
Plans des composants



## STROMLAUF GILT FUER VAR.02


CIRCUIT DIAGRAM IS VALID FOR MOD.02

03/	<b>49165</b>	11.04.95	нМ	1GPK	TAG	NAME	BERENNUNG				
				BEARB.		ни					- 1
			-	GEPP.			NET	ZTEILEIN	HEIT	٠.	٠ ا
				NORM			POWER	SUPPLY UNI	Γ		
				PLOTT	11.84.95		l				
							ZEICHNNP.			BLRTT-	-NR.
/				1 1 2				1062.56	00 049	1	+
REND,	AENDERUNGS-	DATUM	NAME	KUF	IDE&SC	HUARZ		1002.30	120.017	V.	BL.
IND.	MITTEILUNG		HIIIE	ZU GERAE	T SMY			062.5502	. ERSTE Z.		
			6				7		8		

0

L

í




# STROMLAUF GILT FUER V

CIRCUIT DIAGRAM IS VALID. FOR MOD




03/	<b>4916</b> 5	11.04.95	HM	1GPK	TAC	NAME	В
		-		BEARB.		нп	]
				GEPP.			
				MORN			
				PLOTT	11.04.95		
				R			7
<u>/</u>				\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	IDE&SC	44407	
HEND.	RENDERUNGS- Hitteilung	DATUM	NAME	KUT		1197114	
IND.	HILLEGRO			ZU GERAE	r SMY		RE





ACHTUNG: EGB! ELEKTROSTATISCH GEFAEHRDETE BRUELEMENTE ERFORDERN EINE BESONDERE HANDHRBUNG. ATTENTION ESD! ELECTROSTRIC SENSITIVE DEVICES REQUIRE A SPECIAL HANDLING


03/	49165 🐃 -
	· ·
	\$ <u></u>
/	
AEND.	RENDERUNGS- Mitteilung
A	





	1996,56855
03/	49165
	0
	• 4
	*
/	
AEND.	RENDERUNGS MITTEILUNG
A	


ų





ACHTUNG: EGB!


ELEKTROSTATISCH GEFAEHROE
BAUELEREUTE ERFORBERN EI
BESONDERE HANDHABUNG.
ATTENTION ESD!
ELECTROSTATIC SENSITIVE DE
REQUIRE A SPECIAL HANDLI


ZEICHN, -NR.














3


2


ATTENTION ESD! ELECTROSTATIC SENSITIVE DE REQUIRE A SPECIAL HANDL











Ε


В

48169 23.0B.94 16PK TRG BENENNUNG NBNE BEARB 8ប **NETZTE!LE!NHE!T** Z GEPR. A POWER SUPPLY UNIT PEOTT 24.08.94 ZEICHN.-NR. BLATT-NR. 1062.5902.01 ROHDE&SCHUARZ AENOERUNGS-Mitteilung AEND IND. DATUM NAME SMY PEG. 1.V. 5

5A.

ИÐ

.151.




GB!
FREHRDETE
DERN EINE
HABUNG.
SD!
TIVE BEVICES
HANDLING

BINDENDE AHGABEN UEBER VARIANTEN, TRIMMWERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA.

FOR BIHDING INFORMATION ON MODELS, TRIMMING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.

A			6				7 :	
IND.	RITTEILUNG	DHIGH	WHILE	ZU GERRE	r SMY		PEG. 1. V.	1062
REND.	RENDEPUNGS-	DATUN	NAME	j ROH	IDE&SC	HWARZ_		1 *
1				1 7 7				1
				(%)			ZEICHNNR.	
				PLOTT	24.08.94			
	· · · · · · · · · · · · · · · · · · ·			NORM			. POWE	R SU
				GEPR.			NET	
·				BEARB.		BU		<b>-</b> -
03/	48169	23.0B.94	вu	1GPK	TAG	NAME	BENENNUNG	





ACMTUNG: EGB!
ELEKTROSTATISCH GEFAEHRDETE
BAUELERENTE EPFORDERN EINE
BESONDERE HANDHABUNG.
ATTENTION ESD!
ELECTROSTATIC SENSITIVE DEVICES
PEQUIRE A SPECIAL HANDLING

1 3

BINDERDE ANGABEN VEBER VARIANTEN. TRINNVERTE, BRUTEILWERTE UND NICKT BESTVECKTE BRUTEILE SIEHE SA.

FOR BIHDING INFORMATION ON MODELS.
TRIMMING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS CIST.


03/	48169	23.08.94	BU	1GP
				BEARE
				GEPR.
				NORN
				PLOTI
				R
1			-	\\\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\
REND.	RENDERUNGS-	DATUM	NAME	RO
IND.	MITTEILUNG	NI(1011	A III (L	ZU SER
			-6	

4

5 **^** 

. . .





DARSTELLUNG SEITE B VIEW ON SIDE B




ACHTUNG: EGB!
ELEFTROSTATISCH GEFREHRDETE
BRUELERENTE EPFORDERN EINE
BESONDERE BRADHABUNG.
ATTENTION ESD!


ATTENTION ESD! ELECTROSTATIC SENSITIVE DEVICES A SPECIAL HANDLING

BINDENDE ANGABEN UEBER VARIANTEN. TRIMMWERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA

FOR BINDING INFORMATION ON MODELS.
TRIUMING AND COMPONENTS VALUES AND
NONFITTED COMPONENTS SEE PARTS LIS

4





EGB! I GEFAEHRDETE' FORDERH EINE ANDHABUNG. ESD! NSITIVE DEVICES TAL HANDLING

TRIMMUERTE, BAUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA.

BINDEMDE ANGABEN UEBER VARIANTEN,

FOR	B1#D1	NG INFO	DRMATI	ои ан	HODE	LS,
1197	111116	AND CO	MPONEN	TS VAL	.UES	AHD
нонғ	TTTED	COMPO	NENTS	SEE PF	RTS	LIST.

/ REKD.	NENDERUNGS-	DRTUN	NAME	® ROH	IDE&SCI	HWARZ	ZEICHN -NP
				PLOTT	24.08.94		
				NDRM			POWER
				GEPR.			NET
				BEARB.		ви	1
03/	48169	23.08.94	BU	1GPK	IAG	NAME	BENENNUNG


SMY

REG. 1. V.

NETZ

POWER

10



SEITE A




BIHDENDE ANGABEN UEBER VARIANTEN, TRIMMWERTE, BAUTEILWERTE UND NICHT BESTUECKTE BRUTEILE SIEHE SR.

FOR BINDING INFORMATION ON MODELS, TRIMMING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.

	3//	
03/	48169	23.08.94
1	*	
REND.	AENDERUNGS- Mitteilung	DATUN
A		

**1** 3

4





SERVICEUNTERLAGEN
Referenzoszillator (Option)
1039.1027.02

### Inhaltsverzeichnis

7.	Prüfen und Instandsetzung 5
7.1	Funktionsbeschreibung 5
7.2	Meßgeräte und Hilfsmittel 5
7.3	Fehlersuche 5
7.4	Prüfen und Abgleich 6
7.4.1	Stromaufnahme
7.4.2	Prüfen des Oszillators und des 10MHz-
	Verstärkers
7.4.3	Prüfen der Interrupterzeugung (OVEN COLD) 6
7.4.3.1	Variante 02
7.4.3.2	Variante 04
7.4.4	Abalaigh dag Oggillatong
7.4.4.1	Abgleich des Oszillators
7.4.4.2	Variante 02
	Variante 04 7
7.5	Zerlegung und Zusammenbau 7
7.6	Externe Schnittstellen 0

Schaltteilliste Koordinatenliste Stromlauf Bestückungsplan

#### Prüfen und Instandsetzung

### 7.1 Funktionsbeschreibung

Die Option Referenzoszillator OCXO ersetzt die interne 10MHz-Zeitbasis durch einen thermostatgeregelten hochwertigen Quarzoszillator, wodurch sich die Gerätedaten bezüglich Genauigkeit der Referenzfrequenz und Alterung wesentlich verbessern.

Die Baugruppe enthält neben dem eigentlichen Oszillator noch Bausteine zur Erzeugung der Versorgungsspannung von 12V aus der 15V Netzteilspannung, einen abschaltbaren Auskoppelverstärker und bei der Variante 04 noch eine Schaltung zur Erzeugung des 'OVEN-COLD'- Interrupts.

Der Rechner erkennt nach dem Einschalten selbstständig, ob die Option ROSC bestückt ist. Die Zeitbasis auf der Synthese wird daraufhin abgeschaltet.

Es existieren zwei verschiedene Varianten Optionsquarze. Die Variantennummer ist auf der Druckschaltung der Baugruppe ersichtlich. Die Variante 02 läßt eine elektrische Abstimmung der Sollfrequenz zu, während die Variante 04 einen mechanischen Abgleich mit einem Trimmer erfordert.

# 7.2 Meßgeräte und Hilfsmittel

- 1. DC-Voltmeter zB. UDS5, URE
- 2. HF-Spektrumanalysator bis 100MHz zB. FSA
- 3. Kalibrierter Frequenzzähler 10MHz (wie in FSA enthalten)
- 4. Oszilloskop mit ca. 100MHz Bandbreite

#### 7.3 Fehlersuche

Frequenzfehler

Abstimmspannung bis zum Oszillator

verfolgen.

Abweichungen durch Alterung neu

kalibrieren

Pegelfehler

Steuersignal REFOFF verfolgen

Auskoppelstufe prüfen

Ausgangspegel des Oszillators

prüfen

#### 7.4 Prüfen und Abgleich

#### 7.4.1 Stromaufnahme

- · Gerät kalt mit Netzschalter einschalten.
- ▶ Die Stromaufnahme auf +15V soll während der Aufheizphase ca. 270mA nicht überschreiten und nach ca. vier Minuten auf maximal 135mA sinken.

Die Stromaufnahme auf +5V beträgt maximal 2mA, auf -15V 7mA.

# 7.4.2 Prüfen des Oszillators und des 10MHz-Verstärkers

- · SMY einschalten.
- ▶ Das Steuerbit REFOFF muß auf 'low' liegen. Der DC-Arbeitspunkt der Auskoppelstufe soll bei 5 ±2V liegen.
- Mit hochohmigem Tastkopf und Oszilloskop am Ausgang des Oszillators messen.
- ▶ Der Oszillator muß TTL-Pegel liefern.
- Spektrumanalysator an der Ausgangsbuchse X711 der Option anschließen.
- ▶ Das 10MHz-Signal muß eine Amplitude von 7.5dBm ±1.5dB aufweisen.
- Am Display auf externe Referenz schalten (RF EXT/AC).
- ▶ Das Steuerbit REFOFF muß auf 'high' gehen, der Ausgangspegel des Referenzsignals an X711 auf unter -50dBm sinken.

# 7.4.3 Prüfen der Interrupterzeugung (OVEN COLD)

Solange der Thermostat des Quarzoszillators die Solltemperatur nicht erreicht hat, liegt der Ausgang OVENCOLD (X22.13) auf 'high'. Dies wird vom Rechner erkannt und führt zu der Meldung 'OVEN COLD' am Display.

#### 7.4.3.1 Variante 02

- Brücke 40 auf X40.1/2 und Brücke 50 auf X50.1/2 stecken.
- ▶ Ein warmgelaufener Oszillator (ca. 5min) darf keinen OVEN COLD Interrupt liefern (= 'high') und damit auch keine Meldung am Display. Ein warmgelaufener Oszillator muß nach 30 Sekunden abschalten wieder einen Interrupt anzeigen (= 'low').

#### 7.4.3.2 Variante 04

- Steckbrücke X40 ziehen und an X40.2 eine Gleichspannung von 0 bis 12V einspeisen.
- ▶ Bei einer Gleichspannung von unter 5.6 ±.1V und über 6.4 ±.1V muß eine OVEN-COLD-Meldung erfolgen, dazwischen darf kein Interrupt gemeldet werden.

- Spannungsmesser an X40.3 anschließen.
- ▶ Nach etwa 5min Betriebsdauer muß die Spannung an X40.3 mit 6.0 ±.2V gemessen werden.

## 7.4.4 Abgleich des Oszillators

• Kalibrierten Frequenzzähler an X711 anschließen und die Ausgangsfrequenz messen.

## 7.4.4.1 Variante 02

51

- Am Gerät mit Spezialfunktion 48 die Kalibrierung des Referenzoszillators aufrufen, den Wert 2048 eingeben und mit 'Enter' abschließen.
- ▶ Nach zwei Stunden Betrieb mit dem Drehrad die Frequenz auf 10MHz einstellen. Die Spannung an X22.16 muß dabei zwischen 2 und 4V liegen. Das entspricht einem Eingabewert von etwa 820 bis 1640.

#### 7.4.4.2 Variante 04

• Den Oszillator mindestens zwei Stunden einlaufen lassen

Ist die Frequenzabweichung nach dieser Zeit größer 5\*10<sup>-8</sup>, so muß die Sollfrequenz neu abgeglichen werden.

▶ Der Abgleich auf 10MHz erfolgt mit einem Trimmer seitlich am Oszillatorgehäuse.

#### 7.5 Zerlegung und Zusammenbau

- Beplankung des Geräts abnehmen (siehe Serviceanleitung Gesamtgerät 6.5).
- Flachbandkabel von der Buchse am Netzteil lösen.
- HF-Kabel von der Buchse X711 auf der Baugruppe abziehen.

Die Baugruppe ist mit vier Schrauben seitlich am Rahmen des Geräts fixiert. Diese sind von der Außenseite zugänglich.

 Halterungsschrauben lösen und die Baugruppe nach oben herausnehmen.

Der Einbau erfolgt sinngemäß in umgekehrter Reihenfolge.

## 7.6 Externe Schnittsteller

Pin	Hame	Ein/Ausgang	Herkunft/	Ziel	Wertbereich	Signalbeschreibung
X22.1	VA5-P	Eingang	Netzteil	X22.1	+4.9 +5.3V	Imax=2mA, Versorgung
X22.2	VA15-P	"	n	X22.2	+14.4 . +15.6V	Imax=250mA, Versorgung
X22.3	frei					
X22.4	REFOFF	Eingang	Rechner	X3.21	TTL-HCT	Referenz ausschalten
X22.5	OPTERKREF	Ausgang	Rechner	X3.25	TTL-HCT	Erkennung ROSC
X22.6	VA15-N	Eingang	Netztei 1	X22.6	-15.614.4V	Imax=7mA, Versorgung
X22.7	frei					
X22.8	GHD			100 J		
X22.9	frei			5	•	
X22.10	GND			-		
X22.11	frei					
X22.12	frei			j		
X22.13	OVENCOLO	Ausgang	Rechner	X3.26	TTL-KCT	Interrupt OVEN COLD
X22.14	GND .					
X22.15	GND			į		
X22.16	OPTUNE	Eingang	Synthese	X1A.10	0 10V	Abstimmspannung
X711	REF	Ausgang	Synthese	X128	7.5dBm	Referenzsignal



SERVICE INSTRUCTIONS
Reference Oscillator (Option)
1039.1027.02

### Contentss

7.	Testing and Repair
7.1	Function Description 5
7.2	Test Instruments and Utilities 5
7.3	Troubleshooting 5
7.4	Testing and Adjustment 6
7.4.1	Power Consumption 6
7.4.2	Testing the Oscillator and the 10-MHz
	Amplifier 6
7.4.3	Testing the Generation of Interrupts (OVEN
	COLD)
7.4.3.1	Model 02 6
7.4.3.2	Model 046
7.4.4	Adjusting the Oscillator 7
7.4.4.1	Model 02 7
7.4.4.2	Model 04 7
7.5	Disassembly and Assembly 7
7.6	External Interfaces 8

Parts list List of coordinates Circuit diagram Component layout diagram

#### Testing and Repair

#### 7.1 Function Description

The reference-oscillator option OCXO replaces the internal 10-MHz time base by a thermostat-controlled top-quality crystal oscillator thus considerably improving the instrument data on the accuracy of the reference frequency and ageing.

Apart from the oscillator, the module contains components for generation of the 12-V supply voltage from the 15 V of the power supply, a decoupling amplifier which can be switched off, and the model 04 additionally provides a circuit for generation of the 'OVEN COLD' interrupt.

Upon switch-on, the controller checks whether the ROSC option is fitted. If it is, the time base on the synthesis is switched off.

Two different models of crystal are provided. The number of the model can be looked up on the PCB. Model 02 allows for electrical tuning of the rated frequency, whereas model 04 requires mechanical trimming.

#### 7.2 Test Instruments and Utilities

- 1. DC voltmeter, e.g., UDS5, URE
- 2. RF spectrum analyzer up to 100 MHz, e.g., FSA
- 3. Calibrated 10-MHz frequency counter (contained in FSA)
- 4. Oscilloscope with approx. 100-MHz bandwidth

#### 7.3 Troubleshooting

Frequency error

Trace tuning voltage to the

oscillator

Re-calibrate deviations due to

ageing

Level error

Trace control signal REFOFF Check decoupling stage

Check output level of the

oscillator

## 7.4 Testing and Adjustment

# 7.4.1 Power Consumption

- · Cold-start the instrument using the power switch.
- ▶ The power consumption to +15V during the warm-up phase should not exceed approx. 270mA and should drop to max. 135 mA after approx. four minutes.

  The power consumption up to +5V is max. 2 mA, to -15V it is 7mA.

# 7.4.2 Testing the Oscillator and the 10-MHz Amplifier

- Switch on SMY.
- ▶ The control bit REFOFF must assume 'low' state. The dc operating point of the decoupling stage should be at  $5 \pm 2V$ .
- Measure at the oscillator output using a high-impedance probe and an oscilloscope.
- ▶ The oscillator must supply TTL level.
- Connect spectrum analyzer to the output socket X711 of the option.
- ▶ The 10-MHz signal must have an amplitude of 7.5dBm ±1.5dB.
- Switch to external reference (RF EXT/AC) on the display.
- ▶ The control bit REFOFF must assume 'high' state, the output level of the reference signal at X711 must drop below -50dBm.

# 7.4.3 Testing the Generation of Interrupts (OVEN COLD)

As long as the thermostat of the crystal oscillator has not yet reached the rated temperature, the OVENCOLD output (X22.13) assumes 'high' state. The processor initiates output of the message 'OVEN COLD' on the display.

#### 7.4.3.1 Model 02

- Plug on jumper 40 to X40.1/2 and jumper 50 to X50.1/2.
- ▶ After warming up (approx. 5 min.), an oscillator must not initiate an OVEN COLD interrupt (= 'high') and any message on the display.
  30 seconds after switch off, it must indicate an interrupt again (= 'low').

#### 7.4.3.2 Model 04

- Unplug jumper X40 and apply a dc voltage between 0 and 12 V to  $\rm X40.2.$
- ▶ An OVEN-COLD message is output, if the dc voltage is below 5.6 ± .1V or above 6.4 ±.1V, it must not be output, if the voltage is in between.

- · Connect voltmeter to X40.3.
- ▶ After 5 min. of operation, the voltage measured at X40.3 must be 6.0 ±.2V.

#### 7.4.4 Adjustment of the Oscillator

 Connect calibrated frequency counter to X711 and measure the output frequency.

#### 7.4.4.1 Model 02

- Call calibration of the reference oscillator on the instrument via special function 48, enter the value 2048 and terminate with 'Enter'.
- ▶ After two hours of operation, set the frequency to 10 MHz using the spinwheel.

  The voltage at X22.16 must be between 2 and 4V, which corresponds to an input value of approx. 820 to 1640.

#### 7.4.4.2 Model 04

• The oscillator requires a warm-up period of at least two hours.

If the frequency deviation exceeds  $5*10^{-8}$  after this period, the rated frequency must be re-adjusted.

▶ The oscillator is adjusted to 10 MHz using a trimmer at the side of the oscillator housing.

#### 7.5 Disassembly and Assembly

- Remove instrument panelling (see service instructions for the overall instrument, Section 6.5).
- · Disconnect ribbon cable from the socket on the power supply.
- Disconnect RF cable from the socket X711 on the module.

The module is fixed to the lateral frame of the instrument using four screws which are accessible from outside.

Unscrew support screws and remove the module to the top.

The module is installed correspondingly in the reverse order.

# 7.6 External Interfaces

Pin	. Name	Input/Output	Origin/Destination	Specified range	Signal description
X22.1	VA5-P	Input	Power supply X22.1	+4.9 to +5.3V	Imax=2mA, supply
X22.2	VA15-P		" X22.2	+14.4 to +15.6V	lmax=250mA, supply
X22.3	not used				
X22.4	REFOFF	Input	Controller X3.21	TTL-HCT	Switch off reference
X22.5	OPTERKREF	Output	Controller X3.25	TTL-HCT	Identification of ROSC
X22.6	VA15-N	Input	Power supply X22.6	-15.6 to -14.4V	1max=7mA, supply
X22.7	not used				
X22.8	GNO				
X22.g	not used		<b>!</b>	•	
X22.10	GND	1	ì		
X22.11	not used			•	
X22.12	not used				
X22.13	OVENCOLO	Output	Controller X3.26	TTL-HCT	Interrupt OVEN COLO
X22.14	GNO	i i			
X22.15	GNO				
X22.16	OPTUNE	Input	Synthesis X1A.10	0 to 10V	Tuning voltage
X711	REF	Output	Synthesis XI28	7.5dBm	Reference signal



Schaltteillisten
numerisch geordnet
Part lists
in numerical order
Listes des pièces détachées
par numéros de référence

Kennz. Comp. No.	Benen Design				Sechnummer Stock No.	Hersteller Menufecturer	Bezeichnung Designation		alten in alned in
840	EO 10MHZ-QU.O.	SZ.I	DCXD 12V		<del></del>		2100T-S151 (H)		
B50	NUR VAR/ONLY I ED 10MHZ-QU.D: CRYSTAL DSCILI NUR VAR/ONLY I	MOD SZ.1 LATI	: 04 DCXD DR		1039.1410.0D	KVG	OCXD-S15	,	
C1	CE 100UF+-20%			CE	0008.7891.00	PANASONIC	ECA-1EFG101I		
C2	CE 220UF+-20%	ΙΟV	RM2,5	CE	0008.7927.00	PANASONIC	ECA-1AFG221I		
C3	CE 1UF +-10% 2	25V	EIA3528	CE	0007.7217.00	SPRAGUE	293D 105 X9 025 82T		
C4	TANTALUM SMD-(	25V	RM2.5	CE	0008.7891.00	PANASONIC	ECA-1EFG101I		
C11	CC 100NF+-10%	SOV	X7R 1206	cc	0007.5237.00	PHILIPS_CO	2238 581 15649		
C40	CERAMIC CHIP C CE 100UF+-20%2 ELECTDLYTIC CA	25V	RM2.5	CE	0008.7891.00	PANASDNIC	ECA-1EFG101I		
C50	CC 100NF+-10%E CERAMIC CHIP C NUR VAR/DNLY N	OV APA	X7R 1206 CITOR	СС	0007.5237.00	PHILIPS_CO	2238 581 15649		
C66	CC 100NF+-10%5	VO	X7R 1206	СС	0007.5237.00	PHILIPS_CO	2238 581 15649		
C70	CC 220PF+-1%50	V	IPD 1206	СС	0099.8850.00	PHILIPS_CO	2238 863 18221		
C71	CC 1NF+-1% 50V SMD CERAMIC CA	NP	0 1206	СС	0007.7398.00	PHILIPS_CO	2222 863 *8102		
C72	CC 100NF+-10%5 CERAMIC CHIP C	OV	X7R 1206	СС	0007.5237.00	PHILIPS_CO	2238 581 15649		
C73	CC 39PF+-1%50V CERAMIC CHIP C	NP	0 1206	СС	0099.8796.00	MURATA	GRM42-6COG 390F 50PT		
C76	CC 180PF+-1%50 CHIP CAPACITOR	V N		СС	0099.8844.00	PHILIPS_CO	2238 863 18181		
C79	CC 100NF+-10%5 CERAMIC CHIP C	O۷		СС	0007.5237.00	PHILIPS_CO	2238 581 15649		
L1	LD 15UH 10% 1R CHOKE	2 0	, 46A	LD	0026.4149.00	DALE	IM 6		
L2	LD 22UH 10% SMD-INDUCTOR	٥,	14A 1210	LD	0520.7886.00	SIEMENS	882422-A1223-K100		
L40	LD 3,30UH10%O, CHOKE	850	HMO,285A	LD	0067.2928.00	DALE	IM2		
L70	LD 100UH 10% SMD-INDUCTOR	٥,	06A 1210	LD	0007.9261.00	SIEMENS	882422-A1104-K100		
L71	LD 4,7UH 10% SMD-INDUCTOR	٥,	15A 1210	FD	0008.1687.00	SIEMENS	882422-A1472-K100		- 1
L72	LD 2,2UH 10% SMD-INDUCTOR	0,	27A 1210	LD	0520.7870.00	SIEMENS	882422-A1222-K100		
N1	80 LM7812CT+12 VDLTAGE REGULA			80	0344.9641.00	NSC	LM340T 12		
N50	80 TLO72ACD OPERATIONAL AM NUR VAR/ONLY M	PLI			0803.1057.00	TEXAS	TL 072 ACDR		
N6O	80 LM2903D 23 DUAL NUR VAR/ONLY M		COMPAR O4		0520.7734.00	SIGNETICS	LM2903(D)		
R1	RG 1,0 KO +-1%	TK 10	00 1206	RG	0006.7271.00	ROEDERSTEI	DC2 1,0K0HM 1%TK100		
R19	CHIP RESISTOR RG 475 KOHM+~1;	⁄tK	100 1206	RG	0007.6079.00	RDEDERSTEI	DC2 475KDHM 1%TK100		
R21	RESISTOR CHIP NUR VAR/ONLY MI RG 4,75KOHM+-19			RG	0007.5820.00	RDEDERSTEI	DC2 4,75KOHM 1%TK100		
R29	RESISTOR CHIP RG 475 OHM+-1%	ΓK 16	00 1206	RG	0007.5695.00	RDEDERSTEI	DC2 475DHM 1%TK100		
R40	RESISTOR CHIP RG O-OHM WIDERS RESISTOR CHIP (	)-OI	-tM	RG	0007.5108.00	DRALORIC	CR 1206		
R45	NUR VAR/ONLY ME RG O-OHM WIDERS RESISTOR CHIP (	DD: STAI D-O	O2 ND-CHIP HM	RG	0007.5108.00	DRALDRIC	CR 1206		
R50	NUR VAR/DNLY MI RG 4,75KDHM+-19 RESISTDR CHIP NUR VAR/ONLY MI	۲K)	100 1206	RG	0007.5820.00	ROEDERSTEI	DC2 4,75KDHM 1%TK100		
1GPK	413 3PUA	Äſ	Detum Date		Schaltteillis Parts list		Sechnummer Stock No.		Blatt-Nr. Page
(R)		08	16.09.97	_			1039.1027.01	C A	
ROHDE	&SCHWARZ	00	10.05.57		D REFERENZDSZ EFERENCEDSC		1033.1027.01	JA	1+

RESI TOR CHIP NUR VAR/ONLY MOD: 04 RESISTOR CHIP NUR VAR/ONLY MOD: 02 RESISTOR CHIP NUR VAR/ONLY MOD: 02 RESISTOR CHIP NUR VAR/ONLY MOD: 02 RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP O-CHIM RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP O-CHIM RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RE	Kennz. Comp. No.		Benen Design				Sachnummer Stock No.	Hersteller Manufacturer	Bezeichnung Designetion	entheiten in contained in
RES 1 NUR VAR/DNLY MOD: 04 RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR CHIP 0-0HM RESISTOR 0-0HM RESISTOR CHIP 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR 0-0HM RESISTOR	R51 '		5KOHM+-		100 1206	RG				
RES   NUR YAR/ONLY MOD: 02   RG 0007.5108.00   DRALORIC CR 1206   RESISTOR CHIP   RG 0007.5843.00   ROEDERSTEI DC2 15,0KDHM 17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 22,7KDHM-17KT 100   1206   RG 22,7KDHM-17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   1206   RG 15,0KDHM+17KT 100   RG 0007.5889.00   ROEDERSTEI DC2 15,0KDHM 17KT 100   RG 0006.7571.00   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0006.7571.00   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0006.7571.00   RG 0006.7571.00   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0006.7571.00   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0006.7571   RG 15,0KDHM 17KT 100   RG 0007.75889   RG 15,0KDHM 17KT 100   RG 0007.7589   RG 15,0KDHM 17KT 100   RG	R53	NUR VA RG O-D	R/DNLY I	RSTAN	ID-CHIP	RG	0007.5108.00	DRALORIC	CR 1206	
R56 NUR VAR/ONLY MOD: 04 R615TOR CHIP MOD: 05 R62 STOR CHIP MOD: 04 R65 R615TOR CHIP MOD: 04 R68 R615TOR CHIP MOD: 04 R68 R615, OKOMM-1%TK100 1206 R68 R615TOR CHIP NUR VAR/ONLY MOD: 04 R68 R6 4, 75KOMM-1%TK100 1206 R69 NUR VAR/ONLY MOD: 04 R69 NUR VAR/ONLY MOD: 04 R69 NUR VAR/ONLY MOD: 04 R61 A, 75KOMM-1%TK100 1206 R62 STOR CHIP NUR VAR/ONLY MOD: 04 R61 A, 75KOMM-1%TK100 1206 R63 STOR CHIP NUR VAR/ONLY MOD: 04 R61 A, 75KOMM-1%TK100 1206 R63 STOR CHIP NUR VAR/ONLY MOD: 04 R61 A, 75KOMM-1%TK100 1206 R63 STOR CHIP NUR VAR/ONLY MOD: 04 R61 STOR CHIP NUR VAR/ONLY MOD: 04 R61 STOR CHIP NUR VAR/ONLY MOD: 04 R61 STOR CHIP NUR VAR/ONLY MOD: 05 R62 STOR CHIP NUR VAR/ONLY MOD: 05 R63 STOR CHIP NUR VAR/ONLY MOD: 05 R63 STOR CHIP NUR VAR/ONLY MOD: 05 R64 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65 STOR CHIP NUR VAR/ONLY MOD: 05 R65	R54	NUR VA RG O-D	R/ONLY H	MDD: RSTAN	02 ID−CHIP	RG	0007.5108.00	DRALORIC	CR 1206	
REST OR CHIPP NUR VAR/ONLY MOD: 04 RESTSTOR CHIPP NUR VAR/ONLY MOD: 04 RESTSTOR CHIPP NUR VAR/ONLY MOD: 04 RESTSTOR CHIPP NUR VAR/ONLY MOD: 04 RESTSTOR CHIPP NUR VAR/ONLY MOD: 04 RESTSTOR CHIPP NUR VAR/ONLY MOD: 04 RESTSTOR CHIPP NUR VAR/ONLY MOD: 04 RESTSTOR CHIPP NUR VAR/ONLY MOD: 04 RESTSTOR CHIPP RESTSTOR CHIP RESTSTOR CHIP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTSTOR CHIPP RESTST	R56	NUR VA RG 15,	R/ONLY I	WOD:	04	RG	0007.5843.00	ROEDERSTEI	DC2 15,0KDHM 1%TK100	
RES   RG 15, OKOHM+-1XTK 100   1206   RESSITOR CHIP   NUR VAR/OKLY MOD: 04   RESSITOR CHIP   NUR VAR/OKLY MOD: 04   RC   RG   RG   RG   RG   RG   RG   RG	R57	RG 2,2 RESIST	1KOHM+-	1%TK 1	00 1206	RG	0007.5743.00	ROEDERSTEI	DC2 2,21KDHM 1%TK100	
RESP RESISTOR CHIP NUR WAR/ORLY MOD: 04 RG 0007.58920.00 ROEDERSTEI DC2 4,75K0HM 1½TK100 RG 1,0 K0 ++ 1½TK100 1206 RG 4,75K0HM-1½TK100 1206 RG 4,75K0HM-1½TK100 1206 RG 4,75K0HM-1½TK100 1206 RG 5,5TOR CHIP RG 15,0KDHM-1½TK100 1206 RESISTOR CHIP RG 15,0KDHM-1½TK100 1206 RG 5,5TOR CHIP RG 15,0KDHM-1½TK100 1206 RG 5,0KDHM-1½TK100 1206 RG 5,0KDHM-1½TK100 1206 RG 5,0KDHM-1½TK100 1206 RG 5,0KDHM-1½TK100 1206 RG 0007.5589.00 RGCDERSTEI DC2 15,0KOHM 1½TK100 RG 0007.5589.00 RGCDERSTEI DC2 15,0KDHM 1½TK100 RG 0007.5589.00 RGCDERSTEI DC2 15,0KDHM 1½TK100 RG 0007.5589.00 RG 0006.9089.00 RG 0006.9089.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7	R58	RG 15,0 RESIST	OKOHM+- OR CHIP	1%TK 1	00 1206	RG	0007.5843.00	ROEDERSTEI	DC2 15,0KOHM 1%TK100	
R70 R6 1,0 KO + -1/KIK100 1206 R6 0006.7271.00 R0EDERSTEI DC2 1,0 KOHM 1/KTK100 R71 R6 4,7 SKOHMH+-1/KIK100 1206 R6 1510 KOHHH+-1/KIK100 1206 R6 1510 KOHHH+-1/KIK100 1206 R72 R6 15,0 KOHH+-1/KIK100 1206 R73 R74 R51510 KOHH 1/KIK100 R75 R6 1510 KOHH 1/KIK100 R75 R6 1510 KOHH 1/KIK100 R77 R6 151510 KOHH 1/KIK100 R77 R6 151510 KOHH 1/KIK100 R77 R75 R75 R6 162 OHM1/KIK100 R77 R75 R75 R75 R75 R75 R75 R75 R75 R75	R59	RG 4,7	5KOHM+- OR CHIP	I%TK 1	00 1206	RG	0007.5820.00	ROEDERSTEI	DC2 4,75KOHM 1%TK100	
CHIP RESISTOR   Rd   75KG/HM   17KT   1206   Rg   0007   5820   00   RESISTOR CHIP   Rd   15KG/HM   17KT   100   Rg   0007   5843   00   Rd   15KG/HM   17KT   100   Rd   1206   Rd   15KG/HM   17KT   100   Rd   1206   Rd   15KG/HM   17KT   100   Rd   1206   Rd   15KG/HM   17KT   100   Rd   1206   Rd   15KG/HM   17KT   100   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd   1006   Rd	R70					RG	0006.7271.00	RDEDERSTEI	DC2 1, OKOHM 1%TK 100	
RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR AK 0010.6460.00 VALVO BFS17 N 30V 50MA TRANSISTOR AK 0010.6460.00 VALVO BFS17 N 30V 50MA TRANSISTOR AK 0010.6460.00 VALVO BFS17 N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR AK 0010.6460.00 VALVO BFS17 N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSISTOR N 30V 50MA TRANSI	R71	CHIP R	ESISTOR							
RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR CHIP RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR RESISTOR		RESIST(	OR CHIP							
RESISTOR CHIP RESISTOR RG 1.0 K0 + -1/XTK100 1206 CHIP RESISTOR RG 1.0 K0 + -1/XTK100 1206 CHIP RESISTOR RG 1.0 K0 + -1/XTK100 1206 CHIP RESISTOR RG 0.06.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271.00 RG 0006.7271	R72			1%1K1	00 1206					
R75	R73	RG 150	OHM+-1%	TK 10	0 1206	RG	0007.5589.00	RDEDERSTEI	DC2 1500HM 1%TK100	
RG 1,0 KO +-1%TK100 1206 CHIP RESISTOR  V70 AK 8FS17 N 30V 50MA TRANSISTOR  V71 AK BFS17 N 30V 50MA TRANSISTOR  V71 AK BFS17 N 30V 50MA TRANSISTOR  V710 DY KABEL A7/X22 1062.7557.00  V711 FJ EINBAUSTECKER F. GS SMB FJ 0063.5168.00 ROSENBERGE 59S106-400-D3  V711 PLUG  1GPK 413 3PUA ÄI Datum Date Schatttelliste (Ur Parts list for Stock No. Page	R75	RG 562	OHM+-1%	TK 10	0 1206	RG	0006.9068.00	ROEOERSTEI	DC2 5620HM 1%TK100	
TRANSISTOR AK BES17 N 30V 50MA AK 0010.6460.00 VALVO BFS17 TRANSISTOR  DY KABEL A7/X22 1062.7557.00 X711 FJ EINBAUSTECKER F.GS SMB FJ 0063.5168.00 ROSEN8ERGE 59S106-400-D3  1GPK 413 3PUA At Datum Date Schatttellists (Br Parts list for Stock No. Page	R79	RG 1,0	KO +-1%	TK 10	0 1206	RG	0006.7271.00	ROEDERSTEI	DC2 1,0KDHM 1%TK100	
AK BFS17	V70	AK 8FS1	17 N	30V	50MA	AK	0010.6460.00	VALVO	BFS17	
FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.5168.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS SMB FJ COG3.00 ROSEN8ERGE 59S106-400-D3  FJ EINBAUSTECKER F. GS FJ COG3.00 ROSEN8ERGE 59S10	V71	AK BFS	17 N	30V	50MA	AK	0010.6460.00	VALVO	BFS 17	
PLUG    PLUG	W710	DY KASE	EL A7/X2	2			1062.7557.00			
TIGHT 413 3PUA A! Date Parts list for Stock No. Page	X711		BAUSTECK	ER F	.GS SMB	FJ	0063.5168.00	ROSEN8ERGE	59S 106-400-D3	
TIGHT 413 3PUA A! Date Parts list for Stock No. Page										
TIGHT 413 3PUA A! Date Parts list for Stock No. Page										
	1GPK	413	3PUA	ÄI						Blatt-Ni Paga
(\$\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	<u> </u>									

REFERENCE.-DSC.-OCXO



# XY-Liste

# **XY List**

# Erklärung der Spaltenbezeichnungen:

Part: Bauelement-Kennzeichen.

Side: ... Leiterplatten-Seite, auf der sich das Bauelement befindet.

XY: Koordinaten (Millimeter) des Bauelementes auf der Leiterplatte

bezogen auf den Nullpunkt.

SQR, PG: Planquadrat und Seite des Schaltbildes für das jeweilige Bauelement.

# Explanation of column designations:

Part: Identification of instrument part.

Side: Side of the PC board on which instrument part is positioned.

XY: Coordinates (millimeter) of the component on the PC board in reference

to zero point.

SQR, PG: Square and page of the diagram for the respective instrument part.

Part	Side	х 	Y	sqr	Pg	Part :	Side	X	¥	Sqr	Pg	Part	Side	X	Y	Sqr
840	В	56	47	7F	1	Nl	В	20	43	4E	1	N60-C				 4B
850	8	84	50	7E	1	N50-A	A	25	27	5B	1	V70	Α	78	26	90
Cl	В	21	22	ͺ 3E	1	N50-B				8C	1	V71	Α	73	31	9E
C2	В	18	30	3E	1	N50-C				4B	1	W710	В	7	25	2 E
C3	A	23	34	3F	1	N60-A	A	19	46	9в	1	X711	8	65	58	11E
C4	8	25	37	4E	1	№60-в				98	1					


1	Nicht-Service-Relevante Bauteile / Non-Service-Relevant Components																
Part	Side	x	Y	Sqr	Pg	Part	Side	х	Y	Sqr	Pg	Part	Side	x	Y	Sqr	Pg
C11	A	40	37	6F	1	L40	В	42	56	5E	1	R53	A	18	12	11C	1
C40	8	55	58	6E	1	L70	A	53	41	9F	1	R54	A	11	48	11C	1
C50	A	33	41	9C	1	L71	Α	78	43	10E	1	R56	A	29	46	9C	1
C66	A	25	21	7C	1	L72	A	74	55	10E	1	R57	A	33	49	98	1
C70	Α	70	27	9E	1	R1	A	11	30	2E	1	R58	Α	29	52	98	1
C71	A	69	39	10E	1	R19	A	77	17	7E	1	R59	A	11	46	10C	1
C72	A	60	42	9E	1	R21	A	29	39	5 <b>F</b>	1	R70	A	62	22	8E	1
C73	A	72	39	10E	1	R29	Α	11	34	2F	1	R71	A	73	15	8D	1
C76	Α	74	58	10E	1	R40	Α	63	8	7D	1	R72	A	77	36	9E	1
C79	A	41	17	6D	1	R45	A	63	17	7D	1	R73	A	73	27	9 D	1
Ll	8	22	16	2E	1	R50	A	31	34	8C	1	R75	A	63	41	9E	1
L2	A	15	24	2E	1	R51	A	28	23	88	1	R79	A	11	20	5D	1





ROHDE	I	Datum Date	XY-Liste far XY-list for	Sach-Nummer Stock-Nr	Blatt Page
SCHWARZ		21.11.94	ED REFERENZOSZOCXO REFERENCEOSCOCXO	1039.1027.01 XY	1-





Stromläufe
Bestückungspläne
Circuit diagrams
Components plans
Schémas de circuit
Plans des composants















GRAM IS VALID FOR MOD.02,04







2

3

4

N A R





A			Б	A			7		8				
IND. MATTEILUMG		July Innic		ZU GERAET SMY-B1			REG. 1. U. 1039, 0995 ERSTE Z.						
REND.		DATUR	NRME	KUH	DEASC	HUARZ		1033,10	21.01	LU	٧	BL.	
V				1 7 7	05400			1039.10	27 N1	ED		+	
				(R/S)			ZEICHNNR.			ŧ	BLATT		
				PLOTT	21.11.94								
L				NORN			REFERENCEOSCOCXO						
			ļ	GEPR.			REFERENZOSZOCXO						
				BEARB.		. но							
02/_	49169 01	21.11.94	HO	1GPK	186	NAME	BENENNUNG						


5 A

ŠΑ.

LS, AND LIST, Ε

C

E



: EGB!
ICH GEFAERROETE
EFRORDERN EINE
HANDRABUNG.
IN ESD!
SENSITIVE DEVICES
ECIAL HANDLING


TRIMMWERTE, BAUTEILUERTE UND
NICHT BESTUECKTE BAUTEILE SIEHE SA.
FOR BINDING INFORMATION ON MODELS,

4

FOR BINDING	INFORMATION	ON MODI	ELS,
TRIMMING AND	COMPONENTS	VALUES	AND
NONFITTED CO	OMPONENTS SE	E PARTS	LIST

BINDENDE ANGABEN WEBER VARIANTEN,

A			Б				7
J # O .	MITTEILUNG	MULTA	ипис	ZU GERREI	r SMY-	-B1	REG. I.V.
REND.	AENDERUNGS-	DATUM	NAME	KUH	DEASU	HUARZ	
1				1 4 %			
		<u> </u>		R			ZEICHNNR.
				PLOTT	21.11.94		
				NORM			REFE
				GEPR.			REF
				BEARB.		HO	
02/	49169 01	21,11,94	HO	1GPK	TAG	NAME	BENERNUNG



G SEITE B DE B



ACHTUNG: EGB! ELEKTROSTATISCH GEFREHRDETE BAUELEHENTE ERFORDERN EINE BESONDERE HANDHABUNG.

ATTENTION ESD!
ELECTROSTATIC SENSITIVE DEVICES
REQUIRE A SPECIAL HANDLING

BINDENDE ANGABEN WEBER VARIANTEN, TRIMMWERTE, BRUTEILWERTE UND MICHT BESTBECKTE BRUTEILE SIEHE SR.

FOR BINDING INFORMATION ON MODELS, TRINNING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.

		27		4.44
	02/	49169	01:	21.11.9
			*	. 1
		:	-	*
			*	
			<u> </u>	
	1			
	REND.	RENDERI MITTEIL		DATUN
5	٨	V V		3

**↑** 3




DARSTELLUNG SEITE B VIEW ON SIDE B




Λ

BINDENDE ANGABEN UEBER VARIANTEN TRIMMUERTE, BAUTEILUERTE UND NICHT BESTUECKTE BAUTEILE SIEHE

FOR BINDING INFORMATION ON MODEL' TRIMMING AND COMPONENTS VALUES AL HONFITTED COMPONENTS SEE PARTS L



A			5				7	8			
IND.	MITTEILUNG	SULDB	HAUL	ZU GERAE	r SMY∙	-B1	PEG.1.V.	1039.0995 ERSTE Z.			J
/ AEND.	AENDERUNGS-	DATUR	NAME	ROH	IDE&SC	HUARZ	EL TORM . N	1039.1027.01	ED .	2 - 8L.	-
				PLOTT	21.11.94		ZEICHNN	D	8	LATT-NR.	$\mathbf{I}$
				NORM			REF	ERENCEOSCOCXO			1
				GEPR.			RE	FERENZOSZOCXO		Z	ı
				OEARB.		но				-	
02/	49169 01	21.11.94	но	1GPK	TAS	KANE	BENENNUNG				1



ACHTUNG: EGB! EKTROSTÄTTISCH GEFAEHRDETE AVELEMENTE ERFORDERN EINE BESONDERE HANDHABUNG. TTENTION ESD! TROSTATIC SENSITIVE DEVICES
QUIRE A SPECIAL HAMDLING

**↑** 3

BINDENDE ANGABEN UEBER VARIANTEN, TRIMMWERTE, BRUTEILWERTE UND NICHT BESTUECKTE BAUTEILE SIEHE SA.

FOR BINDING INFORMATION ON MODELS, TRIMMING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.

IND.	MITTERLUNG	DATUN	NAME	ZU GERAET			RE
/ AEND.	AENDERUNGS-			ROH	IDE&SC	HUARZ	
			•	PLOTT	21.11.94		   Z
	-			NORH		•	
				GEPR.			1
				BEARB.		НO	
02/	49169 01	21.11.94	HO	1GPK	TAG	NAME	B

R58 R57 R56 L71 ¢50 R21 R72 011 [2] R50 N20 R51 C66 R70 R19 R71 R45 C79 100 50

STELLUNG SEITE A W ON SIDE A



ACHTUNG: EGB!
ELEKTROSTATISCH GEFAEMROETE
BAUELERENTE ERFORDERN EINE
BESONDERE HANDHABUNG.

ELECTROSTATIC SENSITIVE DEVICES
REQUIRE A SPECIAL HANDLING

BINDENDE AKGABEN VEBER VARIANTEN, TRIMMVERTE, BAUTEILVERTE UND NICHT BESTVECKTE BAUTEILE SIEHE SA.

FOR BINDING INFORMATION ON MODELS, TRIMMING AND COMPONENTS VALUES AND NONFITTED COMPONENTS SEE PARTS LIST.

4

02/	4916
<b> </b>	
AEND.	AENDE NITTE

**A** 3

。 5

E PES DATENSATZES ERFOLGEN FUER DIESE ZEIGHNUNG BEHALTEN WIR UNS ALLE RECHTE UDR TCHNERAUSDUCK, RENDERUNGEN KOENNEN NUR DURCH RENDE D C DIESE ZEICHNUNG IST EI В

F

C76
L72

R75

R75

R75

R770

R19

R19

R45

R40

DARSTELLUNG SEITE A VIEW ON SIDE A



A 3

100

BINDENDE ANGABEN UEBER VARIANTEN Trimmuerte, bruteilwerte und Nicht bestueckte bruteile siehe :

50

FOR BINDING INFORMATION ON MODEL TRIMMING AND COMPONENTS VALUES A NONFITTED COMPONENTS SEE PARTS L



**SERVICEUNTERLAGEN** 

Powermodul

1062.7240.01

### Inhaltsverzeichnis

•	Prü	fen und Instandsetzen der Baugruppe	5
	7.1	Funktionsbeschreibung	5
	7.2	Meßgeräte und Hilfsmittel	5
	7.3	Fehlersuche	5
		7.3.1 Fehler nur im Bereich $f_{RF}$ < 10 MHz	6
		7.3.2 Fehler nur im Bereich $f_{RF} > 10 \text{ MHz} \dots$	6
		7.3.3 Fehler im Bereich 9 kHz < $f_{RF} \le 2080 \text{ MHz} \dots$	6
	7.4	Prüfen und Abgleich	6
		7.4.1 Prüfen der Stromaufnahme	7
		7.4.2 Prüfen der Arbeitspunkte der Verstärkerstufen	7
		7.4.3 Prüfen der Ansteuerung des Pulsmodulators	7
		7.4.4 Prüfen der Detektorspannung am Ausgang VDETPOW	8
		7.4.5 Abgleich der Detektor-Linearität am Ausgang FPOW	8
	7.5	Zerlegung und Zusammenbau	8
	7.6	Endprüfung	9
		7.6.1 Prüfen des maximalen Ausgangspegels	9
		7.6.2 Prüfen des Oberwellenabstandes	9
		7.6.3 Prüfen der Pegel-Dynamik der Pulsmodulation	
		7.6.4 Prüfen der Schaltzeiten der Pulsmodulation 1	
		7.6.5 Prüfen der Pegelgenauigkeit	
	7 7	Eutorno Cahnithatalla-	_

Schaltteilliste Koordinatenliste Stromlauf Bestückungsplan

### 7.1 Funktionsbeschreibung

Das RF-Signal vom Ausgangsteil OPUY1 bzw. OPUY2 am Eingang FOPU wird mit einem Signalteiler (R91, R92) geteilt und in identischen Zweigen verstärkt. Jeder Zweig beinhaltet einen Pulsmodulator gefolgt von einem RF-Verstärker. Ein Verstärkerausgang geht über den Ausgang FPOW zur Eichleitung, der andere zum Detektor (V13). Die RF-Spannung wird dort gleichgerichtet. Die Richtspannung wird linearisiert (N6) und geht über den Ausgang VDETPOW zum Motherboard und von dort zum Ausgangsteil OPUY1 bzw. OPUY2 als Istwert für die Amplitudenregelung im Frequenzbereich f > 10 MHz.

Nur der Pulsmodulator zum RF-Verstärker 1 wird angesteuert, der andere bleibt immer im ON-Zustand. Die Ansteuerung erfolgt über den Eingang PULSE. Leerlauf oder High-Pegel am Eingang ergeben RF ON, Low ergibt RF OFF. Diese Polarität kann durch Stecken der Brücke P1-P2 invertiert werden. Die Verstärker N1 und N2 setzen das TTL-Signal auf die Steuerpegel 0 V/-8 V für die GaAs-Schalter D2 und D3 um.

Die RF-Verstärker werden aus Konstantstromquellen V4 und V5 gespeist, die Drainspannungen werden über die Verstärker N3 und N4 geregelt. Die Verstärkerstufen V11 und V12 haben eine Verstärkung von ca. 10 dB. Die Pulsmodulatoren vor den Verstärkerstufen haben eine Dämpfung von ca. 2 dB bei 2 GHz. Der Signalteiler (R91, R92) hat eine Durchgangsdämpfung von 6 dB.

## 7.2 Meßgeräte und Hilfsmittel

- Spektrumanalysator (z.B. FSBS)
- Oszilloskop (z.B. BOL)
- Gleichspannungsmeßgerät (Multimeter, z.B. UDL33)
- RF-Pegelmesser (z.B. NRVD mit Meßkopf Z51)
- 10 dB-Dämpfungsglied mit N-Anschlüssen (z.B. DNF)
- Durchführungsabschluß 50 Ohm (z.B. RAD)

### 7.3 Fehlersuche

Vor dem Öffnen des Gerätes ist es zweckmäßig, zuerst einmal die LEVEL PRESET-Kalibrierung durchzuführen und an Hand der Diagnosespannungen mögliche Fehlerquellen zu lokalisieren. Mit der Spezialfunktion 102 (Detektorspannung Ausgang FOPU) kann die RF-Quelle für das Powermodul kontrolliert werden: bei einem RF-Pegel von -30 dBm und RF-Frequenzen > 10 MHz liegen typische Spannungswerte im Bereich 0.7 ... 1.3 V.

#### Fehler nur im Bereich f<sub>RF</sub> < 10 MHz 7.3.1

falscher RF-Pegel an X4 FPOW Prüfe Signalteiler R91/R92,

> Pulsmodulator D2/D3 und RF-Amplifier 1 bei f = 100 kHz mit

Oszilloscope.

Prüfe die Stromquelle V4 und die schlechter AM-Klirrfaktor

Drainspannungsregelung N3.

#### 7.3.2 Fehler nur im Bereich f<sub>RF</sub> > 10 MHz

Die Pulsmodulatoren D2/D3 und falscher RF-Pegel an X4 FPOW

D4/D5 oder die RF-Verstärker 1 und

2 haben unterschiedliche

Verstärkung, oder die RF-Spannung am Ausgang von RF Amplifier 2 wird

nicht richtig gleichgerichtet.

Prüfe Detektor und

Linearisierungsschaltung.

AM-Klirrfaktor zu groß Prüfen und Abgleich von Detektor

und Linearisierungsschaltung.

#### 7.3.3 Fehler im Bereich 9 kHz $< f_{RF} \le 2080$ MHz

kein RF-Pegel an X4 FPOW Die Steuerspannung des AM-

Modulators (Spezialfunktion 107) muß jetzt > 12 V sein, sonst arbeitet die Pegelregelung nicht richtig oder der Führungswert vom RFLEV-D/A-Wandler ist falsch (der Fehler läge dann im Ausgangsteil

OPUY1 oder OPUY2).

Prüfe Signalteiler R91/R92, PulsmodulatorD2/D3 und RF-

Amplifier 1 bei f = 100 kHz mit

Oszilloscope.

Oberwellen zu groß Prüfe die Stromquelle V4 und die

Drainspannungsregelung N3.

Prüfen und Abgleich von Detektor AM-Klirrfaktor zu groß

und Linearisierungsschaltung.

Pulsmodulation mit falscher

Polarität

Brücke auf P1-P2 darf nicht gesteckt sein, EXOR-Funktion von

D1 prüfen

Pulsmodulation nicht möglich oder falsche Anstiegs- bzw.

Abfallzeiten

Steuersignale in der Signalkette D1, N1 und N2 bis D2 und D3 prüfen

zu geringes Ein/Aus-Verhältnis D2 und D3 prüfen, RC-Tiefpässe der bei Pulsmodulation

Ansteuerleitungen kontrollieren

### 7.4.1 Prüfen der Stromaufnahme

• Einstellung:

PRESET

Die Ströme können entweder am Stecker X1 oder durch den Spannungsabfall an Meßwiderständen nachgemessen werden. Bei mehreren Meßwiderständen sind die Teilströme zu addieren.

Anschluss	Spannung	Stromaufnahme	Widerstand ( 2 Ohm)
X1.11 und X1.12	+5 V	35 45 mA	R66
X1.13 und X1.14	+15 V	340 360 mA	R67 und R68
X1.15 und X1.16	-15 V	45 <b>5</b> 5 mA	R69, R70 und R72

### 7.4.2 Prüfen der Arbeitspunkte der Verstärkerstufen

Prüfpunkt	Sollspannung	Bemerkung
V11 Drain	6.60 ± 0.5V	RF AMPLIFIER 1
V11 Gate	$-1.0 \pm 0.5V$	RF AMPLIFIER 1
V4 Kollektor	7.25 ± 0.2V	Stromquelle
U15VA1 - V4 Emitter	1.21 ± 0.02V	I = 150 mA
V12 Drain	6.60 ± 0.5V	RF AMPLIFIER 1
V12 Gate	-1.0 ± 0.5V	RF AMPLIFIER 1
V5 Kollektor	$7.25 \pm 0.2V$	Stromquelle
U15VA2 - V5 Emitter	1.21 ± 0.02V	I = 150 mA

# 7.4.3 Prüfen der Ansteuerung des Pulsmodulators

Die Spannungswerte nach folgender Tabelle kontrollieren: High = 5 V, Low = 0 V.

P1-P2	PULSE	©D1/10 :	D1/8	D1/3	D1/6	N1/6	CM2/6	D2/5_	-:_D37.5 -	D2/4	@D3/4%
nicht gesteckt	High	High	Low	Low	High	0 V	-7.9 V	0 V	0 V	-7.9 V	-7.9 V
gesteckt	Low	High	Low	Low	High	0 V	-7.9 V	0 7	0 V	-7.9 V	-7.9 V
nicht gesteckt	Low	Low	High	High	Low	-7.9 V	0 V	-7.9 V	-7.9 V	0 V	0 V
gesteckt	High	Low	High	High	Low	-7.9 V	0 V	-7.9 V	-7.9 V	0 V	0 V

Brücke P1-P2 entfernen.

### 7.4.4 Prüfen der Detektorspannung am Ausgang VDETPOW

• Einstellung:

RF

100 MHz

Spezialfunktion 49 einschalten (Pegelkorrektur

aus)

\_ Gleichspannung an VDETPOW nach folgender Tabelle kontrollieren:

RF-Pegel in dBm -30	11.1	13	16	19
Spannung in V 2.0	1.27	1.58	2.23	3.14

Spezialfunktion 50 einschalten (Pegelkorrektur ein)

# 7.4.5 Abgleich der Detektor-Linearität am Ausgang FPOW

• Einstellung:

RF

100 MHz

LEVEL

11.1 dBm

\_ Ausgangspegel am RF-Ausgang des Gerätes messen und merken (= Referenzpegel)

• Einstellung:

Spezialfunktion 1 einschalten

(unterbrechungsfreie Pegeleinstellung)

LEVEL -8.9 dBm

\_ Mit POT R36 so abgleichen, daß der gemessene Pegel 20 dB unter dem zuvor gemessenen Referenzpegel liegt. Abgleich einmal wiederholen, da sich der Referenzwert mit R36 ändert; die Genauigkeit der 20dB-Absenkung soll nach dem Abgleich ± 0.1 dB erreichen.

### 7.5 Zerlegung und Zusammenbau

Oberen Gerätedeckel entfernen. Die Baugruppe ist mit einer Schraube am Rahmen befestigt und an der Querwand gesteckt. Nach dem Entfernen der Schraube und dem Lösen der Koax-Verbindungen an X2, X3, X4 und X5 sowie des Steckers X1 kann die Baugruppe entnommen werden.

### 7.6 Endprüfung

## 7.6.1 Prüfen des maximalen Ausgangspegels

• Einstellung:

LEVEL

25 dBm

- \_ An X226 FOPU einen Leistungsmesser anschließen, dabei auf die max. zulässige RF-Leistung achten! Ggf. muß ein geeignetes Dämpfungsglied vorgeschaltet werden..
- \_ RF-Frequenz von 9 kHz bis 2080 MHz variieren.
- Der RF-Pegel muß > 20 dBm bleiben.

# 7.6.2 Prüfen des Oberwellenabstandes

• Einstellung:

LEVEL 16 dBm

- \_ An die Geräte-RF-Buchse einen Spektrumanalysator anschließen.
- \_ Der Pegel der Harmonischen muß < -25 dBc sein.

### 7.6.3 Prüfen der Pegel-Dynamik der Pulsmodulation

• Einstellung:

LEVEL 19 dBm

- \_ An die Geräte-RF-Buchse einen Spektrumanalysator anschließen.
- \_ An die PULSE-Buchse 0 V anlegen.
- \_ Der RF-Pegel muß bei 70 MHz < -51 dBm sein.
- \_ Der RF-Pegel darf im Frequenzbereich 70 MHz < f < 520 MHz linear bis auf < -46 dBm ansteigen.</p>
- \_ Der RF-Pegel muß im Frequenzbereich 520 MHz < f < 800 MHz < 46 dBm bleiben.
- \_ Der RF-Pegel darf im Frequenzbereich 800 MHz < f < 2080 MHz linear bis auf < -16 dBm ansteigen.

Der typische RF OFF-Pegel liegt 10 dB unter den angegebenen Werten.

# 7.6.4 Prüfen der Schaltzeiten der Pulsmodulation

· Einstellung:

LEVEL

19 dBm

RF

50 MHz

An die Geräte-RF-Buchse ein Oszilloskop mit 50 Ohm Eingangswiderstand anschließen.

\_ An die PULSE-Buchse ein TTL-Signal mit f = 1 MHz anlegen.

\_ Die Anstiegs- und Abfallzeit (10/90%) der Einhüllenden des RF-Signals muß < 20 ns sein.</p>

\_ Die Verzögerungszeit der Einhüllenden gegenüber dem Steuersignal am PULSE Eingang (50%) muß < 200 ns sein.

## 7.6.5 Prüfen der Pegelgenauigkeit

• Einstellung:

LEVEL

0 dBm

RF

9 kHz ... 2080 MHz

- \_ An die Geräte-RF-Buchse einen Leistungsmesser anschließen.
- \_ Der RF-Pegel muß 0 dBm  $\pm$  1 dB betragen. Typisch sind Abweichungen  $<\pm0.1$  dB nach der Kalibrierung des Ausgangspegels (siehe dazu Band 1 Kapitel 6.4).

# 7.7 Externe Schnittstellen

Pin	Name	Ein/Ausgang	Herkunft/Ziel	Wertebereich	Signalbeschreibung
X1.01	GND				
X1.02	SERDAT	Eingang	CPU	HCMOS-Pegel	wird nicht verwendet
X1.03	GND				
X1.04	SERCLK	Eingang	CPU	HCMOS-Pegel	wird nicht verwendet
X1.05	GND				
X1.06	ELSTB	Eingang	CPU	HCMOS-Pegel	wird nicht verwendet
X1.07	GND	ļ			
X1.08	OVERLOAD	Ausgang	CPU	HCMOS-Pegel	wird nicht verwendet
X1.09	GND				
X1.10	PULSE-INV	Eingang			wird nicht verwendet
X1.11	VA-5P	Eingan <del>g</del>	Netzteil X21.5	5.10V5.25V	Versorgungsspannung analog
X1.12	VA-5P	Eingang	Netzteil X21.5	5.10V5.25V	Versorgungsspannung analog
X1.13	VA15-P	Eingang	Netzteil X21.13	14.80 V15.75 V	Versorgungsspannung analog
X1.14	VA15-P	Eingang	Netzteil X21.13	14.80 V15.75 V	Versorgungsspannung analog
X1.15	VA15-N	Eingang	Netzteil X21.19	-15.75V14.85V	Versorgungsspannung analog
X1.16	VA15-N	Eingang	Netzteil X21.19	-15.75V14.85V	Versorgungsspannung analog
X2	FOPU	Eingang	OPUY1/2	11 19 dBm	9 kHz 2080 MHz
Х3	PULSE	Eingang	Rückwand	HCMOS-Pegel	DC 1 MHz
X4	FPOW	Ausgang	Eichleitung X2	11 19 dBm	9 kHz 2080 MHz
X5	VDETPOW	Ausgang	OPUY1/2	0 5 V	DC 100 kHz



SERVICE INSTRUCTIONS

**Power Module** 

1062.7240.01

## Contents

7	Test	ting and Repair of the Module	5
	7.1	Function Description	5
	7.2	Test Instruments and Utilities	5
	7.3	Troubleshooting	5
		7.3.1 Errors Occurring Only in the Range $f_{\mbox{\scriptsize RF}}$ < 10 MHz	6
		7.3.2 Errors Occurring Only in the Range $\rm f_{RF} > 10~MHz \ldots$	6
		7.3.3 Errors in the Range 9 kHz < $f_{\mbox{RF}} \leq$ 2080 MHz	6
	7.4	Testing and Adjustment	6
		7.4.1 Testing the Power Consumption	7
		7.4.2 Testing the Operating Points of the Amplifier Stages.	7
		7.4.3 Testing the Pulse-modulator Control	7
		7.4.4 Testing the Detector Voltage at the Output VDETPOW	8
		7.4.5 Adjusting the Detector Linearity at the Output FPOW	8
	7.5	Disassembly and Assembly	8
		7.6.1 Maximum Output Level Check	9
		7.6.2 Harmonics Suppression Check	9
		7.6.3 Checking the Dynamic Range of Pulse Modulation	9
		7.6.4 Checking Switching Times of Pulse Modulation 1	0
		7.6.5 Level Accuracy Check	0
	7 7	Eutornal Interfaces 1	n

Parts list List of coordinates Circuit diagram Component layout diagram

#### 7.1 Function Description

The RF signal from the output module OPUY1 or OPUY2 is provided at the input FOPU, divided by means of a signal divider (R91, R92) and amplified in identical paths. Each path contains a pulse modulator which is followed by an RF amplifier. One amplifier output passes via the FPOW output to the attenuator, the other one to the detector (V13). The RF voltage is rectified, there. The directional voltage is linearized (N6) and routed via the VDETPOW output to the motherboard and then to the output unit OPUY1 or OPUY2 as actual value for amplitude control in the frequency range f > 10 MHz.

Only the pulse modulator followed by the RF amplifier 1 is controlled, the other one assumes always the On state. Control is effected via the PULSE input. Level (EMF) or HIGH level at the input lead to RF ON, Low means RF OFF. This polarity may be inverted by plugging on the jumper P1-P2. The amplifiers N1 and N2 convert the TTL signal to the control level 0 V/-8 V for the GaAs switches D2 and D3.

The RF amplifiers are fed from constant-current sources V4 and V5, the drain voltages are regulated via the amplifiers N3 and N4. The amplifier stages V11 and V12 provide a gain of approx. 10 dB. The pulse modulators preceding the amplifier stages have an attenuation of approx. 2 dB with 2 GHz. The signal divider (R91, R92) has a transmission loss of 6 dB.

### Test Instruments and Utilities

- Spectrum analyzer (e.g., FSBS)
- Oscilloscope (e.g., BOL)
   DC voltmeter (multimeter, e.g., UDL33)
- RF level meter (e.g., NRVD with sensor Z51)
- 10-dB attenuator with N connectors (e.g., DNF)
- $50-\Omega$  termination (e.g., RAD)

#### Troubleshooting 7.3

Before opening the instrument, it is useful to first perform the LEVEL PRESET calibration and localize possible error sources using the diagnostic voltages. The special function 102 (detector voltage FOPU output) allows for checking the RF source for the Power Module: with a RF level of -30 dBm and RF frequencies > 10 MHz the typical voltage values are in the range from 0.7 to 1.3 V.

#### Errors Occurring Only in the Range $f_{RF}$ < 10 MHz 7.3.1

incorrect RF level at X4 FPOW Check signal divider R91/R92,

pulse modulator D2/D3 and RF

amplifier 1 with f = 100 kHz using

an oscilloscope.

bad AM distortion

Check current source V4 and the drain-voltage control N3.

#### 7.3.2 Errors Occurring Only in the Range fre > 10 MHz

incorrect RF level at X4 FPOW The gain of pulse modulators D2/D3

and D4/D5 or of the RF amplifiers 1 and 2 is not equal or the RF voltage at the output of RF amplifier 2 is not rectified correctly. Check detector and

linearization circuit.

AM distortion too high Test and adjust detector and

linearization circuit.

#### Errors in the Range 9 kHz $< f_{RF} \le 2080$ MHz 7.3.3

no level at X4 FPOW The control voltage of the AM

modulator (special function 107)
must be > 12 V, otherwise, the level control does not work correctly or the reference value

of RFLEV D/A converter is incorrect (the error is then located in the output units OPUY1

or OPUY2).

Check signal divider R91/R92, pulse modulator D2/D3 and RF

amplifier 1 with f = 100 kHz using

an oscilloscope.

harmonics too high Check the current source V4 and

the drain-voltage control N3.

AM distortion too high Test and adjust detector and

linearization circuit.

pulse modulation with incorrect polarity

pulse modulation not possible

or incorrect rise and/or fall times

on/off-ratio with pulse

modulation too low

Jumper P1-P2 must not be plugged,

check EXOR function of Dl

Check control signals in the signal chain Dl, Nl and N2 to D2

and D3

Check D2 and D3 and RC lowpasses

of the control lines

# 7.4.1

### Testing the Power Consumption

• Setting:

PRESET

The currents can either be measured at the connector X1 or by means of the voltage drop at measurement resistors. If several measurement resistors are provided, the individual currents have to be added.

Connector	Voltage	Power consumption	Resistor ( 2 Ω)
X1.11 and X1.12	+5 V	35 to 45 mA	R66
X1.13 and X1.14	+15 V	340 to 360 mA	R67 and R68
X1.15 and X1.16	-15 V	45 to 55 mA	R69, R70 and R72

# 7.4.2 Testing the Operating Points of the Amplifier Stages

Test point	Rated voltage	Remark
V11 Drain	6.60 ± 0.5V	RF AMPLIFIER 1
V11 Gate	$-1.0 \pm 0.5V$	RF AMPLIFIER 1
V4 Collector	7.25 ± 0.2V	current source
U15VA1 - V4 Emitter	1.21 ± 0.02V	I = 150 mA
V12 Drain	6.60 ± 0.5V	RF AMPLIFIER 1
V12 Gate	$-1.0 \pm 0.5V$	RF AMPLIFIER 1
V5 Collector	7.25 ± 0.2V	current source
U15VA2 - V5 Emitter	1.21 ± 0.02V	I = 150 mA

### 7.4.3 Testing the Pulse-modulator Control

Check the voltages according to the table below: High = 5 V, Low = 0 V.

P1-P2	PULSE	D1/10	D1/8	D1/3	D1/6	N1/6	N2/6	D2/5	D3/5	D2/4	D3/4
not connected	High	High	Low	Low	Hìgh	0 V	-7.9 V	0 V	0 V	-7.9 ♥	-7.9 V
connected	Low	High	Low	Low	High	0 V	-7.9 V	0 V	0 V	-7.9 V	-7.9 V
not connected	Low	Low	High	Hìgh	Low	~7.9 V	0 V	-7.9 V	-7.9 V	0 V	0 V
connected	High	Low	High	High	Low	-7.9 V	0 V	-7.9 V	-7.9 V	0 V	0 V

Remove jumper P1-P2.

7.4.4 Testing the Detector Voltage at the Output VDETPOW

• Setting: RF 100 MHz

Switch on special function 49 (level correction inactive)

\_ Check dc voltage at VDETPOW according to the following table:

Tale 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1					
RF level in dBm	-30	11.1	13	16	10
Voltage in V	2 0	1 00		10	19
VOICAGE III.V	2.0	1.27	1.58	2.23	3 14
				~	→ • * **

Switch on special function 50 (level correction active)

# 7.4.5 Adjusting the Detector Linearity at the Output FPOW

· Setting:

RF

100 MHz

LEVEL

11.1 dBm

\_ Measure and note output level at the RF output of the instrument (= reference level)

• Setting:

Switch on special function 1 (non-interrupting level

setting)

LEVEL -8.9 dBm

Use POT R36 such that the measured level is 20 dB below the previously measured reference level. Repeat adjustment once, since the reference value changes by using R36; the accuracy of the 20-dB attenuation must be ± 0.1 dB.

# 7.5 Disassembly and Assembly

Remove top cover. The module is screwed to the frame and plugged in the transverse panel. The module can be removed after removing the screw and disconnecting the coaxial connections at X2, X3, X4, X5 and the connector X1.

### 7.6 Final Test

### 7.6.1 Maximum Output Level Check

- Setting: LEVEL 25 dBm
- Connect a power meter to X226 FOPU, make sure not to exceed the maximum RF power permitted! If necessary, an appropriate attenuator pad must be series-connected.
- \_ Vary the RF frequency from 9 kHz to 2080 MHz. The RF level must remain > 20 dBm.

### 7.6.2 Harmonics Suppression Check

- Setting: LEVEL 16 dBm
- Connect a spectrum analyzer to the RF connector of the instrument.
- \_ The level of the harmonics must be < -25 dBc.

# 7.6.3 Checking the Dynamic Range of Pulse Modulation

- Setting: LEVEL 19 dBm
- \_ Connect a spectrum analyzer to the RF connector of the instrument.
- \_ Apply 0 V to the PULSE connector.
- \_ The RF level must be < -51 dBm with 70 MHz.
- \_ The RF level may increase linearly up to < -46 dBm in the frequency range 70 MHz < f < 520 MHz.
- \_ The RF level must remain < -46 dBm in the frequency range 520 MHz < f < 800 MHz.
- \_ The RF level may increase linearly up to < -16 dBm in the frequency range 800 MHz < f < 2080 MHz.

The typical RF-OFF level is 10 dB below the given values.

### 7.6.4 Checking Switching Times of Pulse Modulation

• Setting: LEVEL 19 dBm RF 50 MHz

Connect an oscilloscope with an input impedance of 50  $\Omega$  to the RF connector of the instrument.

\_ Apply a TTL signal with f = 1 MHz to PULSE.

- \_ The rise and fall time (10/90%) of the RF-signal envelope must be < 20 ns.</p>
- \_ The delay of the envelope compared to the control signal at the PULSE input (50%) must be < 200 ns.

## 7.6.5 Level Accuracy Check

• Setting: LEVEL 0 dBm

RF 9 kHz to 2080 MHz

- \_ Connect a power meter to the RF connector of the instrument.
- \_ The RF level must be 0 dBm  $\pm$  1 dB. Typical deviations after calibration of the output level are  $< \pm 0.1$  dB (cf. To Vol. 1, Section 6.4).

# 7.7 External Interfaces

Pin	Name	Input/Output	Origin/Destination	Range	Signal description
X1.01	GND				
X1.02	SERDAT	Input	CPU	HCMOS level	not used
X1.03	GND				
X1.04	SERCLK	Input	CPU	HCMOS level	not used
X1.05	GND				
X1.06	ELSTB	Input	CPU	HCMOS level	not used
X1.07	GND	j	1		}
X1.08	OVERLOAD	Output	CPU	HCMOS level	not used
X1.09	GND				1
X1.10	PULSE-INV	Input		1	
X1.11	VA-5P	Input	Power supply X21.5	5.10 V to 5.25 V	not used
X1.12	VA-SP	Input	Power supply X21.5	5.10 V to 5.25 V	Analog supply voltage
X1.13	VA15-P	Input	Power supply X21.13	14.80 V to1 5.75 V	Analog supply voltage
X1.14	VA15-P	Input	Power supply X21.13	14.80 V to 15.75 V	Analog supply voltage
X1.15	VA15-N	Input	Power supply X21.19	-15.75 V to -14.85 V	Analog supply voltage
X1.16	VAl5-N	Input	Power supply X21.19	-15.75 V to -14.85 V	Analog supply voltage
X2	FOPU	Input	OPUY1/2	11 to 19 dBm	9 kHz to. 2080 MHz
Х3	PULSE	Input	Rear panel	HCMOS level	DC to 1 MHz
X4	FPOW	Output	Attenuator X2	11 to 19 dBm	9 kHz to 2080 MHz
X5	VDETPOW	Output	OPUY1/2	0 to 5 V	DC to 100 kHz



Schaltteillisten
numerisch geordnet
Part lists
in numerical order
Listes des pièces détachées
par numéros de référence

Kennz. Comp. No.	Banannung Designation		Sachnummer Stock No.	Hersteller Menufecturer	Bazeichnung Designation		eiten in eined in
	XX VARIANTENERKLAERUN IDENTIFICATION OF MOD	ELS					
	VARO2=GRUNDAUSFUEHRUN MODO2=BASIC_MODEL	<b>ن</b>			_L		
C1	CC 33NF+-10% 25V HDK		1051.4697.00	AVX	CM105X7R333K25AT		
C10	CC 39PF+-1% 50VNPO	0603	0009.9730.00	VITRAMON	VJ0603A *** FXAT		
13 C14	SMD-CERAMIC-CAPACITOR CC 33NF+-10% 25V HDK		1051.4697.00	AVX	CM105X7R333K25AT		
29 c30	ERAMIC CHIP CAPACITO CE 10UF+-20%35V RUND		CE 0009.5605.00		EEV HB 1V 100P		
C31	SMD-ELECTROLYTIC CAPA CE 10UF+-20%35V RUND	CIT.	CE 0009.5605.00		EEV HB 1V 100P		
	SMD-ELECTROLYTIC CAPA	CIT.					
C32	TANTALUM SMD-CAPACITO		E 0007.7246.00	SPRAGUE	293D 106 X9 025 D2T		
C33	NICHT BESTUECKT   CE 10UF +-10% 25V   TANTALUM SMD-CAPACITO		E 0007.7246.00	SPRAGUE	293D 106 X9 025 D2T		
C34	NICHT BESTUECKT CC 10PF+-0,1 50V NPO (		°C 0000 4567 00	ANZ	0602 E4 *** 04700 !		
	SMD-CERAMIC-CAPACITOR		C 0009.4567.00		D603 5A *** BATOOJ		
C35	TANTALUM SMD-CAPACITO		E 0007.7281.00	KEMET	T491 C 106 K 010 AS		
C36	NICHT BESTUECKT CE 10UF+-20%35V RUND S		E 0009.5605.00	PANASONIC	EEV HB 1V 100P		
C37	SMD-ELECTROLYTIC CAPAC CC 15PF-+1% 50VNPO C		0009.8227.00	VITRAMON	VJ0603A *** BXAT		
C38	SMD-CERAMIC-CAPACITOR CC 15PF-+1% 50VNPO (	603	0009.8227.00	VITRAMON '	VJ0603A *** BXAT		
C39	SMO-CERAMIC-CAPACITOR CC 33NF+-10% 25V HDK (		1051.4697.00		CM105X7R333K25AT		
C40	ERAMIC CHIP CAPACITOR CC 47PF+-1% 50VNPO C	₹	C 0009.4644.00		/J0603A *** FXAT		
C41	SMD-CERAMIC-CAPACITOR		E 0007.7252.00		2930 105 X9 010 D2T		
C42	TANTALUM-SMD-CAPACITO	1			1		. 4
44	CE 1UF +-10% 25V EIAS TANTALUM SMD-CAPACITOR	1	E 0007.7217.00		2930 105 X9 025 B2T		
C45	TANTALUM-SMD-CAPACITOR	:	E 0007.7252.00		293D 105 X9 010 02T		
C46	CE 1UF +-10% 25V EIA3 TANTALUM SMO-CAPACITOR		E 0007.7217.00		293D 105 X9 025 82T		
C47	CC 0,7PF+-0,05PF C SMD-CERAMIC CAPACITOR	603	0010.7150.00	AWX (	0603 5J OR7 AAW TR		
C48	CC 0,7PF+-0,05PF C SMD-CERAMIC CAPACITOR	603	0010.7150.00	AWX (	0603 5J OR7 AAW TR		
C49	CC 1,0NF+-10%50V HOK C SMD-CERAMIC-CAPACITOR	603 C	C 0009.4938.00	MURATA (	GRM39X7R***K50C500PT		
C50	CC 15PF-+1% 50VNPO C SMO-CERAMIC-CAPACITOR	603	0009.8227.00	VITRAMON \	/J0603A *** 8XAT		
C51	CC 100PF+-1% 50VNPO C SMD-CERAMIC-CAPACITOR	603 C	C 0009.4680.00	MURATA (	GRM39COG***F5OPT		
C52	CC 33NF+-10% 25V HDK C ERAMIC CHIP CAPACITOR		1051.4697.00	AVX (	CM105X7R333K25AT		
C53	CC 15PF-+1% 50VNPO C		0009.8227.00	VITRAMON \	/J0603A *** BXAT		
C54	SMD-CERAMIC-CAPACITOR CC 33NF+-10% 25V HDK C		1051.4697.00	AVX (	M105X7R333K25AT		
C55	CC 100PF+-1% 50VNPO C		С 0009.4680.00	MURATA (	GRM39COG***F50PT		
C56	SMD-CERAMIC-CAPACITOR CC 100PF+-1% 50VNPO C	603 C	C 0009.4680.00	MURATA (	SRM39COG***F5OPT		
C57	SMD-CERAMIC-CAPACITOR CC 33NF+-10% 25V HDK C	603	1051.4697.00	AVX (	M105X7R333K25AT		
C5B	ERAMIC CHIP CAPACITOR CC 100PF+-1% 50VNP0 0		C 0009.4680.00	de .	SRM39CDG***F50PT		
C59	SMD-CERAMIC-CAPACITOR CC 100PF+-1% 50VNPO C		C 0009.4680.00		SRM39COG***F50PT		
C60	SMD-CERAMIC-CAPACITOR CE 10UF+-20%35V RUND S		E 0009.5605.00				
C61	SMD-ELECTROLYTIC CAPAC CE 10UF+-20%35V RUND S	IT.	E 0009.5605.00				
C62	SMD-ELECTROLYTIC CAPAC		0010.7150.00				
002	SMD-CERAMIC CAPACITOR NICHT BESTUECKT		00.007130.007	min (	0603 5J OR7 AAW TR		
	-	Num.	المار عام المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار المار ال	eta étir	6		Diess_31-
MENP5	413 3PUA Ä! Da	lum ite	Schaltteillis Parts list		Sachnummer Stock No.		Biatt-Nr. Page
ROHDI	E&SCHWARZ 05 16.0	9.97	ED POWERMODUL		1062.7240.01	SA	1+

Kennz. Comp. No.	Benennung Designation	Sechnummer Stock No.	Hersteller Manufacturer	Bezeichnung Designetion	enthalten in contained in
C63	CC 0,7PF+-0,05PF 0603 SMD-CERAMIC CAPACITOR	0010.7150.00	AWX.	0603 5J OR7 AAW TR	
C64	NICHT BESTUECKT CC 0,7PF+-0,05PF 0603 SMD-CERAMIC CAPACITOR	0010.7150.00	AWX	0603 5J OR7 AAW TR	
C65	NICHT BESTUECKT CC 0,7PF+-0,05PF 0603 SMD-CERAMIC CAPACITOR	0010.7150.00	AWX	0603 5J OR7 AAW TR	
C66	NICHT BESTUECKT CC 220PF+-1% 50VNPO 0603 SMD-CERAMIC-CAPACITOR	CC 0009.4721.00	MURATA	GRM39COG***F50PT	
D1	BL 74ACT86SC 4X 2IN-EXOR	BL 2005.4307.00	HARRIS	(CD74)ACT86(M)	
D2 5	QUAD 2-INPUT EXOR GATE BM SW-239 GAAS SPDTSWITCH GAAS RF-SWITCH	0853.5579.00	ANZAC	SW239	
L1	LD 2,2UH 10% 0,27A 1210	LD 0520.7B70.00	SIEMENS	BB2422-A1222-K100	
L2	SMD-INDUCTOR LD 2,2UH 10% 0,27A 1210 SMD-INDUCTOR	LD 0520.7870.00	SIEMENS	B82422-A1222-K100	
L3	LD 47 NH+-10% O,3A 0805 SMD-MULTILAYER INDUCTOR	LD 0009.6824.00	ΤΟΚΟ	LL2012-F47NK	
L4	LD 47 NH+-10% 0,3A 0805	LD 0009.6824.00	токо	LL2012-F47NK	
L5	SMD-MULTILAYER INDUCTOR LO 1UH 10% 0,38A 1210	LD 6006.0130.00	SIEMENS	B82422-A1102-K100	
L6	SMD-INDUCTOR LD 1UH 10% 0,38A 1210	LD 6006.0130.00	SIEMENS	B82422-A1102-K100	
L7	SMD-INDUCTOR LD 100UH 10% 0,06A 1210	LD 0007.9261.00		B82422-A1104-K100	
L8	SMO-INDUCTOR LD 22 NH+-10% 0,3A 0603	LD 0009.6730.00	токо	LL160B-FK	
L9	SMD-MULTILAYER INDUCTOR LD 22 NH+~10% 0,3A 0603 SMD-MULTILAYER INDUCTOR	LO 0009.6730.00	токо	LL1608-FK	
L10 21 L26	XX ENTHALTEN IN INCLUGEO IN LO 1000UH*-20%0,3A SMD	0048.4041.00	COTI CDAET	003316P-105	
L28	INDUCTOR				
L29	LD 1000UH*-20%0,3A SMO INOUCTOR LD SP-OROSSEL 68UH 0,68A CHOKE	0048.4041.00 1081.1821.00		003316P-105 CDR74-680	
N1	80 CLC430AJE CF OPAMP	2032.2524.00	COMLINEAR	CL(C)430AJE	
N2	IC CURRENT FEEOBACK OPAMP BO CLC430AJE CF OPAMP	2032.2524.00	COMLINEAR	CL(C)430AJE	
N3	IC CURRENT FEEDBACK OPAMP BO TLO72ACD 2XFET OPAMP	0803.1057.00		TL 072 ACDR	
N4	OPERATIONAL AMPLIFIER BO TLO72ACO 2XFET OPAMP	0803.1057.00	TEXAS	TL 072 ACDR	
N5	OPERATIONAL AMPLIFIER BO TLO74ACD 4XFET OPAMP	0007.7823.00	TEXAS	TLO74A(CD)	
N6	OPERATIONAL AMPLIFIER BO AD744KR FET OPAMP BIFET OPAMP	0854.1754.00	ANALOG_DEV	(AD)744KR	
P1 7	VL EINPRESSSTIFT L=6,8	VL 0010.7250.00	AMP	1-928776-5	
7 P9	PIN VL EINPRESSSTIFT L≃6,B	VL 0010.7250.00	AMP	1-928776-5	
P10	PIN VL EINPRESSSTIFT L=6,B PIN	VL 0010.7250.00	AMP	1-928776-5	
R1	RG 27,4 OHM+-1%TK100 1206	RG 0007.5508.00	ROEDERSTEI	DC2 27,40HM 1%TK100	
R2	RESISTOR CHIP RG 100R +-1% TK200 0603	RG 0009.5334.00		CR 0603 100R 1%TK200	
4 R5	SMD-RESISTOR EIAO603 RG 82,5 OHM+-1%TK200 0603	0009.9052.00			
R6	SMD-RESISTOR EIAO603 RG 7K5 +-1% TK200 0603	0010.8440.00	_;		
R7	SMD-RESISTOR EIAO603 RG 7K5 +-1% TK200 0603	0010.8440.00			
R8	SMD-RESISTOR EIAO603 RG 1BR2 +-1% TK200 0603	0010.8385.00		and the second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second second s	
R9	SMD-RESISTOR EIAO603 RG 18R2 +-1% TK200 0603 SMD-RESISTOR EIAO603	0010.8385.00			
MENP5	413 3PUA Ät Detum	Schaltteille Parts list		Sachnummer Stock No.	Sistt-Ni Page
® DOUDE	05 16.09.97			1062.7240.01	

	Kennz. Comp. No.	Benenni Designa		<del></del>		Sachnummer Stock No.	Hersteller Manufacturer		ezelchnung esignation			ilten In Ined in
	R10	RG 10K +-1% TK		0603	RG	0009.5357.00	DRALORIC			1% TK200		
	19 R20	SMD-RESISTOR E RG 15K +-1% TK		603 0603		0009.7043.00	DRALORIC	CR	0603 15K	1% TK200		
	R21	SMD-RESISTOR E RG 392R+-1% TK		603 0603		0010.9300.00						
	R22	SMD-RESISTOR E		603 0603	١	0010.9300.00						
	R23	SMD-RESISTOR E RG 10K +-1% TK			RG	0009.5357.00	DRALDRIC	CR	0603 10K	1% TK200		
	28 R29	SMD-RESISTOR E	IAO			0009.7043.00				1% TK200		
	R30	SMD-RESISTDR E	IAO	503	BG.	0006.8849.00						
	R31	CHIP RESISTOR RG 68,1 DHM+-1	_			0006.8849.00						
	R32	CHIP RESISTOR RG 10K +-1% TK		0603	1	0009.5357.00				1% TK200		
	35 R36	SMD-RESISTOR EL	IAO	503	ĺ	0007.9626.00			-2KDHM	174 11200		
		POTENTIOMETER		0603	3					OH		
	R37	RG 3K3 +-1% TK2 SMD-RESISTOR E	IAO	603		0009.7014.00				Он		
	R38	RG 3K3 +-1% TK2 SMD-RESISTOR EI	[AO6			0009.7014.00				OH		
	R39	RG 56,2 OHM+~1%		_	1	0006.8826.00						
	R40	RG 56,2 OHM+-19 CHIP RESISTOR			l	0006.8826.00						
	R41	RG 27,4 OHM+-19 RESISTOR CHIP			KG	0007.5508.00	אטכטכא2151	DC2	∠1,4UHM	1/41/4100		
	R42	RG 39K2 +-1% TH SMD-REGISTER			_	0010.9823.00	DD 41 OD 7 C	CD.	0000 41/	II/ TK 000		
	R43	RG 1KO +-1% TK2 SMD-RESISTOR E1	IAOE			0009.5340.00			0603 1K 1	·		
ı	R44	RG 1KO +-1% TK2 SMD-RESISTOR E1	IAOE		RG	0009.5340.00			0603 1K 1			
	R45	RG 470R +- 1% TH SMD-RESISTOR EI	AOE	603		0009.6976.00				ОН		
	R46	RG 1K5 +-1% TK2 SMD-RESISTOR EI	AOE			0009.6999.00				он		
	R47	RG 330R +-1% TK	AOE	603		0009.6960.00	DRALURIC	CR	0603	0		
	R48	RG 270R +- 1% TK SMD-RESISTOR EI	AOE	03 270R		0010.9581.00						- 1
	R49	RG 330R +-1% TK SMD-RESISTOR EI	AOE	803		0009.6960.00	DRALURIC	CR	0603	0		ļ
	R50	RG 270R +-1% TK SMD-RESISTOR EI	AOE	03 270R		0010.9581.00	00000000			611		
	R51	RG 110 OHM+-1%T SMD-RESISTOR EI	AOE	803		0009.9481.00				ОН		
	R52	RG 110 OHM+~1%T	AOE	603		0009.9481.00	KUEDEKSTEI	ווע	0603	он		
	R53	RG 392R+~1% TK2 SMD-RESISTOR EJ	AOE			0010.9300.00	DDEDEDETET	D11	0500	011		
1	R54	RG 47OR +-1% TK SMD-RESISTOR EI	AOE	803		0009.6976.00	KDEDEKSIET	ווט	0603	он		
	R55	RG 1K21 +-1% TK SMD-REGISTER			D.C.	0010.9817.00	DD NI OD TO	CD.	0500			
	R56	RG 10R +-1% TK2 SMD-RESISTOR EI	AOE	603		0009.5328.00			0603			
	R57	RG 10R +-1% TK2 SMD-RESISTOR EI	AOE			0009.5328.00			0603 24 20UM	19/TV 100		
	R58 63	RG 24,3 OHM+-1% RESISTOR CHIP				0007.5495.00				1/41K 100		
	R64	RG O-OHM WIDERS RESISTDR CHIP O	)-OF		KG	0007.5108.00	DKALUKIU	CK	1206			
	R65	RG O-DHM WIDERS	4AT		RG	0007.5108.00	DRALDRIC	CR	1206			
	DCC	RESISTOR CHIP O	Г			0007 5100 00	DDALODZO	CB	1906			
	R66	RG O-OHM WIDERS	)-D}	(M		0007.5108.00			1206			
	R67	RG 2,0 DHM+-1%1 CHIP-RESISTDR			l	0007.8336.00		RC				
	R68	RG 2,0 OHM+-1%1 CHIP-RESISTOR			l	0007.8336.00		RC ·	1206			
	R69	RG O-OHM WIDERS RESISTOR CHIP O			"	00.001 . 100.00	DKALUKIC	CK	1200			
	MENP5	413 3PUA	ÄI	Datum Date		Schaltteill Parts lis				Sachnummer Stock No.		Biatt-Nr. Page
	<b>⊗</b>		05	16.09.97		ED POWERMODUL			1062.	7240.01	SA	3+

Kennz. Comp. No.	Bener Design	nnung nation			Sachnummer Stock No.	Hersteller Manufacturer	Bezeichnung Designetion			alten in eined in
R70 .	RG O-OHM WIDE			RG	0007.5108.00	ORALORIC	CR 1206			
R71	RESISTOR CHIP RG 1KO +-1% T	K200	0603	RG	0009.5340.00	DRALORIC	CR 0603 1	K 1% TK200		
R72	SMD-RESISTOR RG O-DHM WIDE	RSTA	ND-CHIP	RG	0007.5108.00	DRALORIC	CR 1206			
R73	RESISTOR CHIP RG 10K +-1% T SMD-RESISTOR	K200 E1A0	0603	RG	0009.5357.00	DRALORIC	CR 0603 1	OK 1% TK200		
R74	NICHT BESTUEC	K200	0603	RG	0009.5370.00	ORALORIC	CR 0603 1	M 1% TK200		
76 R77	SMO-RESISTOR RG 560R +-1% SMD-RESISTOR	TK20	0603		0009.9630.00	DRALORIC	CR 0603	0		
R78	RG 680K +-1% SMD-RESISTOR	TK 200	0603		0009.7137.00	ROEOERSTEI	011 0603	он		
R79	RG 680K +-1% SMD-RESISTOR	TK20	0603		0009.7137.00	ROEDERSTEI	D11 0603	он		
R80	RG 39R2 +-1% SMD-RESISTOR	TK200	0603		0010.9400.00					
RB1	RG 39R2 +-1% SMD-RESISTOR	TK200	0603		0010.9400.00					
R82	RG 560R +-1%	TK200	0603		0009.9630.00	DRALORIC	CR 0603	0		- 113
R83	RG 560R +-1% SMD-RESISTOR				0009.9630.00	ORALORIC	CR 0603	0		
R84	RG 4R75 +-1% SMD-RESISTOR				0010.8379.00					
R85	RG 1KO +-1% TH SMD-RESISTOR H	EIAOE		RG	0009.5340.00	ORALORIC	CR 0603 1	( 1% TK200		
R86	RG 4R75 +-1% SMD-RESISTOR	IAOE	503		0010.8379.00					
R87	RG 1KO +-1% TH SMD-RESISTOR	EIAOE		RG	0009.5340.00		CR 0603 1H	1% TK200		
R88	RG 22K +-1% TH SMD-RESISTOR E	IAO			0009.7050.00	ROEOERSTEI	D11 0603	Он		
R89	RG 2KO +-1% TH SMD RESISTOR		0603		1097.6328.00					
R90 R91	RG 2KO +-1% TH SMD RESISTOR		0603		1097.6328.00	nor orner-	D44 0000			
94 R95	RG 51.0 OHM+-1 SMD-RESISTOR E RG 150R +-1% 1	IAOE	103		0009.9030.00			ОН		
98 R99	SMD-RESISTOR E	IAO	603		0009.6947.00			ОН		
104 R105	SMD-RESISTOR E	IAOE			0009.6924.00			НО		
R106	SMD-RESISTOR E	IA06	03		0010.8427.00	COLUCIATION	211 0003	он		
108 R109	SMD-RESISTOR E RG 100K +-1% T	IA06	03	RG	0009.5363.00	DRALORIC	CR 0603 10	OK 1%TK200		
112 R113	SMD RESISTOR RG 357R +-1% T	K200			1097.6405.00					
R114	SMD RESISTOR RG 357R +-1% T				1097.6405.00					
R115	SMD RESISTOR RG 3K92 +-1% T				0010.8427.00					
R116	SMD-RESISTOR E	K200	0603		0010.8427.00					
R117	SMD-RESISTOR E	200	0603		0009.9646.00	ROEOERSTEI	D11 0603	ОН		ĺ
R118	SMD-RESISTOR E RG 56R +-1% TK SMD-RESISTOR E	200	0603		0009.9646.00	ROEDERSTEI	011 0603	Он		
R119	RG 562 OHM+-1%			RG	0006.9068.00	ROEDERSTEI	DC2 5620HW	1%TK 100		
R120	RG 562 OHM+-1% CHIP RESISTOR	TK 10	0 1206	RG	0006.9068.00	ROEDERSTEI	DC2 5620HM	1%TK 100		
	NICHT BESTUECK NOT FITTED"	T"								
R121	RG 121 OHM+-1% CHIP RESISTOR	TK 10	0 1206	RG	0006.8903.00	ROEDERSTEI	DC2 1210HM	1%TK 100		- 1
R122	RG 121 OHM+-1% CHIP RESISTOR NICHT BESTUECK		0 1206	RG	0006.8903.00	ROEDERSTEI	DC2 1210HM	1%TK 100		
R123	NOT FITTEO" RG 39R2 +-1% T SMD-RESISTOR E	K200			0010.9400.00		·			
MENP5	413 3PUA	Äi	Datum Date		Schalltailli Perts IIs			Sachnummer		Blatt-Nr.
						. 196	4000	Stock No.		Page
ROHDE	&SCHWARZ	05	16.09.97	E	D PDWERMOOUL		1062	2.7240.01	SA	4+

Für diese Unterlage behalten wir uns alle Rechte vor.

Γ	Kennz. Comp. No.	Benenn Dasigna			T	Sachnum Stock		Herstallar Manufacturer		azaichnung asignation			altan in alnad in
ľ	R124	RG O-OHM WIDER	STA		T			PHILIP5_CO					
	R125	O-OHM RESISTOR RG O-OHM WIDER O-OHM RESISTOR NICHT BESTUECK	STA	ND 0603		0009.9	369.00	PHILIPS_CO	RC2	21 O OHM			
ı	R126	RG 150K +-1% T	K20			0009.7	095.00	ROEDERSTEI	D11	0603	он		
	R127	SMD-RESISTOR E RG 39K2 +-1% T				0010.9	B23.00						
1	R12B	SMD-REGISTER RG 39,2 OHM+-1	%TK	100 1206	RG	0007.5	543.00	ROEDERSTEI	DC2	39,20HM	1%TK 100		
Ī	133 R134	RESISTOR CHIP RG 1MO +-1% TK			RG	0009.5	3 <b>70.</b> 00	DRALORIC	CR	0603 1M 1	% TK200		
	143 R144	5MD-RESISTOR E RG 39R2 +-1% T	K20	0 0603		0010.9	400.00						
	R150	SMD-RE5ISTOR E RL 0,60W 8,25K RESISTOR			RL	0083.1	239.00	RESISTA	MK2				
	V1	AE BZV55/C4V7	0	.5W ZDI	ΑE	0006.9	822.00	PHILIPS	BZV	55B4V <b>7</b>			
	V2	ZENER DIODE AE BZV55/C4V7	0	.5W ZDI	AE	0006.9	822.00	PHILIPS	BZV	55B4V7			
	V3			V REFDI	AE	0418.0	029.00	COMPENSATE	1N8	27(A)			
ı	V4			1A TRAN		10B5.1	755.00	PHILIPS_SE	BSP	31			
	V5	7.1.2.1	60V	1A TRAN		10B5.1	755.00	PHILIP5_5E	В5Р	31			
	V6		<b>7</b> 5V	UDI	AD	0006.7	28B.00	PHILIPS	BA5	32 (L)			
ı	8 v9		70V	OUO UDI	AD	0911.0	092.00	VALV0	8AV	99			
ı	V10		<b>7</b> 0V	DUO UOI	ΑO	0911.00	092.00	VALVO	BAV	99	ĺ		
ı	V11	OIOOE AM SHFO186 SEL	_			1062.93	308.00						
	V12	TRANSISTOR GAAS	EC.	OV GAASF		1062.93	308.00				}		
İ	V13	TRANSISTOR GAAS AE 8AT62 1+1 40				1051.40	045.00	SIEMENS	BAT	62 (62)			ĺ
l	V14		70V	DUO UDI	AD	0911.00	92.00	VALVO	8AV	99			
l	V15	OIODE AE HSMS2810	S	CHOTTKY		0520.73	340.00	HEWLETT_PA	HSM	\$2810			
l	V16	DIOOE AE HSMS2810 OIODE	S	CHOTTKY		0520.73	340.00	HEWLETT_PA	HSM:	S28 10			
Ī	V17	NICHT BESTUECKT		CHOTTKY		0520 73	240 00	HEWLETT_PA	HCM	52010			İ
	V18	DIODE AE HSMS2810		CHOTTKY				HEWLETT PA					
	1.0	DIODE NICHT BESTUECK		CHOTIKI		0520.70	140.00	DEUTE I I TLY	пан.	32010			
	V19	AE HSMS2810 DIOOE		CHOTTKY		0520.73	340.00	HEWLETT_PA	H5M	S2810			
l	V20	AE HSMS2810 DIODE	S	CHOTTKY		0520.73	340.00	HEWLETT_PA	HSM	\$2810			
	V21	AE BZV55/C8V2 ZENER DIODE	0	,5W ZDI	ΑE	0006.98	374.00	PHILIPS	BZV	55B8V2			
	V22	AE BZV55/C8V2 ZENER DIODE	0	,5W ZDI	ΑE	0006 . 9E	374.00	PHILIPS	BZV:	55B8V2			
	V23	AE HSMS2825 14 SCHOTTKY DIODE				1010.62	214.00	HEWLETT_PA	H5MS	S2B25 L31	i		
	V24		1 5	CHOTTKY		1010.62	14.00	HEWLETT_PA	HSMS	S2825 L31	1		
	V25				AD	0911.00	92.00	VALVO	BAV	99			
	V26	AE BZV55/C5V6 ZENER DIDDE NICHT BESTUECKT	_	.5W ZDI	ΑE	0006.98	345.00	PHILIP5	BZV	55B5V6			
	V27	NOT FITTED"	<b>'</b> 5V	UDI	AD	0006.72	288.00	PHILIPS	BAS	32 (L)			
	X1	FP STECKERLEIST	ſΕ	16P.WIN	FΡ	<b>07</b> 3B.53	341.00	SIEMENS	V23!	535-A2210-	-162		
$\vdash$	MENP5	413 3PUA	ÄI	Datum Data			Schaltteitli: Parts iist				Sachnummer Stock No.		Blatt-Nr.
-	Δ			Sara						1000 -			Page
	<b>₩</b> ROHDE	E&SCHWARZ	05	16.09.97	E	D POWER	RMODUL			1062.7	240.01	SA	5+

	Kennz. Comp. No.	Bene Dasig	nnung nation	Sachnummer Stock No.	Hersteller Manufecturer	Bezeichnung Designetion	enti	aiten in teined in
	X2	FJ EINLOETBUC	CHSE SMA	1085.1726.00	SUHNER	82SMA-S-50-0-45/111		
	хз	FJ EINLOETBUC CONNECTOR	CHSE MMCX	1085.1532.00	SUHNER	82MMCXS50-0-2/111KE		
	X4	FJ EINLOETBUC	CHSE SMA	1085.1726.00	SUHNER	82SMA-S-50-0-45/111		
	X5	CONNECTOR FJ EINLOETBUC	HSE MMCX	1085.1532.00	SUHNER	82MMCXS50-0-2/111KE		
	Х6	CONNECTOR FJ EINLOETBUC CONNECTOR NICHT BESTUEC		1085.2045.00	IMS	1863.09.2620.001(003		
	Z1 6	LD SMO-T-FILT SMO-FILTER		1039.1362.00	MURATA	NFM61R20T332T1		
We dres and notatio vot.								
	MENP5	413 3PUA	Äl Datum	Schafttelli <b>l</b> s		Sachnummer		Biatt-Nr.
		&SCHWARZ	05 16.09.97	Parts list	<u>for</u>	1062.7240.01	SA	Page 6-



# XY-Liste

# XY List

# Erklärung der Spaltenbezeichnungen:

Part: Bauelement-Kennzeichen.

Side: ..- Leiterplatten-Seite, auf der sich das Bauelement befindet.

X/Y: Koordinaten (Millimeter) des Bauelementes auf der Leiterplatte

bezogen auf den Nullpunkt.

SQR, PG: Planquadrat und Seite des Schaltbildes für das jeweilige Bauelement.

## Explanation of column designations:

Part: Identification of instrument part.

Side: Side of the PC board on which instrument part is positioned.

X/Y: Coordinates (millimeter) of the component on the PC board in reference

to zero point.

SQR, PG: Square and page of the diagram for the respective instrument part.

†	Sei	vic	 ce-Re1	eva	nte Ba	uteil	.e /	Ser	vice-	Rel	evant	Compo	nent	 s		
Part S	ide X	Y	Sqr	Pg	Part	Side	X	Y	Sqr	Pg	Part	Side	×	Y	Sqr	Pg
R36	B 1D4	61	L 2D	4	† <b></b>						<b>+-</b> 					
+ +					+						+·					
Ni +	.cht-Ser	Vic	ce-Re1	eva	nte Ba	uteil	e /	Non-	Serv	rice	-Releva	ant C	ompo	nent	:s	
Part S	ide X	Y	Sqr	Pg	Part	Side	X	Y	Sqr	Pg	Part	Side	X	Y	Sqr	Pg
C1 C2 C3 C4 C5 C6 C7 C8 C9 C10 C11 C12 C13 C14 C15 C16 C17 C18 C19 C20 C21 C22 C23 C24 C25 C26 C37 C36 C37 C38 C37 C38	61 61 61 61 61 61 61 61 61 61	1222714131177114222565113117761442085534865544122656514327424	4D 6D 6D 6D 6D 7DB 4F 4E 4D 7C 2D 7C 4F 2D 7C 2F 3F 4F 2E 2D 3F 4F 2E 2D 55A 3B 3C 6B 3C 6B	231111222222233333334444444112341111	C47 C489 C512 C554 C556 C556 C557 C556 C557 C557 C557 C557	B B B A A B A A B B B B B A A A A A B B B B B B B B B B B B B B B B B B B B	644 1088 1088 1077 1055 1077 1055 1077 1055 1077 1055 1055	191514790984112451666661152886131818752459	4E 3D A A D B B B B E E 4 A 4 C D B C C C C C C C C C C C C C C C C C	234222333442323111112233323234442322222	L31 N1 N1 N2 N3 N4 N5 N5 N5 N6 N6 N6 P2 P6 P7 P1 R1 R2 R7 R8 R8 R9 R1	B B B B B B B B B B B B B B B B B B B	14 14 22 14 18 88 55 55 10 10 10 10 10 10 10 10 10 10 10 10 10	6100000888888800D003333018588834116865680	10 10 10 10 10 10 10 10 10 10 10 10 10 1	111111122233344444441144444444234433231
C39 C40 C41 C42 C43 C44 C45	A 35 B 101 B 74 B 89 B 56 B 56 B 74	22 41 15 15 29 33	3B 5D 7D 4D 4E	1422233	L15 L16 L17 L19 L2D L26 L28	B B B B B	63 81 92 78 89 81 55	29 29 35 32 29 58 57	4E 6D 6C 5D 6D 6B 6B	333323	R11 R12 R13 R14 R15 R16 R17	A A A A A	21 31 24 26 33 81 81	30 22 24 35 24 63 65	4C 6B 6C 8D 7D 7B 7B	1 1 1 2 2 2
C46	В 89	29 +		3	L29	В	24	68	1c	ĭ	R18	Ä	85	50	8B	2
ROHDE	áI		Datum Date			·		List list	e f= fo		Sach- Stock		er	- <b></b>	B1 Pa	att ge
& SCHWARZ		02	21.04	.97	ED POV	ERMO	DUL				1D62.	7240	.01	XY 		1+

Part	Side X	Y	Sqr	Pg	Part	Side X	Y	Sqr	Pg	Part	Side X	Y	Sqr	Pg
R19	A 88	50	8B	2	R68	В 43	55	3D	1	R118	B 101	65	2D	4
R20	A 77	57	7B	2	R69	B 43	49	3D	1	R119	B 18	31	3B	1
R21 R22	B 111 B 108	45 49	3C 3D	4 4	R70	B 43 B 41	46	3D	1	R120	B 15	31	3B	1
R23	B 100	14	4D	2	R72	B 41 B 43	53 44	3D	1	R121	A 9	29	3B	1
R24	B 62	31	4D	3	R73	B 33	53	3D 1D	1	R122 R123	A 9 A 30	32 14	3B	1
R25	A 58	64	7B	3	R74	A 81	59	7B	2	R123	B 107	37	3B 6A	1 4
R26	A 58	62	7B	3	R75	A 55	59	7B	3	R125	B 107	36	6A	4
R27	A 59	50	8B	3	R76	B 102	47	2B	4	V1	A 57	10	4D	2
R28	A 63	50	8B	3	R77	B 21	31	4C	1	V2	A 57	35	4D	3
R29	A 51	57	7B	3	R78	B 102	45	2B	4	V3	B 98	66	6D	4
R30	A 11	23	6E	1	R79	в 96	48	3B	4	V4	A 73	58	5B	2
R31	A 13	23	6E	1	R80	A 80	63	6B	2	V5	A 48	58	5B	3
R32	B 106	59	5D	4	R81	A 54	64	6B	3	V6	B 103	60	5D	4
R33	B 95	58	6D	4	R82	A 21	17	7B	1	V7	B 105	55	3D	4
R34 R35	B 94	57	6D	4	R83	A 11	17	7C	1	V8	B 108	47	2B	4
R35	B 95 B 106	51 51	7C	4	R85	A 81	51	5B	2	V9	A 78	49	5B	2
R38	B 106	45	2D 2C	4 4	R87	A 55	51	5B	3	V10	A 53	49	5B	3
R39	B 106	30	5A	4	R89	B 105 A 38	57 37	5D	4	V11	B 74	15	5D	2
R40	B 95	32	5A	4	R90	A 28	36	5B	1	V12	B 74	29	5E	3
R41	B 101	33	5A	4	R91	B 26	15	5C 3A	1	V13 V13	B 96 B 96	40 40	3B	4
R42	A 79	57	6A	4	R92	B 26	18	3A	ī	V15	A 40	24	4B 5B	4
R43	A 81	67	6B	2	R93	B 37	18	2E	2	V16	A 38	22	5B	i
R44	A 54	62	6B	3	R94	B 49	-8	3E	2	V17	A 32	10	7B	i
R45	B 112	53	3C	4	R95	A 45	9	3C	2	V18	A 15	37	5C	ī
R46	B 95	60	6C	4	R96	A 45	15	3C	2	V19	A 23	35	5C	1
R47	B 78	12	5D	2	R97	A 34	11	2C	2	V20	A 18	10	7C	1
R48	B 86	11	5C	2	R98	A 34	17	2C	2	V21	A 27	7	7B	1
R49	B 78	32	5D	3	R99	A 34	34	2D	3	V22	A 14	7	7C	1
R50	B 86	34	5C	3	R100	A 34	28	2D	3	V23	B 25	29	4B	1
R51 R52	A 79 A 53	43	5A	2	R101	A 45	32	3D	3	V23	B 25	29	4C	1
R52	A 53 B 108	43 58	5A 6D	3 4	R102 R103	A 45	26	3D	3	V24	B 113	48	3C	4
R54	B 108	56	3D	4	R103	B 49 B 37	25 35	3E 2E	3	V24	B 113	48	3D	4
R55	B 100	38	3B	4	R104	B 110	35	6A	4	X1 X2	B 9 B 9	48	1E	1
R56	B 71	15	5D	2	R106	B 101	42	2B	4	X2 X3	B 9 B 6	22 35	3A 3C	1 1
R57	B 71	31	5E	3	R107	B 94	38	5B	4	X4	B 112	15	7D	2
R58	A 68	43	6A	2	R108	B 90	42	4B	4	X5	B 115	55	4D	4
R59	A 70	43	6A	2	R109	A 63	9	4D	2	X6	В 107	31	7A	4
R60	A 73	43	6A	2	R110	A 64	36	4D	3	<b>Z1</b>	B 20	43	2C	il
R61	A 42	43	6A	3	R111	B 102	62	2E	4	Z2	B 34	55	2C	ī
R62	A 45	43	6A	3	R112	B 100	67	2D	4	<b>Z</b> 3	B 34	45	2D	ī
R63	A 47	43	6A	3	R113	A 20	24	6B	1	Z4	B 34	50	2D	1
R64	A 19	45	1E	1	R114	A 15	24	6C	1	<b>Z</b> 5	8 25	43	2E	1
R65	A 31	57	1E	1	R115	B 105	49	2D	4	Z6	В 34	60	2E	1
R66 R67	B 17 B 43	36	3C	1	R116	B 107	45	2C	4					
1		58 	3C	1	R117	B 101	64	2E	4					1

ROHDE	áI	Datum Date	XY-Liste for XY-list for	Sach-Nummer Stock-Nr	Blatt Page
SCHWARZ	02	21.04.97	ED POWERMODUL	1062.7240.01 XY	2-





Stromläufe
Bestückungspläne
Circuit diagrams
Components plans
Schémas de circuit
Plans des composants

